

Intel® 64 and IA-32 Architectures Software Developer's Manual

Volume 2B: Instruction Set Reference, N-Z

NOTE: The Intel 64 and IA-32 Architectures Software Developer's Manual consists of five volumes: *Basic Architecture*, Order Number 253665; *Instruction Set Reference A-M*, Order Number 253666; *Instruction Set Reference N-Z*, Order Number 253667; *System Programming Guide, Part 1*, Order Number 253668; *System Programming Guide, Part 2*, Order Number 253669. Refer to all five volumes when evaluating your design needs.

Order Number: 253667-038US

April 2011

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS OTHERWISE AGREED IN WRITING BY INTEL, THE INTEL PRODUCTS ARE NOT DESIGNED NOR INTENDED FOR ANY APPLICATION IN WHICH THE FAILURE OF THE INTEL PRODUCT COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR.

Intel may make changes to specifications and product descriptions at any time, without notice. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The information here is subject to change without notice. Do not finalize a design with this information.

The Intel $^{\otimes}$ 64 architecture processors may contain design defects or errors known as errata. Current characterized errata are available on request.

Intel[®] Hyper-Threading Technology requires a computer system with an Intel[®] processor supporting Hyper-Threading Technology and an Intel[®] HT Technology enabled chipset, BIOS and operating system. Performance will vary depending on the specific hardware and software you use. For more information, see http://www.intel.com/technology/hyperthread/index.htm; including details on which processors support Intel HT Technology.

Intel® Virtualization Technology requires a computer system with an enabled Intel® processor, BIOS, virtual machine monitor (VMM) and for some uses, certain platform software enabled for it. Functionality, performance or other benefits will_vary depending on hardware and software configurations. Intel® Virtualization Technology-enabled BIOS and VMM applications are currently in development.

64-bit computing on Intel architecture requires a computer system with a processor, chipset, BIOS, operating system, device drivers and applications enabled for Intel[®] 64 architecture. Processors will not operate (including 32-bit operation) without an Intel[®] 64 architecture-enabled BIOS. Performance will vary depending on your hardware and software configurations. Consult with your system vendor for more information.

Enabling Execute Disable Bit functionality requires a PC with a processor with Execute Disable Bit capability and a supporting operating system. Check with your PC manufacturer on whether your system delivers Execute Disable Bit functionality.

Intel, Pentium, Intel Xeon, Intel NetBurst, Intel Core, Intel Core Solo, Intel Core Duo, Intel Core 2 Duo, Intel Core 2 Extreme, Intel Pentium D, Itanium, Intel SpeedStep, MMX, Intel Atom, and VTune are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

*Other names and brands may be claimed as the property of others.

Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.

Copies of documents which have an ordering number and are referenced in this document, or other Intel literature, may be obtained by calling 1-800-548-4725, or by visiting Intel's website at http://www.intel.com

Copyright © 1997-2011 Intel Corporation

CHAPTER 4 INSTRUCTION SET REFERENCE, N-Z

4.1 IMM8 CONTROL BYTE OPERATION FOR PCMPESTRI / PCMPESTRM / PCMPISTRI / PCMPISTRM

The notations introduced in this section are referenced in the reference pages of PCMPESTRI, PCMPESTRM, PCMPISTRI, PCMPISTRM. The operation of the immediate control byte is common to these four string text processing instructions of SSE4.2. This section describes the common operations.

4.1.1 General Description

The operation of PCMPESTRI, PCMPESTRM, PCMPISTRI, PCMPISTRM is defined by the combination of the respective opcode and the interpretation of an immediate control byte that is part of the instruction encoding.

The opcode controls the relationship of input bytes/words to each other (determines whether the inputs terminated strings or whether lengths are expressed explicitly) as well as the desired output (index or mask).

The Imm8 Control Byte for PCMPESTRM/PCMPESTRI/PCMPISTRM/PCMPISTRI encodes a significant amount of programmable control over the functionality of those instructions. Some functionality is unique to each instruction while some is common across some or all of the four instructions. This section describes functionality which is common across the four instructions.

The arithmetic flags (ZF, CF, SF, OF, AF, PF) are set as a result of these instructions. However, the meanings of the flags have been overloaded from their typical meanings in order to provide additional information regarding the relationships of the two inputs.

PCMPxSTRx instructions perform arithmetic comparisons between all possible pairs of bytes or words, one from each packed input source operand. The boolean results of those comparisons are then aggregated in order to produce meaningful results. The Imm8 Control Byte is used to affect the interpretation of individual input elements as well as control the arithmetic comparisons used and the specific aggregation scheme.

Specifically, the Imm8 Control Byte consists of bit fields that control the following attributes:

Source data format — Byte/word data element granularity, signed or unsigned elements

- Aggregation operation Encodes the mode of per-element comparison operation and the aggregation of per-element comparisons into an intermediate result
- Polarity Specifies intermediate processing to be performed on the intermediate result
- Output selection Specifies final operation to produce the output (depending on index or mask) from the intermediate result

4.1.2 Source Data Format

Table 4-1. Source Data Format

Imm8[1:0]	Meaning	Description
00Ь	Unsigned bytes	Both 128-bit sources are treated as packed, unsigned bytes.
01ь	Unsigned words	Both 128-bit sources are treated as packed, unsigned words.
10b	Signed bytes	Both 128-bit sources are treated as packed, signed bytes.
11b	Signed words	Both 128-bit sources are treated as packed, signed words.

If the Imm8 Control Byte has bit[0] cleared, each source contains 16 packed bytes. If the bit is set each source contains 8 packed words. If the Imm8 Control Byte has bit[1] cleared, each input contains unsigned data. If the bit is set each source contains signed data.

4.1.3 Aggregation Operation

Table 4-2. Aggregation Operation

Imm8[3:2]	Mode	Comparison	
00Ь	Equal any	The arithmetic comparison is "equal."	
01ь	Ranges	Arithmetic comparison is "greater than or equal" between even indexed bytes/words of reg and each byte/word of reg/mem.	
		Arithmetic comparison is "less than or equal" between odd indexed bytes/words of reg and each byte/word of reg/mem.	
		(reg/mem[m] >= reg[n] for n = even, reg/mem[m] <= reg[n] for n = odd)	
10b	Equal each	The arithmetic comparison is "equal."	
11b	Equal ordered	The arithmetic comparison is "equal."	

All 256 (64) possible comparisons are always performed. The individual Boolean results of those comparisons are referred by "BoolRes[Reg/Mem element index, Reg element index]." Comparisons evaluating to "True" are represented with a 1, False with a 0 (positive logic). The initial results are then aggregated into a 16-bit (8-bit) intermediate result (IntRes1) using one of the modes described in the table below, as determined by Imm8 Control Byte bit[3:2].

See Section 4.1.6 for a description of the overrideIfDataInvalid() function used in Table 4-3.

Table 4-3. Aggregation Operation

Mode	Pseudocode
Equal any	UpperBound = imm8[0] ? 7 : 15;
(find characters from a set)	IntRes1 = 0;
	For j = 0 to UpperBound, j++
	For i = 0 to UpperBound, i++
	IntRes1[j] OR= overrideIfDataInvalid(BoolRes[j,i])
Ranges	UpperBound = imm8[0] ? 7 : 15;
(find characters from ranges)	IntRes1 = 0;
	For j = 0 to UpperBound, j++
	For i = 0 to UpperBound, i+=2
	IntRes1[j] OR= (overrideIfDataInvalid(BoolRes[j,i]) AND overrideIfDataInvalid(BoolRes[j,i+1]))
Equal each	UpperBound = imm8[0] ? 7 : 15;
(string compare)	IntRes1 = 0;
	For i = 0 to UpperBound, i++
	IntRes1[i] = overrideIfDataInvalid(BoolRes[i,i])
Equal ordered	UpperBound = imm8[0] ? 7 :15;
(substring search)	IntRes1 = imm8[0] ? 0xFF : 0xFFFF
	For j = 0 to UpperBound, j++
	For i = 0 to UpperBound-j, k=j to UpperBound, k++, i++
	IntRes1[j] AND= overridelfDataInvalid(BoolRes[k,i])

4.1.4 Polarity

IntRes1 may then be further modified by performing a 1's compliment, according to the value of the Imm8 Control Byte bit[4]. Optionally, a mask may be used such that only those IntRes1 bits which correspond to "valid" reg/mem input elements are complimented (note that the definition of a valid input element is dependant on the specific opcode and is defined in each opcode's description). The result of the possible negation is referred to as IntRes2.

Table 4-4. Polarity

Imm8[5:4]	Operation	Description
00b	Positive Polarity (+)	IntRes2 = IntRes1
01ь	Negative Polarity (-)	IntRes2 = -1 XOR IntRes1
10b	Masked (+)	IntRes2 = IntRes1
11b	Masked (-)	IntRes2[i] = IntRes1[i] if reg/mem[i] invalid, else = ~IntRes1[i]

4.1.5 Output Selection

Table 4-5. Ouput Selection

Imm8[6]	Operation	Description
Ob	Least significant index	The index returned to ECX is of the least significant set bit in IntRes2.
1b	Most significant index	The index returned to ECX is of the most significant set bit in IntRes2.

For PCMPESTRI/PCMPISTRI, the Imm8 Control Byte bit[6] is used to determine if the index is of the least significant or most significant bit of IntRes2.

Table 4-6. Output Selection

Imm8[6]	Operation	Description
Ob	Bit mask	IntRes2 is returned as the mask to the least significant bits of XMM0 with zero extension to 128 bits.
1b	Byte/word mask	IntRes2 is expanded into a byte/word mask (based on imm8[1]) and placed in XMMO. The expansion is performed by replicating each bit into all of the bits of the byte/word of the same index.

Specifically for PCMPESTRM/PCMPISTRM, the Imm8 Control Byte bit[6] is used to determine if the mask is a 16 (8) bit mask or a 128 bit byte/word mask.

4.1.6 Valid/Invalid Override of Comparisons

PCMPxSTRx instructions allow for the possibility that an end-of-string (EOS) situation may occur within the 128-bit packed data value (see the instruction descriptions below for details). Any data elements on either source that are determined to be past the EOS are considered to be invalid, and the treatment of invalid data within a comparison pair varies depending on the aggregation function being performed.

In general, the individual comparison result for each element pair BoolRes[i.j] can be forced true or false if one or more elements in the pair are invalid. See Table 4-7.

Table 4-7. Comparison Result for Each Element Pair BoolRes[i.j]

xmm1 byte/ word	xmm2/ m128 byte/word	Imm8[3:2] = 00b (equal any)	Imm8[3:2] = 01b (ranges)	Imm8[3:2] = 10b (equal each)	lmm8[3:2] = 11b (equal ordered)
Invalid	Invalid	Force false	Force false	Force true	Force true
Invalid	Valid	Force false	Force false	Force false	Force true
Valid	Invalid	Force false	Force false	Force false	Force false
Valid	Valid	Do not force	Do not force	Do not force	Do not force

4.1.7 Summary of Im8 Control byte

Table 4-8. Summary of Imm8 Control Byte

Imm8	Description
Ob	128-bit sources treated as 16 packed bytes.
1b	128-bit sources treated as 8 packed words.
0-b	Packed bytes/words are unsigned.
1-b	Packed bytes/words are signed.
00b	Mode is equal any.
01b	Mode is ranges.
10b	Mode is equal each.
11b	Mode is equal ordered.
0b	IntRes1 is unmodified.
1b	IntRes1 is negated (1's compliment).
0b	Negation of IntRes1 is for all 16 (8) bits.
1b	Negation of IntRes1 is masked by reg/mem validity.
-0b	Index of the least significant, set, bit is used (regardless of corresponding input element validity).
	IntRes2 is returned in least significant bits of XMM0.
-1b	Index of the most significant, set, bit is used (regardless of corresponding input element validity).
	Each bit of IntRes2 is expanded to byte/word.
0b	This bit currently has no defined effect, should be 0.
1b	This bit currently has no defined effect, should be 0.

4.1.8 Diagram Comparison and Aggregation Process




Figure 4-1. Operation of PCMPSTRx and PCMPESTRx

4.2 INSTRUCTIONS (N-Z)

Chapter 4 continues an alphabetical discussion of Intel[®] 64 and IA-32 instructions (N-Z). See also: Chapter 3, "Instruction Set Reference, A-M," in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 2A*.

NEG—Two's Complement Negation

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F6 /3	NEG r/m8	Α	Valid	Valid	Two's complement negate r/m8.
REX + F6 /3	NEG r/m8*	Α	Valid	N.E.	Two's complement negate r/m8.
F7 /3	NEG r/m16	Α	Valid	Valid	Two's complement negate r/m16.
F7 /3	NEG r/m32	Α	Valid	Valid	Two's complement negate r/m32.
REX.W + F7 /3	NEG r/m64	Α	Valid	N.E.	Two's complement negate r/m64.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r, w)	NA	NA	NA

Description

Replaces the value of operand (the destination operand) with its two's complement. (This operation is equivalent to subtracting the operand from 0.) The destination operand is located in a general-purpose register or a memory location.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
\begin{aligned} \text{IF DEST} &= 0 \\ &\quad \text{THEN CF} &\leftarrow 0; \\ &\quad \text{ELSE CF} &\leftarrow 1; \\ \text{FI;} \\ &\quad \text{DEST} &\leftarrow [-\text{(DEST)}] \end{aligned}
```

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

Flags Affected

The CF flag set to 0 if the source operand is 0; otherwise it is set to 1. The OF, SF, ZF, AF, and PF flags are set according to the result.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) For a page fault.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

NOP—No Operation

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
90	NOP	Α	Valid	Valid	One byte no-operation instruction.
0F 1F /0	NOP r/m16	В	Valid	Valid	Multi-byte no-operation instruction.
0F 1F /0	NOP r/m32	В	Valid	Valid	Multi-byte no-operation instruction.

Instruction Operand Encoding

		-		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA
В	ModRM:r/m (r)	NA	NA	NA

Description

This instruction performs no operation. It is a one-byte or multi-byte NOP that takes up space in the instruction stream but does not impact machine context, except for the EIP register.

The multi-byte form of NOP is available on processors with model encoding:

CPUID.01H.EAX[Bytes 11:8] = 0110B or 1111B

The multi-byte NOP instruction does not alter the content of a register and will not issue a memory operation. The instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

The one-byte NOP instruction is an alias mnemonic for the XCHG (E)AX, (E)AX instruction.

The multi-byte NOP instruction performs no operation on supported processors and generates undefined opcode exception on processors that do not support the multi-byte NOP instruction.

The memory operand form of the instruction allows software to create a byte sequence of "no operation" as one instruction. For situations where multiple-byte NOPs are needed, the recommended operations (32-bit mode and 64-bit mode) are:

Table 4-9. Recommended Multi-Byte Sequence of NOP Instruction

Length	Assembly	Byte Sequence
2 bytes	66 NOP	66 90H
3 bytes	NOP DWORD ptr [EAX]	0F 1F 00H
4 bytes	NOP DWORD ptr [EAX + 00H]	0F 1F 40 00H
5 bytes	NOP DWORD ptr [EAX + EAX*1 + 00H]	0F 1F 44 00 00H
6 bytes	66 NOP DWORD ptr [EAX + EAX*1 + 00H]	66 0F 1F 44 00 00H
7 bytes	NOP DWORD ptr [EAX + 00000000H]	0F 1F 80 00 00 00 00H
8 bytes	NOP DWORD ptr [EAX + EAX*1 + 00000000H]	0F 1F 84 00 00 00 00 00H
9 bytes	66 NOP DWORD ptr [EAX + EAX*1 + 00000000H]	66 0F 1F 84 00 00 00 00 00H

Flags Affected

None.

Exceptions (All Operating Modes)

#UD If the LOCK prefix is used.

NOT—One's Complement Negation

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F6 /2	NOT <i>r/m8</i>	Α	Valid	Valid	Reverse each bit of <i>r/m8</i> .
REX + F6 /2	NOT <i>r/m8</i> *	Α	Valid	N.E.	Reverse each bit of <i>r/m8.</i>
F7 /2	NOT r/m16	Α	Valid	Valid	Reverse each bit of r/m16.
F7 /2	NOT <i>r/m32</i>	Α	Valid	Valid	Reverse each bit of <i>r/m32</i> .
REX.W + F7 /2	NOT r/m64	Α	Valid	N.E.	Reverse each bit of <i>r/m64.</i>

NOTES:

Instruction Operand Encoding

(Op/En	Operand 1	Operand 2	Operand 3	Operand 4
	Α	ModRM:r/m (r, w)	NA	NA	NA

Description

Performs a bitwise NOT operation (each 1 is set to 0, and each 0 is set to 1) on the destination operand and stores the result in the destination operand location. The destination operand can be a register or a memory location.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

DEST \leftarrow NOT DEST;

Flags Affected

None.

Protected Mode Exceptions

#GP(0)

If the destination operand points to a non-writable segment. If a memory operand effective address is outside the CS, DS, ES, FS, or GS segment limit.

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

OR—Logical Inclusive OR

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OC ib	OR AL, i <i>mm8</i>	Α	Valid	Valid	AL OR imm8.
OD iw	OR AX, imm16	Α	Valid	Valid	AX OR imm16.
OD id	OR EAX, i <i>mm32</i>	Α	Valid	Valid	EAX OR imm32.
REX.W + OD id	OR RAX, i <i>mm32</i>	Α	Valid	N.E.	RAX OR imm32 (sign-extended).
80 /1 <i>ib</i>	OR r/m8, imm8	В	Valid	Valid	r/m8 OR imm8.
REX + 80 /1 ib	OR r/m8*, imm8	В	Valid	N.E.	r/m8 OR imm8.
81 /1 iw	OR <i>r/m16, imm16</i>	В	Valid	Valid	r/m16 OR imm16.
81 /1 id	OR <i>r/m32, imm32</i>	В	Valid	Valid	r/m32 OR imm32.
REX.W + 81 /1 id	OR <i>r/m64, imm32</i>	В	Valid	N.E.	r/m64 OR imm32 (sign- extended).
83 /1 ib	OR <i>r/m16, imm8</i>	В	Valid	Valid	r/m16 OR imm8 (sign- extended).
83 /1 ib	OR <i>r/m32, imm8</i>	В	Valid	Valid	r/m32 OR imm8 (sign- extended).
REX.W + 83 /1 ib	OR <i>r/m64, imm8</i>	В	Valid	N.E.	r/m64 OR imm8 (sign- extended).
08 /r	OR <i>r/m8, r8</i>	С	Valid	Valid	r/m8 OR r8.
REX + 08 /r	OR r/m8*, r8*	С	Valid	N.E.	r/m8 OR r8.
09 /r	OR r/m16, r16	С	Valid	Valid	r/m16 OR r16.
09 /r	OR <i>r/m32, r32</i>	С	Valid	Valid	r/m32 OR r32.
REX.W + 09 /r	OR <i>r/m64, r64</i>	С	Valid	N.E.	r/m64 OR r64.
0A / <i>r</i>	OR <i>r8, r/m8</i>	D	Valid	Valid	r8 OR r/m8.
REX + 0A /r	OR r8*, r/m8*	D	Valid	N.E.	r8 OR r/m8.
0B / <i>r</i>	OR <i>r16, r/m16</i>	D	Valid	Valid	r16 OR r/m16.
0B /r	OR <i>r32, r/m32</i>	D	Valid	Valid	r32 OR r/m32.
REX.W + OB /r	OR <i>r64, r/m64</i>	D	Valid	N.E.	r64 OR r/m64.

NOTES:

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	AL/AX/EAX/RAX	imm8/16/32	NA	NA
В	ModRM:r/m (r, w)	imm8/16/32	NA	NA
С	ModRM:r/m (r, w)	ModRM:reg (r)	NA	NA
D	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA

Instruction Operand Encoding

Description

Performs a bitwise inclusive OR operation between the destination (first) and source (second) operands and stores the result in the destination operand location. The source operand can be an immediate, a register, or a memory location; the destination operand can be a register or a memory location. (However, two memory operands cannot be used in one instruction.) Each bit of the result of the OR instruction is set to 0 if both corresponding bits of the first and second operands are 0; otherwise, each bit is set to 1.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

DEST \leftarrow DEST OR SRC:

Flags Affected

The OF and CF flags are cleared; the SF, ZF, and PF flags are set according to the result. The state of the AF flag is undefined.

Protected Mode Exceptions

#GP(0) If the destination operand points to a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

ORPD—Bitwise Logical OR of Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 56 /r ORPD xmm1, xmm2/m128	Α	V/V	SSE2	Bitwise OR of xmm2/m128 and xmm1.
VEX.NDS.128.66.0F.WIG 56 /r VORPD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Return the bitwise logical OR of packed double-precision floating-point values in xmm2 and xmm3/mem.
VEX.NDS.256.66.0F.WIG 56 /r VORPD ymm1, ymm2, ymm3/m256	В	V/V	AVX	Return the bitwise logical OR of packed double-precision floating-point values in ymm2 and ymm3/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical OR of the two or four packed double-precision floatingpoint values from the first source operand and the second source operand, and stores the result in the destination operand

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the destination YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

If VORPD is encoded with VEX.L= 1, an attempt to execute the instruction encoded with VEX.L= 1 will cause an #UD exception.

Operation

ORPD (128-bit Legacy SSE version)

DEST[63:0] \leftarrow DEST[63:0] BITWISE OR SRC[63:0] DEST[127:64] \leftarrow DEST[127:64] BITWISE OR SRC[127:64] DEST[VLMAX-1:128] (Unmodified)

VORPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] BITWISE OR SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] BITWISE OR SRC2[127:64] DEST[VLMAX-1:128] \leftarrow 0

VORPD (VEX.256 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] BITWISE OR SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] BITWISE OR SRC2[127:64] DEST[191:128] \leftarrow SRC1[191:128] BITWISE OR SRC2[191:128] DEST[255:192] \leftarrow SRC1[255:192] BITWISE OR SRC2[255:192]

Intel® C/C++ Compiler Intrinsic Equivalent

```
ORPD __m128d _mm_or_pd(__m128d a, __m128d b);

VORPD __m256d _mm256_or_pd (__m256d a, __m256d b);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 56 /r ORPS xmm1, xmm2/m128	Α	V/V	SSE	Bitwise OR of xmm1 and xmm2/m128.
VEX.NDS.128.0F.WIG 56 /r VORPS xmm1, xmm2, xmm3/m128	В	V/V	AVX	Return the bitwise logical OR of packed single-precision floating-point values in xmm2 and xmm3/mem.
VEX.NDS.256.0F.WIG 56 /r VORPS ymm1, ymm2, ymm3/m256	В	V/V	AVX	Return the bitwise logical OR of packed single-precision floating-point values in ymm2 and ymm3/mem.

Instruction Operand Encoding

0	p/En	Operand 1	Operand 2	Operand 3	Operand 4
	Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
	В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical OR of the four or eight packed single-precision floatingpoint values from the first source operand and the second source operand, and stores the result in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the destination YMM register destination are zeroed.

VEX.256 Encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

If VORPS is encoded with VEX.L= 1, an attempt to execute the instruction encoded with VEX.L= 1 will cause an #UD exception.

Operation

ORPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SRC1[31:0] BITWISE OR SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] BITWISE OR SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] BITWISE OR SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] BITWISE OR SRC2[127:96] DEST[VLMAX-1:128] (Unmodified)

VORPS (VEX.128 encoded version)

DEST[31:0] ← SRC1[31:0] BITWISE OR SRC2[31:0] DEST[63:32] ← SRC1[63:32] BITWISE OR SRC2[63:32] DEST[95:64] ← SRC1[95:64] BITWISE OR SRC2[95:64] DEST[127:96] ← SRC1[127:96] BITWISE OR SRC2[127:96] DEST[VLMAX-1:128] ← 0

VORPS (VEX.256 encoded version)

DEST[31:0] \leftarrow SRC1[31:0] BITWISE OR SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] BITWISE OR SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] BITWISE OR SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] BITWISE OR SRC2[127:96] DEST[159:128] \leftarrow SRC1[159:128] BITWISE OR SRC2[159:128] DEST[191:160] \leftarrow SRC1[191:160] BITWISE OR SRC2[191:160] DEST[223:192] \leftarrow SRC1[223:192] BITWISE OR SRC2[223:192] DEST[255:224] \leftarrow SRC1[255:224] BITWISE OR SRC2[255:224].

Intel C/C++ Compiler Intrinsic Equivalent

```
ORPS __m128 _mm_or_ps (__m128 a, __m128 b);

VORPS __m256 _mm256_or_ps (__m256 a, __m256 b);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

OUT—Output to Port

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
E6 <i>ib</i>	OUT imm8, AL	Α	Valid	Valid	Output byte in AL to I/O port address <i>imm8</i> .
E7 ib	OUT imm8, AX	Α	Valid	Valid	Output word in AX to I/O port address imm8.
E7 ib	OUT imm8, EAX	Α	Valid	Valid	Output doubleword in EAX to I/O port address <i>imm8</i> .
EE	OUT DX, AL	В	Valid	Valid	Output byte in AL to I/O port address in DX.
EF	OUT DX, AX	В	Valid	Valid	Output word in AX to I/O port address in DX.
EF	OUT DX, EAX	В	Valid	Valid	Output doubleword in EAX to I/O port address in DX.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	imm8	NA	NA	NA
В	NA	NA	NA	NA

Description

Copies the value from the second operand (source operand) to the I/O port specified with the destination operand (first operand). The source operand can be register AL, AX, or EAX, depending on the size of the port being accessed (8, 16, or 32 bits, respectively); the destination operand can be a byte-immediate or the DX register. Using a byte immediate allows I/O port addresses 0 to 255 to be accessed; using the DX register as a source operand allows I/O ports from 0 to 65,535 to be accessed.

The size of the I/O port being accessed is determined by the opcode for an 8-bit I/O port or by the operand-size attribute of the instruction for a 16- or 32-bit I/O port.

At the machine code level, I/O instructions are shorter when accessing 8-bit I/O ports. Here, the upper eight bits of the port address will be 0.

This instruction is only useful for accessing I/O ports located in the processor's I/O address space. See Chapter 13, "Input/Output," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for more information on accessing I/O ports in the I/O address space.

^{*} See IA-32 Architecture Compatibility section below.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

IA-32 Architecture Compatibility

After executing an OUT instruction, the Pentium[®] processor ensures that the EWBE# pin has been sampled active before it begins to execute the next instruction. (Note that the instruction can be prefetched if EWBE# is not active, but it will not be executed until the EWBE# pin is sampled active.) Only the Pentium processor family has the EWBE# pin.

Operation

```
IF ((PE = 1) and ((CPL > IOPL) or (VM = 1)))

THEN (* Protected mode with CPL > IOPL or virtual-8086 mode *)

IF (Any I/O Permission Bit for I/O port being accessed = 1)

THEN (* I/O operation is not allowed *)

#GP(0);

ELSE ( * I/O operation is allowed *)

DEST \leftarrow SRC; (* Writes to selected I/O port *)

FI;

ELSE (Real Mode or Protected Mode with CPL \leq IOPL *)

DEST \leftarrow SRC; (* Writes to selected I/O port *)

FI;
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the CPL is greater than (has less privilege) the I/O privilege

level (IOPL) and any of the corresponding I/O permission bits in

TSS for the I/O port being accessed is 1.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If any of the I/O permission bits in the TSS for the I/O port being

accessed is 1.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same as protected mode exceptions.

64-Bit Mode Exceptions

Same as protected mode exceptions.

OUTS/OUTSB/OUTSW/OUTSD—Output String to Port

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
6E	OUTS DX, m8	Α	Valid	Valid	Output byte from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.
6F	OUTS DX, m16	Α	Valid	Valid	Output word from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.
6F	OUTS DX, <i>m32</i>	Α	Valid	Valid	Output doubleword from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.
6E	OUTSB	Α	Valid	Valid	Output byte from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.
6F	OUTSW	Α	Valid	Valid	Output word from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.
6F	OUTSD	Α	Valid	Valid	Output doubleword from memory location specified in DS:(E)SI or RSI to I/O port specified in DX**.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Copies data from the source operand (second operand) to the I/O port specified with the destination operand (first operand). The source operand is a memory location, the address of which is read from either the DS:SI, DS:ESI or the RSI registers (depending on the address-size attribute of the instruction, 16, 32 or 64, respec-

^{*} See IA-32 Architecture Compatibility section below.

^{**} In 64-bit mode, only 64-bit (RSI) and 32-bit (ESI) address sizes are supported. In non-64-bit mode, only 32-bit (ESI) and 16-bit (SI) address sizes are supported.

tively). (The DS segment may be overridden with a segment override prefix.) The destination operand is an I/O port address (from 0 to 65,535) that is read from the DX register. The size of the I/O port being accessed (that is, the size of the source and destination operands) is determined by the opcode for an 8-bit I/O port or by the operand-size attribute of the instruction for a 16- or 32-bit I/O port.

At the assembly-code level, two forms of this instruction are allowed: the "explicit-operands" form and the "no-operands" form. The explicit-operands form (specified with the OUTS mnemonic) allows the source and destination operands to be specified explicitly. Here, the source operand should be a symbol that indicates the size of the I/O port and the source address, and the destination operand must be DX. This explicit-operands form is provided to allow documentation; however, note that the documentation provided by this form can be misleading. That is, the source operand symbol must specify the correct **type** (size) of the operand (byte, word, or doubleword), but it does not have to specify the correct **location**. The location is always specified by the DS:(E)SI or RSI registers, which must be loaded correctly before the OUTS instruction is executed.

The no-operands form provides "short forms" of the byte, word, and doubleword versions of the OUTS instructions. Here also DS:(E)SI is assumed to be the source operand and DX is assumed to be the destination operand. The size of the I/O port is specified with the choice of mnemonic: OUTSB (byte), OUTSW (word), or OUTSD (doubleword).

After the byte, word, or doubleword is transferred from the memory location to the I/O port, the SI/ESI/RSI register is incremented or decremented automatically according to the setting of the DF flag in the EFLAGS register. (If the DF flag is 0, the (E)SI register is incremented; if the DF flag is 1, the SI/ESI/RSI register is decremented.) The SI/ESI/RSI register is incremented or decremented by 1 for byte operations, by 2 for word operations, and by 4 for doubleword operations.

The OUTS, OUTSB, OUTSW, and OUTSD instructions can be preceded by the REP prefix for block input of ECX bytes, words, or doublewords. See "REP/REPE/REPZ /REPNE/REPNZ—Repeat String Operation Prefix" in this chapter for a description of the REP prefix. This instruction is only useful for accessing I/O ports located in the processor's I/O address space. See Chapter 13, "Input/Output," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for more information on accessing I/O ports in the I/O address space.

In 64-bit mode, the default operand size is 32 bits; operand size is not promoted by the use of REX.W. In 64-bit mode, the default address size is 64 bits, and 64-bit address is specified using RSI by default. 32-bit address using ESI is support using the prefix 67H, but 16-bit address is not supported in 64-bit mode.

IA-32 Architecture Compatibility

After executing an OUTS, OUTSB, OUTSW, or OUTSD instruction, the Pentium processor ensures that the EWBE# pin has been sampled active before it begins to execute the next instruction. (Note that the instruction can be prefetched if EWBE#

is not active, but it will not be executed until the EWBE# pin is sampled active.) Only the Pentium processor family has the EWBE# pin.

For the Pentium 4, Intel[®] Xeon[®], and P6 processor family, upon execution of an OUTS, OUTSB, OUTSW, or OUTSD instruction, the processor will not execute the next instruction until the data phase of the transaction is complete.

Operation

```
IF ((PE = 1) \text{ and } ((CPL > IOPL) \text{ or } (VM = 1)))
    THEN (* Protected mode with CPL > IOPL or virtual-8086 mode *)
         IF (Any I/O Permission Bit for I/O port being accessed = 1)
              THEN (* I/O operation is not allowed *)
                   #GP(0);
              ELSE (* I/O operation is allowed *)
                   DEST \leftarrow SRC: (* Writes to I/O port *)
         FI:
   ELSE (Real Mode or Protected Mode or 64-Bit Mode with CPL ≤ IOPL *)
         DEST \leftarrow SRC: (* Writes to I/O port *)
FI:
Byte transfer:
   IF 64-bit mode
         Then
              IF 64-Bit Address Size
                   THEN
                         IF DF = 0
                              THEN RSI \leftarrow RSI RSI + 1:
                              ELSE RSI \leftarrow RSI or - 1:
                         FI:
                   ELSE (* 32-Bit Address Size *)
                         IF DF = 0
                              THEN
                                         ESI \leftarrow ESI + 1:
                                         ESI \leftarrow ESI - 1:
                              ELSE
                         FI:
              FI:
         FLSE
              IF DF = 0
                   THFN
                              (E)SI \leftarrow (E)SI + 1;
                   ELSE (E)SI \leftarrow (E)SI - 1;
              FI:
   FI:
Word transfer:
   IF 64-bit mode
         Then
```

```
IF 64-Bit Address Size
                    THEN
                          IF DF = 0
                                THEN RSI \leftarrow RSI RSI + 2;
                                ELSE RSI \leftarrow RSI or - 2;
                          FI;
                    ELSE (* 32-Bit Address Size *)
                          IF DF = 0
                                THEN
                                           ESI \leftarrow ESI + 2;
                                           ESI \leftarrow ESI - 2;
                                ELSE
                          FI;
               FI:
         ELSE
               IF DF = 0
                    THEN (E)SI \leftarrow (E)SI + 2;
                    ELSE (E)SI \leftarrow (E)SI - 2;
               FI;
    FI;
Doubleword transfer:
    IF 64-bit mode
         Then
               IF 64-Bit Address Size
                    THEN
                          IF DF = 0
                                THEN RSI \leftarrow RSI RSI + 4;
                                ELSE RSI \leftarrow RSI or - 4;
                          FI;
                    ELSE (* 32-Bit Address Size *)
                          IF DF = 0
                                THEN
                                           ESI \leftarrow ESI + 4;
                                           ESI \leftarrow ESI - 4;
                                ELSE
                          FI;
               FI;
         ELSE
               IF DF = 0
                    THEN
                             (E)SI \leftarrow (E)SI + 4;
                    ELSE (E)SI \leftarrow (E)SI - 4;
               FI;
    FI:
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the CPL is greater than (has less privilege) the I/O privilege

level (IOPL) and any of the corresponding I/O permission bits in

TSS for the I/O port being accessed is 1.

If a memory operand effective address is outside the limit of the

CS, DS, ES, FS, or GS segment.

If the segment register contains a NULL segment selector.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If any of the I/O permission bits in the TSS for the I/O port being

accessed is 1.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the CPL is greater than (has less privilege) the I/O privilege

level (IOPL) and any of the corresponding I/O permission bits in

TSS for the I/O port being accessed is 1.

If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

PABSB/PABSW/PABSD — Packed Absolute Value

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 1C /r ¹ PABSB mm1, mm2/m64	Α	V/V	SSSE3	Compute the absolute value of bytes in mm2/m64 and store UNSIGNED result in mm1.
66 OF 38 1C /r PABSB xmm1, xmm2/m128	Α	V/V	SSSE3	Compute the absolute value of bytes in xmm2/m128 and store UNSIGNED result in xmm1.
OF 38 1D /r ¹ PABSW mm1, mm2/m64	Α	V/V	SSSE3	Compute the absolute value of 16-bit integers in mm2/m64 and store UNSIGNED result in mm1.
66 OF 38 1D /r PABSW xmm1, xmm2/m128	Α	V/V	SSSE3	Compute the absolute value of 16-bit integers in xmm2/m128 and store UNSIGNED result in xmm1.
OF 38 1E /r ¹ PABSD mm1, mm2/m64	Α	V/V	SSSE3	Compute the absolute value of 32-bit integers in mm2/m64 and store UNSIGNED result in mm1.
66 OF 38 1E /r PABSD xmm1, xmm2/m128	Α	V/V	SSSE3	Compute the absolute value of 32-bit integers in xmm2/m128 and store UNSIGNED result in xmm1.
VEX.128.66.0F38.WIG 1C /r VPABSB xmm1, xmm2/m128	Α	V/V	AVX	Compute the absolute value of bytes in xmm2/m128 and store UNSIGNED result in xmm1.
VEX.128.66.0F38.WIG 1D /r VPABSW xmm1, xmm2/m128	Α	V/V	AVX	Compute the absolute value of 16- bit integers in xmm2/m128 and store UNSIGNED result in xmm1.

VEX.128.66.0F38.WIG 1E /r	Α	V/V	AVX	Compute the absolute value
VPABSD xmm1, xmm2/m128				of 32- bit integers in
				xmm2/m128 and store
				UNSIGNED result in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

PABSB/W/D computes the absolute value of each data element of the source operand (the second operand) and stores the UNSIGNED results in the destination operand (the first operand). PABSB operates on signed bytes, PABSW operates on 16-bit words, and PABSD operates on signed 32-bit integers. The source operand can be an MMX register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX or an XMM register. Both operands can be MMX register or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0; otherwise instructions will #UD.

Operation

PABSB (with 64 bit operands)

Unsigned DEST[7:0] \leftarrow ABS(SRC[7:0]) Repeat operation for 2nd through 7th bytes Unsigned DEST[63:56] \leftarrow ABS(SRC[63:56])

PABSB (with 128 bit operands)

Unsigned DEST[7:0] ← ABS(SRC[7:.0])
Repeat operation for 2nd through 15th bytes

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Unsigned DEST[127:120] \leftarrow ABS(SRC[127:120])

PABSW (with 64 bit operands)

Unsigned DEST[15:0] ← ABS(SRC[15:0])
Repeat operation for 2nd through 3rd 16-bit words
Unsigned DEST[63:48] ← ABS(SRC[63:48])

PABSW (with 128 bit operands)

Unsigned DEST[15:0] \leftarrow ABS(SRC[15:0]) Repeat operation for 2nd through 7th 16-bit words Unsigned DEST[127:112] \leftarrow ABS(SRC[127:112])

PABSD (with 64 bit operands)

Unsigned DEST[31:0] \leftarrow ABS(SRC[31:0]) Unsigned DEST[63:32] \leftarrow ABS(SRC[63:32])

PABSD (with 128 bit operands)

Unsigned DEST[31:0] \leftarrow ABS(SRC[31:0]) Repeat operation for 2nd through 3rd 32-bit double words Unsigned DEST[127:96] \leftarrow ABS(SRC[127:96])

PABSB (128-bit Legacy SSE version)

DEST[127:0] \leftarrow BYTE_ABS(SRC) DEST[VLMAX-1:128] (Unmodified)

VPABSB (VEX.128 encoded version)

DEST[127:0] \leftarrow BYTE_ABS(SRC) DEST[VLMAX-1:128] \leftarrow 0

PABSW (128-bit Legacy SSE version)

DEST[127:0] ← WORD_ABS(SRC)
DEST[VLMAX-1:128] (Unmodified)

VPABSW (VEX.128 encoded version)

DEST[127:0] \leftarrow WORD_ABS(SRC) DEST[VLMAX-1:128] \leftarrow 0

PABSD (128-bit Legacy SSE version)

DEST[127:0] \leftarrow DWORD_ABS(SRC) DEST[VLMAX-1:128] (Unmodified)

VPABSD (VEX.128 encoded version)

DEST[127:0] \leftarrow DWORD_ABS(SRC) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PABSB __m64 _mm_abs_pi8 (__m64 a)
PABSB __m128i _mm_abs_epi8 (__m128i a)
PABSW __m64 _mm_abs_pi16 (__m64 a)
PABSW __m128i _mm_abs_epi16 (__m128i a)
PABSD __m64 _mm_abs_pi32 (__m64 a)
PABSD __m128i _mm_abs_epi32 (__m128i a)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PACKSSWB/PACKSSDW—Pack with Signed Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 63 /r ¹ PACKSSWB mm1, mm2/m64	Α	V/V	MMX	Converts 4 packed signed word integers from mm1 and from mm2/m64 into 8 packed signed byte integers in mm1 using signed saturation.
66 OF 63 /r PACKSSWB xmm1, xmm2/m128	Α	V/V	SSE2	Converts 8 packed signed word integers from xmm1 and from xxm2/m128 into 16 packed signed byte integers in xxm1 using signed saturation.
OF 6B /r ¹ PACKSSDW mm1, mm2/m64	Α	V/V	MMX	Converts 2 packed signed doubleword integers from mm1 and from mm2/m64 into 4 packed signed word integers in mm1 using signed saturation.
66 OF 6B /r PACKSSDW xmm1, xmm2/m128	Α	V/V	SSE2	Converts 4 packed signed doubleword integers from xmm1 and from xxm2/m128 into 8 packed signed word integers in xxm1 using signed saturation.
VEX.NDS.128.66.0F.WIG 63 /r VPACKSSWB xmm1,xmm2, xmm3/m128	В	V/V	AVX	Converts 8 packed signed word integers from xmm2 and from xmm3/m128 into 16 packed signed byte integers in xmm1 using signed saturation.

VEX.NDS.128.66.0F.WIG 6B /r	В	V/V	AVX	Converts 4 packed signed
VPACKSSDW xmm1,xmm2, xmm3/m128				doubleword integers from xmm2 and from xmm3/m128 into 8 packed signed word integers in xmm1 using signed saturation.

NOTES:

1. See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Converts packed signed word integers into packed signed byte integers (PACKSSWB) or converts packed signed doubleword integers into packed signed word integers (PACKSSDW), using saturation to handle overflow conditions. See Figure 4-2 for an example of the packing operation.




Figure 4-2. Operation of the PACKSSDW Instruction Using 64-bit Operands

The PACKSSWB instruction converts 4 or 8 signed word integers from the destination operand (first operand) and 4 or 8 signed word integers from the source operand (second operand) into 8 or 16 signed byte integers and stores the result in the destination operand. If a signed word integer value is beyond the range of a signed byte integer (that is, greater than 7FH for a positive integer or greater than 80H for a negative integer), the saturated signed byte integer value of 7FH or 80H, respectively, is stored in the destination.

The PACKSSDW instruction packs 2 or 4 signed doublewords from the destination operand (first operand) and 2 or 4 signed doublewords from the source operand (second operand) into 4 or 8 signed words in the destination operand (see Figure 4-2). If a signed doubleword integer value is beyond the range of a signed word (that is, greater than 7FFFH for a positive integer or greater than 8000H for a negative integer), the saturated signed word integer value of 7FFFH or 8000H, respectively, is stored into the destination.

The PACKSSWB and PACKSSDW instructions operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PACKSSWB (with 64-bit operands)

 ${\sf DEST[7:0]} \leftarrow {\sf SaturateSignedWordToSignedByte\ DEST[15:0]};$

 $DEST[15:8] \leftarrow SaturateSignedWordToSignedByte\ DEST[31:16];$

 ${\sf DEST[23:16]} \leftarrow {\sf SaturateSignedWordToSignedByte\ DEST[47:32]};$

 ${\sf DEST[31:24]} \leftarrow SaturateSignedWordToSignedByte\ DEST[63:48];$

DEST[39:32] ← SaturateSignedWordToSignedByte SRC[15:0]; DEST[47:40] ← SaturateSignedWordToSignedByte SRC[31:16];

DEST[55:48] ← SaturateSignedWordToSignedByte SRC[47:32];

DEST[63:56] \leftarrow SaturateSignedWordToSignedByte SRC[63:48];

PACKSSDW (with 64-bit operands)

 ${\sf DEST[15:0]} \leftarrow SaturateSignedDoublewordToSignedWord\ DEST[31:0];$

 ${\sf DEST[31:16]} \leftarrow SaturateSignedDoublewordToSignedWord\ DEST[63:32];$

 ${\sf DEST[47:32]} \leftarrow SaturateSignedDoublewordToSignedWord~SRC[31:0];$

 $DEST[63:48] \leftarrow SaturateSignedDoublewordToSignedWord~SRC[63:32];$

PACKSSWB (with 128-bit operands)

DEST[7:0]← SaturateSignedWordToSignedByte (DEST[15:0]);

DEST[15:8] ← SaturateSignedWordToSignedByte (DEST[31:16]);

 $DEST[23:16] \leftarrow SaturateSignedWordToSignedByte \ (DEST[47:32]);$

 $DEST[31:24] \leftarrow SaturateSignedWordToSignedByte \ (DEST[63:48]);$

DEST[39:32] \leftarrow SaturateSignedWordToSignedByte (DEST[79:64]);

```
\label{eq:def:DEST} \begin{split} \text{DEST}[47:40] \leftarrow & \text{SaturateSignedWordToSignedByte (DEST}[95:80]); \\ \text{DEST}[55:48] \leftarrow & \text{SaturateSignedWordToSignedByte (DEST}[111:96]); \\ \text{DEST}[63:56] \leftarrow & \text{SaturateSignedWordToSignedByte (DEST}[127:112]); \\ \text{DEST}[71:64] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[15:0]); \\ \text{DEST}[79:72] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[31:16]); \\ \text{DEST}[87:80] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[47:32]); \\ \text{DEST}[95:88] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[63:48]); \\ \text{DEST}[103:96] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[79:64]); \\ \text{DEST}[111:104] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[111:96]); \\ \text{DEST}[127:120] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[127:112]); \\ \text{DEST}[127:120] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[127:112]]; \\ \text{DEST}[127:120] \leftarrow & \text{SaturateSignedWordToSignedByte (SRC}[127:112]]; \\ \text{DES
```

PACKSSDW (with 128-bit operands)

```
\label{eq:def:DEST[15:0]} \begin{split} &\leftarrow SaturateSignedDwordToSignedWord (DEST[31:0]); \\ &\text{DEST[31:16]} \leftarrow SaturateSignedDwordToSignedWord (DEST[63:32]); \\ &\text{DEST[47:32]} \leftarrow SaturateSignedDwordToSignedWord (DEST[95:64]); \\ &\text{DEST[63:48]} \leftarrow SaturateSignedDwordToSignedWord (DEST[127:96]); \\ &\text{DEST[79:64]} \leftarrow SaturateSignedDwordToSignedWord (SRC[31:0]); \\ &\text{DEST[95:80]} \leftarrow SaturateSignedDwordToSignedWord (SRC[63:32]); \\ &\text{DEST[111:96]} \leftarrow SaturateSignedDwordToSignedWord (SRC[95:64]); \\ &\text{DEST[127:112]} \leftarrow SaturateSignedDwordToSignedWord (SRC[127:96]); \\ \end{aligned}
```

PACKSSDW

DEST[127:0] ← SATURATING_PACK_DW(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

VPACKSSDW

DEST[127:0] \leftarrow SATURATING_PACK_DW(DEST, SRC) DEST[VLMAX-1:128] \leftarrow 0

PACKSSWB

DEST[127:0] ← SATURATING_PACK_WB(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

VPACKSSWB

DEST[127:0] \leftarrow SATURATING_PACK_WB(DEST, SRC) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PACKSSWB __m64 _mm_packs_pi16(__m64 m1, __m64 m2)
PACKSSWB __m128i _mm_packs_epi16(__m128i m1, __m128i m2)
PACKSSDW __m64 _mm_packs_pi32 (__m64 m1, __m64 m2)
```

INSTRUCTION SET REFERENCE, N-Z

PACKSSDW __m128i _mm_packs_epi32(__m128i m1, __m128i m2)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

PACKUSDW — Pack with Unsigned Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 2B /r PACKUSDW xmm1, xmm2/m128	Α	V/V	SSE4_1	Convert 4 packed signed doubleword integers from xmm1 and 4 packed signed doubleword integers from xmm2/m128 into 8 packed unsigned word integers in xmm1 using unsigned saturation.
VEX.NDS.128.66.0F38.WIG 2B /r VPACKUSDW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Convert 4 packed signed doubleword integers from xmm2 and 4 packed signed doubleword integers from xmm3/m128 into 8 packed unsigned word integers in xmm1 using unsigned saturation.

Instruction Operand Encoding

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Converts packed signed doubleword integers into packed unsigned word integers using unsigned saturation to handle overflow conditions. If the signed doubleword value is beyond the range of an unsigned word (that is, greater than FFFFH or less than 0000H), the saturated unsigned word integer value of FFFFH or 0000H, respectively, is stored in the destination.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

 $TMP[15:0] \leftarrow (DEST[31:0] < 0) ? 0 : DEST[15:0];$ $DEST[15:0] \leftarrow (DEST[31:0] > FFFFH) ? FFFFH : TMP[15:0];$

```
TMP[31:16] \leftarrow (DEST[63:32] < 0) ? 0 : DEST[47:32];
DEST[31:16] \leftarrow (DEST[63:32] > FFFFH)? FFFFH: TMP[31:16];
TMP[47:32] \leftarrow (DEST[95:64] < 0) ? 0 : DEST[79:64];
DEST[47:32] \leftarrow (DEST[95:64] > FFFFH)? FFFFH: TMP[47:32];
TMP[63:48] \leftarrow (DEST[127:96] < 0) ? 0 : DEST[111:96];
DEST[63:48] \leftarrow (DEST[127:96] > FFFFH)? FFFFH: TMP[63:48];
TMP[63:48] \leftarrow (DEST[127:96] < 0)? 0 : DEST[111:96];
DEST[63:48] \leftarrow (DEST[127:96] > FFFFH)? FFFFH: TMP[63:48];
TMP[79:64] \leftarrow (SRC[31:0] < 0) ? 0 : SRC[15:0];
DEST[63:48] \leftarrow (SRC[31:0] > FFFFH)? FFFFH: TMP[79:64];
TMP[95:80] \leftarrow (SRC[63:32] < 0)? 0 : SRC[47:32];
DEST[95:80] \leftarrow (SRC[63:32] > FFFFH)? FFFFH: TMP[95:80];
TMP[111:96] \leftarrow (SRC[95:64] < 0)? 0 : SRC[79:64];
DEST[111:96] \leftarrow (SRC[95:64] > FFFFH)? FFFFH: TMP[111:96];
TMP[127:112] \leftarrow (SRC[127:96] < 0) ? 0 : SRC[111:96];
DEST[128:112] \leftarrow (SRC[127:96] > FFFFH)? FFFFH: TMP[127:112];
```

PACKUSDW (128-bit Legacy SSE version)

DEST[127:0] ← UNSIGNED_SATURATING_PACK_DW(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

VPACKUSDW (VEX.128 encoded version)

$$\label{eq:desting_pack_dw} \begin{split} \mathsf{DEST}[127:0] &\leftarrow \mathsf{UNSIGNED_SATURATING_PACK_DW}(\mathsf{SRC1}, \mathsf{SRC2}) \\ \mathsf{DEST}[\mathsf{VLMAX-}1:128] &\leftarrow 0 \end{split}$$

Intel C/C++ Compiler Intrinsic Equivalent

PACKUSDW m128i mm packus epi32(m128i m1, m128i m2);

Flags Affected

None.

SIMD Exceptions

None.

Other Exceptions

PACKUSWB—Pack with Unsigned Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 67 /r ¹ PACKUSWB mm, mm/m64	Α	V/V	MMX	Converts 4 signed word integers from mm and 4 signed word integers from mm/m64 into 8 unsigned byte integers in mm using unsigned saturation.
66 OF 67 /r PACKUSWB xmm1, xmm2/m128	Α	V/V	SSE2	Converts 8 signed word integers from xmm1 and 8 signed word integers from xmm2/m128 into 16 unsigned byte integers in xmm1 using unsigned saturation.
VEX.NDS.128.66.0F.WIG 67 /r VPACKUSWB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Converts 8 signed word integers from xmm2 and 8 signed word integers from xmm3/m128 into 16 unsigned byte integers in xmm1 using unsigned saturation.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Converts 4 or 8 signed word integers from the destination operand (first operand) and 4 or 8 signed word integers from the source operand (second operand) into 8 or 16 unsigned byte integers and stores the result in the destination operand. (See Figure 4-2 for an example of the packing operation.) If a signed word integer value is beyond the range of an unsigned byte integer (that is, greater than FFH or less than

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

00H), the saturated unsigned byte integer value of FFH or 00H, respectively, is stored in the destination.

The PACKUSWB instruction operates on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Operation

PACKUSWB (with 64-bit operands)

```
\label{eq:def:DEST[3:0]} \begin{split} \mathsf{DEST[7:0]} \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ \mathsf{DEST[15:0]}; \\ \mathsf{DEST[15:8]} \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ \mathsf{DEST[31:16]}; \\ \mathsf{DEST[23:16]} \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ \mathsf{DEST[47:32]}; \\ \mathsf{DEST[31:24]} \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ \mathsf{DEST[63:48]}; \\ \mathsf{DEST[39:32]} \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ \mathsf{SRC[15:0]}; \end{split}
```

DEST[47:40] ← SaturateSignedWordToUnsignedByte SRC[31:16]; DEST[55:48] ← SaturateSignedWordToUnsignedByte SRC[47:32];

DEST[63:56] ← SaturateSignedWordToUnsignedByte SRC[63:48];

PACKUSWB (with 128-bit operands)

DEST[7:0]← SaturateSignedWordToUnsignedByte (DEST[15:0]);

 $DEST[15:8] \leftarrow SaturateSignedWordToUnsignedByte (DEST[31:16]);$

 $DEST[23:16] \leftarrow SaturateSignedWordToUnsignedByte \ (DEST[47:32]);$

DEST[31:24] ← SaturateSignedWordToUnsignedByte (DEST[63:48]);

DEST[39:32] ← SaturateSignedWordToUnsignedByte (DEST[79:64]);

DEST[47:40] ← SaturateSignedWordToUnsignedByte (DEST[95:80]);

DEST[55:48] ← SaturateSignedWordToUnsignedByte (DEST[111:96]);

 $DEST[63:56] \leftarrow SaturateSignedWordToUnsignedByte \ (DEST[127:112]);$

 $DEST[71:64] \leftarrow SaturateSignedWordToUnsignedByte~(SRC[15:0]);\\$

 $\mathsf{DEST}[79:72] \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ (\mathsf{SRC}[31:16]);$

 $\mathsf{DEST}[87:80] \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ (\mathsf{SRC}[47:32]);$

DEST[95:88] ← SaturateSignedWordToUnsignedByte (SRC[63:48]);

DEST[103:96] ← SaturateSignedWordToUnsignedByte (SRC[79:64]); DEST[111:104] ← SaturateSignedWordToUnsignedByte (SRC[95:80]);

DEST[119:112] ← SaturateSignedWordToUnsignedByte (SRC[111:96]);

 $\mathsf{DEST}[127:120] \leftarrow \mathsf{SaturateSignedWordToUnsignedByte} \ (\mathsf{SRC}[127:112]);$

PACKUSWB (128-bit Legacy SSE version)

 $\mathsf{DEST}[127:0] \leftarrow \mathsf{UNSIGNED_SATURATING_PACK_WB}(\mathsf{DEST},\mathsf{SRC})$

DEST[VLMAX-1:128] (Unmodified)

VPACKUSWB (VEX.128 encoded version)

$$\label{eq:desting_pack_wb(src1, src2)} \begin{split} \text{DEST[127:0]} \leftarrow \text{UNSIGNED_SATURATING_PACK_WB(src1, src2)} \\ \text{DEST[VLMAX-1:128]} \leftarrow 0 \end{split}$$

Intel C/C++ Compiler Intrinsic Equivalent

```
PACKUSWB __m64 _mm_packs_pu16(__m64 m1, __m64 m2)
```

PACKUSWB __m128i _mm_packus_epi16(__m128i m1, __m128i m2)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

PADDB/PADDW/PADDD—Add Packed Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF FC /r ¹ PADDB mm, mm/m64	Α	V/V	MMX	Add packed byte integers from <i>mm/m64</i> and <i>mm</i> .
66 OF FC /r PADDB xmm1, xmm2/m128	Α	V/V	SSE2	Add packed byte integers from <i>xmm2/m128</i> and <i>xmm1</i> .
OF FD /r ¹ PADDW <i>mm, mm/m64</i>	Α	V/V	MMX	Add packed word integers from <i>mm/m64</i> and <i>mm</i> .
66 OF FD /r PADDW xmm1, xmm2/m128	Α	V/V	SE2	Add packed word integers from xmm2/m128 and xmm1.
OF FE /r ¹ PADDD <i>mm, mm/m64</i>	Α	V/V	MMX	Add packed doubleword integers from <i>mm/m64</i> and <i>mm</i> .
66 OF FE /r PADDD xmm1, xmm2/m128	Α	V/V	SSE2	Add packed doubleword integers from xmm2/m128 and xmm1.
VEX.NDS.128.66.0F.WIG FC /r VPADDB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed byte integers from xmm3/m128 and xmm2.
VEX.NDS.128.66.0F.WIG FD /r VPADDW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed word integers from xmm3/m128 and xmm2.
VEX.NDS.128.66.0F.WIG FE /r VPADDD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed doubleword integers from xmm3/m128 and xmm2.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Description

Performs a SIMD add of the packed integers from the source operand (second operand) and the destination operand (first operand), and stores the packed integer results in the destination operand. See Figure 9-4 in the *Intel*® 64 and *IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD operation. Overflow is handled with wraparound, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

Adds the packed byte, word, doubleword, or quadword integers in the first source operand to the second source operand and stores the result in the destination operand. When a result is too large to be represented in the 8/16/32 integer (overflow), the result is wrapped around and the low bits are written to the destination element (that is, the carry is ignored).

Note that these instructions can operate on either unsigned or signed (two's complement notation) integers; however, it does not set bits in the EFLAGS register to indicate overflow and/or a carry. To prevent undetected overflow conditions, software must control the ranges of the values operated on.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PADDB (with 64-bit operands)

DEST[7:0] \leftarrow DEST[7:0] + SRC[7:0]; (* Repeat add operation for 2nd through 7th byte *) DEST[63:56] \leftarrow DEST[63:56] + SRC[63:56];

PADDB (with 128-bit operands)

DEST[7:0] \leftarrow DEST[7:0] + SRC[7:0]; (* Repeat add operation for 2nd through 14th byte *) DEST[127:120] \leftarrow DEST[111:120] + SRC[127:120];

PADDW (with 64-bit operands)

DEST[15:0] \leftarrow DEST[15:0] + SRC[15:0]; (* Repeat add operation for 2nd and 3th word *) DEST[63:48] \leftarrow DEST[63:48] + SRC[63:48];

PADDW (with 128-bit operands)

DEST[15:0] \leftarrow DEST[15:0] + SRC[15:0]; (* Repeat add operation for 2nd through 7th word *) DEST[127:112] \leftarrow DEST[127:112] + SRC[127:112];

PADDD (with 64-bit operands)

DEST[31:0] \leftarrow DEST[31:0] + SRC[31:0]; DEST[63:32] \leftarrow DEST[63:32] + SRC[63:32];

PADDD (with 128-bit operands)

DEST[31:0] \leftarrow DEST[31:0] + SRC[31:0]; (* Repeat add operation for 2nd and 3th doubleword *) DEST[127:96] \leftarrow DEST[127:96] + SRC[127:96];

VPADDB (VEX.128 encoded version)

 $\mathsf{DEST}[7:0] \leftarrow \mathsf{SRC1}[7:0] + \mathsf{SRC2}[7:0]$

DEST[15:8] \leftarrow SRC1[15:8]+SRC2[15:8]

DEST[23:16] \leftarrow SRC1[23:16]+SRC2[23:16]

DEST[31:24] \leftarrow SRC1[31:24]+SRC2[31:24]

DEST[39:32] \leftarrow SRC1[39:32]+SRC2[39:32]

DEST[47:40] \leftarrow SRC1[47:40]+SRC2[47:40]

DEST[55:48] \leftarrow SRC1[55:48]+SRC2[55:48]

DEST[63:56] \leftarrow SRC1[63:56]+SRC2[63:56]

DEST[71:64] ← SRC1[71:64]+SRC2[71:64]

DEST[79:72] \leftarrow SRC1[79:72]+SRC2[79:72] DEST[87:80] \leftarrow SRC1[87:80]+SRC2[87:80]

DEST[95:88] ← SRC1[95:88]+SRC2[95:88]

DEST[103:96] ← SRC1[103:96]+SRC2[103:96]

DEST[111:104] \leftarrow SRC1[111:104]+SRC2[111:104]

 $\mathsf{DEST}[119:112] \leftarrow \mathsf{SRC1}[119:112] + \mathsf{SRC2}[119:112]$

 $\mathsf{DEST}[127:120] \leftarrow \mathsf{SRC1}[127:120] + \mathsf{SRC2}[127:120]$

DEST[VLMAX-1:128] ← 0

VPADDW (VEX.128 encoded version)

DEST[15:0] ← SRC1[15:0]+SRC2[15:0]

DEST[31:16] \leftarrow SRC1[31:16]+SRC2[31:16]

DEST[47:32] \leftarrow SRC1[47:32]+SRC2[47:32]

DEST[63:48] \leftarrow SRC1[63:48]+SRC2[63:48]

 $\mathsf{DEST}[79:64] \leftarrow \mathsf{SRC1}[79:64] + \mathsf{SRC2}[79:64]$

 $\mathsf{DEST}[95:80] \leftarrow \mathsf{SRC1}[95:80] + \mathsf{SRC2}[95:80]$

 $DEST[111:96] \leftarrow SRC1[111:96] + SRC2[111:96]$

DEST[127:112]

SRC1[127:112] + SRC2[127:112]

DEST[VLMAX-1:128] \leftarrow 0

VPADDD (VEX.128 encoded version)

DEST[31:0] \leftarrow SRC1[31:0]+SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32]+SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64]+SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96]+SRC2[127:96] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PADDB __m64 _mm_add_pi8(__m64 m1, __m64 m2)
PADDB __m128i _mm_add_epi8 (__m128ia,__m128ib )
PADDW __m64 _mm_add_pi16(__m64 m1, __m64 m2)
PADDW __m128i _mm_add_epi16 ( __m128i a, __m128i b)
PADDD __m64 _mm_add_pi32(__m64 m1, __m64 m2)
PADDD __m128i _mm_add_epi32 ( __m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

PADDQ—Add Packed Quadword Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF D4 /r ¹ PADDQ mm1, mm2/m64	Α	V/V	SSE2	Add quadword integer mm2/m64 to mm1.
66 OF D4 /r PADDQ xmm1, xmm2/m128	Α	V/V	SSE2	Add packed quadword integers xmm2/m128 to xmm1.
VEX.NDS.128.66.0F.WIG D4 /r VPADDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed quadword integers xmm3/m128 and xmm2.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Adds the first operand (destination operand) to the second operand (source operand) and stores the result in the destination operand. The source operand can be a quadword integer stored in an MMX technology register or a 64-bit memory location, or it can be two packed quadword integers stored in an XMM register or an 128-bit memory location. The destination operand can be a quadword integer stored in an MMX technology register or two packed quadword integers stored in an XMM register. When packed quadword operands are used, a SIMD add is performed. When a quadword result is too large to be represented in 64 bits (overflow), the result is wrapped around and the low 64 bits are written to the destination element (that is, the carry is ignored).

Note that the PADDQ instruction can operate on either unsigned or signed (two's complement notation) integers; however, it does not set bits in the EFLAGS register to indicate overflow and/or a carry. To prevent undetected overflow conditions, software must control the ranges of the values operated on.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PADDQ (with 64-Bit operands)

 $DEST[63:0] \leftarrow DEST[63:0] + SRC[63:0];$

PADDQ (with 128-Bit operands)

DEST[63:0] \leftarrow DEST[63:0] + SRC[63:0]; DEST[127:64] \leftarrow DEST[127:64] + SRC[127:64];

VPADDQ (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0]+SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64]+SRC2[127:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

PADDQ __m64 _mm_add_si64 (__m64 a, __m64 b)
PADDQ __m128i _mm_add_epi64 (__m128i a, __m128i b)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

PADDSB/PADDSW—Add Packed Signed Integers with Signed Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF EC /r ¹ PADDSB mm, mm/m64	Α	V/V	MMX	Add packed signed byte integers from <i>mm/m64</i> and <i>mm</i> and saturate the results.
66 OF EC /r PADDSB xmm1, xmm2/m128	Α	V/V	SSE2	Add packed signed byte integers from xmm2/m128 and xmm1 saturate the results.
OF ED /r ¹ PADDSW mm, mm/m64	Α	V/V	MMX	Add packed signed word integers from <i>mm/m64</i> and <i>mm</i> and saturate the results.
66 OF ED /r PADDSW xmm1, xmm2/m128	Α	V/V	SSE2	Add packed signed word integers from xmm2/m128 and xmm1 and saturate the results.
VEX.NDS.128.66.0F.WIG EC /r VPADDSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed signed byte integers from xmm3/m128 and xmm2 saturate the results.
VEX.NDS.128.66.0F.WIG ED /r VPADDSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed signed word integers from xmm3/m128 and xmm2 and saturate the results.

NOTES:

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

		modraction operana c	-incoding	
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:rea (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Instruction Operand Encoding

Description

Performs a SIMD add of the packed signed integers from the source operand (second operand) and the destination operand (first operand), and stores the packed integer results in the destination operand. See Figure 9-4 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD operation. Overflow is handled with signed saturation, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

The PADDSB instruction adds packed signed byte integers. When an individual byte result is beyond the range of a signed byte integer (that is, greater than 7FH or less than 80H), the saturated value of 7FH or 80H, respectively, is written to the destination operand.

The PADDSW instruction adds packed signed word integers. When an individual word result is beyond the range of a signed word integer (that is, greater than 7FFFH or less than 8000H), the saturated value of 7FFFH or 8000H, respectively, is written to the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PADDSB (with 64-bit operands)

DEST[7:0] ← SaturateToSignedByte(DEST[7:0] + SRC (7:0]); (* Repeat add operation for 2nd through 7th bytes *) DEST[63:56] ← SaturateToSignedByte(DEST[63:56] + SRC[63:56]);

PADDSB (with 128-bit operands)

DEST[7:0] \leftarrow SaturateToSignedByte (DEST[7:0] + SRC[7:0]);

```
(* Repeat add operation for 2nd through 14th bytes *)
DEST[127:120] ← SaturateToSignedByte (DEST[111:120] + SRC[127:120]);
```

VPADDSB

```
DEST[7:0] \leftarrow SaturateToSignedByte (SRC1[7:0] + SRC2[7:0]);

(* Repeat subtract operation for 2nd through 14th bytes *)

DEST[127:120] \leftarrow SaturateToSignedByte (SRC1[111:120] + SRC2[127:120]);

DEST[VLMAX-1:128] \leftarrow 0
```

PADDSW (with 64-bit operands)

```
DEST[15:0] \leftarrow SaturateToSignedWord(DEST[15:0] + SRC[15:0]); (* Repeat add operation for 2nd and 7th words *) DEST[63:48] \leftarrow SaturateToSignedWord(DEST[63:48] + SRC[63:48]);
```

PADDSW (with 128-bit operands)

```
DEST[15:0] \leftarrow SaturateToSignedWord (DEST[15:0] + SRC[15:0]); (* Repeat add operation for 2nd through 7th words *) DEST[127:112] \leftarrow SaturateToSignedWord (DEST[127:112] + SRC[127:112]);
```

VPADDSW

```
DEST[15:0] \leftarrow SaturateToSignedWord (SRC1[15:0] + SRC2[15:0]); (* Repeat subtract operation for 2nd through 7th words *) DEST[127:112] \leftarrow SaturateToSignedWord (SRC1[127:112] + SRC2[127:112]); DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PADDSB __m64 _mm_adds_pi8(__m64 m1, __m64 m2)
PADDSB __m128i _mm_adds_epi8 ( __m128i a, __m128i b)
PADDSW __m64 _mm_adds_pi16(__m64 m1, __m64 m2)
PADDSW __m128i _mm_adds_epi16 ( __m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PADDUSB/PADDUSW—Add Packed Unsigned Integers with Unsigned Saturation

Opcode/ Instruction		Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF DC /r ¹ PADDUSB mm, mm/m64		Α	V/V	MMX	Add packed unsigned byte integers from <i>mm/m64</i> and <i>mm</i> and saturate the results.
66 OF DC /r PADDUSB xmm1, xmm2/m128		Α	V/V	SSE2	Add packed unsigned byte integers from xmm2/m128 and xmm1 saturate the results.
OF DD /r ¹ PADDUSW mm, mm/m64		Α	V/V	MMX	Add packed unsigned word integers from <i>mm/m64</i> and <i>mm</i> and saturate the results.
66 OF DD /r PADDUSW xmm1, xmm2/m128		Α	V/V	SSE2	Add packed unsigned word integers from xmm2/m128 to xmm1 and saturate the results.
VEX.NDS.128.6 60F.WIG DC /r	VPADDUSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed unsigned byte integers from xmm3/m128 to xmm2 and saturate the results.
VEX.NDS.128.6 6.0F.WIG DD /r	VPADDUSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add packed unsigned word integers from xmm3/m128 to xmm2 and saturate the results.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (г, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Description

Performs a SIMD add of the packed unsigned integers from the source operand (second operand) and the destination operand (first operand), and stores the packed integer results in the destination operand. See Figure 9-4 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD operation. Overflow is handled with unsigned saturation, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

The PADDUSB instruction adds packed unsigned byte integers. When an individual byte result is beyond the range of an unsigned byte integer (that is, greater than FFH), the saturated value of FFH is written to the destination operand.

The PADDUSW instruction adds packed unsigned word integers. When an individual word result is beyond the range of an unsigned word integer (that is, greater than FFFFH), the saturated value of FFFFH is written to the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PADDUSB (with 64-bit operands)

DEST[7:0] \leftarrow SaturateToUnsignedByte(DEST[7:0] + SRC (7:0]); (* Repeat add operation for 2nd through 7th bytes *) DEST[63:56] \leftarrow SaturateToUnsignedByte(DEST[63:56] + SRC[63:56]

PADDUSB (with 128-bit operands)

DEST[7:0] ← SaturateToUnsignedByte (DEST[7:0] + SRC[7:0]); (* Repeat add operation for 2nd through 14th bytes *) DEST[127:120] ← SaturateToUnSignedByte (DEST[127:120] + SRC[127:120]);

VPADDUSB

DEST[7:0] \leftarrow SaturateToUnsignedByte (SRC1[7:0] + SRC2[7:0]); (* Repeat subtract operation for 2nd through 14th bytes *) DEST[127:120] \leftarrow SaturateToUnsignedByte (SRC1[111:120] + SRC2[127:120]); DEST[VLMAX-1:128] \leftarrow 0

PADDUSW (with 64-bit operands)

```
DEST[15:0] \leftarrow SaturateToUnsignedWord(DEST[15:0] + SRC[15:0]); (* Repeat add operation for 2nd and 3rd words *) DEST[63:48] \leftarrow SaturateToUnsignedWord(DEST[63:48] + SRC[63:48]);
```

PADDUSW (with 128-bit operands)

```
DEST[15:0] \leftarrow SaturateToUnsignedWord (DEST[15:0] + SRC[15:0]); (* Repeat add operation for 2nd through 7th words *) DEST[127:112] \leftarrow SaturateToUnSignedWord (DEST[127:112] + SRC[127:112]);
```

VPADDUSW

```
\begin{aligned} & \mathsf{DEST}[15:0] \leftarrow \mathsf{SaturateToUnsignedWord} \ (\mathsf{SRC1}[15:0] + \mathsf{SRC2}[15:0]); \\ & (*\mathsf{Repeat} \ \mathsf{subtract} \ \mathsf{operation} \ \mathsf{for} \ \mathsf{2nd} \ \mathsf{through} \ \mathsf{7th} \ \mathsf{words} \ \mathsf{*}) \\ & \mathsf{DEST}[127:112] \leftarrow \mathsf{SaturateToUnsignedWord} \ (\mathsf{SRC1}[127:112] + \mathsf{SRC2}[127:112]); \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{aligned}
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PADDUSB __m64 _mm_adds_pu8(__m64 m1, __m64 m2)
PADDUSW __m64 _mm_adds_pu16(__m64 m1, __m64 m2)
PADDUSB __m128i _mm_adds_epu8 ( __m128i a, __m128i b)
PADDUSW __m128i _mm_adds_epu16 ( __m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PALIGNR — Packed Align Right

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 3A OF ¹ PALIGNR mm1, mm2/m64, imm8	Α	V/V	SSSE3	Concatenate destination and source operands, extract byte-aligned result shifted to the right by constant value in imm8 into mm1.
66 OF 3A OF PALIGNR xmm1, xmm2/m128, imm8	Α	V/V	SSSE3	Concatenate destination and source operands, extract byte-aligned result shifted to the right by constant value in imm8 into xmm1
VEX.NDS.128.66.0F3A.WIG 0F /r ib VPALIGNR xmm1, xmm2, xmm3/m128, imm8	В	V/V	AVX	Concatenate xmm2 and xmm3/m128, extract byte aligned result shifted to the right by constant value in imm8 and result is stored in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PALIGNR concatenates the destination operand (the first operand) and the source operand (the second operand) into an intermediate composite, shifts the composite at byte granularity to the right by a constant immediate, and extracts the right-aligned result into the destination. The first and the second operands can be an MMX or an XMM register. The immediate value is considered unsigned. Immediate shift counts larger than the 2L (i.e. 32 for 128-bit operands, or 16 for 64-bit operands) produce a zero result. Both operands can be MMX register or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PALIGNR (with 64-bit operands)

```
temp1[127:0] = CONCATENATE(DEST,SRC)>>(imm8*8)
DEST[63:0] = temp1[63:0]
```

PALIGNR (with 128-bit operands)

```
temp1[255:0] = CONCATENATE(DEST,SRC)>>(imm8*8)
DEST[127:0] = temp1[127:0]
```

VPALIGNR

```
temp1[255:0] \leftarrow CONCATENATE(SRC1,SRC2)>>(imm8*8)
DEST[127:0] \leftarrow temp1[127:0]
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PALIGNR __m64 _mm_alignr_pi8 (__m64 a, __m64 b, int n)
PALIGNR __m128i _mm_alignr_epi8 (__m128i a, __m128i b, int n)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PAND—Logical AND

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F DB / <i>r</i> ¹	Α	V/V	MMX	Bitwise AND mm/m64 and
PAND mm, mm/m64				mm.
66 OF DB /r	Α	V/V	SSE2	Bitwise AND of
PAND xmm1, xmm2/m128				xmm2/m128 and xmm1.
VEX.NDS.128.66.0F.WIG DB /r	В	V/V	AVX	Bitwise AND of
VPAND xmm1, xmm2, xmm3/m128				xmm3/m128 and xmm.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical AND operation on the source operand (second operand) and the destination operand (first operand) and stores the result in the destination operand. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. Each bit of the result is set to 1 if the corresponding bits of the first and second operands are 1; otherwise, it is set to 0.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PAND (128-bit Legacy SSE version)

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

DEST ← DEST AND SRC
DEST[VLMAX-1:1288] (Unmodified)

VPAND (VEX.128 encoded version)

DEST \leftarrow SRC1 AND SRC2 DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PAND __m64 _mm_and_si64 (__m64 m1, __m64 m2)
PAND __m128i _mm_and_si128 (__m128i a, __m128i b)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

PANDN—Logical AND NOT

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F DF /r ¹	Α	V/V	MMX	Bitwise AND NOT of
PANDN mm, mm/m64				mm/m64 and mm.
66 0F DF /r	Α	V/V	SSE2	Bitwise AND NOT of
PANDN xmm1, xmm2/m128				xmm2/m128 and $xmm1$.
VEX.NDS.128.66.0F.WIG DF /r	В	V/V	AVX	Bitwise AND NOT of
VPANDN xmm1, xmm2, xmm3/m128				xmm3/m128 and xmm2.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical NOT of the destination operand (first operand), then performs a bitwise logical AND of the source operand (second operand) and the inverted destination operand. The result is stored in the destination operand. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. Each bit of the result is set to 1 if the corresponding bit in the first operand is 0 and the corresponding bit in the second operand is 1; otherwise, it is set to 0.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:1288) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Operation

PANDN(128-bit Legacy SSE version)

DEST ← NOT(DEST) AND SRC
DEST[VLMAX-1:128] (Unmodified)

VPANDN (VEX.128 encoded version)

DEST \leftarrow NOT(SRC1) AND SRC2 DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PANDN __m64 _mm_andnot_si64 (__m64 m1, __m64 m2)
PANDN _m128i _mm_andnot_si128 (__m128i a, __m128i b)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

PAUSE—Spin Loop Hint

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F3 90	PAUSE	Α	Valid	Valid	Gives hint to processor that improves performance of spin-wait loops.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Improves the performance of spin-wait loops. When executing a "spin-wait loop," a Pentium 4 or Intel Xeon processor suffers a severe performance penalty when exiting the loop because it detects a possible memory order violation. The PAUSE instruction provides a hint to the processor that the code sequence is a spin-wait loop. The processor uses this hint to avoid the memory order violation in most situations, which greatly improves processor performance. For this reason, it is recommended that a PAUSE instruction be placed in all spin-wait loops.

An additional function of the PAUSE instruction is to reduce the power consumed by a Pentium 4 processor while executing a spin loop. The Pentium 4 processor can execute a spin-wait loop extremely quickly, causing the processor to consume a lot of power while it waits for the resource it is spinning on to become available. Inserting a pause instruction in a spin-wait loop greatly reduces the processor's power consumption.

This instruction was introduced in the Pentium 4 processors, but is backward compatible with all IA-32 processors. In earlier IA-32 processors, the PAUSE instruction operates like a NOP instruction. The Pentium 4 and Intel Xeon processors implement the PAUSE instruction as a pre-defined delay. The delay is finite and can be zero for some processors. This instruction does not change the architectural state of the processor (that is, it performs essentially a delaying no-op operation).

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

Execute_Next_Instruction(DELAY);

Numeric Exceptions

None.

Exceptions (All Operating Modes)

#UD If the LOCK prefix is used.

PAVGB/PAVGW—Average Packed Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF EO /r ¹ PAVGB mm1, mm2/m64	Α	V/V	SSE	Average packed unsigned byte integers from mm2/m64 and mm1 with rounding.
66 OF EO, /r PAVGB xmm1, xmm2/m128	Α	V/V	SSE2	Average packed unsigned byte integers from xmm2/m128 and xmm1 with rounding.
OF E3 /r ¹ PAVGW mm1, mm2/m64	Α	V/V	SSE	Average packed unsigned word integers from mm2/m64 and mm1 with rounding.
66 OF E3 /r PAVGW xmm1, xmm2/m128	Α	V/V	SSE2	Average packed unsigned word integers from xmm2/m128 and xmm1 with rounding.
VEX.NDS.128.66.0F.WIG E0 /r VPAVGB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Average packed unsigned byte integers from xmm3/m128 and xmm2 with rounding.
VEX.NDS.128.66.0F.WIG E3 /r VPAVGW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Average packed unsigned word integers from xmm3/m128 and xmm2 with rounding.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD average of the packed unsigned integers from the source operand

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

(second operand) and the destination operand (first operand), and stores the results in the destination operand. For each corresponding pair of data elements in the first and second operands, the elements are added together, a 1 is added to the temporary sum, and that result is shifted right one bit position. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

The PAVGB instruction operates on packed unsigned bytes and the PAVGW instruction operates on packed unsigned words.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PAVGB (with 64-bit operands)

```
DEST[7:0] \leftarrow (SRC[7:0] + DEST[7:0] + 1) >> 1; (* Temp sum before shifting is 9 bits *) (* Repeat operation performed for bytes 2 through 6 *) DEST[63:56] \leftarrow (SRC[63:56] + DEST[63:56] + 1) >> 1;
```

PAVGW (with 64-bit operands)

```
DEST[15:0] \leftarrow (SRC[15:0] + DEST[15:0] + 1) >> 1; (* Temp sum before shifting is 17 bits *) (* Repeat operation performed for words 2 and 3 *) DEST[63:48] \leftarrow (SRC[63:48] + DEST[63:48] + 1) >> 1;
```

PAVGB (with 128-bit operands)

```
\begin{aligned} & \mathsf{DEST[7:0]} \leftarrow (\mathsf{SRC[7:0]} + \mathsf{DEST[7:0]} + 1) >> 1; (* \mathsf{Temp} \; \mathsf{sum} \; \mathsf{before} \; \mathsf{shifting} \; \mathsf{is} \; 9 \; \mathsf{bits} \; *) \\ & (* \mathsf{Repeat} \; \mathsf{operation} \; \mathsf{performed} \; \mathsf{for} \; \mathsf{bytes} \; 2 \; \mathsf{through} \; 14 \; *) \\ & \mathsf{DEST[127:120]} \leftarrow (\mathsf{SRC[127:120]} + \mathsf{DEST[127:120]} + 1) >> 1; \end{aligned}
```

PAVGW (with 128-bit operands)

```
DEST[15:0] \leftarrow (SRC[15:0] + DEST[15:0] + 1) >> 1; (* Temp sum before shifting is 17 bits *) (* Repeat operation performed for words 2 through 6 *) DEST[127:112] \leftarrow (SRC[127:112] + DEST[127:112] + 1) >> 1;
```

VPAVGB (VEX.128 encoded version)

```
DEST[7:0] ← (SRC1[7:0] + SRC2[7:0] + 1) >> 1;

(* Repeat operation performed for bytes 2 through 15 *)

DEST[127:120] ← (SRC1[127:120] + SRC2[127:120] + 1) >> 1

DEST[VLMAX-1:128] ← 0
```

VPAVGW (VEX.128 encoded version)

```
DEST[15:0] \leftarrow (SRC1[15:0] + SRC2[15:0] + 1) >> 1;

(* Repeat operation performed for 16-bit words 2 through 7 *)

DEST[127:112] \leftarrow (SRC1[127:112] + SRC2[127:112] + 1) >> 1

DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PAVGB __m64 _mm_avg_pu8 (__m64 a, __m64 b)
PAVGW __m64 _mm_avg_pu16 (__m64 a, __m64 b)
PAVGB __m128i _mm_avg_epu8 (__m128i a, __m128i b)
PAVGW __m128i _mm_avg_epu16 (__m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 10 /r PBLENDVB xmm1, xmm2/m128, <xmm0></xmm0>	Α	V/V	SSE4_1	Select byte values from xmm1 and xmm2/m128 from mask specified in the high bit of each byte in XMMO and store the values into xmm1.
VEX.NDS.128.66.0F3A.W0 4C /r /is4 VPBLENDVB xmm1, xmm2, xmm3/m128, xmm4	В	V/V	AVX	Select byte values from xmm2 and xmm3/m128 using mask bits in the specified mask register, xmm4, and store the values into xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	<xmm0></xmm0>	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Conditionally copies byte elements from the source operand (second operand) to the destination operand (first operand) depending on mask bits defined in the implicit third register argument, XMM0. The mask bits are the most significant bit in each byte element of the XMM0 register.

If a mask bit is "1", then the corresponding byte element in the source operand is copied to the destination, else the byte element in the destination operand is left unchanged.

The register assignment of the implicit third operand is defined to be the architectural register XMM0.

128-bit Legacy SSE version: The first source operand and the destination operand is the same. Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged. The mask register operand is implicitly defined to be the architectural register XMM0. An attempt to execute PBLENDVB with a VEX prefix will cause #UD.

VEX.128 encoded version: The first source operand and the destination operand are XMM registers. The second source operand is an XMM register or 128-bit memory location. The mask operand is the third source register, and encoded in bits[7:4] of the immediate byte(imm8). The bits[3:0] of imm8 are ignored. In 32-bit mode, imm8[7] is ignored. The upper bits (VLMAX-1:128) of the corresponding YMM

PBLENDVB (128-bit Legacy SSE version)

register (destination register) are zeroed. VEX.L must be 0, otherwise the instruction will #UD. VEX.W must be 0, otherwise, the instruction will #UD.

VPBLENDVB permits the mask to be any XMM or YMM register. In contrast, PBLENDVB treats XMM0 implicitly as the mask and do not support non-destructive destination operation. An attempt to execute PBLENDVB encoded with a VEX prefix will cause a #UD exception.

Operation

MASK ← XMM0

IF (MASK[7] = 1) THEN DEST[7:0] \leftarrow SRC[7:0]; ELSE DEST[7:0] \leftarrow DEST[7:0]; IF (MASK[15] = 1) THEN DEST[15:8] \leftarrow SRC[15:8]; ELSE DEST[15:8] \leftarrow DEST[15:8]; IF (MASK[23] = 1) THEN DEST[23:16] \leftarrow SRC[23:16] ELSE DEST[23:16] \leftarrow DEST[23:16]; IF (MASK[31] = 1) THEN DEST[31:24] \leftarrow SRC[31:24] ELSE DEST[31:24] \leftarrow DEST[31:24]; IF (MASK[39] = 1) THEN DEST[39:32] \leftarrow SRC[39:32] ELSE DEST[39:32] \leftarrow DEST[39:32]; IF (MASK[47] = 1) THEN DEST[47:40] \leftarrow SRC[47:40] ELSE DEST[47:40] \leftarrow DEST[47:40]; IF (MASK[55] = 1) THEN DEST[55:48] \leftarrow SRC[55:48] ELSE DEST[55:48] \leftarrow DEST[55:48]; IF (MASK[63] = 1) THEN DEST[63:56] \leftarrow SRC[63:56] ELSE DEST[63:56] \leftarrow DEST[63:56]; IF (MASK[71] = 1) THEN DEST[71:64] \leftarrow SRC[71:64] ELSE DEST[71:64] \leftarrow DEST[71:64]; IF (MASK[79] = 1) THEN DEST[79:72] \leftarrow SRC[79:72] ELSE DEST[79:72] \leftarrow DEST[79:72]; IF (MASK[87] = 1) THEN DEST[87:80] \leftarrow SRC[87:80] ELSE DEST[87:80] \leftarrow DEST[87:80]; IF (MASK[95] = 1) THEN DEST[95:88] \leftarrow SRC[95:88] ELSE DEST[95:88] \leftarrow DEST[95:88]; IF (MASK[103] = 1) THEN DEST[103:96] \leftarrow SRC[103:96] ELSE DEST[103:96] \leftarrow DEST[103:96];

IF (MASK[111] = 1) THEN DEST[111:104] ← SRC[111:104]

IF (MASK[119] = 1) THEN DEST[119:112] ← SRC[119:112]

IF (MASK[127] = 1) THEN DEST[127:120] ← SRC[127:120]

ELSE DEST[111:104] \leftarrow DEST[111:104];

ELSE DEST[119:112] \leftarrow DEST[119:112];

ELSE DEST[127:120] \leftarrow DEST[127:120])

DEST[VLMAX-1:128] (Unmodified)

MASK ← SRC3

VPBLENDVB (VEX.128 encoded version)

```
IF (MASK[7] = 1) THEN DEST[7:0] \leftarrow SRC2[7:0];
ELSE DEST[7:0] \leftarrow SRC1[7:0];
IF (MASK[15] = 1) THEN DEST[15:8] \leftarrow SRC2[15:8];
ELSE DEST[15:8] \leftarrow SRC1[15:8];
IF (MASK[23] = 1) THEN DEST[23:16] \leftarrow SRC2[23:16]
ELSE DEST[23:16] \leftarrow SRC1[23:16];
IF (MASK[31] = 1) THEN DEST[31:24] \leftarrow SRC2[31:24]
ELSE DEST[31:24] \leftarrow SRC1[31:24];
IF (MASK[39] = 1) THEN DEST[39:32] \leftarrow SRC2[39:32]
ELSE DEST[39:32] \leftarrow SRC1[39:32];
IF (MASK[47] = 1) THEN DEST[47:40] \leftarrow SRC2[47:40]
ELSE DEST[47:40] \leftarrow SRC1[47:40];
IF (MASK[55] = 1) THEN DEST[55:48] \leftarrow SRC2[55:48]
ELSE DEST[55:48] \leftarrow SRC1[55:48];
IF (MASK[63] = 1) THEN DEST[63:56] \leftarrow SRC2[63:56]
ELSE DEST[63:56] \leftarrow SRC1[63:56];
IF (MASK[71] = 1) THEN DEST[71:64] \leftarrow SRC2[71:64]
```

ELSE DEST[71:64] \leftarrow SRC1[71:64]; IF (MASK[79] = 1) THEN DEST[79:72] \leftarrow SRC2[79:72]

ELSE DEST[79:72] \leftarrow SRC1[79:72];

IF (MASK[87] = 1) THEN DEST[87:80] \leftarrow SRC2[87:80]

ELSE DEST[87:80] \leftarrow SRC1[87:80];

IF (MASK[95] = 1) THEN DEST[95:88] \leftarrow SRC2[95:88]

ELSE DEST[95:88] \leftarrow SRC1[95:88];

IF (MASK[103] = 1) THEN DEST[103:96] \leftarrow SRC2[103:96]

ELSE DEST[103:96] \leftarrow SRC1[103:96];

IF (MASK[111] = 1) THEN DEST[111:104] \leftarrow SRC2[111:104]

ELSE DEST[111:104] \leftarrow SRC1[111:104];

IF (MASK[119] = 1) THEN DEST[119:112] \leftarrow SRC2[119:112]

ELSE DEST[119:112] \leftarrow SRC1[119:112];

IF (MASK[127] = 1) THEN DEST[127:120] \leftarrow SRC2[127:120]

ELSE DEST[127:120] \leftarrow SRC1[127:120])

DEST[VLMAX-1:128] ← 0

Intel C/C++ Compiler Intrinsic Equivalent

PBLENDVB __m128i _mm_blendv_epi8 (__m128i v1, __m128i v2, __m128i mask);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1. If VEX.W = 1.

PBLENDW — Blend Packed Words

Opcode/ Instruction		Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A OE /r ib PBLENDW xmm1 imm8		Α	V/V	SSE4_1	Select words from xmm1 and xmm2/m128 from mask specified in imm8 and store the values into xmm1.
VEX.NDS.128.6 6.0F3A.WIG 0E /r ib	VPBLENDW xmm1, xmm2, xmm3/m128, imm8	В	V/V	AVX	Select words from xmm2 and xmm3/m128 from mask specified in imm8 and store the values into xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Conditionally copies word elements from the source operand (second operand) to the destination operand (first operand) depending on the immediate byte (third operand). Each bit of Imm8 correspond to a word element.

If a bit is "1", then the corresponding word element in the source operand is copied to the destination, else the word element in the destination operand is left unchanged.

128-bit Legacy SSE version: Bits (VLMAX-1:1288) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PBLENDW (128-bit Legacy SSE version)

IF (imm8[0] = 1) THEN DEST[15:0] \leftarrow SRC[15:0]

ELSE DEST[15:0] \leftarrow DEST[15:0]

IF (imm8[1] = 1) THEN DEST[31:16] \leftarrow SRC[31:16]

ELSE DEST[31:16] \leftarrow DEST[31:16]

IF (imm8[2] = 1) THEN DEST[47:32] \leftarrow SRC[47:32]

ELSE DEST[47:32] ← DEST[47:32]

IF (imm8[3] = 1) THEN DEST[63:48] \leftarrow SRC[63:48]

```
ELSE DEST[63:48] \leftarrow DEST[63:48]

IF (imm8[4] = 1) THEN DEST[79:64] \leftarrow SRC[79:64]

ELSE DEST[79:64] \leftarrow DEST[79:64]

IF (imm8[5] = 1) THEN DEST[95:80] \leftarrow SRC[95:80]

ELSE DEST[95:80] \leftarrow DEST[95:80]

IF (imm8[6] = 1) THEN DEST[111:96] \leftarrow SRC[111:96]

ELSE DEST[111:96] \leftarrow DEST[111:96]

IF (imm8[7] = 1) THEN DEST[127:112] \leftarrow SRC[127:112]

ELSE DEST[127:112] \leftarrow DEST[127:112]
```

VPBLENDW (VEX.128 encoded version)

```
IF (imm8[0] = 1) THEN DEST[15:0] \leftarrow SRC2[15:0]
ELSE DEST[15:0] \leftarrow SRC1[15:0]
IF (imm8[1] = 1) THEN DEST[31:16] \leftarrow SRC2[31:16]
ELSE DEST[31:16] ← SRC1[31:16]
IF (imm8[2] = 1) THEN DEST[47:32] \leftarrow SRC2[47:32]
ELSE DEST[47:32] ← SRC1[47:32]
IF (imm8[3] = 1) THEN DEST[63:48] \leftarrow SRC2[63:48]
ELSE DEST[63:48] ← SRC1[63:48]
IF (imm8[4] = 1) THEN DEST[79:64] \leftarrow SRC2[79:64]
ELSE DEST[79:64] ← SRC1[79:64]
IF (imm8[5] = 1) THEN DEST[95:80] \leftarrow SRC2[95:80]
ELSE DEST[95:80] \leftarrow SRC1[95:80]
IF (imm8[6] = 1) THEN DEST[111:96] ← SRC2[111:96]
ELSE DEST[111:96] \leftarrow SRC1[111:96]
IF (imm8[7] = 1) THEN DEST[127:112] \leftarrow SRC2[127:112]
ELSE DEST[127:112] \leftarrow SRC1[127:112]
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

PBLENDW __m128i _mm_blend_epi16 (__m128i v1, __m128i v2, const int mask);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PCLMULQDQ - Carry-Less Multiplication Quadword

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 44 /r ib PCLMULQDQ xmm1, xmm2/m128, imm8	A	V/V	CLMUL	Carry-less multiplication of one quadword of xmm1 by one quadword of xmm2/m128, stores the 128-bit result in xmm1. The immediate is used to determine which quadwords of xmm1 and xmm2/m128 should be used.
VEX.NDS.128.66.0F3A.WIG 44 /r ib VPCLMULQDQ xmm1, xmm2, xmm3/m128, imm8	В	V/V	Both CLMUL and AVX flags	Carry-less multiplication of one quadword of xmm2 by one quadword of xmm3/m128, stores the 128-bit result in xmm1. The immediate is used to determine which quadwords of xmm2 and xmm3/m128 should be used.

Instruction Operand Encoding

Op/En	Operand 1	Operand2	Operand3	Operand4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a carry-less multiplication of two quadwords, selected from the first source and second source operand according to the value of the immediate byte. Bits 4 and 0 are used to select which 64-bit half of each operand to use according to Table 4-10, other bits of the immediate byte are ignored.

Table 4-10	. PCLMULODO	Ouadword Se	election of	f Immediate Br	vte
------------	-------------	-------------	-------------	----------------	-----

lmm[4]	lmm[0]	PCLMULQDQ Operation
0	0	CL_MUL(SRC2 ¹ [63:0], SRC1[63:0])
0	1	CL_MUL(SRC2[63:0], SRC1[127:64])
1	0	CL_MUL(SRC2[127:64], SRC1[63:0])
1	1	CL_MUL(SRC2[127:64], SRC1[127:64])

NOTES:

 SRC2 denotes the second source operand, which can be a register or memory; SRC1 denotes the first source and destination operand.

The first source operand and the destination operand are the same and must be an XMM register. The second source operand can be an XMM register or a 128-bit memory location. Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

Compilers and assemblers may implement the following pseudo-op syntax to simply programming and emit the required encoding for Imm8.

•	
Pseudo-Op	Imm8 Encoding
PCLMULLQLQDQ xmm1, xmm2	0000_0000B
PCLMULHQLQDQ xmm1, xmm2	0000_0001B
PCLMULLQHDQ xmm1, xmm2	0001_0000B
PCLMULHQHDQ xmm1, xmm2	0001_0001B

Table 4-11. Pseudo-Op and PCLMULQDQ Implementation

Operation

```
PCLMULQDQ
IF (Imm8[0] = 0)
   THEN
        TEMP1 \leftarrow SRC1 [63:0];
   FLSE
        TEMP1 \leftarrow SRC1 [127:64];
FΙ
IF (Imm8[4] = 0)
   THEN
        TEMP2 \leftarrow SRC2 [63:0];
   FLSE
        TEMP2 ← SRC2 [127:64];
FΙ
For i = 0 to 63 {
   TmpB [ i ] \leftarrow (TEMP1[ 0 ] and TEMP2[ i ]);
   For i = 1 to i {
        TmpB [i] \leftarrow TmpB [i] xor (TEMP1[i] and TEMP2[i-i])
   DEST[i] \leftarrow TmpB[i];
For i = 64 to 126 {
```

```
TmpB [ i ] \leftarrow 0;
   For j = i - 63 to 63 {
        TmpB [i] \leftarrow TmpB [i] xor (TEMP1[j] and TEMP2[i-j])
   DEST[i] \leftarrow TmpB[i];
DEST[127] \leftarrow 0;
DEST[VLMAX-1:128] (Unmodified)
VPCLMULQDQ
IF (Imm8[0] = 0)
   THEN
        TEMP1 \leftarrow SRC1 [63:0];
   ELSE
        TEMP1 ← SRC1 [127:64];
FI
IF (Imm8[4] = 0)
   THEN
        TEMP2 ← SRC2 [63:0];
   ELSE
        TEMP2 \leftarrow SRC2 [127:64];
FΙ
For i = 0 to 63 {
   TmpB [i] \leftarrow (TEMP1[0] and TEMP2[i]);
   For j = 1 to i{
        TmpB [i] \leftarrow TmpB [i] xor (TEMP1[j] and TEMP2[i-j])
   DEST[i] \leftarrow TmpB[i];
For i = 64 to 126 {
   TmpB[i] \leftarrow 0;
   For j = i - 63 to 63 {
        TmpB [i] \leftarrow TmpB [i] xor (TEMP1[j] and TEMP2[i-j])
   DEST[i] \leftarrow TmpB[i];
DEST[VLMAX-1:127] \leftarrow 0;
Intel C/C++ Compiler Intrinsic Equivalent
(V)PCLMULQDQ __m128i _mm_clmulepi64_si128 (__m128i, __m128i, const int)
```

INSTRUCTION SET REFERENCE, N-Z

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

PCMPEQB/PCMPEQW/PCMPEQD— Compare Packed Data for Equal

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 74 /r ¹ PCMPEQB <i>mm, mm/m64</i>	Α	V/V	MMX	Compare packed bytes in mm/m64 and mm for equality.
66 OF 74 /r PCMPEQB xmm1, xmm2/m128	Α	V/V	SSE2	Compare packed bytes in xmm2/m128 and xmm1 for equality.
OF 75 /r ¹ PCMPEQW mm, mm/m64	Α	V/V	MMX	Compare packed words in mm/m64 and mm for equality.
66 OF 75 /r PCMPEQW xmm1, xmm2/m128	Α	V/V	SSE2	Compare packed words in xmm2/m128 and xmm1 for equality.
OF 76 /r ¹ PCMPEQD <i>mm, mm/m64</i>	Α	V/V	MMX	Compare packed doublewords in <i>mm/m64</i> and <i>mm</i> for equality.
66 OF 76 /r PCMPEQD xmm1, xmm2/m128	Α	V/V	SSE2	Compare packed doublewords in xmm2/m128 and xmm1 for equality.
VEX.NDS.128.66.0F.WIG 74 /r VPCMPEQB xmm1, xmm2, xmm3 /m128	В	V/V	AVX	Compare packed bytes in xmm3/m128 and xmm2 for equality.
VEX.NDS.128.66.0F.WIG 75 /r VPCMPEQW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed words in xmm3/m128 and xmm2 for equality.
VEX.NDS.128.66.0F.WIG 76 /r VPCMPEQD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed doublewords in xmm3/m128 and xmm2 for equality.

NOTES:

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Instruction	0	perand	End	codina

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD compare for equality of the packed bytes, words, or doublewords in the destination operand (first operand) and the source operand (second operand). If a pair of data elements is equal, the corresponding data element in the destination operand is set to all 1s; otherwise, it is set to all 0s. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

The PCMPEQB instruction compares the corresponding bytes in the destination and source operands; the PCMPEQW instruction compares the corresponding words in the destination and source operands; and the PCMPEQD instruction compares the corresponding doublewords in the destination and source operands.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PCMPEQB (with 64-bit operands)

```
IF DEST[7:0] = SRC[7:0]

THEN DEST[7:0] \leftarrow FFH;

ELSE DEST[7:0] \leftarrow 0; FI;

(* Continue comparison of 2nd through 7th bytes in DEST and SRC *)

IF DEST[63:56] = SRC[63:56]

THEN DEST[63:56] \leftarrow FFH;

ELSE DEST[63:56] \leftarrow 0; FI;
```

PCMPEQB (with 128-bit operands)

```
IF DEST[7:0] = SRC[7:0]

THEN DEST[7:0) ← FFH;

ELSE DEST[7:0] ← 0; FI;

(* Continue comparison of 2nd through 15th bytes in DEST and SRC *)

IF DEST[127:120] = SRC[127:120]

THEN DEST[127:120] ← FFH;
```

```
ELSE DEST[127:120] \leftarrow 0; FI;
```

PCMPEQW (with 64-bit operands)

IF DEST[15:0] = SRC[15:0]

THEN DEST[15:0] \leftarrow FFFFH;

ELSE DEST[15:0] \leftarrow 0; FI;

(* Continue comparison of 2nd and 3rd words in DEST and SRC *)

IF DEST[63:48] = SRC[63:48]

THEN DEST[63:48] \leftarrow FFFFH;

ELSE DEST[63:48] \leftarrow 0; FI;

PCMPEQW (with 128-bit operands)

IF DEST[15:0] = SRC[15:0]

THEN DEST[15:0] \leftarrow FFFFH;

ELSE DEST[15:0] \leftarrow 0; FI;

(* Continue comparison of 2nd through 7th words in DEST and SRC *)

IF DEST[127:112] = SRC[127:112]

THEN DEST[127:112] \leftarrow FFFFH;

ELSE DEST[127:112] \leftarrow 0; FI;

PCMPEQD (with 64-bit operands)

IF DEST[31:0] = SRC[31:0]

THEN DEST[31:0] \leftarrow FFFFFFFH;

ELSE DEST[31:0] \leftarrow 0; FI;

IF DEST[63:32] = SRC[63:32]

THEN DEST[63:32] \leftarrow FFFFFFFH;

ELSE DEST[63:32] \leftarrow 0; FI;

PCMPEQD (with 128-bit operands)

IF DEST[31:0] = SRC[31:0]

THEN DEST[31:0] \leftarrow FFFFFFFH;

ELSE DEST[31:0] \leftarrow 0; FI;

(* Continue comparison of 2nd and 3rd doublewords in DEST and SRC *)

IF DEST[127:96] = SRC[127:96]

THEN DEST[127:96] ← FFFFFFFH:

ELSE DEST[127:96] \leftarrow 0; FI;

VPCMPEQB (VEX.128 encoded version)

DEST[127:0] ←COMPARE_BYTES_EQUAL(SRC1,SRC2)

DEST[VLMAX-1:128] \leftarrow 0

VPCMPEQW (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_WORDS_EQUAL(SRC1,SRC2)

DEST[VLMAX-1:1281 ← 0

VPCMPEQD (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_DWORDS_EQUAL(SRC1,SRC2) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PCMPEQB __m64 _mm_cmpeq_pi8 (__m64 m1, __m64 m2)
PCMPEQW __m64 _mm_cmpeq_pi16 (__m64 m1, __m64 m2)
PCMPEQD __m64 _mm_cmpeq_pi32 (__m64 m1, __m64 m2)
PCMPEQB __m128i _mm_cmpeq_epi8 ( __m128i a, __m128i b)
PCMPEQW __m128i _mm_cmpeq_epi16 ( __m128i a, __m128i b)
PCMPEQD __m128i _mm_cmpeq_epi32 ( __m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PCMPEQQ — Compare Packed Qword Data for Equal

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 29 /r PCMPEQQ xmm1, xmm2/m128	Α	V/V	SSE4_1	Compare packed qwords in xmm2/m128 and xmm1 for equality.
VEX.NDS.128.66.0F38.WIG 29 /r VPCMPEQQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed quadwords in xmm3/m128 and xmm2 for equality.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an SIMD compare for equality of the packed quadwords in the destination operand (first operand) and the source operand (second operand). If a pair of data elements is equal, the corresponding data element in the destination is set to all 1s; otherwise, it is set to 0s.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

IF (DEST[63:0] = SRC[63:0])

THEN DEST[63:0] \leftarrow FFFFFFFFFFFFFH;

ELSE DEST[63:0] \leftarrow 0; FI;

IF (DEST[127:64] = SRC[127:64])

THEN DEST[127:64] \leftarrow FFFFFFFFFFFFFH;

ELSE DEST[127:64] \leftarrow 0; FI;

VPCMPEQQ (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_QWORDS_EQUAL(SRC1,SRC2) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PCMPEQQ __m128i _mm_cmpeq_epi64(__m128i a, __m128i b);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PCMPESTRI — Packed Compare Explicit Length Strings, Return Index

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 61 /r imm8 PCMPESTRI xmm1, xmm2/m128, imm8	A	V/V	SSE4_2	Perform a packed comparison of string data with explicit lengths, generating an index, and storing the result in ECX.
VEX.128.66.0F3A 61 /r ib VPCMPESTRI xmm1, xmm2/m128, imm8	A	V/V	AVX	Perform a packed comparison of string data with explicit lengths, generating an index, and storing the result in ECX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	imm8	NA

Description

The instruction compares and processes data from two string fragments based on the encoded value in the Imm8 Control Byte (see Section 4.1, "Imm8 Control Byte Operation for PCMPESTRI / PCMPESTRM / PCMPISTRI / PCMPISTRM"), and generates an index stored to the count register (ECX/RCX).

Each string fragment is represented by two values. The first value is an xmm (or possibly m128 for the second operand) which contains the data elements of the string (byte or word data). The second value is stored in an input length register. The input length register is EAX/RAX (for xmm1) or EDX/RDX (for xmm2/m128). The length represents the number of bytes/words which are valid for the respective xmm/m128 data.

The length of each input is interpreted as being the absolute-value of the value in the length register. The absolute-value computation saturates to 16 (for bytes) and 8 (for words), based on the value of imm8[bit3] when the value in the length register is greater than 16 (8) or less than -16 (-8).

The comparison and aggregation operations are performed according to the encoded value of Imm8 bit fields (see Section 4.1). The index of the first (or last, according to imm8[6]) set bit of IntRes2 (see Section 4.1.4) is returned in ECX. If no bits are set in IntRes2, ECX is set to 16 (8).

Note that the Arithmetic Flags are written in a non-standard manner in order to supply the most relevant information:

CFlag - Reset if IntRes2 is equal to zero, set otherwise

```
ZFlag – Set if absolute-value of EDX is < 16 (8), reset otherwise
SFlag – Set if absolute-value of EAX is < 16 (8), reset otherwise
OFlag – IntRes2[0]
AFlag – Reset
PFlag – Reset
```

Effective Operand Size

Operating mode/size	Operand 1	Operand 2	Length 1	Length 2	Result
16 bit	xmm	xmm/m128	EAX	EDX	ECX
32 bit	xmm	xmm/m128	EAX	EDX	ECX
64 bit	xmm	xmm/m128	EAX	EDX	ECX
64 bit + REX.W	xmm	xmm/m128	RAX	RDX	RCX

Intel C/C++ Compiler Intrinsic Equivalent For Returning Index

int _mm_cmpestri (__m128i a, int la, __m128i b, int lb, const int mode);

Intel C/C++ Compiler Intrinsics For Reading EFlag Results

```
int _mm_cmpestra (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrc (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestro (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrs (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrz (__m128i a, int la, __m128i b, int lb, const int mode);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally

#UD If VEX.L = 1.

If VEX.vvvv != 1111B.
```

PCMPESTRM — Packed Compare Explicit Length Strings, Return Mask

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 60 /r imm8 PCMPESTRM xmm1, xmm2/m128, imm8	A	V/V	SSE4_2	Perform a packed comparison of string data with explicit lengths, generating a mask, and storing the result in <i>XMMO</i>
VEX.128.66.0F3A 60 /r ib VPCMPESTRM xmm1, xmm2/m128, imm8	A	V/V	AVX	Perform a packed comparison of string data with explicit lengths, generating a mask, and storing the result in XMMO.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	imm8	NA

Description

The instruction compares data from two string fragments based on the encoded value in the imm8 control byte (see Section 4.1, "Imm8 Control Byte Operation for PCMPESTRI / PCMPESTRM / PCMPISTRI / PCMPISTRM"), and generates a mask stored to XMM0.

Each string fragment is represented by two values. The first value is an xmm (or possibly m128 for the second operand) which contains the data elements of the string (byte or word data). The second value is stored in an input length register. The input length register is EAX/RAX (for xmm1) or EDX/RDX (for xmm2/m128). The length represents the number of bytes/words which are valid for the respective xmm/m128 data.

The length of each input is interpreted as being the absolute-value of the value in the length register. The absolute-value computation saturates to 16 (for bytes) and 8 (for words), based on the value of imm8[bit3] when the value in the length register is greater than 16 (8) or less than -16 (-8).

The comparison and aggregation operations are performed according to the encoded value of Imm8 bit fields (see Section 4.1). As defined by imm8[6], IntRes2 is then either stored to the least significant bits of XMM0 (zero extended to 128 bits) or expanded into a byte/word-mask and then stored to XMM0.

Note that the Arithmetic Flags are written in a non-standard manner in order to supply the most relevant information:

CFlag - Reset if IntRes2 is equal to zero, set otherwise

INSTRUCTION SET REFERENCE, N-Z

```
ZFlag – Set if absolute-value of EDX is < 16 (8), reset otherwise

SFlag – Set if absolute-value of EAX is < 16 (8), reset otherwise

OFlag –IntRes2[0]

AFlag – Reset

PFlag – Reset
```

Note: In VEX.128 encoded versions, bits (VLMAX-1:128) of XMM0 are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Effective Operand Size

Operating mode/size	Operand1	Operand 2	Length1	Length2	Result
16 bit	xmm	xmm/m128	EAX	EDX	XMM0
32 bit	xmm	xmm/m128	EAX	EDX	XMM0
64 bit	xmm	xmm/m128	EAX	EDX	XMM0
64 bit + REX.W	xmm	xmm/m128	RAX	RDX	XMM0

Intel C/C++ Compiler Intrinsic Equivalent For Returning Mask

```
__m128i _mm_cmpestrm (__m128i a, int la, __m128i b, int lb, const int mode);
```

Intel C/C++ Compiler Intrinsics For Reading EFlag Results

```
int _mm_cmpestra (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrc (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestro (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrs (__m128i a, int la, __m128i b, int lb, const int mode);
int _mm_cmpestrz (__m128i a, int la, __m128i b, int lb, const int mode);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally

#UD If VEX.L = 1.

If VEX.vvvv != 1111B.
```

PCMPGTB/PCMPGTW/PCMPGTD—Compare Packed Signed Integers for Greater Than

Opcode/ Instruction		Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 64 /r ¹ PCMPGTB mm, m	nm/m64	Α	V/V	MMX	Compare packed signed byte integers in <i>mm</i> and <i>mm/m64</i> for greater than.
66 OF 64 /r PCMPGTB xmm1	, хтт2/т128	Α	V/V	SSE2	Compare packed signed byte integers in xmm1 and xmm2/m128 for greater than.
OF 65 /r ¹ PCMPGTW mm, mm/m64		Α	V/V	MMX	Compare packed signed word integers in <i>mm</i> and <i>mm/m64</i> for greater than.
66 OF 65 /r PCMPGTW xmm1	, хтт2/т128	Α	V/V	SSE2	Compare packed signed word integers in <i>xmm1</i> and <i>xmm2/m128</i> for greater than.
OF 66 /r ¹ PCMPGTD mm, m	nm/m64	Α	V/V	MMX	Compare packed signed doubleword integers in <i>mm</i> and <i>mm/m64</i> for greater than.
66 OF 66 /r PCMPGTD xmm1, xmm2/m128		Α	V/V	SSE2	Compare packed signed doubleword integers in xmm1 and xmm2/m128 for greater than.
VEX.NDS.128.6 6.0F.WIG 64 /r	VPCMPGTB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed byte integers in xmm2 and xmm3/m128 for greater than.
VEX.NDS.128.6 6.0F.WIG 65 /r	VPCMPGTW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed word integers in xmm2 and xmm3/m128 for greater than.

VEX.NDS.128.6 6.0F.WIG 66 /r	VPCMPGTD xmm1, xmm2.	В	V/V	AVX	Compare packed signed doubleword integers in
0.01 .WIG 00 /1	xmm3/m128				xmm2 and xmm3/m128 for
					greater than.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD signed compare for the greater value of the packed byte, word, or doubleword integers in the destination operand (first operand) and the source operand (second operand). If a data element in the destination operand is greater than the corresponding date element in the source operand, the corresponding data element in the destination operand is set to all 1s; otherwise, it is set to all 0s. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

The PCMPGTB instruction compares the corresponding signed byte integers in the destination and source operands; the PCMPGTW instruction compares the corresponding signed word integers in the destination and source operands; and the PCMPGTD instruction compares the corresponding signed doubleword integers in the destination and source operands.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PCMPGTB (with 64-bit operands)

IF DEST[7:0] > SRC[7:0] THEN DEST[7:0) \leftarrow FFH;

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

```
ELSE DEST[7:0] \leftarrow 0; FI;
   (* Continue comparison of 2nd through 7th bytes in DEST and SRC *)
   IF DEST[63:56] > SRC[63:56]
        THEN DEST[63:56] \leftarrow FFH;
        ELSE DEST[63:56] \leftarrow 0; FI;
PCMPGTB (with 128-bit operands)
   IF DEST[7:0] > SRC[7:0]
        THEN DEST[7:0) \leftarrow FFH;
        ELSE DEST[7:0] \leftarrow 0; FI;
   (* Continue comparison of 2nd through 15th bytes in DEST and SRC *)
   IF DEST[127:120] > SRC[127:120]
        THEN DEST[127:120] \leftarrow FFH;
        ELSE DEST[127:120] \leftarrow 0; FI;
PCMPGTW (with 64-bit operands)
   IF DEST[15:0] > SRC[15:0]
        THEN DEST[15:0] \leftarrow FFFFH;
        ELSE DEST[15:0] \leftarrow 0; FI;
   (* Continue comparison of 2nd and 3rd words in DEST and SRC *)
   IF DEST[63:48] > SRC[63:48]
        THEN DEST[63:48] \leftarrow FFFFH;
        ELSE DEST[63:48] \leftarrow 0; FI;
PCMPGTW (with 128-bit operands)
   IF DEST[15:0] > SRC[15:0]
        THEN DEST[15:0] \leftarrow FFFFH;
        ELSE DEST[15:0] \leftarrow 0; FI;
   (* Continue comparison of 2nd through 7th words in DEST and SRC *)
   IF DEST[63:48] > SRC[127:112]
        THEN DEST[127:112] \leftarrow FFFFH;
        ELSE DEST[127:112] \leftarrow 0; FI;
PCMPGTD (with 64-bit operands)
   IF DEST[31:0] > SRC[31:0]
        THEN DEST[31:0] \leftarrow FFFFFFFH;
        ELSE DEST[31:0] \leftarrow 0; FI;
   IF DEST[63:32] > SRC[63:32]
        THEN DEST[63:32] \leftarrow FFFFFFFH;
        ELSE DEST[63:32] \leftarrow 0; FI;
PCMPGTD (with 128-bit operands)
   IF DEST[31:0] > SRC[31:0]
        THEN DEST[31:0] \leftarrow FFFFFFFH;
        ELSE DEST[31:0] \leftarrow 0; FI;
```

```
(* Continue comparison of 2nd and 3rd doublewords in DEST and SRC *) IF DEST[127:96] > SRC[127:96] 
THEN DEST[127:96] \leftarrow FFFFFFFH; 
ELSE DEST[127:96] \leftarrow 0; FI;
```

VPCMPGTB (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_BYTES_GREATER(SRC1,SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPCMPGTW (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_WORDS_GREATER(SRC1,SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPCMPGTD (VEX.128 encoded version)

DEST[127:0] \leftarrow COMPARE_DWORDS_GREATER(SRC1,SRC2) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PCMPGTB __m64 _mm_cmpgt_pi8 (__m64 m1, __m64 m2)
PCMPGTW __m64 _mm_pcmpgt_pi16 (__m64 m1, __m64 m2)
DCMPGTD __m64 _mm_pcmpgt_pi32 (__m64 m1, __m64 m2)
PCMPGTB __m128i _mm_cmpgt_epi8 ( __m128i a, __m128i b)
PCMPGTW __m128i _mm_cmpgt_epi16 ( __m128i a, __m128i b)
DCMPGTD __m128i _mm_cmpgt_epi32 ( __m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PCMPGTQ — Compare Packed Data for Greater Than

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 37 /r PCMPGTQ xmm1,xmm2/m128	Α	V/V	SSE4_2	Compare packed qwords in xmm2/m128 and xmm1 for greater than.
VEX.NDS.128.66.0F38.WIG 37 /r VPCMPGTQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed qwords in xmm2 and xmm3/m128 for greater than.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an SIMD compare for the packed quadwords in the destination operand (first operand) and the source operand (second operand). If the data element in the first (destination) operand is greater than the corresponding element in the second (source) operand, the corresponding data element in the destination is set to all 1s; otherwise, it is set to 0s.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

IF (DEST[63-0] > SRC[63-0])

THEN DEST[63-0] \leftarrow FFFFFFFFFFFFFFH;

ELSE DEST[63-0] \leftarrow 0; FI

IF (DEST[127-64] > SRC[127-64])

THEN DEST[127-64] \leftarrow FFFFFFFFFFFFFFH;

ELSE DEST[127-64] \leftarrow 0; FI

VPCMPGTQ (VEX.128 encoded version)

$$\label{eq:destination} \begin{split} \mathsf{DEST}[127:0] \leftarrow& \mathsf{COMPARe_QWORDS_GREATER}(\mathsf{SRC1}, \mathsf{SRC2}) \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow& 0 \end{split}$$

Intel C/C++ Compiler Intrinsic Equivalent

PCMPGTQ __m128i _mm_cmpgt_epi64(__m128i a, __m128i b)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PCMPISTRI — Packed Compare Implicit Length Strings, Return Index

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 63 /r imm8 PCMPISTRI xmm1, xmm2/m128, imm8	A	V/V	SSE4_2	Perform a packed comparison of string data with implicit lengths, generating an index, and storing the result in ECX.
VEX.128.66.0F3A.WIG 63 /r ib VPCMPISTRI xmm1, xmm2/m128, imm8	A	V/V	AVX	Perform a packed comparison of string data with implicit lengths, generating an index, and storing the result in ECX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	imm8	NA

Description

The instruction compares data from two strings based on the encoded value in the Imm8 Control Byte (see Section 4.1, "Imm8 Control Byte Operation for PCMPESTRI / PCMPESTRM / PCMPISTRI / PCMPISTRI / PCMPISTRM"), and generates an index stored to ECX.

Each string is represented by a single value. The value is an xmm (or possibly m128 for the second operand) which contains the data elements of the string (byte or word data). Each input byte/word is augmented with a valid/invalid tag. A byte/word is considered valid only if it has a lower index than the least significant null byte/word. (The least significant null byte/word is also considered invalid.)

The comparison and aggregation operations are performed according to the encoded value of Imm8 bit fields (see Section 4.1). The index of the first (or last, according to imm8[6]) set bit of IntRes2 is returned in ECX. If no bits are set in IntRes2, ECX is set to 16 (8).

Note that the Arithmetic Flags are written in a non-standard manner in order to supply the most relevant information:

CFlag - Reset if IntRes2 is equal to zero, set otherwise

ZFlag - Set if any byte/word of xmm2/mem128 is null, reset otherwise

SFlag - Set if any byte/word of xmm1 is null, reset otherwise

OFlag -IntRes2[0]

AFlag - Reset

PFlag - Reset

Note: In VEX.128 encoded version, VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Effective Operand Size

Operating mode/size	Operand1	Operand 2	Result
16 bit	xmm	xmm/m128	ECX
32 bit	xmm	xmm/m128	ECX
64 bit	xmm	xmm/m128	ECX
64 bit + REX.W	xmm	xmm/m128	RCX

Intel C/C++ Compiler Intrinsic Equivalent For Returning Index

```
int mm cmpistri ( m128i a, m128i b, const int mode);
```

Intel C/C++ Compiler Intrinsics For Reading EFlag Results

```
int _mm_cmpistra (__m128i a, __m128i b, const int mode);
int _mm_cmpistrc (__m128i a, __m128i b, const int mode);
int _mm_cmpistro (__m128i a, __m128i b, const int mode);
int _mm_cmpistrs (__m128i a, __m128i b, const int mode);
int _mm_cmpistrz (__m128i a, __m128i b, const int mode);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally

#UD If VEX.L = 1.

If VEX.vvvv != 1111B.
```

PCMPISTRM — Packed Compare Implicit Length Strings, Return Mask

			_	3 •
Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 62 /r imm8 PCMPISTRM xmm1, xmm2/m128, imm8	Α	V/V	SSE4_2	Perform a packed comparison of string data with implicit lengths, generating a mask, and storing the result in <i>XMMO</i> .
VEX.128.66.0F3A.WIG 62 /r ib VPCMPISTRM xmm1, xmm2/m128, imm8	Α	V/V	AVX	Perform a packed comparison of string data with implicit lengths, generating a Mask, and storing the result in XMMO.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	imm8	NA

Description

The instruction compares data from two strings based on the encoded value in the imm8 byte (see Section 4.1, "Imm8 Control Byte Operation for PCMPESTRI / PCMPESTRM / PCMPISTRI / PCMPISTRM") generating a mask stored to XMM0.

Each string is represented by a single value. The value is an xmm (or possibly m128 for the second operand) which contains the data elements of the string (byte or word data). Each input byte/word is augmented with a valid/invalid tag. A byte/word is considered valid only if it has a lower index than the least significant null byte/word. (The least significant null byte/word is also considered invalid.)

The comparison and aggregation operation are performed according to the encoded value of Imm8 bit fields (see Section 4.1). As defined by imm8[6], IntRes2 is then either stored to the least significant bits of XMM0 (zero extended to 128 bits) or expanded into a byte/word-mask and then stored to XMM0.

Note that the Arithmetic Flags are written in a non-standard manner in order to supply the most relevant information:

CFlag - Reset if IntRes2 is equal to zero, set otherwise

ZFlag - Set if any byte/word of xmm2/mem128 is null, reset otherwise

SFlag - Set if any byte/word of xmm1 is null, reset otherwise

OFlag - IntRes2[0]

AFlag - Reset

PFlag - Reset

Note: In VEX.128 encoded versions, bits (VLMAX-1:128) of XMM0 are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Effective Operand Size

Operating mode/size	Operand1	Operand 2	Result
16 bit	xmm	xmm/m128	XMM0
32 bit	xmm	xmm/m128	XMM0
64 bit	xmm	xmm/m128	XMM0
64 bit + REX.W	xmm	xmm/m128	XMM0

Intel C/C++ Compiler Intrinsic Equivalent For Returning Mask

```
__m128i _mm_cmpistrm (__m128i a, __m128i b, const int mode);
```

Intel C/C++ Compiler Intrinsics For Reading EFlag Results

```
int _mm_cmpistra (__m128i a, __m128i b, const int mode);
int _mm_cmpistrc (__m128i a, __m128i b, const int mode);
int _mm_cmpistro (__m128i a, __m128i b, const int mode);
int _mm_cmpistrs (__m128i a, __m128i b, const int mode);
int _mm_cmpistrz (__m128i a, __m128i b, const int mode);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally

#UD If VEX.L = 1.

If VEX.vvvv != 1111B.
```

PEXTRB/PEXTRD/PEXTRQ — Extract Byte/Dword/Qword

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 14 /r ib PEXTRB reg/m8, xmm2, imm8	Α	V/V	SSE4_1	Extract a byte integer value from xmm2 at the source byte offset specified by imm8 into rreg or m8. The upper bits of r32 or r64 are zeroed.
66 OF 3A 16 /r ib PEXTRD <i>r/m32, xmm2, imm8</i>	A	V/V	SSE4_1	Extract a dword integer value from xmm2 at the source dword offset specified by imm8 into r/m32.
66 REX.W OF 3A 16 /r ib PEXTRQ r/m64, xmm2, imm8	A	V/N.E.	SSE4_1	Extract a qword integer value from xmm2 at the source qword offset specified by imm8 into r/m64.
VEX.128.66.0F3A.W0 14 /r ib VPEXTRB reg/m8, xmm2, imm8	Α	V ¹ /V	AVX	Extract a byte integer value from xmm2 at the source byte offset specified by imm8 into reg or m8. The upper bits of r64/r32 is filled with zeros.
VEX.128.66.0F3A.W0 16 /r ib VPEXTRD r32/m32, xmm2, imm8	A	V/V	AVX	Extract a dword integer value from xmm2 at the source dword offset specified by imm8 into r32/m32.
VEX.128.66.0F3A.W1 16 /r ib VPEXTRQ r64/m64, xmm2, imm8	A	V/i	AVX	Extract a qword integer value from xmm2 at the source dword offset specified by imm8 into r64/m64.

NOTES:

1. In 64-bit mode, VEX.W1 is ignored for VPEXTRB (similar to legacy REX.W=1 prefix in PEXTRB).

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	ModRM:reg (r)	imm8	NA

Description

Extract a byte/dword/qword integer value from the source XMM register at a byte/dword/qword offset determined from imm8[3:0]. The destination can be a register or byte/dword/qword memory location. If the destination is a register, the upper bits of the register are zero extended.

In legacy non-VEX encoded version and if the destination operand is a register, the default operand size in 64-bit mode for PEXTRB/PEXTRD is 64 bits, the bits above the least significant byte/dword data are filled with zeros. PEXTRQ is not encodable in non-64-bit modes and requires REX.W in 64-bit mode.

Note: In VEX.128 encoded versions, VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD. If the destination operand is a register, the default operand size in 64-bit mode for VPEXTRB/VPEXTRD is 64 bits, the bits above the least significant byte/word/dword data are filled with zeros. Attempt to execute VPEXTRO in non-64-bit mode will cause #UD.

Operation

```
CASE of
   PEXTRB: SEL \leftarrow COUNT[3:0];
             TEMP ← (Src >> SEL*8) AND FFH:
             IF (DEST = Mem8)
                  THEN
                  Mem8 \leftarrow TEMP[7:0];
             ELSE IF (64-Bit Mode and 64-bit register selected)
                  THEN
                      R64[7:0] \leftarrow TEMP[7:0];
                      r64[63:8] ← ZERO FILL; };
             ELSE
                      R32[7:0] \leftarrow TEMP[7:0];
                      r32[31:8] \leftarrow ZERO FILL; };
             FI:
   PEXTRD:SEL \leftarrow COUNT[1:0];
             TEMP ← (Src >> SEL*32) AND FFFF FFFFH;
             DEST ← TEMP:
   PEXTRQ: SEL ← COUNT[0];
             TEMP \leftarrow (Src >> SEL*64);
             DEST ← TEMP;
FASC.
(V)PEXTRTD/(V)PEXTRQ
IF (64-Bit Mode and 64-bit dest operand)
THEN
   Src Offset ← Imm8[0]
```

```
r64/m64 ←(Src >> Src Offset * 64)
ELSE
   Src Offset ← Imm8[1:0]
   r32/m32 ← ((Src >> Src_Offset *32) AND OFFFFFFFh);
FΙ
(V)PEXTRB ( dest=m8)
SRC Offset ← Imm8[3:0]
Mem8 ← (Src >> Src_Offset*8)
(V)PEXTRB ( dest=reg)
IF (64-Bit Mode)
THEN
   SRC\_Offset \leftarrow Imm8[3:0]
   DEST[7:0] ← ((Src >> Src Offset*8) AND OFFh)
   DEST[63:8] \leftarrow ZERO_FILL;
ELSE
   SRC\_Offset \leftarrow . Imm8[3:0];
   DEST[7:0] \leftarrow ((Src >> Src Offset*8) AND OFFh);
   DEST[31:8] ← ZERO FILL;
FΙ
Intel C/C++ Compiler Intrinsic Equivalent
PEXTRB
            int _mm_extract_epi8 (__m128i src, const int ndx);
PEXTRD
            int _mm_extract_epi32 (__m128i src, const int ndx);
            __int64 _mm_extract_epi64 (__m128i src, const int ndx);
PEXTRO
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 5; additionally
#UD
                      If VEX.L = 1.
                      If VEX.vvvv != 1111B.
                      If VPEXTRQ in non-64-bit mode, VEX.W=1.
```

PEXTRW—Extract Word

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF C5 /r ib ¹ PEXTRW reg, mm, imm8	A	V/V	SSE	Extract the word specified by <i>imm8</i> from <i>mm</i> and move it to <i>reg</i> , bits 15-0. The upper bits of r32 or r64 is zeroed.
66 OF C5 /r ib PEXTRW reg, xmm, imm8	A	V/V	SSE2	Extract the word specified by <i>imm8</i> from <i>xmm</i> and move it to <i>reg</i> , bits 15-0. The upper bits of r32 or r64 is zeroed.
66 OF 3A 15 /r ib PEXTRW reg/m16, xmm, imm8	В	V/V	SSE4_1	Extract the word specified by <i>imm8</i> from <i>xmm</i> and copy it to lowest 16 bits of <i>reg or m16</i> . Zero-extend the result in the destination, r32 or r64.
VEX.128.66.0F.W0 C5 /r ib VPEXTRW reg, xmm1, imm8	Α	V ² /V	AVX	Extract the word specified by imm8 from xmm1 and move it to reg, bits 15:0. Zero-extend the result. The upper bits of r64/r32 is filled with zeros.
VEX.128.66.0F3A.W0 15 /r ib VPEXTRW reg/m16, xmm2, imm8	В	V/V	AVX	Extract a word integer value from xmm2 at the source word offset specified by imm8 into reg or m16. The upper bits of r64/r32 is filled with zeros.

NOTES:

2. In 64-bit mode, VEX.W1 is ignored for VPEXTRW (similar to legacy REX.W=1 prefix in PEXTRW).

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
В	ModRM:r/m (w)	ModRM:reg (r)	imm8	NA

Description

Copies the word in the source operand (second operand) specified by the count operand (third operand) to the destination operand (first operand). The source operand can be an MMX technology register or an XMM register. The destination operand can be the low word of a general-purpose register or a 16-bit memory address. The count operand is an 8-bit immediate. When specifying a word location in an MMX technology register, the 2 least-significant bits of the count operand specify the location; for an XMM register, the 3 least-significant bits specify the location. The content of the destination register above bit 16 is cleared (set to all 0s).

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15, R8-15). If the destination operand is a general-purpose register, the default operand size is 64-bits in 64-bit mode.

Note: In VEX.128 encoded versions, VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD. If the destination operand is a register, the default operand size in 64-bit mode for VPEXTRW is 64 bits, the bits above the least significant byte/word/dword data are filled with zeros.

Operation

```
IF (DEST = Mem16)
THEN
   SEL \leftarrow COUNT[2:0];
   TEMP ← (Src >> SEL*16) AND FFFFH;
   Mem16 \leftarrow TEMP[15:0];
ELSE IF (64-Bit Mode and destination is a general-purpose register)
   THEN
        FOR (PEXTRW instruction with 64-bit source operand)
           { SEL \leftarrow COUNT[1:0];
             TEMP \leftarrow (SRC >> (SEL * 16)) AND FFFFH;
             r64[15:0] \leftarrow TEMP[15:0];
             r64[63:16] ← ZERO FILL; };
        FOR (PEXTRW instruction with 128-bit source operand)
           { SEL \leftarrow COUNT[2:0];
             TEMP \leftarrow (SRC >> (SEL * 16)) AND FFFFH;
             r64[15:0] \leftarrow TEMP[15:0];
             r64[63:16] ← ZERO FILL; }
   ELSE
        FOR (PEXTRW instruction with 64-bit source operand)
          \{ SEL \leftarrow COUNT[1:0]; \}
             TEMP \leftarrow (SRC >> (SEL * 16)) AND FFFFH;
```

```
r32[15:0] \leftarrow TEMP[15:0];
            r32[31:16] ← ZERO FILL; };
        FOR (PEXTRW instruction with 128-bit source operand)
          \{ SEL \leftarrow COUNT[2:0]; \}
            TEMP \leftarrow (SRC >> (SEL * 16)) AND FFFFH;
            r32[15:0] \leftarrow TEMP[15:0];
            r32[31:16] \leftarrow ZERO\_FILL; };
   FI:
FI:
(V)PEXTRW ( dest=m16)
SRC\_Offset \leftarrow Imm8[2:0]
Mem16 \leftarrow (Src >> Src_Offset*16)
(V)PEXTRW ( dest=reg)
IF (64-Bit Mode)
THEN
   SRC Offset ← Imm8[2:0]
   DEST[15:0] ← ((Src >> Src_Offset*16) AND OFFFFh)
   DEST[63:16] \leftarrow ZERO_FILL;
FL SE
   SRC\_Offset \leftarrow Imm8[2:0]
   DEST[15:0] \leftarrow ((Src >> Src_Offset*16) AND OFFFFh)
   DEST[31:16] ← ZERO_FILL;
FΙ
Intel C/C++ Compiler Intrinsic Equivalent
PEXTRW int mm extract pi16 ( m64 a, int n)
PEXTRW int _mm_extract_epi16 ( __m128i a, int imm)
Flags Affected
None.
Numeric Exceptions
None.
Other Exceptions
See Exceptions Type 5; additionally
#UD
                       If VEX.L = 1.
                       If VEX.vvvv != 1111B.
                       If VPEXTRQ in non-64-bit mode, VEX.W=1.
```

INSTRUCTION SET REFERENCE, N-Z

PHADDW/PHADDD — Packed Horizontal Add

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 01 /r ¹ PHADDW mm1, mm2/m64	Α	V/V	SSSE3	Add 16-bit integers horizontally, pack to MM1.
66 0F 38 01 /r PHADDW xmm1, xmm2/m128	Α	V/V	SSSE3	Add 16-bit integers horizontally, pack to XMM1.
OF 38 02 /r PHADDD mm1, mm2/m64	Α	V/V	SSSE3	Add 32-bit integers horizontally, pack to MM1.
66 0F 38 02 /r PHADDD xmm1, xmm2/m128	Α	V/V	SSSE3	Add 32-bit integers horizontally, pack to XMM1.
VEX.NDS.128.66.0F38.WIG 01 /r VPHADDW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add 16-bit integers horizontally, pack to xmm1.
VEX.NDS.128.66.0F38.WIG 02 /r VPHADDD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add 32-bit integers horizontally, pack to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PHADDW adds two adjacent 16-bit signed integers horizontally from the source and destination operands and packs the 16-bit signed results to the destination operand (first operand). PHADDD adds two adjacent 32-bit signed integers horizontally from the source and destination operands and packs the 32-bit signed results to the destination operand (first operand). Both operands can be MMX or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

Note that these instructions can operate on either unsigned or signed (two's complement notation) integers; however, it does not set bits in the EFLAGS register to indi-

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

cate overflow and/or a carry. To prevent undetected overflow conditions, software must control the ranges of the values operated on.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PHADDW (with 64-bit operands)

```
mm1[15-0] = mm1[31-16] + mm1[15-0];

mm1[31-16] = mm1[63-48] + mm1[47-32];

mm1[47-32] = mm2/m64[31-16] + mm2/m64[15-0];

mm1[63-48] = mm2/m64[63-48] + mm2/m64[47-32];
```

PHADDW (with 128-bit operands)

```
xmm1[15-0] = xmm1[31-16] + xmm1[15-0];

xmm1[31-16] = xmm1[63-48] + xmm1[47-32];

xmm1[47-32] = xmm1[95-80] + xmm1[79-64];

xmm1[63-48] = xmm1[127-112] + xmm1[111-96];

xmm1[79-64] = xmm2/m128[31-16] + xmm2/m128[15-0];

xmm1[95-80] = xmm2/m128[63-48] + xmm2/m128[47-32];

xmm1[111-96] = xmm2/m128[95-80] + xmm2/m128[79-64];

xmm1[127-112] = xmm2/m128[127-112] + xmm2/m128[111-96];
```

PHADDD (with 64-bit operands)

```
mm1[31-0] = mm1[63-32] + mm1[31-0];
mm1[63-32] = mm2/m64[63-32] + mm2/m64[31-0];
```

PHADDD (with 128-bit operands)

```
xmm1[31-0] = xmm1[63-32] + xmm1[31-0];

xmm1[63-32] = xmm1[127-96] + xmm1[95-64];

xmm1[95-64] = xmm2/m128[63-32] + xmm2/m128[31-0];

xmm1[127-96] = xmm2/m128[127-96] + xmm2/m128[95-64];
```

VPHADDW (VEX.128 encoded version)

```
DEST[15:0] \leftarrow SRC1[31:16] + SRC1[15:0]

DEST[31:16] \leftarrow SRC1[63:48] + SRC1[47:32]

DEST[47:32] \leftarrow SRC1[95:80] + SRC1[79:64]

DEST[63:48] \leftarrow SRC1[127:112] + SRC1[111:96]

DEST[79:64] \leftarrow SRC2[31:16] + SRC2[15:0]

DEST[95:80] \leftarrow SRC2[63:48] + SRC2[47:32]
```

DEST[111:96] \leftarrow SRC2[95:80] + SRC2[79:64] DEST[127:112] \leftarrow SRC2[127:112] + SRC2[111:96] DEST[VLMAX-1:128] \leftarrow 0

VPHADDD (VEX.128 encoded version)

DEST[31-0] \leftarrow SRC1[63-32] + SRC1[31-0] DEST[63-32] \leftarrow SRC1[127-96] + SRC1[95-64] DEST[95-64] \leftarrow SRC2[63-32] + SRC2[31-0] DEST[127-96] \leftarrow SRC2[127-96] + SRC2[95-64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

PHADDW __m64 _mm_hadd_pi16 (__m64 a, __m64 b)
PHADDW __m128i _mm_hadd_epi16 (__m128i a, __m128i b)
PHADDD __m64 _mm_hadd_pi32 (__m64 a, __m64 b)
PHADDD __m128i _mm_hadd_epi32 (__m128i a, __m128i b)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PHADDSW — Packed Horizontal Add and Saturate

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F 38 03 /r ¹ PHADDSW mm1, mm2/m64	Α	V/V	SSSE3	Add 16-bit signed integers horizontally, pack saturated integers to MM1.
66 0F 38 03 /r PHADDSW xmm1, xmm2/m128	Α	V/V	SSSE3	Add 16-bit signed integers horizontally, pack saturated integers to XMM1.
VEX.NDS.128.66.0F38.WIG 03 /r VPHADDSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Add 16-bit signed integers horizontally, pack saturated integers to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PHADDSW adds two adjacent signed 16-bit integers horizontally from the source and destination operands and saturates the signed results; packs the signed, saturated 16-bit results to the destination operand (first operand) Both operands can be MMX or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PHADDSW (with 64-bit operands)

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

```
mm1[15-0] = SaturateToSignedWord((mm1[31-16] + mm1[15-0]);

mm1[31-16] = SaturateToSignedWord(mm1[63-48] + mm1[47-32]);

mm1[47-32] = SaturateToSignedWord(mm2/m64[31-16] + mm2/m64[15-0]);

mm1[63-48] = SaturateToSignedWord(mm2/m64[63-48] + mm2/m64[47-32]);
```

PHADDSW (with 128-bit operands)

```
xmm1[15-0]= SaturateToSignedWord(xmm1[31-16] + xmm1[15-0]);

xmm1[31-16] = SaturateToSignedWord(xmm1[63-48] + xmm1[47-32]);

xmm1[47-32] = SaturateToSignedWord(xmm1[95-80] + xmm1[79-64]);

xmm1[63-48] = SaturateToSignedWord(xmm1[127-112] + xmm1[111-96]);

xmm1[79-64] = SaturateToSignedWord(xmm2/m128[31-16] + xmm2/m128[15-0]);

xmm1[95-80] = SaturateToSignedWord(xmm2/m128[63-48] + xmm2/m128[47-32]);

xmm1[111-96] = SaturateToSignedWord(xmm2/m128[95-80] + xmm2/m128[79-64]);

xmm1[127-112] = SaturateToSignedWord(xmm2/m128[127-112] + xmm2/m128[111-96]);
```

VPHADDSW (VEX.128 encoded version)

```
\begin{split} & \mathsf{DEST}[15:0] = \mathsf{SaturateToSignedWord}(\mathsf{SRC1}[31:16] + \mathsf{SRC1}[15:0]) \\ & \mathsf{DEST}[31:16] = \mathsf{SaturateToSignedWord}(\mathsf{SRC1}[63:48] + \mathsf{SRC1}[47:32]) \\ & \mathsf{DEST}[47:32] = \mathsf{SaturateToSignedWord}(\mathsf{SRC1}[95:80] + \mathsf{SRC1}[79:64]) \\ & \mathsf{DEST}[63:48] = \mathsf{SaturateToSignedWord}(\mathsf{SRC1}[127:112] + \mathsf{SRC1}[111:96]) \\ & \mathsf{DEST}[79:64] = \mathsf{SaturateToSignedWord}(\mathsf{SRC2}[31:16] + \mathsf{SRC2}[15:0]) \\ & \mathsf{DEST}[95:80] = \mathsf{SaturateToSignedWord}(\mathsf{SRC2}[63:48] + \mathsf{SRC2}[47:32]) \\ & \mathsf{DEST}[111:96] = \mathsf{SaturateToSignedWord}(\mathsf{SRC2}[95:80] + \mathsf{SRC2}[79:64]) \\ & \mathsf{DEST}[127:112] = \mathsf{SaturateToSignedWord}(\mathsf{SRC2}[127:112] + \mathsf{SRC2}[111:96]) \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \\ \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PHADDSW __m64 _mm_hadds_pi16 (__m64 a, __m64 b)
PHADDSW __m128i mm hadds_epi16 (__m128i a, __m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PHMINPOSUW — Packed Horizontal Word Minimum

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 41 /r PHMINPOSUW xmm1, xmm2/m128	Α	V/V	SSE4_1	Find the minimum unsigned word in xmm2/m128 and place its value in the low word of xmm1 and its index in the second-lowest word of xmm1.
VEX.128.66.0F38.WIG 41 /r VPHMINPOSUW xmm1, xmm2/m128	Α	V/V	AVX	Find the minimum unsigned word in xmm2/m128 and place its value in the low word of xmm1 and its index in the second-lowest word of xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	l
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA	

Description

Determine the minimum unsigned word value in the source operand (second operand) and place the unsigned word in the low word (bits 0-15) of the destination operand (first operand). The word index of the minimum value is stored in bits 16-18 of the destination operand. The remaining upper bits of the destination are set to zero.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PHMINPOSUW (128-bit Legacy SSE version)

$$\begin{split} & \text{INDEX} \leftarrow 0; \\ & \text{MIN} \leftarrow \text{SRC}[15:0] \\ & \text{IF} \left(\text{SRC}[31:16] < \text{MIN} \right) \\ & \quad \text{THEN INDEX} \leftarrow 1; \text{ MIN} \leftarrow \text{SRC}[31:16]; \text{FI}; \\ & \text{IF} \left(\text{SRC}[47:32] < \text{MIN} \right) \end{split}$$

VPHMINPOSUW (VEX.128 encoded version)

Intel C/C++ Compiler Intrinsic Equivalent

PHMINPOSUW __m128i _mm_minpos_epu16(__m128i packed_words);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PHSUBW/PHSUBD — Packed Horizontal Subtract

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 05 /r ¹ PHSUBW mm1, mm2/m64	Α	V/V	SSSE3	Subtract 16-bit signed integers horizontally, pack to MM1.
66 0F 38 05 /r PHSUBW xmm1, xmm2/m128	Α	V/V	SSSE3	Subtract 16-bit signed integers horizontally, pack to XMM1.
OF 38 06 /r PHSUBD mm1, mm2/m64	Α	V/V	SSSE3	Subtract 32-bit signed integers horizontally, pack to MM1.
66 0F 38 06 /r PHSUBD xmm1, xmm2/m128	Α	V/V	SSSE3	Subtract 32-bit signed integers horizontally, pack to XMM1.
VEX.NDS.128.66.0F38.WIG 05 /r VPHSUBW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract 16-bit signed integers horizontally, pack to xmm1.
VEX.NDS.128.66.0F38.WIG 06 /r VPHSUBD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract 32-bit signed integers horizontally, pack to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (r, w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PHSUBW performs horizontal subtraction on each adjacent pair of 16-bit signed integers by subtracting the most significant word from the least significant word of each pair in the source and destination operands, and packs the signed 16-bit results to the destination operand (first operand). PHSUBD performs horizontal subtraction on each adjacent pair of 32-bit signed integers by subtracting the most significant doubleword from the least significant doubleword of each pair, and packs the signed

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

32-bit result to the destination operand. Both operands can be MMX or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PHSUBW (with 64-bit operands)

```
mm1[15-0] = mm1[15-0] - mm1[31-16];

mm1[31-16] = mm1[47-32] - mm1[63-48];

mm1[47-32] = mm2/m64[15-0] - mm2/m64[31-16];

mm1[63-48] = mm2/m64[47-32] - mm2/m64[63-48];
```

PHSUBW (with 128-bit operands)

```
xmm1[15-0] = xmm1[15-0] - xmm1[31-16];

xmm1[31-16] = xmm1[47-32] - xmm1[63-48];

xmm1[47-32] = xmm1[79-64] - xmm1[95-80];

xmm1[63-48] = xmm1[111-96] - xmm1[127-112];

xmm1[79-64] = xmm2/m128[15-0] - xmm2/m128[31-16];

xmm1[95-80] = xmm2/m128[47-32] - xmm2/m128[63-48];

xmm1[111-96] = xmm2/m128[79-64] - xmm2/m128[95-80];

xmm1[127-112] = xmm2/m128[111-96] - xmm2/m128[127-112];
```

PHSUBD (with 64-bit operands)

```
mm1[31-0] = mm1[31-0] - mm1[63-32];
mm1[63-32] = mm2/m64[31-0] - mm2/m64[63-32];
```

PHSUBD (with 128-bit operands)

```
xmm1[31-0] = xmm1[31-0] - xmm1[63-32];

xmm1[63-32] = xmm1[95-64] - xmm1[127-96];

xmm1[95-64] = xmm2/m128[31-0] - xmm2/m128[63-32];

xmm1[127-96] = xmm2/m128[95-64] - xmm2/m128[127-96];
```

VPHSUBW (VEX.128 encoded version)

```
DEST[15:0] \leftarrow SRC1[15:0] - SRC1[31:16]
DEST[31:16] \leftarrow SRC1[47:32] - SRC1[63:48]
DEST[47:32] \leftarrow SRC1[79:64] - SRC1[95:80]
DEST[63:48] \leftarrow SRC1[111:96] - SRC1[127:112]
```

 $\begin{aligned} & \mathsf{DEST}[79:64] \leftarrow \mathsf{SRC2}[15:0] - \mathsf{SRC2}[31:16] \\ & \mathsf{DEST}[95:80] \leftarrow \mathsf{SRC2}[47:32] - \mathsf{SRC2}[63:48] \\ & \mathsf{DEST}[111:96] \leftarrow \mathsf{SRC2}[79:64] - \mathsf{SRC2}[95:80] \\ & \mathsf{DEST}[127:112] \leftarrow \mathsf{SRC2}[111:96] - \mathsf{SRC2}[127:112] \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \\ & \mathsf{VPHSUBD} \ (\mathsf{VEX.128} \ \mathsf{encoded} \ \mathsf{version}) \\ & \mathsf{DEST}[31-0] \leftarrow \mathsf{SRC1}[31-0] - \mathsf{SRC1}[63-32] \\ & \mathsf{DEST}[63-32] \leftarrow \mathsf{SRC1}[95-64] - \mathsf{SRC1}[127-96] \\ & \mathsf{DEST}[95-64] \leftarrow \mathsf{SRC2}[31-0] - \mathsf{SRC2}[63-32] \\ & \mathsf{DEST}[127-96] \leftarrow \mathsf{SRC2}[95-64] - \mathsf{SRC2}[127-96] \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{aligned}$

Intel C/C++ Compiler Intrinsic Equivalents

```
PHSUBW __m64 _mm_hsub_pi16 (__m64 a, __m64 b)
PHSUBW __m128i _mm_hsub_epi16 (__m128i a, __m128i b)
PHSUBD __m64 _mm_hsub_pi32 (__m64 a, __m64 b)
PHSUBD __m128i _mm_hsub_epi32 (__m128i a, __m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PHSUBSW — Packed Horizontal Subtract and Saturate

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 07 /r ¹ PHSUBSW mm1, mm2/m64	Α	V/V	SSSE3	Subtract 16-bit signed integer horizontally, pack saturated integers to MM1.
66 0F 38 07 /r PHSUBSW xmm1, xmm2/m128	Α	V/V	SSSE3	Subtract 16-bit signed integer horizontally, pack saturated integers to XMM1
VEX.NDS.128.66.0F38.WIG 07 /r VPHSUBSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract 16-bit signed integer horizontally, pack saturated integers to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (r, w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PHSUBSW performs horizontal subtraction on each adjacent pair of 16-bit signed integers by subtracting the most significant word from the least significant word of each pair in the source and destination operands. The signed, saturated 16-bit results are packed to the destination operand (first operand). Both operands can be MMX or XMM register. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

PHSUBSW (with 64-bit operands)

```
mm1[15-0] = SaturateToSignedWord(mm1[15-0] - mm1[31-16]);
mm1[31-16] = SaturateToSignedWord(mm1[47-32] - mm1[63-48]);
mm1[47-32] = SaturateToSignedWord(mm2/m64[15-0] - mm2/m64[31-16]);
mm1[63-48] = SaturateToSignedWord(mm2/m64[47-32] - mm2/m64[63-48]);
```

PHSUBSW (with 128-bit operands)

```
xmm1[15-0] = SaturateToSignedWord(xmm1[15-0] - xmm1[31-16]);
xmm1[31-16] = SaturateToSignedWord(xmm1[47-32] - xmm1[63-48]);
xmm1[47-32] = SaturateToSignedWord(xmm1[79-64] - xmm1[95-80]);
xmm1[63-48] = SaturateToSignedWord(xmm1[111-96] - xmm1[127-112]);
xmm1[79-64] = SaturateToSignedWord(xmm2/m128[15-0] - xmm2/m128[31-16]);
xmm1[95-80] =SaturateToSignedWord(xmm2/m128[47-32] - xmm2/m128[63-48]);
xmm1[111-96] =SaturateToSignedWord(xmm2/m128[79-64] - xmm2/m128[95-80]);
xmm1[127-112]= SaturateToSignedWord(xmm2/m128[111-96] - xmm2/m128[127-112]);
```

VPHSUBSW (VEX.128 encoded version)

```
DEST[15:0]= SaturateToSignedWord(SRC1[15:0] - SRC1[31:16])
DEST[31:16] = SaturateToSignedWord(SRC1[47:32] - SRC1[63:48])
DEST[47:32] = SaturateToSignedWord(SRC1[79:64] - SRC1[95:80])
DEST[63:48] = SaturateToSignedWord(SRC1[111:96] - SRC1[127:112])
DEST[79:64] = SaturateToSignedWord(SRC2[15:0] - SRC2[31:16])
DEST[95:80] = SaturateToSignedWord(SRC2[47:32] - SRC2[63:48])
DEST[111:96] = SaturateToSignedWord(SRC2[79:64] - SRC2[95:80])
DEST[127:112] = SaturateToSignedWord(SRC2[111:96] - SRC2[127:112])
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PHSUBSW m64 mm hsubs pi16 (m64 a, m64 b)
PHSUBSW m128i mm hsubs epi16 (m128i a, m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally
#UD
                    If VEX.L = 1.
```

PINSRB/PINSRD/PINSRQ — Insert Byte/Dword/Qword

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 20 /r ib PINSRB xmm1, r32/m8, imm8	Α	V/V	SSE4_1	Insert a byte integer value from r32/m8 into xmm1 at the destination element in xmm1 specified by imm8.
66 OF 3A 22 /r ib PINSRD <i>xmm1</i> , <i>r/m32</i> , <i>imm8</i>	Α	V/V	SSE4_1	Insert a dword integer value from r/m32 into the xmm1 at the destination element specified by imm8.
66 REX.W OF 3A 22 /r ib PINSRQ xmm1, r/m64, imm8	Α	N. E./V	SSE4_1	Insert a qword integer value from r/m32 into the xmm1 at the destination element specified by imm8.
VEX.NDS.128.66.0F3A.W0 20 /r ib VPINSRB xmm1, xmm2, r32/m8, imm8	В	V ¹ /V	AVX	Merge a byte integer value from r32/m8 and rest from xmm2 into xmm1 at the byte offset in imm8.
VEX.NDS.128.66.0F3A.W0 22 /r ib VPINSRD xmm1, xmm2, r32/m32, imm8	В	V/V	AVX	Insert a dword integer value from r32/m32 and rest from xmm2 into xmm1 at the dword offset in imm8.
VEX.NDS.128.66.0F3A.W1 22 /r ib VPINSRQ xmm1, xmm2, r64/m64, imm8	В	V/I	AVX	Insert a qword integer value from r64/m64 and rest from xmm2 into xmm1 at the qword offset in imm8.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Copies a byte/dword/qword from the source operand (second operand) and inserts it in the destination operand (first operand) at the location specified with the count operand (third operand). (The other elements in the destination register are left untouched.) The source operand can be a general-purpose register or a memory

^{1.} In 64-bit mode, VEX.W1 is ignored for VPINSRB (similar to legacy REX.W=1 prefix with PINSRB).

location. (When the source operand is a general-purpose register, PINSRB copies the low byte of the register.) The destination operand is an XMM register. The count operand is an 8-bit immediate. When specifying a qword[dword, byte] location in an XMM register, the [2, 4] least-significant bit(s) of the count operand specify the location.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15, R8-15). Use of REX.W permits the use of 64 bit general purpose registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD. Attempt to execute VPINSRQ in non-64-bit mode will cause #UD.

```
CASE OF
   PINSRB: SEL \leftarrow COUNT[3:0];
             MASK \leftarrow (OFFH << (SEL * 8));
             TEMP \leftarrow (((SRC[7:0] << (SEL *8)) AND MASK);
   PINSRD: SEL \leftarrow COUNT[1:0];
             MASK ← (OFFFFFFFH << (SEL * 32)):
             TEMP \leftarrow (((SRC << (SEL *32)) AND MASK);
   PINSRQ: SEL ← COUNT[0]
             MASK ← (OFFFFFFFFFFFFFF << (SEL * 64));
             TEMP \leftarrow (((SRC << (SEL *32)) AND MASK);
ESAC:
        DEST ← ((DEST AND NOT MASK) OR TEMP);
VPINSRB (VEX.128 encoded version)
SEL ← imm8[3:0]
DEST[127:0] \leftarrow write_b_element(SEL, SRC2, SRC1)
DEST[VLMAX-1:128] \leftarrow 0
VPINSRD (VEX.128 encoded version)
SEL ← imm8[1:0]
DEST[127:0] \leftarrow write_d_element(SEL, SRC2, SRC1)
DEST[VLMAX-1:128] \leftarrow 0
VPINSRQ (VEX.128 encoded version)
SEL ← imm8[0]
DEST[127:0] \leftarrow write_q_element(SEL, SRC2, SRC1)
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PINSRB __m128i _mm_insert_epi8 (__m128i s1, int s2, const int ndx);

PINSRD __m128i _mm_insert_epi32 (__m128i s2, int s, const int ndx);

PINSRQ __m128i _mm_insert_epi64(__m128i s2, __int64 s, const int ndx);
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L = 1.

If VINSRQ in non-64-bit mode with VEX.W=1.

PINSRW—Insert Word

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF C4 / r ib ¹ PINSRW <i>mm</i> , r32/m16, imm8	Α	V/V	SSE	Insert the low word from r32 or from m16 into mm at the word position specified by imm8
66 OF C4 / <i>r</i> ib PINSRW xmm, <i>r32/m16</i> , imm8	Α	V/V	SSE2	Move the low word of <i>r32</i> or from <i>m16</i> into xmm at the word position specified by <i>imm8</i> .
VEX.NDS.128.66.0F.W0 C4 /r ib VPINSRW xmm1, xmm2, r32/m16, imm8	В	V ² /V	AVX	Insert a word integer value from r32/m16 and rest from xmm2 into xmm1 at the word offset in imm8.

NOTES:

- 1. See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.
- 2. In 64-bit mode, VEX.W1 is ignored for VPINSRW (similar to legacy REX.W=1 prefix in PINSRW).

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Copies a word from the source operand (second operand) and inserts it in the destination operand (first operand) at the location specified with the count operand (third operand). (The other words in the destination register are left untouched.) The source operand can be a general-purpose register or a 16-bit memory location. (When the source operand is a general-purpose register, the low word of the register is copied.) The destination operand can be an MMX technology register or an XMM register. The count operand is an 8-bit immediate. When specifying a word location in an MMX technology register, the 2 least-significant bits of the count operand specify the location; for an XMM register, the 3 least-significant bits specify the location.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15, R8-15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PINSRW (with 64-bit source operand)

```
SEL \leftarrow COUNT AND 3H;

CASE (Determine word position) OF

SEL \leftarrow 0: MASK \leftarrow 00000000000FFFFH;

SEL \leftarrow 1: MASK \leftarrow 00000000FFF0000H;

SEL \leftarrow 2: MASK \leftarrow 0000FFF00000000H;

SEL \leftarrow 3: MASK \leftarrow FFFF000000000000H;

DEST \leftarrow (DEST AND NOT MASK) OR (((SRC << (SEL * 16)) AND MASK);
```

PINSRW (with 128-bit source operand)

```
SEL \leftarrow COUNT AND 7H;
  CASE (Determine word position) OF
    SEL \leftarrow 0:
          SEL \leftarrow 1:
          SEL \leftarrow 2:
          SEL \leftarrow 3: MASK \leftarrow 0000000000000000FFFF000000000000H;
    SEL \leftarrow 4:
          SEL ← 5:
          SEL \leftarrow 6:
          SEL \leftarrow 7:
          DEST ← (DEST AND NOT MASK) OR (((SRC << (SEL * 16)) AND MASK);
```

VPINSRW (VEX.128 encoded version)

```
SEL \leftarrow imm8[2:0]

DEST[127:0] \leftarrow write_w_element(SEL, SRC2, SRC1)

DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PINSRW __m64 _mm_insert_pi16 (__m64 a, int d, int n)
PINSRW __m128i _mm_insert_epi16 ( __m128i a, int b, int imm)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L = 1.

If VINSRQ in non-64-bit mode with VEX.W=1.

PMADDUBSW — Multiply and Add Packed Signed and Unsigned Bytes

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 04 /r ¹ PMADDUBSW mm1, mm2/m64	Α	V/V	MMX	Multiply signed and unsigned bytes, add horizontal pair of signed words, pack saturated signed-words to MM1.
66 OF 38 O4 /r PMADDUBSW xmm1, xmm2/m128	Α	V/V	SSSE3	Multiply signed and unsigned bytes, add horizontal pair of signed words, pack saturated signed-words to XMM1.
VEX.NDS.128.66.0F38.WIG 04 /r VPMADDUBSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply signed and unsigned bytes, add horizontal pair of signed words, pack saturated signed-words to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PMADDUBSW multiplies vertically each unsigned byte of the destination operand (first operand) with the corresponding signed byte of the source operand (second operand), producing intermediate signed 16-bit integers. Each adjacent pair of signed words is added and the saturated result is packed to the destination operand. For example, the lowest-order bytes (bits 7-0) in the source and destination operands are multiplied and the intermediate signed word result is added with the corresponding intermediate result from the 2nd lowest-order bytes (bits 15-8) of the operands; the sign-saturated result is stored in the lowest word of the destination register (15-0). The same operation is performed on the other pairs of adjacent bytes. Both operands can be MMX register or XMM registers. When the source

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMADDUBSW (with 64 bit operands)

```
DEST[15-0] = SaturateToSignedWord(SRC[15-8]*DEST[15-8]+SRC[7-0]*DEST[7-0]);
DEST[31-16] = SaturateToSignedWord(SRC[31-24]*DEST[31-24]+SRC[23-16]*DEST[23-16]);
DEST[47-32] = SaturateToSignedWord(SRC[47-40]*DEST[47-40]+SRC[39-32]*DEST[39-32]);
DEST[63-48] = SaturateToSignedWord(SRC[63-56]*DEST[63-56]+SRC[55-48]*DEST[55-48]);
```

PMADDUBSW (with 128 bit operands)

```
DEST[15-0] = SaturateToSignedWord(SRC[15-8]* DEST[15-8]+SRC[7-0]*DEST[7-0]);
// Repeat operation for 2nd through 7th word
SRC1/DEST[127-112] = SaturateToSignedWord(SRC[127-120]*DEST[127-120]+ SRC[119-112]* DEST[119-112]);
```

VPMADDUBSW (VEX.128 encoded version)

```
\label{eq:description} DEST[15:0] \leftarrow SaturateToSignedWord(SRC2[15:8]*SRC1[15:8]+SRC2[7:0]*SRC1[7:0]) \\ // Repeat operation for 2nd through 7th word \\ DEST[127:112] \leftarrow SaturateToSignedWord(SRC2[127:120]*SRC1[127:120]+SRC2[119:112]*SRC1[119:112]) \\ DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PMADDUBSW __m64 _mm_maddubs_pi16 (__m64 a, __m64 b)
PMADDUBSW __m128i _mm_maddubs_epi16 (__m128i a, __m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PMADDWD—Multiply and Add Packed Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF F5 /r ¹ PMADDWD <i>mm, mm/m64</i>	A	V/V	MMX	Multiply the packed words in mm by the packed words in mm/m64, add adjacent doubleword results, and store in mm.
66 OF F5 /r PMADDWD xmm1, xmm2/m128	Α	V/V	SSE2	Multiply the packed word integers in xmm1 by the packed word integers in xmm2/m128, add adjacent doubleword results, and store in xmm1.
VEX.NDS.128.66.0F.WIG F5 /r VPMADDWD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply the packed word integers in xmm2 by the packed word integers in xmm3/m128, add adjacent doubleword results, and store in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Multiplies the individual signed words of the destination operand (first operand) by the corresponding signed words of the source operand (second operand), producing temporary signed, doubleword results. The adjacent doubleword results are then summed and stored in the destination operand. For example, the corresponding low-order words (15-0) and (31-16) in the source and destination operands are multiplied by one another and the doubleword results are added together and stored in the low doubleword of the destination register (31-0). The same operation is performed on the other pairs of adjacent words. (Figure 4-3 shows this operation when using 64-bit operands.) The source operand can be an MMX technology register

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

The PMADDWD instruction wraps around only in one situation: when the 2 pairs of words being operated on in a group are all 8000H. In this case, the result wraps around to 80000000H.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.




Figure 4-3. PMADDWD Execution Model Using 64-bit Operands

Operation

PMADDWD (with 64-bit operands)

```
DEST[31:0] \leftarrow (DEST[15:0] * SRC[15:0]) + (DEST[31:16] * SRC[31:16]);
DEST[63:32] \leftarrow (DEST[47:32] * SRC[47:32]) + (DEST[63:48] * SRC[63:48]);
```

PMADDWD (with 128-bit operands)

```
\begin{aligned} & \mathsf{DEST[31:0]} \leftarrow (\mathsf{DEST[15:0]} * \mathsf{SRC[15:0]}) + (\mathsf{DEST[31:16]} * \mathsf{SRC[31:16]}); \\ & \mathsf{DEST[63:32]} \leftarrow (\mathsf{DEST[47:32]} * \mathsf{SRC[47:32]}) + (\mathsf{DEST[63:48]} * \mathsf{SRC[63:48]}); \\ & \mathsf{DEST[95:64]} \leftarrow (\mathsf{DEST[79:64]} * \mathsf{SRC[79:64]}) + (\mathsf{DEST[95:80]} * \mathsf{SRC[95:80]}); \\ & \mathsf{DEST[127:96]} \leftarrow (\mathsf{DEST[111:96]} * \mathsf{SRC[111:96]}) + (\mathsf{DEST[127:112]} * \mathsf{SRC[127:112]}); \end{aligned}
```

VPMADDWD (VEX.128 encoded version)

```
\begin{split} \mathsf{DEST}[31:0] &\leftarrow (\mathsf{SRC1}[15:0] * \mathsf{SRC2}[15:0]) + (\mathsf{SRC1}[31:16] * \mathsf{SRC2}[31:16]) \\ \mathsf{DEST}[63:32] &\leftarrow (\mathsf{SRC1}[47:32] * \mathsf{SRC2}[47:32]) + (\mathsf{SRC1}[63:48] * \mathsf{SRC2}[63:48]) \\ \mathsf{DEST}[95:64] &\leftarrow (\mathsf{SRC1}[79:64] * \mathsf{SRC2}[79:64]) + (\mathsf{SRC1}[95:80] * \mathsf{SRC2}[95:80]) \\ \mathsf{DEST}[127:96] &\leftarrow (\mathsf{SRC1}[111:96] * \mathsf{SRC2}[111:96]) + (\mathsf{SRC1}[127:112] * \mathsf{SRC2}[127:112]) \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] &\leftarrow 0 \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

PMADDWD __m64 _mm_madd_pi16(__m64 m1, __m64 m2)
PMADDWD __m128i _mm_madd_epi16 (__m128i a, __m128i b)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMAXSB — Maximum of Packed Signed Byte Integers

				3
Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3C /r PMAXSB xmm1, xmm2/m128	A	V/V	SSE4_1	Compare packed signed byte integers in xmm1 and xmm2/m128 and store packed maximum values in xmm1.
VEX.NDS.128.66.0F38.WIG 3C /r VPMAXSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed byte integers in xmm2 and xmm3/m128 and store packed maximum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed signed byte integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:1288) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

```
IF (DEST[7:0] > SRC[7:0])

THEN DEST[7:0] ← DEST[7:0];

ELSE DEST[7:0] ← SRC[7:0]; FI;

IF (DEST[15:8] > SRC[15:8])

THEN DEST[15:8] ← DEST[15:8];

ELSE DEST[15:8] ← SRC[15:8]; FI;

IF (DEST[23:16] > SRC[23:16])

THEN DEST[23:16] ← DEST[23:16];

ELSE DEST[23:16] ← SRC[23:16]; FI;

IF (DEST[31:24] > SRC[31:24])
```

```
THEN DEST[31:24] \leftarrow DEST[31:24];
   ELSE DEST[31:24] \leftarrow SRC[31:24]; FI;
IF (DEST[39:32] > SRC[39:32])
   THEN DEST[39:32] \leftarrow DEST[39:32];
   ELSE DEST[39:32] \leftarrow SRC[39:32]; FI;
IF (DEST[47:40] > SRC[47:40])
   THEN DEST[47:40] \leftarrow DEST[47:40];
   ELSE DEST[47:40] \leftarrow SRC[47:40]; FI;
IF (DEST[55:48] > SRC[55:48])
   THEN DEST[55:48] \leftarrow DEST[55:48];
   ELSE DEST[55:48] \leftarrow SRC[55:48]; FI;
IF (DEST[63:56] > SRC[63:56])
   THEN DEST[63:56] \leftarrow DEST[63:56];
   ELSE DEST[63:56] \leftarrow SRC[63:56]; FI;
IF (DEST[71:64] > SRC[71:64])
   THEN DEST[71:64] \leftarrow DEST[71:64];
   ELSE DEST[71:64] \leftarrow SRC[71:64]; FI;
IF (DEST[79:72] > SRC[79:72])
   THEN DEST[79:72] \leftarrow DEST[79:72];
   ELSE DEST[79:72] \leftarrow SRC[79:72]; FI;
IF (DEST[87:80] > SRC[87:80])
   THEN DEST[87:80] \leftarrow DEST[87:80];
   ELSE DEST[87:80] \leftarrow SRC[87:80]; FI;
IF (DEST[95:88] > SRC[95:88])
   THEN DEST[95:88] \leftarrow DEST[95:88];
   ELSE DEST[95:88] \leftarrow SRC[95:88]; FI;
IF (DEST[103:96] > SRC[103:96])
   THEN DEST[103:96] \leftarrow DEST[103:96];
   ELSE DEST[103:96] \leftarrow SRC[103:96]; FI;
IF (DEST[111:104] > SRC[111:104])
   THEN DEST[111:104] \leftarrow DEST[111:104];
   ELSE DEST[111:104] \leftarrow SRC[111:104]; FI;
IF (DEST[119:112] > SRC[119:112])
   THEN DEST[119:112] \leftarrow DEST[119:112];
   ELSE DEST[119:112] \leftarrow SRC[119:112]; FI;
IF (DEST[127:120] > SRC[127:120])
   THEN DEST[127:120] \leftarrow DEST[127:120];
   ELSE DEST[127:120] \leftarrow SRC[127:120]; FI;
```

VPMAXSB (VEX.128 encoded version)

IF SRC1[7:0] \rightarrow SRC2[7:0] THEN DEST[7:0] \leftarrow SRC1[7:0]; ELSE

```
\label{eq:decomposition} \begin{split} \mathsf{DEST}[7:0] &\leftarrow \mathsf{SRC2}[7:0]; \mathsf{FI}; \\ \text{(* Repeat operation for 2nd through 15th bytes in source and destination operands *)} \\ \mathsf{IF} \, \mathsf{SRC1}[127:120] &> \mathsf{SRC2}[127:120] \,\mathsf{THEN} \\ \mathsf{DEST}[127:120] &\leftarrow \mathsf{SRC1}[127:120]; \\ \mathsf{ELSE} \\ \mathsf{DEST}[127:120] &\leftarrow \mathsf{SRC2}[127:120]; \mathsf{FI}; \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] &\leftarrow 0 \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

PMAXSB __m128i _mm_max_epi8 (__m128i a, __m128i b);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMAXSD — Maximum of Packed Signed Dword Integers

			_		3
Opcode/ Instruction		Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3D /r PMAXSD <i>xmm1, x</i>	kmm2/m128	Α	V/V	SSE4_1	Compare packed signed dword integers in xmm1 and xmm2/m128 and store packed maximum values in xmm1.
6.0F38.WIG 3D	VPMAXSD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed dword integers in xmm2 and xmm3/m128 and store packed maximum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed signed dword integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:1288) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

```
IF (DEST[31:0] > SRC[31:0])

THEN DEST[31:0] ← DEST[31:0];

ELSE DEST[31:0] ← SRC[31:0]; FI;

IF (DEST[63:32] > SRC[63:32])

THEN DEST[63:32] ← DEST[63:32]; FI;

ELSE DEST[63:32] ← SRC[63:32]; FI;

IF (DEST[95:64] > SRC[95:64])

THEN DEST[95:64] ← DEST[95:64];

ELSE DEST[95:64] ← SRC[95:64]; FI;

IF (DEST[127:96] > SRC[127:96])
```

```
THEN DEST[127:96] \leftarrow DEST[127:96];
   ELSE DEST[127:96] \leftarrow SRC[127:96]; FI;
VPMAXSD (VEX.128 encoded version)
   IF SRC1[31:0] > SRC2[31:0] THEN
        DEST[31:0] \leftarrow SRC1[31:0];
   ELSE
        DEST[31:0] \leftarrow SRC2[31:0]; FI;
   (* Repeat operation for 2nd through 3rd dwords in source and destination operands *)
   IF SRC1[127:95] > SRC2[127:95] THEN
        DEST[127:95] \leftarrow SRC1[127:95];
   ELSE
        DEST[127:95] \leftarrow SRC2[127:95]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMAXSD __m128i _mm_max_epi32 ( __m128i a, __m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
```

See Exceptions Type 4; additionally

If VEX.L = 1.

#UD

PMAXSW—Maximum of Packed Signed Word Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF EE /r ¹ PMAXSW mm1, mm2/m64	Α	V/V	SSE	Compare signed word integers in <i>mm2/m64</i> and <i>mm1</i> and return maximum values.
66 OF EE /r PMAXSW xmm1, xmm2/m128	Α	V/V	SSE2	Compare signed word integers in xmm2/m128 and xmm1 and return maximum values.
VEX.NDS.128.66.0F.WIG EE /r VPMAXSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed word integers in xmm3/m128 and xmm2 and store packed maximum values in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD compare of the packed signed word integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum value for each pair of word integers to the destination operand. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

```
PMAXSW (64-bit operands)
   IF DEST[15:0] > SRC[15:0]) THEN
        DEST[15:0] \leftarrow DEST[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC[15:0]; FI;
   (* Repeat operation for 2nd and 3rd words in source and destination operands *)
   IF DEST[63:48] > SRC[63:48]) THEN
        DEST[63:48] \leftarrow DEST[63:48];
   ELSE
        DEST[63:48] \leftarrow SRC[63:48]; FI;
PMAXSW (128-bit operands)
   IF DEST[15:0] > SRC[15:0]) THEN
        DEST[15:0] \leftarrow DEST[15:0];
   FLSE
        DEST[15:0] \leftarrow SRC[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF DEST[127:112] > SRC[127:112]) THEN
        DEST[127:112] \leftarrow DEST[127:112];
   FLSE
        DEST[127:112] \leftarrow SRC[127:112]; FI;
VPMAXSW (VEX.128 encoded version)
   IF SRC1[15:0] > SRC2[15:0] THEN
        DEST[15:0] \leftarrow SRC1[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC2[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF SRC1[127:112] > SRC2[127:112] THEN
        DEST[127:112] \leftarrow SRC1[127:112]:
   ELSE
        DEST[127:112] \leftarrow SRC2[127:112]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMAXSW m64 mm max pi16( m64 a, m64 b)
PMAXSW m128i mm max epi16 ( m128i a, m128i b)
Flags Affected
None.
```

INSTRUCTION SET REFERENCE, N-Z

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMAXUB—Maximum of Packed Unsigned Byte Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF DE /r ¹ PMAXUB mm1, mm2/m64	Α	V/V	SSE	Compare unsigned byte integers in <i>mm2/m64</i> and <i>mm1</i> and returns maximum values.
66 OF DE /r PMAXUB xmm1, xmm2/m128	Α	V/V	SSE2	Compare unsigned byte integers in xmm2/m128 and xmm1 and returns maximum values.
VEX.NDS.128.66.0F.WIG DE /r VPMAXUB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned byte integers in xmm2 and xmm3/m128 and store packed maximum values in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD compare of the packed unsigned byte integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum value for each pair of byte integers to the destination operand. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

PMAXUB (64-bit operands)

```
IF DEST[7:0] > SRC[17:0]) THEN
        DEST[7:0] \leftarrow DEST[7:0];
   ELSE
        DEST[7:0] \leftarrow SRC[7:0]; FI;
   (* Repeat operation for 2nd through 7th bytes in source and destination operands *)
   IF DEST[63:56] > SRC[63:56]) THEN
        DEST[63:56] \leftarrow DEST[63:56];
   ELSE
        DEST[63:56] \leftarrow SRC[63:56]; FI;
PMAXUB (128-bit operands)
   IF DEST[7:0] > SRC[17:0]) THEN
        DEST[7:0] \leftarrow DEST[7:0];
   FLSE
        DEST[7:0] \leftarrow SRC[7:0]; FI;
   (* Repeat operation for 2nd through 15th bytes in source and destination operands *)
   IF DEST[127:120] > SRC[127:120]) THEN
        DEST[127:120] \leftarrow DEST[127:120];
   FLSE
        DEST[127:120] \leftarrow SRC[127:120]; FI;
VPMAXUB (VEX.128 encoded version)
   IF SRC1[7:0] > SRC2[7:0] THEN
        DEST[7:0] \leftarrow SRC1[7:0];
   ELSE
        DEST[7:0] \leftarrow SRC2[7:0]; FI;
   (* Repeat operation for 2nd through 15th bytes in source and destination operands *)
   IF SRC1[127:120] > SRC2[127:120] THEN
        DEST[127:120] \leftarrow SRC1[127:120];
   FLSE
        DEST[127:120] \leftarrow SRC2[127:120]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMAXUB m64 mm max pu8( m64 a, m64 b)
PMAXUB m128i mm max epu8 ( m128i a, m128i b)
Flags Affected
None.
```

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMAXUD — Maximum of Packed Unsigned Dword Integers

Opcode/ Instruction		Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3F /r PMAXUD xmm1,	хтт2/т128	A	V/V	SSE4_1	Compare packed unsigned dword integers in xmm1 and xmm2/m128 and store packed maximum values in xmm1.
VEX.NDS.128.6 6.0F38.WIG 3F /r	VPMAXUD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned dword integers in xmm2 and xmm3/m128 and store packed maximum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed unsigned dword integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

```
IF (DEST[31:0] > SRC[31:0])

THEN DEST[31:0] ← DEST[31:0];

ELSE DEST[31:0] ← SRC[31:0]; FI;

IF (DEST[63:32] > SRC[63:32])

THEN DEST[63:32] ← DEST[63:32]; FI;

ELSE DEST[63:32] ← SRC[63:32]; FI;

IF (DEST[95:64] > SRC[95:64])

THEN DEST[95:64] ← DEST[95:64];

ELSE DEST[95:64] ← SRC[95:64]; FI;

IF (DEST[127:96] > SRC[127:96])
```

```
THEN DEST[127:96] \leftarrow DEST[127:96];
   ELSE DEST[127:96] \leftarrow SRC[127:96]; FI;
VPMAXUD (VEX.128 encoded version)
   IF SRC1[31:0] > SRC2[31:0] THEN
        DEST[31:0] \leftarrow SRC1[31:0];
   ELSE
        DEST[31:0] \leftarrow SRC2[31:0]; FI;
   (* Repeat operation for 2nd through 3rd dwords in source and destination operands *)
   IF SRC1[127:95] > SRC2[127:95] THEN
        DEST[127:95] \leftarrow SRC1[127:95];
   ELSE
        DEST[127:95] \leftarrow SRC2[127:95]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMAXUD __m128i _mm_max_epu32 ( __m128i a, __m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
#UD
                       If VEX.L = 1.
```

PMAXUW — Maximum of Packed Word Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3E /r PMAXUW xmm1, xmm2/m128	Α	V/V	SSE4_1	Compare packed unsigned word integers in xmm1 and xmm2/m128 and store packed maximum values in xmm1.
VEX.NDS.128.66.0F38.WIG 3E/r VPMAXUW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned word integers in xmm3/m128 and xmm2 and store maximum packed values in xmm1.

Instruction Operand Encoding

Op/Er	o Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed unsigned word integers in the destination operand (first operand) and the source operand (second operand), and returns the maximum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

```
IF (DEST[15:0] > SRC[15:0])

THEN DEST[15:0] \leftarrow DEST[15:0];

ELSE DEST[15:0] \leftarrow SRC[15:0]; FI;

IF (DEST[31:16] > SRC[31:16])

THEN DEST[31:16] \leftarrow DEST[31:16];

ELSE DEST[31:16] \leftarrow SRC[31:16]; FI;

IF (DEST[47:32] > SRC[47:32])

THEN DEST[47:32] \leftarrow DEST[47:32];

ELSE DEST[47:32] \leftarrow SRC[47:32]; FI;

IF (DEST[63:48] > SRC[63:48])
```

```
THEN DEST[63:48] \leftarrow DEST[63:48];
   ELSE DEST[63:48] \leftarrow SRC[63:48]; FI;
IF (DEST[79:64] > SRC[79:64])
   THEN DEST[79:64] \leftarrow DEST[79:64];
   ELSE DEST[79:64] \leftarrow SRC[79:64]; FI;
IF (DEST[95:80] > SRC[95:80])
   THEN DEST[95:80] \leftarrow DEST[95:80];
   ELSE DEST[95:80] \leftarrow SRC[95:80]; FI;
IF (DEST[111:96] > SRC[111:96])
   THEN DEST[111:96] \leftarrow DEST[111:96];
   ELSE DEST[111:96] ← SRC[111:96]; FI;
IF (DEST[127:112] > SRC[127:112])
   THEN DEST[127:112] \leftarrow DEST[127:112];
   ELSE DEST[127:112] \leftarrow SRC[127:112]; FI;
VPMAXUW (VEX.128 encoded version)
   IF SRC1[15:0] > SRC2[15:0] THEN
        DEST[15:0] \leftarrow SRC1[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC2[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF SRC1[127:112] > SRC2[127:112] THEN
        DEST[127:112] \leftarrow SRC1[127:112];
   ELSE
        DEST[127:112] \leftarrow SRC2[127:112]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMAXUW m128i mm max epu16 ( m128i a, m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
#UD
                        If VEX.L = 1.
```

PMINSB — Minimum of Packed Signed Byte Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 38 /r PMINSB xmm1, xmm2/m128	А	V/V	SSE4_1	Compare packed signed byte integers in xmm1 and xmm2/m128 and store packed minimum values in xmm1.
VEX.NDS.128.66.0F38.WIG 38 /r VPMINSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed byte integers in xmm2 and xmm3/m128 and store packed minimum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed signed byte integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:1288) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
IF (DEST[7:0] < SRC[7:0])

THEN DEST[7:0] ← DEST[7:0];

ELSE DEST[7:0] ← SRC[7:0]; FI;

IF (DEST[15:8] < SRC[15:8])

THEN DEST[15:8] ← DEST[15:8];

ELSE DEST[15:8] ← SRC[15:8]; FI;

IF (DEST[23:16] < SRC[23:16])

THEN DEST[23:16] ← DEST[23:16];

ELSE DEST[23:16] ← SRC[23:16]; FI;

IF (DEST[31:24] < SRC[31:24])
```

```
THEN DEST[31:24] \leftarrow DEST[31:24];
   ELSE DEST[31:24] ← SRC[31:24]; FI;
IF (DEST[39:32] < SRC[39:32])
   THEN DEST[39:32] \leftarrow DEST[39:32];
    ELSE DEST[39:32] \leftarrow SRC[39:32]; FI;
IF (DEST[47:40] < SRC[47:40])
    THEN DEST[47:40] \leftarrow DEST[47:40];
   ELSE DEST[47:40] \leftarrow SRC[47:40]; FI;
IF (DEST[55:48] < SRC[55:48])
    THEN DEST[55:48] \leftarrow DEST[55:48];
   ELSE DEST[55:48] \leftarrow SRC[55:48]; FI;
IF (DEST[63:56] < SRC[63:56])
   THEN DEST[63:56] \leftarrow DEST[63:56];
   ELSE DEST[63:56] \leftarrow SRC[63:56]; FI;
IF (DEST[71:64] < SRC[71:64])
    THEN DEST[71:64] \leftarrow DEST[71:64];
   ELSE DEST[71:64] \leftarrow SRC[71:64]; FI;
IF (DEST[79:72] < SRC[79:72])
    THEN DEST[79:72] \leftarrow DEST[79:72];
    ELSE DEST[79:72] \leftarrow SRC[79:72]; FI;
IF (DEST[87:80] < SRC[87:80])
   THEN DEST[87:80] \leftarrow DEST[87:80];
    ELSE DEST[87:80] \leftarrow SRC[87:80]; FI;
IF (DEST[95:88] < SRC[95:88])
    THEN DEST[95:88] \leftarrow DEST[95:88];
    ELSE DEST[95:88] \leftarrow SRC[95:88]; FI;
IF (DEST[103:96] < SRC[103:96])
    THEN DEST[103:96] \leftarrow DEST[103:96];
   ELSE DEST[103:96] \leftarrow SRC[103:96]; FI;
IF (DEST[111:104] < SRC[111:104])
   THEN DEST[111:104] \leftarrow DEST[111:104];
   ELSE DEST[111:104] \leftarrow SRC[111:104]; FI;
IF (DEST[119:112] < SRC[119:112])
    THEN DEST[119:112] \leftarrow DEST[119:112];
   ELSE DEST[119:112] \leftarrow SRC[119:112]; FI;
IF (DEST[127:120] < SRC[127:120])
    THEN DEST[127:120] \leftarrow DEST[127:120];
   ELSE DEST[127:120] \leftarrow SRC[127:120]; FI;
```

VPMINSB (VEX.128 encoded version)

IF SRC1[7:0] < SRC2[7:0] THEN DEST[7:0] \leftarrow SRC1[7:0]; ELSE

```
\begin{aligned} &\text{DEST[7:0]} \leftarrow \text{SRC2[7:0]; FI;}\\ &\text{(* Repeat operation for 2nd through 15th bytes in source and destination operands *)}\\ &\text{IF SRC1[127:120]} < &\text{SRC2[127:120] THEN}\\ &\text{DEST[127:120]} \leftarrow &\text{SRC1[127:120];}\\ &\text{ELSE}\\ &\text{DEST[127:120]} \leftarrow &\text{SRC2[127:120]; FI;}\\ &\text{DEST[VLMAX-1:128]} \leftarrow &\text{O} \end{aligned}
```

Intel C/C++ Compiler Intrinsic Equivalent

PMINSB __m128i _mm_min_epi8 (__m128i a, __m128i b);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMINSD — Minimum of Packed Dword Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 39 /r PMINSD xmm1, xmm2/m128	A	V/V	SSE4_1	Compare packed signed dword integers in xmm1 and xmm2/m128 and store packed minimum values in xmm1.
VEX.NDS.128.66.0F38.WIG 39 /r VPMINSD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed dword integers in xmm2 and xmm3/m128 and store packed minimum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed signed dword integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:1288) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
IF (DEST[31:0] < SRC[31:0])

THEN DEST[31:0] \leftarrow DEST[31:0];

ELSE DEST[31:0] \leftarrow SRC[31:0]; FI;

IF (DEST[63:32] < SRC[63:32])

THEN DEST[63:32] \leftarrow DEST[63:32]; FI;

ELSE DEST[63:32] \leftarrow SRC[63:32]; FI;

IF (DEST[95:64] < SRC[95:64])

THEN DEST[95:64] \leftarrow DEST[95:64]; FI;

ELSE DEST[95:64] \leftarrow SRC[95:64]; FI;

IF (DEST[127:96] < SRC[127:96])
```

```
THEN DEST[127:96] \leftarrow DEST[127:96];
   ELSE DEST[127:96] \leftarrow SRC[127:96]; FI;
VPMINSD (VEX.128 encoded version)
   IF SRC1[31:0] < SRC2[31:0] THEN
        DEST[31:0] \leftarrow SRC1[31:0];
   ELSE
        DEST[31:0] \leftarrow SRC2[31:0]; FI;
   (* Repeat operation for 2nd through 3rd dwords in source and destination operands *)
   IF SRC1[127:95] < SRC2[127:95] THEN
        DEST[127:95] \leftarrow SRC1[127:95];
   ELSE
        DEST[127:95] \leftarrow SRC2[127:95]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMINSD __m128i _mm_min_epi32 ( __m128i a, __m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
                       If VEX.L = 1.
#UD
```

PMINSW—Minimum of Packed Signed Word Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF EA /r ¹ PMINSW mm1, mm2/m64	Α	V/V	SSE	Compare signed word integers in mm2/m64 and mm1 and return minimum values.
66 OF EA /r PMINSW xmm1, xmm2/m128	Α	V/V	SSE2	Compare signed word integers in xmm2/m128 and xmm1 and return minimum values.
VEX.NDS.128.66.0F.WIG EA /r VPMINSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed signed word integers in xmm3/m128 and xmm2 and return packed minimum values in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD compare of the packed signed word integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum value for each pair of word integers to the destination operand. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:1288) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Operation

```
PMINSW (64-bit operands)
   IF DEST[15:0] < SRC[15:0] THEN
        DEST[15:0] \leftarrow DEST[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC[15:0]; FI;
   (* Repeat operation for 2nd and 3rd words in source and destination operands *)
   IF DEST[63:48] < SRC[63:48] THEN
        DEST[63:48] \leftarrow DEST[63:48];
   ELSE
        DEST[63:48] \leftarrow SRC[63:48]; FI;
PMINSW (128-bit operands)
   IF DEST[15:0] < SRC[15:0] THEN
        DEST[15:0] \leftarrow DEST[15:0];
   FLSE
        DEST[15:0] \leftarrow SRC[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF DEST[127:112] < SRC/m64[127:112] THEN
        DEST[127:112] \leftarrow DEST[127:112];
   FLSE
        DEST[127:112] \leftarrow SRC[127:112]; FI;
VPMINSW (VEX.128 encoded version)
   IF SRC1[15:0] < SRC2[15:0] THEN
        DEST[15:0] \leftarrow SRC1[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC2[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF SRC1[127:112] < SRC2[127:112] THEN
        DEST[127:112] \leftarrow SRC1[127:112]:
   FLSE
        DEST[127:112] \leftarrow SRC2[127:112]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMINSW m64 mm min pi16 ( m64 a, m64 b)
PMINSW m128i mm min epi16 ( m128i a, m128i b)
Flags Affected
None.
```

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

#MF (64-bit operations only) If there is a pending x87 FPU exception.

PMINUB—Minimum of Packed Unsigned Byte Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF DA /r ¹ PMINUB mm1, mm2/m64	Α	V/V	SSE	Compare unsigned byte integers in <i>mm2/m64</i> and <i>mm1</i> and returns minimum values.
66 OF DA /r PMINUB xmm1, xmm2/m128	Α	V/V	SSE2	Compare unsigned byte integers in xmm2/m128 and xmm1 and returns minimum values.
VEX.NDS.128.66.0F.WIG DA /r VPMINUB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned byte integers in xmm2 and xmm3/m128 and store packed minimum values in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD compare of the packed unsigned byte integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum value for each pair of byte integers to the destination operand. The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Operation

```
PMINUB (for 64-bit operands)
   IF DEST[7:0] < SRC[17:0] THEN
        DEST[7:0] \leftarrow DEST[7:0];
   ELSE
        DEST[7:0] \leftarrow SRC[7:0]; FI;
   (* Repeat operation for 2nd through 7th bytes in source and destination operands *)
   IF DEST[63:56] < SRC[63:56] THEN
        DEST[63:56] \leftarrow DEST[63:56];
   ELSE
        DEST[63:56] \leftarrow SRC[63:56]; FI;
PMINUB (for 128-bit operands)
   IF DEST[7:0] < SRC[17:0] THEN
        DEST[7:0] \leftarrow DEST[7:0];
   FLSE
        DEST[7:0] \leftarrow SRC[7:0]; FI;
   (* Repeat operation for 2nd through 15th bytes in source and destination operands *)
   IF DEST[127:120] < SRC[127:120] THEN
        DEST[127:120] \leftarrow DEST[127:120];
   FLSE
        DEST[127:120] \leftarrow SRC[127:120]; FI;
VPMINUB (VEX.128 encoded version)
VPMINUB instruction for 128-bit operands:
   IF SRC1[7:0] < SRC2[7:0] THEN
        DEST[7:0] \leftarrow SRC1[7:0];
   ELSE
        DEST[7:0] \leftarrow SRC2[7:0]; FI;
   (* Repeat operation for 2nd through 15th bytes in source and destination operands *)
   IF SRC1[127:120] < SRC2[127:120] THEN
        DEST[127:120] \leftarrow SRC1[127:120];
   FLSE
        DEST[127:120] \leftarrow SRC2[127:120]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMINUB __m64 _m_min_pu8 (__m64 a, __m64 b)
PMINUB __m128i _mm_min_epu8 ( __m128i a, __m128i b)
Flags Affected
None.
```

INSTRUCTION SET REFERENCE, N-Z

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMINUD — Minimum of Packed Dword Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3B /r PMINUD xmm1, xmm2/m128	А	V/V	SSE4_1	Compare packed unsigned dword integers in xmm1 and xmm2/m128 and store packed minimum values in xmm1.
VEX.NDS.128.66.0F38.WIG 3B /r VPMINUD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned dword integers in xmm2 and xmm3/m128 and store packed minimum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed unsigned dword integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
IF (DEST[31:0] < SRC[31:0])

THEN DEST[31:0] \leftarrow DEST[31:0];

ELSE DEST[31:0] \leftarrow SRC[31:0]; FI;

IF (DEST[63:32] < SRC[63:32])

THEN DEST[63:32] \leftarrow DEST[63:32];

ELSE DEST[63:32] \leftarrow SRC[63:32]; FI;

IF (DEST[95:64] < SRC[95:64])

THEN DEST[95:64] \leftarrow DEST[95:64];

ELSE DEST[95:64] \leftarrow SRC[95:64]; FI;

IF (DEST[127:96] < SRC[127:96])
```

```
THEN DEST[127:96] \leftarrow DEST[127:96];
   ELSE DEST[127:96] \leftarrow SRC[127:96]; FI;
VPMINUD (VEX.128 encoded version)
VPMINUD instruction for 128-bit operands:
   IF SRC1[31:0] < SRC2[31:0] THEN
        DEST[31:0] \leftarrow SRC1[31:0];
   ELSE
        DEST[31:0] \leftarrow SRC2[31:0]; FI;
   (* Repeat operation for 2nd through 3rd dwords in source and destination operands *)
   IF SRC1[127:95] < SRC2[127:95] THEN
        DEST[127:95] \leftarrow SRC1[127:95];
   ELSE
        DEST[127:95] \leftarrow SRC2[127:95]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMINUD __m128i _mm_min_epu32 ( __m128i a, __m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
#UD
                       If VEX.L = 1.
```

PMINUW — Minimum of Packed Word Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 3A /r PMINUW xmm1, xmm2/m128	Α	V/V	SSE4_1	Compare packed unsigned word integers in xmm1 and xmm2/m128 and store packed minimum values in xmm1.
VEX.NDS.128.66.0F38.WIG 3A/r VPMINUW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Compare packed unsigned word integers in xmm3/m128 and xmm2 and return packed minimum values in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Compares packed unsigned word integers in the destination operand (first operand) and the source operand (second operand), and returns the minimum for each packed value in the destination operand.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
IF (DEST[15:0] < SRC[15:0])

THEN DEST[15:0] \leftarrow DEST[15:0];

ELSE DEST[15:0] \leftarrow SRC[15:0]; FI;

IF (DEST[31:16] < SRC[31:16])

THEN DEST[31:16] \leftarrow DEST[31:16];

ELSE DEST[31:16] \leftarrow SRC[31:16]; FI;

IF (DEST[47:32] < SRC[47:32])

THEN DEST[47:32] \leftarrow DEST[47:32];

ELSE DEST[47:32] \leftarrow SRC[47:32]; FI;

IF (DEST[63:48] < SRC[63:48])
```

```
THEN DEST[63:48] \leftarrow DEST[63:48];
   ELSE DEST[63:48] \leftarrow SRC[63:48]; FI;
IF (DEST[79:64] < SRC[79:64])
   THEN DEST[79:64] \leftarrow DEST[79:64];
   ELSE DEST[79:64] \leftarrow SRC[79:64]; FI;
IF (DEST[95:80] < SRC[95:80])
   THEN DEST[95:80] \leftarrow DEST[95:80];
   ELSE DEST[95:80] \leftarrow SRC[95:80]; FI;
IF (DEST[111:96] < SRC[111:96])
   THEN DEST[111:96] \leftarrow DEST[111:96];
   ELSE DEST[111:96] \leftarrow SRC[111:96]; FI;
IF (DEST[127:112] < SRC[127:112])
   THEN DEST[127:112] \leftarrow DEST[127:112];
   ELSE DEST[127:112] \leftarrow SRC[127:112]; FI;
VPMINUW (VEX.128 encoded version)
VPMINUW instruction for 128-bit operands:
   IF SRC1[15:0] < SRC2[15:0] THEN
        DEST[15:0] \leftarrow SRC1[15:0];
   ELSE
        DEST[15:0] \leftarrow SRC2[15:0]; FI;
   (* Repeat operation for 2nd through 7th words in source and destination operands *)
   IF SRC1[127:112] < SRC2[127:112] THEN
        DEST[127:112] \leftarrow SRC1[127:112];
   ELSE
        DEST[127:112] \leftarrow SRC2[127:112]; FI;
DEST[VLMAX-1:128] \leftarrow 0
Intel C/C++ Compiler Intrinsic Equivalent
PMINUW
            __m128i _mm_min_epu16 ( __m128i a, __m128i b);
Flags Affected
None.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
#UD
                        If VEX.L = 1.
```

PMOVMSKB—Move Byte Mask

Opcode I	nstruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF D7 /r ¹ PMOVMSKB reg, m	m	Α	V/V	SSE	Move a byte mask of <i>mm</i> to reg. The upper bits of r32 or r64 are zeroed
66 OF D7 /r PMOVMSKB reg, xr	mm	Α	V/V	SSE2	Move a byte mask of <i>xmm</i> to <i>reg</i> . The upper bits of r32 or r64 are zeroed
VEX.128.66.0F.WIC		Α	V/V	AVX	Move a byte mask of xmm1 to reg. The upper bits of r32 or r64 are filled with zeros.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:reg (r)	NA	NA

Description

Creates a mask made up of the most significant bit of each byte of the source operand (second operand) and stores the result in the low byte or word of the destination operand (first operand). The source operand is an MMX technology register or an XMM register; the destination operand is a general-purpose register. When operating on 64-bit operands, the byte mask is 8 bits; when operating on 128-bit operands, the byte mask is 16-bits.

In 64-bit mode, the instruction can access additional registers (XMM8-XMM15, R8-R15) when used with a REX.R prefix. The default operand size is 64-bit in 64-bit mode.

VEX.128 encodings are valid but identical in function. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMOVMSKB (with 64-bit source operand and r32)

 $r32[0] \leftarrow SRC[7];$ $r32[1] \leftarrow SRC[15];$

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

```
(* Repeat operation for bytes 2 through 6 *)
   r32[7] \leftarrow SRC[63];
   r32[31:8] \leftarrow ZERO FILL;
(V)PMOVMSKB (with 128-bit source operand and r32)
   r32[0] \leftarrow SRC[7];
   r32[1] \leftarrow SRC[15];
   (* Repeat operation for bytes 2 through 14 *)
   r32[15] \leftarrow SRC[127];
   r32[31:16] \leftarrow ZERO\_FILL;
PMOVMSKB (with 64-bit source operand and r64)
   r64[0] \leftarrow SRC[7];
   r64[1] \leftarrow SRC[15];
   (* Repeat operation for bytes 2 through 6 *)
   r64[7] \leftarrow SRC[63];
   r64[63:8] ← ZERO FILL;
(V)PMOVMSKB (with 128-bit source operand and r64)
   r64[0] \leftarrow SRC[7];
   r64[1] \leftarrow SRC[15];
   (* Repeat operation for bytes 2 through 14 *)
   r64[15] \leftarrow SRC[127];
   r64[63:16] \leftarrow ZERO\_FILL;
Intel C/C++ Compiler Intrinsic Equivalent
PMOVMSKB
                   int mm movemask pi8( m64 a)
PMOVMSKB
                   int _mm_movemask_epi8 ( __m128i a)
Flags Affected
None.
Numeric Exceptions
None.
Other Exceptions
See Exceptions Type 7; additionally
#UD
                        If VEX.L = 1.
                        If VEX.vvvv != 1111B.
```

PMOVSX — Packed Move with Sign Extend

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 Of 38 20 /r PMOVSXBW <i>xmm1, xmm2/m64</i>	Α	V/V	SSE4_1	Sign extend 8 packed signed 8-bit integers in the low 8 bytes of xmm2/m64 to 8 packed signed 16-bit integers in xmm1.
66 Of 38 21 /r PMOVSXBD <i>xmm1, xmm2/m32</i>	Α	V/V	SSE4_1	Sign extend 4 packed signed 8-bit integers in the low 4 bytes of xmm2/m32 to 4 packed signed 32-bit integers in xmm1.
66 Of 38 22 /r PMOVSXBQ <i>xmm1, xmm2/m16</i>	Α	V/V	SSE4_1	Sign extend 2 packed signed 8-bit integers in the low 2 bytes of xmm2/m16 to 2 packed signed 64-bit integers in xmm1.
66 Of 38 23 /r PMOVSXWD <i>xmm1, xmm2/m64</i>	Α	V/V	SSE4_1	Sign extend 4 packed signed 16-bit integers in the low 8 bytes of xmm2/m64 to 4 packed signed 32-bit integers in xmm1.
66 Of 38 24 /r PMOVSXWQ <i>xmm1, xmm2/m32</i>	Α	V/V	SSE4_1	Sign extend 2 packed signed 16-bit integers in the low 4 bytes of xmm2/m32 to 2 packed signed 64-bit integers in xmm1.
66 Of 38 25 /r PMOVSXDQ <i>xmm1, xmm2/m64</i>	Α	V/V	SSE4_1	Sign extend 2 packed signed 32-bit integers in the low 8 bytes of xmm2/m64 to 2 packed signed 64-bit integers in xmm1.
VEX.128.66.0F38.WIG 20 /r VPMOVSXBW xmm1, xmm2/m64	Α	V/V	AVX	Sign extend 8 packed 8-bit integers in the low 8 bytes of xmm2/m64 to 8 packed 16-bit integers in xmm1.
VEX.128.66.0F38.WIG 21 /r VPMOVSXBD xmm1, xmm2/m32	Α	V/V	AVX	Sign extend 4 packed 8-bit integers in the low 4 bytes of xmm2/m32 to 4 packed 32-bit integers in xmm1.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.128.66.0F38.WIG 22 /r VPMOVSXBQ xmm1, xmm2/m16	Α	V/V	AVX	Sign extend 2 packed 8-bit integers in the low 2 bytes of xmm2/m16 to 2 packed 64-bit integers in xmm1.
VEX.128.66.0F38.WIG 23 /r VPMOVSXWD xmm1, xmm2/m64	Α	V/V	AVX	Sign extend 4 packed 16-bit integers in the low 8 bytes of xmm2/m64 to 4 packed 32-bit integers in xmm1.
VEX.128.66.0F38.WIG 24 /r VPMOVSXWQ xmm1, xmm2/m32	Α	V/V	AVX	Sign extend 2 packed 16-bit integers in the low 4 bytes of xmm2/m32 to 2 packed 64-bit integers in xmm1.
VEX.128.66.0F38.WIG 25 /r VPMOVSXDQ xmm1, xmm2/m64	Α	V/V	AVX	Sign extend 2 packed 32-bit integers in the low 8 bytes of xmm2/m64 to 2 packed 64-bit integers in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Sign-extend the low byte/word/dword values in each word/dword/qword element of the source operand (second operand) to word/dword/qword integers and stored as packed data in the destination operand (first operand).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMOVSXBW

DEST[15:0] \leftarrow SignExtend(SRC[7:0]);

DEST[31:16] \leftarrow SignExtend(SRC[15:8]);

DEST[47:32] \leftarrow SignExtend(SRC[23:16]);

DEST[63:48] \leftarrow SignExtend(SRC[31:24]);

DEST[79:64] ← SignExtend(SRC[39:32]); DEST[95:80] ← SignExtend(SRC[47:40]); DEST[111:96] ← SignExtend(SRC[55:48]); DEST[127:112] ← SignExtend(SRC[63:56]);

PMOVSXBD

DEST[31:0] ← SignExtend(SRC[7:0]); DEST[63:32] ← SignExtend(SRC[15:8]); DEST[95:64] ← SignExtend(SRC[23:16]); DEST[127:96] ← SignExtend(SRC[31:24]);

PMOVSXBQ

DEST[63:0] \leftarrow SignExtend(SRC[7:0]); DEST[127:64] \leftarrow SignExtend(SRC[15:8]);

PMOVSXWD

DEST[31:0] \leftarrow SignExtend(SRC[15:0]); DEST[63:32] \leftarrow SignExtend(SRC[31:16]); DEST[95:64] \leftarrow SignExtend(SRC[47:32]); DEST[127:96] \leftarrow SignExtend(SRC[63:48]);

PMOVSXWO

DEST[63:0] \leftarrow SignExtend(SRC[15:0]); DEST[127:64] \leftarrow SignExtend(SRC[31:16]);

PMOVSXDQ

DEST[63:0] \leftarrow SignExtend(SRC[31:0]); DEST[127:64] \leftarrow SignExtend(SRC[63:32]);

VPMOVSXBW

Packed_Sign_Extend_BYTE_to_WORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVSXBD

Packed_Sign_Extend_BYTE_to_DWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVSXBO

Packed_Sign_Extend_BYTE_to_QWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVSXWD

Packed_Sign_Extend_WORD_to_DWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVSXWQ

Packed_Sign_Extend_WORD_to_QWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVSXDQ

Packed_Sign_Extend_DWORD_to_QWORD() DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PMOVSXBW __m128i _mm_ cvtepi8_epi16 ( __m128i a);

PMOVSXBD __m128i _mm_ cvtepi8_epi32 ( __m128i a);

PMOVSXBQ __m128i _mm_ cvtepi8_epi64 ( __m128i a);

PMOVSXWD __m128i _mm_ cvtepi16_epi32 ( __m128i a);

PMOVSXWQ __m128i _mm_ cvtepi16_epi64 ( __m128i a);

PMOVSXDQ __m128i _mm_ cvtepi32_epi64 ( __m128i a);
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PMOVZX — Packed Move with Zero Extend

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 Of 38 30 /r PMOVZXBW <i>xmm1, xmm2/m64</i>	Α	V/V	SSE4_1	Zero extend 8 packed 8-bit integers in the low 8 bytes of xmm2/m64 to 8 packed 16-bit integers in xmm1.
66 Of 38 31 /r PMOVZXBD <i>xmm1, xmm2/m32</i>	Α	V/V	SSE4_1	Zero extend 4 packed 8-bit integers in the low 4 bytes of xmm2/m32 to 4 packed 32-bit integers in xmm1.
66 Of 38 32 /r PMOVZXBQ <i>xmm1, xmm2/m16</i>	Α	V/V	SSE4_1	Zero extend 2 packed 8-bit integers in the low 2 bytes of xmm2/m16 to 2 packed 64-bit integers in xmm1.
66 Of 38 33 /r PMOVZXWD <i>xmm1, xmm2/m64</i>	А	V/V	SSE4_1	Zero extend 4 packed 16-bit integers in the low 8 bytes of xmm2/m64 to 4 packed 32-bit integers in xmm1.
66 Of 38 34 /r PMOVZXWQ <i>xmm1, xmm2/m32</i>	Α	V/V	SSE4_1	Zero extend 2 packed 16-bit integers in the low 4 bytes of xmm2/m32 to 2 packed 64-bit integers in xmm1.
66 Of 38 35 /r PMOVZXDQ <i>xmm1, xmm2/m64</i>	Α	V/V	SSE4_1	Zero extend 2 packed 32-bit integers in the low 8 bytes of xmm2/m64 to 2 packed 64-bit integers in xmm1.
VEX.128.66.0F38.WIG 30 /r VPMOVZXBW xmm1, xmm2/m64	Α	V/V	AVX	Zero extend 8 packed 8-bit integers in the low 8 bytes of xmm2/m64 to 8 packed 16-bit integers in xmm1.
VEX.128.66.0F38.WIG 31 /r VPMOVZXBD xmm1, xmm2/m32	Α	V/V	AVX	Zero extend 4 packed 8-bit integers in the low 4 bytes of xmm2/m32 to 4 packed 32-bit integers in xmm1.
VEX.128.66.0F38.WIG 32 /r VPMOVZXBQ xmm1, xmm2/m16	Α	V/V	AVX	Zero extend 2 packed 8-bit integers in the low 2 bytes of xmm2/m16 to 2 packed 64-bit integers in xmm1.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.128.66.0F38.WIG 33 /r VPMOVZXWD xmm1, xmm2/m64	Α	V/V	AVX	Zero extend 4 packed 16-bit integers in the low 8 bytes of xmm2/m64 to 4 packed 32-bit integers in xmm1.
VEX.128.66.0F38.WIG 34 /r VPMOVZXWQ xmm1, xmm2/m32	Α	V/V	AVX	Zero extend 2 packed 16-bit integers in the low 4 bytes of xmm2/m32 to 2 packed 64-bit integers in xmm1.
VEX.128.66.0F38.WIG 35 /r VPMOVZXDQ xmm1, xmm2/m64	Α	V/V	AVX	Zero extend 2 packed 32-bit integers in the low 8 bytes of xmm2/m64 to 2 packed 64-bit integers in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Zero-extend the low byte/word/dword values in each word/dword/qword element of the source operand (second operand) to word/dword/qword integers and stored as packed data in the destination operand (first operand).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMOVZXBW

DEST[15:0] \leftarrow ZeroExtend(SRC[7:0]); DEST[31:16] \leftarrow ZeroExtend(SRC[15:8]); DEST[47:32] \leftarrow ZeroExtend(SRC[23:16]); DEST[63:48] \leftarrow ZeroExtend(SRC[31:24]); DEST[79:64] \leftarrow ZeroExtend(SRC[39:32]); DEST[95:80] \leftarrow ZeroExtend(SRC[47:40]); DEST[111:96] \leftarrow ZeroExtend(SRC[55:48]); DEST[127:112] \leftarrow ZeroExtend(SRC[63:56]);

PMOVZXBD

DEST[31:0] \leftarrow ZeroExtend(SRC[7:0]); DEST[63:32] \leftarrow ZeroExtend(SRC[15:8]); DEST[95:64] \leftarrow ZeroExtend(SRC[23:16]); DEST[127:96] \leftarrow ZeroExtend(SRC[31:24]);

PMOVZXOB

DEST[63:0] \leftarrow ZeroExtend(SRC[7:0]); DEST[127:64] \leftarrow ZeroExtend(SRC[15:8]);

PMOVZXWD

DEST[31:0] \leftarrow ZeroExtend(SRC[15:0]); DEST[63:32] \leftarrow ZeroExtend(SRC[31:16]); DEST[95:64] \leftarrow ZeroExtend(SRC[47:32]); DEST[127:96] \leftarrow ZeroExtend(SRC[63:48]);

PMOVZXWQ

DEST[63:0] \leftarrow ZeroExtend(SRC[15:0]); DEST[127:64] \leftarrow ZeroExtend(SRC[31:16]);

PMOVZXDQ

DEST[63:0] \leftarrow ZeroExtend(SRC[31:0]); DEST[127:64] \leftarrow ZeroExtend(SRC[63:32]);

VPMOVZXBW

Packed_Zero_Extend_BYTE_to_WORD()
DEST[VLMAX-1:128] ← 0

VPMOVZXBD

Packed_Zero_Extend_BYTE_to_DWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVZXBO

Packed_Zero_Extend_BYTE_to_QWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVZXWD

Packed_Zero_Extend_WORD_to_DWORD() DEST[VLMAX-1:128] \leftarrow 0

VPMOVZXWO

Packed_Zero_Extend_WORD_to_QWORD()
DEST[VLMAX-1:128] ← 0

VPMOVZXDO

Packed_Zero_Extend_DWORD_to_QWORD()
DEST[VLMAX-1:128] ← 0

Flags Affected

None

Intel C/C++ Compiler Intrinsic Equivalent

```
        PMOVZXBW
        __m128i _mm_ cvtepu8_epi16 ( __m128i a);

        PMOVZXBD
        __m128i _mm_ cvtepu8_epi32 ( __m128i a);

        PMOVZXBQ
        __m128i _mm_ cvtepu8_epi64 ( __m128i a);

        PMOVZXWD
        __m128i _mm_ cvtepu16_epi32 ( __m128i a);

        PMOVZXWQ
        __m128i _mm_ cvtepu16_epi64 ( __m128i a);

        PMOVZXDQ
        __m128i _mm_ cvtepu32_epi64 ( __m128i a);
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L = 1.

If VFX.vvvv != 1111B.

PMULDQ — Multiply Packed Signed Dword Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 28 /r PMULDQ xmm1, xmm2/m128	А	V/V	SSE4_1	Multiply the packed signed dword integers in <i>xmm1</i> and <i>xmm2/m128</i> and store the quadword product in <i>xmm1</i> .
VEX.NDS.128.66.0F38.WIG 28 /r VPMULDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply packed signed doubleword integers in xmm2 by packed signed doubleword integers in xmm3/m128, and store the quadword results in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs two signed multiplications from two pairs of signed dword integers and stores two 64-bit products in the destination operand (first operand). The 64-bit product from the first/third dword element in the destination operand and the first/third dword element of the source operand (second operand) is stored to the low/high gword element of the destination.

If the source is a memory operand then all 128 bits will be fetched from memory but the second and fourth dwords will not be used in the computation.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMULDQ (128-bit Legacy SSE version)

DEST[63:0] ← DEST[31:0] * SRC[31:0]
DEST[127:64] ← DEST[95:64] * SRC[95:64]
DEST[VLMAX-1:128] (Unmodified)

VPMULDQ (VEX.128 encoded version)

INSTRUCTION SET REFERENCE, N-Z

DEST[63:0] \leftarrow SRC1[31:0] * SRC2[31:0] DEST[127:64] \leftarrow SRC1[95:64] * SRC2[95:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PMULDQ __m128i _mm_mul_epi32(__m128i a, __m128i b);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PMULHRSW — Packed Multiply High with Round and Scale

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 OB /r ¹ PMULHRSW mm1, mm2/m64	Α	V/V	SSSE3	Multiply 16-bit signed words, scale and round signed doublewords, pack high 16 bits to MM1.
66 OF 38 OB /r PMULHRSW xmm1, xmm2/m128	Α	V/V	SSSE3	Multiply 16-bit signed words, scale and round signed doublewords, pack high 16 bits to XMM1.
VEX.NDS.128.66.0F38.WIG 0B /r VPMULHRSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply 16-bit signed words, scale and round signed doublewords, pack high 16 bits to xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PMULHRSW multiplies vertically each signed 16-bit integer from the destination operand (first operand) with the corresponding signed 16-bit integer of the source operand (second operand), producing intermediate, signed 32-bit integers. Each intermediate 32-bit integer is truncated to the 18 most significant bits. Rounding is always performed by adding 1 to the least significant bit of the 18-bit intermediate result. The final result is obtained by selecting the 16 bits immediately to the right of the most significant bit of each 18-bit intermediate result and packed to the destination operand. Both operands can be MMX register or XMM registers.

When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
PMULHRSW (with 64-bit operands)
```

```
temp0[31:0] = INT32 ((DEST[15:0] * SRC[15:0]) >>14) + 1;
temp1[31:0] = INT32 ((DEST[31:16] * SRC[31:16]) >>14) + 1;
temp2[31:0] = INT32 ((DEST[47:32] * SRC[47:32]) >> 14) + 1;
temp3[31:0] = INT32 ((DEST[63:48] * SRc[63:48]) >> 14) + 1;
DEST[15:0] = temp0[16:1];
DEST[47:32] = temp2[16:1];
DEST[63:48] = temp3[16:1];
```

PMULHRSW (with 128-bit operand)

```
temp0[31:0] = INT32 ((DEST[15:0] * SRC[15:0]) >> 14) + 1;
temp1[31:0] = INT32 ((DEST[31:16] * SRC[31:16]) >>14) + 1;
temp2[31:0] = INT32 ((DEST[47:32] * SRC[47:32]) >> 14) + 1;
temp3[31:0] = INT32 ((DEST[63:48] * SRC[63:48]) >>14) + 1;
temp4[31:0] = INT32 ((DEST[79:64] * SRC[79:64]) >>14) + 1;
temp5[31:0] = INT32 ((DEST[95:80] * SRC[95:80]) >> 14) + 1;
temp6[31:0] = INT32 ((DEST[111:96] * SRC[111:96]) >>14) + 1;
temp7[31:0] = INT32 ((DEST[127:112] * SRC[127:112) >> 14) + 1;
DEST[15:0] = temp0[16:1];
DEST[31:16] = temp1[16:1];
DEST[47:32] = temp2[16:1];
DEST[63:48] = temp3[16:1];
DEST[79:64] = temp4[16:1];
DEST[95:80] = temp5[16:1];
DEST[111:96] = temp6[16:1];
DEST[127:112] = temp7[16:1];
```

VPMULHRSW (VEX.128 encoded version)

```
\begin{split} \text{temp0}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[15:0] * \text{SRC2}[15:0]) >> 14 \right) + 1 \\ \text{temp1}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[31:16] * \text{SRC2}[31:16]) >> 14 \right) + 1 \\ \text{temp2}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[47:32] * \text{SRC2}[47:32]) >> 14 \right) + 1 \\ \text{temp3}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[63:48] * \text{SRC2}[63:48]) >> 14 \right) + 1 \\ \text{temp4}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[79:64] * \text{SRC2}[79:64]) >> 14 \right) + 1 \\ \text{temp5}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[95:80] * \text{SRC2}[95:80]) >> 14 \right) + 1 \\ \text{temp6}[31:0] &\leftarrow \text{INT32} \left( (\text{SRC1}[111:96] * \text{SRC2}[111:96]) >> 14 \right) + 1 \end{split}
```

```
\begin{split} & temp7[31:0] \leftarrow INT32 \, ((SRC1[127:112] * SRC2[127:112) >>14) + 1 \\ & DEST[15:0] \leftarrow temp0[16:1] \\ & DEST[31:16] \leftarrow temp1[16:1] \\ & DEST[47:32] \leftarrow temp2[16:1] \\ & DEST[63:48] \leftarrow temp3[16:1] \\ & DEST[79:64] \leftarrow temp4[16:1] \\ & DEST[95:80] \leftarrow temp5[16:1] \\ & DEST[111:96] \leftarrow temp6[16:1] \\ & DEST[127:112] \leftarrow temp7[16:1] \\ & DEST[VLMAX-1:128] \leftarrow 0 \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PMULHRSW __m64 _mm_mulhrs_pi16 (__m64 a, __m64 b)

PMULHRSW __m128i _mm_mulhrs_epi16 (__m128i a, __m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMULHUW—Multiply Packed Unsigned Integers and Store High Result

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF E4 /r ¹ PMULHUW mm1, mm2/m64	Α	V/V	SSE	Multiply the packed unsigned word integers in mm1 register and mm2/m64, and store the high 16 bits of the results in mm1.
66 OF E4 /r PMULHUW xmm1, xmm2/m128	Α	V/V	SSE2	Multiply the packed unsigned word integers in xmm1 and xmm2/m128, and store the high 16 bits of the results in xmm1.
VEX.NDS.128.66.0F.WIG E4 /r VPMULHUW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply the packed unsigned word integers in xmm2 and xmm3/m128, and store the high 16 bits of the results in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD unsigned multiply of the packed unsigned word integers in the destination operand (first operand) and the source operand (second operand), and stores the high 16 bits of each 32-bit intermediate results in the destination operand. (Figure 4-4 shows this operation when using 64-bit operands.) The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.




Figure 4-4. PMULHUW and PMULHW Instruction Operation Using 64-bit Operands

Operation

PMULHUW (with 64-bit operands)

```
TEMPO[31:0] \leftarrow DEST[15:0] * SRC[15:0]; (* Unsigned multiplication *)
   TEMP1[31:0] \leftarrow DEST[31:16] * SRC[31:16];
   TEMP2[31:0] \leftarrow DEST[47:32] * SRC[47:32];
   TEMP3[31:0] \leftarrow DEST[63:48] * SRC[63:48];
   DEST[15:01 ←
                     TEMP0[31:16];
   DEST[31:16] ←
                    TEMP1[31:16];
                    TEMP2[31:16];
   DEST[47:32] ←
   DEST[63:48] ←
                   TEMP3[31:16];
PMULHUW (with 128-bit operands)
   TEMPO[31:0] \leftarrow DEST[15:0] * SRC[15:0]; (* Unsigned multiplication *)
   TEMP1[31:0] \leftarrow DEST[31:16] * SRC[31:16];
   TEMP2[31:0] \leftarrow DEST[47:32] * SRC[47:32];
   TEMP3[31:0] \leftarrow DEST[63:48] * SRC[63:48];
   TEMP4[31:0] \leftarrow DEST[79:64] * SRC[79:64];
   TEMP5[31:0] \leftarrow DEST[95:80] * SRC[95:80];
   TEMP6[31:0] ←
                     DEST[111:96] * SRC[111:96];
   TEMP7[31:01 ←
                     DEST[127:112] * SRC[127:112];
   DEST[15:01 ←
                     TEMP0[31:16];
   DEST[31:16] ←
                     TEMP1[31:16];
   DEST[47:32] ←
                    TEMP2[31:16];
   DEST[63:48] ←
                    TEMP3[31:16];
```

TEMP4[31:16];

DEST[79:64] ←

```
\begin{array}{ll} {\sf DEST[95:80]} \leftarrow & {\sf TEMP5[31:16];} \\ {\sf DEST[111:96]} \leftarrow & {\sf TEMP6[31:16];} \\ {\sf DEST[127:112]} \leftarrow {\sf TEMP7[31:16];} \end{array}
```

VPMULHUW (VEX.128 encoded version)

```
TEMPO[31:0] \leftarrow SRC1[15:0] * SRC2[15:0]
```

TEMP1[31:0] \leftarrow SRC1[31:16] * SRC2[31:16]

 $TEMP2[31:0] \leftarrow SRC1[47:32] * SRC2[47:32]$

 $TEMP3[31:0] \leftarrow SRC1[63:48] * SRC2[63:48]$

TEMP4[31:0] ← SRC1[79:64] * SRC2[79:64]

 $TEMP5[31:0] \leftarrow SRC1[95:80] * SRC2[95:80]$

 $TEMP6[31:0] \leftarrow SRC1[111:96] * SRC2[111:96]$

 $TEMP7[31:0] \leftarrow SRC1[127:112] * SRC2[127:112]$

DEST[15:0] \leftarrow TEMP0[31:16]

DEST[31:16] ← TEMP1[31:16]

DEST[47:32] \leftarrow TEMP2[31:16]

DEST[63:48] \leftarrow TEMP3[31:16]

 $\mathsf{DEST}[79:64] \leftarrow \mathsf{TEMP4}[31:16]$

 $\mathsf{DEST}[95:80] \leftarrow \mathsf{TEMP5}[31:16]$

DEST[111:96] \leftarrow TEMP6[31:16] DEST[127:112] \leftarrow TEMP7[31:16]

DEST[VLMAX-1:128] ← 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PMULHUW __m64 _mm_mulhi_pu16(__m64 a, __m64 b)

PMULHUW __m128i mm mulhi epu16 ( __m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMULHW—Multiply Packed Signed Integers and Store High Result

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF E5 /r ¹ PMULHW <i>mm, mm/m64</i>	Α	V/V	MMX	Multiply the packed signed word integers in mm1 register and mm2/m64, and store the high 16 bits of the results in mm1.
66 OF E5 /r PMULHW xmm1, xmm2/m128	A	V/V	SSE2	Multiply the packed signed word integers in xmm1 and xmm2/m128, and store the high 16 bits of the results in xmm1.
VEX.NDS.128.66.0F.WIG E5 /r VPMULHW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply the packed signed word integers in xmm2 and xmm3/m128, and store the high 16 bits of the results in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD signed multiply of the packed signed word integers in the destination operand (first operand) and the source operand (second operand), and stores the high 16 bits of each intermediate 32-bit result in the destination operand. (Figure 4-4 shows this operation when using 64-bit operands.) The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

n 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

```
PMULHW (with 64-bit operands)
```

```
\begin{split} & \mathsf{TEMP0[31:0]} \leftarrow & \mathsf{DEST[15:0]} * \mathsf{SRC[15:0]}; (* \ \mathsf{Signed \ multiplication} \ *) \\ & \mathsf{TEMP1[31:0]} \leftarrow & \mathsf{DEST[31:16]} * \mathsf{SRC[31:16]}; \\ & \mathsf{TEMP2[31:0]} \leftarrow & \mathsf{DEST[47:32]} * \mathsf{SRC[47:32]}; \\ & \mathsf{TEMP3[31:0]} \leftarrow & \mathsf{DEST[63:48]} * \mathsf{SRC[63:48]}; \\ & \mathsf{DEST[15:0]} \leftarrow & \mathsf{TEMP0[31:16]}; \\ & \mathsf{DEST[31:16]} \leftarrow & \mathsf{TEMP1[31:16]}; \\ & \mathsf{DEST[47:32]} \leftarrow & \mathsf{TEMP2[31:16]}; \\ & \mathsf{DEST[63:48]} \leftarrow & \mathsf{TEMP3[31:16]}; \\ \end{split}
```

PMULHW (with 128-bit operands)

```
TEMPO[31:0] \leftarrow DEST[15:0] * SRC[15:0]; (* Signed multiplication *)
TEMP1[31:0] \leftarrow DEST[31:16] * SRC[31:16];
TEMP2[31:0] \leftarrow DEST[47:32] * SRC[47:32];
TEMP3[31:0] \leftarrow DEST[63:48] * SRC[63:48];
TEMP4[31:0] \leftarrow DEST[79:64] * SRC[79:64];
TEMP5[31:0] \leftarrow DEST[95:80] * SRC[95:80];
TEMP6[31:0] \leftarrow DEST[111:96] * SRC[111:96];
TEMP7[31:0] \leftarrow DEST[127:112] * SRC[127:112];
DEST[15:0] ←
                   TEMP0[31:16];
DEST[31:16] \leftarrow TEMP1[31:16];
DEST[47:32] \leftarrow TEMP2[31:16];
DEST[63:48] \leftarrow TEMP3[31:16];
DEST[79:64] \leftarrow TEMP4[31:16];
DEST[95:80] \leftarrow TEMP5[31:16];
DEST[111:96] \leftarrow TEMP6[31:16];
DEST[127:112] \leftarrow TEMP7[31:16];
```

VPMULHW (VEX.128 encoded version)

```
\begin{split} & \mathsf{TEMPO[31:0]} \leftarrow \mathsf{SRC1[15:0]} * \mathsf{SRC2[15:0]} (*\mathsf{Signed Multiplication*}) \\ & \mathsf{TEMP1[31:0]} \leftarrow \mathsf{SRC1[31:16]} * \mathsf{SRC2[31:16]} \\ & \mathsf{TEMP2[31:0]} \leftarrow \mathsf{SRC1[47:32]} * \mathsf{SRC2[47:32]} \\ & \mathsf{TEMP3[31:0]} \leftarrow \mathsf{SRC1[63:48]} * \mathsf{SRC2[63:48]} \\ & \mathsf{TEMP4[31:0]} \leftarrow \mathsf{SRC1[79:64]} * \mathsf{SRC2[79:64]} \\ & \mathsf{TEMP5[31:0]} \leftarrow \mathsf{SRC1[95:80]} * \mathsf{SRC2[95:80]} \\ & \mathsf{TEMP6[31:0]} \leftarrow \mathsf{SRC1[111:96]} * \mathsf{SRC2[111:96]} \\ & \mathsf{TEMP7[31:0]} \leftarrow \mathsf{SRC1[127:112]} * \mathsf{SRC2[127:112]} \end{split}
```

DEST[15:0] \leftarrow TEMP0[31:16] DEST[31:16] \leftarrow TEMP1[31:16] DEST[47:32] \leftarrow TEMP2[31:16] DEST[63:48] \leftarrow TEMP3[31:16] DEST[79:64] \leftarrow TEMP4[31:16] DEST[95:80] \leftarrow TEMP5[31:16] DEST[111:96] \leftarrow TEMP6[31:16] DEST[127:112] \leftarrow TEMP7[31:16] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PMULHW __m64 _mm_mulhi_pi16 (__m64 m1, __m64 m2)
PMULHW __m128i _mm_mulhi_epi16 (__m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMULLD — Multiply Packed Signed Dword Integers and Store Low Result

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 40 /r PMULLD xmm1, xmm2/m128	Α	V/V	SSE4_1	Multiply the packed dword signed integers in xmm1 and xmm2/m128 and store the low 32 bits of each product in xmm1.
VEX.NDS.128.66.0F38.WIG 40 /r VPMULLD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply the packed dword signed integers in xmm2 and xmm3/m128 and store the low 32 bits of each product in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs four signed multiplications from four pairs of signed dword integers and stores the lower 32 bits of the four 64-bit products in the destination operand (first operand). Each dword element in the destination operand is multiplied with the corresponding dword element of the source operand (second operand) to obtain a 64-bit intermediate product.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

Temp0[63:0] \leftarrow DEST[31:0] * SRC[31:0]; Temp1[63:0] \leftarrow DEST[63:32] * SRC[63:32]; Temp2[63:0] \leftarrow DEST[95:64] * SRC[95:64]; Temp3[63:0] \leftarrow DEST[127:96] * SRC[127:96];

DEST[31:0] ← Temp0[31:0];

 $\mathsf{DEST[63:32]} \leftarrow \mathsf{Temp1[31:0]};$

 $\mathsf{DEST}[95:64] \leftarrow \mathsf{Temp2}[31:0];$

DEST[127:96] \leftarrow Temp3[31:0];

VPMULLD (VEX.128 encoded version)

 $Temp0[63:0] \leftarrow SRC1[31:0] * SRC2[31:0]$

Temp1[63:0] \leftarrow SRC1[63:32] * SRC2[63:32]

 $Temp2[63:0] \leftarrow SRC1[95:64] * SRC2[95:64]$

Temp3[63:0] \leftarrow SRC1[127:96] * SRC2[127:96]

DEST[31:0] \leftarrow Temp0[31:0]

DEST[63:32] \leftarrow Temp1[31:0]

DEST[95:64] \leftarrow Temp2[31:0]

 $\mathsf{DEST}[127:96] \leftarrow \mathsf{Temp3}[31:0]$

DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PMULLUD __m128i _mm_mullo_epi32(__m128i a, __m128i b);

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMULLW—Multiply Packed Signed Integers and Store Low Result

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF D5 /r ¹ PMULLW <i>mm, mm/m64</i>	Α	V/V	MMX	Multiply the packed signed word integers in <i>mm1</i> register and <i>mm2/m64</i> , and store the low 16 bits of the results in <i>mm1</i> .
66 OF D5 /r PMULLW xmm1, xmm2/m128	A	V/V	SSE2	Multiply the packed signed word integers in <i>xmm1</i> and <i>xmm2/m128</i> , and store the low 16 bits of the results in <i>xmm1</i> .
VEX.NDS.128.66.0F.WIG D5 /r VPMULLW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply the packed dword signed integers in xmm2 and xmm3/m128 and store the low 32 bits of each product in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD signed multiply of the packed signed word integers in the destination operand (first operand) and the source operand (second operand), and stores the low 16 bits of each intermediate 32-bit result in the destination operand. (Figure 4-4 shows this operation when using 64-bit operands.) The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.




Figure 4-5. PMULLU Instruction Operation Using 64-bit Operands

Operation

```
PMULLW (with 64-bit operands)
   TEMPO[31:0] \leftarrow DEST[15:0] * SRC[15:0]; (* Signed multiplication *)
   TEMP1[31:0] \leftarrow DEST[31:16] * SRC[31:16]:
   TEMP2[31:0] \leftarrow DEST[47:32] * SRC[47:32];
   TEMP3[31:0] \leftarrow DEST[63:48] * SRC[63:48];
   DEST[15:0] ←
                     TEMP0[15:0];
   DEST[31:16] ←
                    TEMP1[15:0];
   DEST[47:32] ←
                     TEMP2[15:0];
   DEST[63:48] ←
                     TEMP3[15:0];
PMULLW (with 128-bit operands)
   TEMPO[31:0] \leftarrow DEST[15:0] * SRC[15:0]; (* Signed multiplication *)
   TEMP1[31:0] \leftarrow DEST[31:16] * SRC[31:16];
   TEMP2[31:0] \leftarrow DEST[47:32] * SRC[47:32];
   TEMP3[31:0] \leftarrow DEST[63:48] * SRC[63:48];
   TEMP4[31:0] \leftarrow DEST[79:64] * SRC[79:64];
   TEMP5[31:0] \leftarrow DEST[95:80] * SRC[95:80];
   TEMP6[31:0] ←
                    DEST[111:96] * SRC[111:96];
   TEMP7[31:0] ←
                    DEST[127:112] * SRC[127:112];
   DEST[15:0] ←
                     TEMP0[15:0];
   DEST[31:16] ←
                    TEMP1[15:0];
   DEST[47:32] ←
                    TEMP2[15:0];
   DEST[63:48] ←
                   TEMP3[15:0];
   DEST[79:64] ←
                    TEMP4[15:0];
```

```
DEST[95:80] \leftarrow TEMP5[15:0];
DEST[111:96] \leftarrow TEMP6[15:0];
DEST[127:112] \leftarrow TEMP7[15:0];
```

VPMULLW (VEX.128 encoded version)

```
Temp0[31:0] \leftarrow SRC1[15:0] * SRC2[15:0]
```

Temp1[31:0] \leftarrow SRC1[31:16] * SRC2[31:16]

Temp2[31:0] \leftarrow SRC1[47:32] * SRC2[47:32]

Temp3[31:0] \leftarrow SRC1[63:48] * SRC2[63:48]

Temp4[31:0] \leftarrow SRC1[79:64] * SRC2[79:64]

Temp5[31:0] \leftarrow SRC1[95:80] * SRC2[95:80]

Temp6[31:0] \leftarrow SRC1[111:96] * SRC2[111:96]

Temp7[31:0] \leftarrow SRC1[127:112] * SRC2[127:112]

DEST[15:0] \leftarrow Temp0[15:0]

DEST[31:16] \leftarrow Temp1[15:0]

DEST[47:32] \leftarrow Temp2[15:0]

DEST[63:48] \leftarrow Temp3[15:0]

DEST[79:64] \leftarrow Temp4[15:0]

DEST[95:80] ← Temp5[15:0]

DEST[111:96] \leftarrow Temp6[15:0]

DEST[127:112] ← Temp7[15:0]

DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PMULLW __m64 _mm_mullo_pi16(__m64 m1, __m64 m2)
PMULLW __m128i _mm_mullo_epi16 ( __m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PMULUDQ—Multiply Packed Unsigned Doubleword Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF F4 /r ¹ PMULUDQ mm1, mm2/m64	Α	V/V	SSE2	Multiply unsigned doubleword integer in mm1 by unsigned doubleword integer in mm2/m64, and store the quadword result in mm1.
66 OF F4 /r PMULUDQ xmm1, xmm2/m128	A	V/V	SSE2	Multiply packed unsigned doubleword integers in xmm1 by packed unsigned doubleword integers in xmm2/m128, and store the quadword results in xmm1.
VEX.NDS.128.66.0F.WIG F4 /r VPMULUDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Multiply packed unsigned doubleword integers in xmm2 by packed unsigned doubleword integers in xmm3/m128, and store the quadword results in xmm1.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Multiplies the first operand (destination operand) by the second operand (source operand) and stores the result in the destination operand. The source operand can be an unsigned doubleword integer stored in the low doubleword of an MMX technology register or a 64-bit memory location, or it can be two packed unsigned doubleword integers stored in the first (low) and third doublewords of an XMM register or an 128-bit memory location. The destination operand can be an unsigned doubleword integer stored in the low doubleword an MMX technology register or two packed doubleword integers stored in the first and third doublewords of an XMM register. The

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

result is an unsigned quadword integer stored in the destination an MMX technology register or two packed unsigned quadword integers stored in an XMM register. When a quadword result is too large to be represented in 64 bits (overflow), the result is wrapped around and the low 64 bits are written to the destination element (that is, the carry is ignored).

For 64-bit memory operands, 64 bits are fetched from memory, but only the low doubleword is used in the computation; for 128-bit memory operands, 128 bits are fetched from memory, but only the first and third doublewords are used in the computation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PMULUDQ (with 64-Bit operands)

 $\mathsf{DEST}[63:0] \leftarrow \mathsf{DEST}[31:0] * \mathsf{SRC}[31:0];$

PMULUDQ (with 128-Bit operands)

DEST[63:0] \leftarrow DEST[31:0] * SRC[31:0]; DEST[127:64] \leftarrow DEST[95:64] * SRC[95:64];

VPMULUDQ (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[31:0] * SRC2[31:0] DEST[127:64] \leftarrow SRC1[95:64] * SRC2[95:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PMULUDQ __m64 _mm_mul_su32 (__m64 a, __m64 b)

PMULUDQ __m128i _mm_mul_epu32 (__m128i a, __m128i b)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally

#UD If VEX.L = 1.

POP—Pop a Value from the Stack

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
8F /0	POP r/m16	Α	Valid	Valid	Pop top of stack into <i>m16</i> ; increment stack pointer.
8F /0	POP r/m32	Α	N.E.	Valid	Pop top of stack into <i>m32</i> ; increment stack pointer.
8F /0	POP r/m64	Α	Valid	N.E.	Pop top of stack into <i>m64</i> ; increment stack pointer. Cannot encode 32-bit operand size.
58+ rw	POP <i>r16</i>	В	Valid	Valid	Pop top of stack into <i>r16</i> ; increment stack pointer.
58+ rd	POP <i>r32</i>	В	N.E.	Valid	Pop top of stack into <i>r32</i> ; increment stack pointer.
58+ rd	POP <i>r64</i>	В	Valid	N.E.	Pop top of stack into <i>r64</i> ; increment stack pointer. Cannot encode 32-bit operand size.
1F	POP DS	С	Invalid	Valid	Pop top of stack into DS; increment stack pointer.
07	POP ES	С	Invalid	Valid	Pop top of stack into ES; increment stack pointer.
17	POP SS	С	Invalid	Valid	Pop top of stack into SS; increment stack pointer.
OF A1	POP FS	С	Valid	Valid	Pop top of stack into FS; increment stack pointer by 16 bits.
OF A1	POP FS	С	N.E.	Valid	Pop top of stack into FS; increment stack pointer by 32 bits.
OF A1	POP FS	С	Valid	N.E.	Pop top of stack into FS; increment stack pointer by 64 bits.
OF A9	POP GS	С	Valid	Valid	Pop top of stack into GS; increment stack pointer by 16 bits.
OF A9	POP GS	С	N.E.	Valid	Pop top of stack into GS; increment stack pointer by 32 bits.

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF A9	POP GS	С	Valid	N.E.	Pop top of stack into GS; increment stack pointer by 64 bits.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA
В	reg (w)	NA	NA	NA
С	NA	NA	NA	NA

Description

Loads the value from the top of the stack to the location specified with the destination operand (or explicit opcode) and then increments the stack pointer. The destination operand can be a general-purpose register, memory location, or segment register.

Address and operand sizes are determined and used as follows:

- Address size. The D flag in the current code-segment descriptor determines the default address size; it may be overridden by an instruction prefix (67H).
 - The address size is used only when writing to a destination operand in memory.
- Operand size. The D flag in the current code-segment descriptor determines the default operand size; it may be overridden by instruction prefixes (66H or REX.W).
 - The operand size (16, 32, or 64 bits) determines the amount by which the stack pointer is incremented (2, 4 or 8).
- Stack-address size. Outside of 64-bit mode, the B flag in the current stacksegment descriptor determines the size of the stack pointer (16 or 32 bits); in 64-bit mode, the size of the stack pointer is always 64 bits.
 - The stack-address size determines the width of the stack pointer when reading from the stack in memory and when incrementing the stack pointer. (As stated above, the amount by which the stack pointer is incremented is determined by the operand size.)

If the destination operand is one of the segment registers DS, ES, FS, GS, or SS, the value loaded into the register must be a valid segment selector. In protected mode, popping a segment selector into a segment register automatically causes the descriptor information associated with that segment selector to be loaded into the hidden (shadow) part of the segment register and causes the selector and the descriptor information to be validated (see the "Operation" section below).

A NULL value (0000-0003) may be popped into the DS, ES, FS, or GS register without causing a general protection fault. However, any subsequent attempt to reference a segment whose corresponding segment register is loaded with a NULL value causes a general protection exception (#GP). In this situation, no memory reference occurs and the saved value of the segment register is NULL.

The POP instruction cannot pop a value into the CS register. To load the CS register from the stack, use the RET instruction.

If the ESP register is used as a base register for addressing a destination operand in memory, the POP instruction computes the effective address of the operand after it increments the ESP register. For the case of a 16-bit stack where ESP wraps to 0H as a result of the POP instruction, the resulting location of the memory write is processor-family-specific.

The POP ESP instruction increments the stack pointer (ESP) before data at the old top of stack is written into the destination.

A POP SS instruction inhibits all interrupts, including the NMI interrupt, until after execution of the next instruction. This action allows sequential execution of POP SS and MOV ESP, EBP instructions without the danger of having an invalid stack during an interrupt 1 . However, use of the LSS instruction is the preferred method of loading the SS and ESP registers.

In 64-bit mode, using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). When in 64-bit mode, POPs using 32-bit operands are not encodable and POPs to DS, ES, SS are not valid. See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
IF StackAddrSize = 32  
THEN  
IF OperandSize = 32  
THEN  
DEST \leftarrow SS:ESP; (* Copy a doubleword *)  
ESP \leftarrow ESP + 4;  
ELSE (* OperandSize = 16*)  
DEST \leftarrow SS:ESP; (* Copy a word *)
```

 If a code instruction breakpoint (for debug) is placed on an instruction located immediately after a POP SS instruction, the breakpoint may not be triggered. However, in a sequence of instructions that POP the SS register, only the first instruction in the sequence is guaranteed to delay an interrupt.

In the following sequence, interrupts may be recognized before POP ESP executes:

POP SS

POP ESP

```
ESP \leftarrow ESP + 2;
         FI:
   ELSE IF StackAddrSize = 64
         THEN
              IF OperandSize = 64
                   THEN
                         DEST ← SS:RSP; (* Copy quadword *)
                         RSP \leftarrow RSP + 8:
                   ELSE (* OperandSize = 16*)
                         DEST \leftarrow SS:RSP; (* Copy a word *)
                         RSP \leftarrow RSP + 2;
              FI:
         FI:
   ELSE StackAddrSize = 16
         THEN
              IF OperandSize = 16
                   THEN
                         DEST \leftarrow SS:SP; (* Copy a word *)
                         SP \leftarrow SP + 2;
                   ELSE (* OperandSize = 32 *)
                         DEST \leftarrow SS:SP; (* Copy a doubleword *)
                         SP \leftarrow SP + 4;
              FI:
FI;
```

Loading a segment register while in protected mode results in special actions, as described in the following listing. These checks are performed on the segment selector and the segment descriptor it points to.

```
64-BIT_MODE

IF FS, or GS is loaded with non-NULL selector;
THEN

IF segment selector index is outside descriptor table limits
OR segment is not a data or readable code segment
OR ((segment is a data or nonconforming code segment)
AND (both RPL and CPL > DPL))
THEN #GP(selector);
IF segment not marked present
THEN #NP(selector);
ELSE
SegmentRegister ← segment selector;
SegmentRegister ← segment descriptor;
FI:
```

```
FI;
IF FS, or GS is loaded with a NULL selector;
        THEN
             SegmentRegister ← segment selector;
             SegmentRegister \leftarrow segment descriptor;
FI;
PREOTECTED MODE OR COMPATIBILITY MODE:
IF SS is loaded;
   THEN
        IF segment selector is NULL
             THEN #GP(0);
        FI;
        IF segment selector index is outside descriptor table limits
             or segment selector's RPL ≠ CPL
             or segment is not a writable data segment
             or DPL ≠ CPL
                  THEN #GP(selector);
        FI:
        IF segment not marked present
             THEN #SS(selector);
             ELSE
                  SS \leftarrow segment selector;
                  SS \leftarrow segment descriptor;
        FI;
FI;
IF DS, ES, FS, or GS is loaded with non-NULL selector;
   THEN
        IF segment selector index is outside descriptor table limits
             or segment is not a data or readable code segment
             or ((segment is a data or nonconforming code segment)
             and (both RPL and CPL > DPL))
                  THEN #GP(selector);
        FI;
        IF segment not marked present
             THEN #NP(selector);
             ELSE
                  SegmentRegister ← segment selector;
                  SegmentRegister \leftarrow segment descriptor;
         FI;
```

FI;

IF DS, ES, FS, or GS is loaded with a NULL selector

THEN

SegmentRegister ← segment selector; SegmentRegister ← segment descriptor;

FI:

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If attempt is made to load SS register with NULL segment

selector.

If the destination operand is in a non-writable segment. If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#GP(selector) If segment selector index is outside descriptor table limits.

If the SS register is being loaded and the segment selector's RPL and the segment descriptor's DPL are not equal to the CPL.

If the SS register is being loaded and the segment pointed to is a

non-writable data segment.

If the DS, ES, FS, or GS register is being loaded and the segment pointed to is not a data or readable code segment. If the DS, ES, FS, or GS register is being loaded and the segment pointed to is a data or nonconforming code segment,

but both the RPL and the CPL are greater than the DPL.

#SS(0) If the current top of stack is not within the stack segment.

If a memory operand effective address is outside the SS

segment limit.

#SS(selector) If the SS register is being loaded and the segment pointed to is

marked not present.

#NP If the DS, ES, FS, or GS register is being loaded and the

segment pointed to is marked not present.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

#SS(U) If the stack address is in a non-canonical form.

#GP(selector) If the descriptor is outside the descriptor table limit.

If the FS or GS register is being loaded and the segment pointed

to is not a data or readable code segment.

If the FS or GS register is being loaded and the segment pointed to is a data or nonconforming code segment, but both the RPL

and the CPL are greater than the DPL.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#PF(fault-code) If a page fault occurs.

#NP If the FS or GS register is being loaded and the segment pointed

to is marked not present.

#UD If the LOCK prefix is used.

POPA/POPAD—Pop All General-Purpose Registers

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
61	POPA	Α	Invalid	Valid	Pop DI, SI, BP, BX, DX, CX, and AX.
61	POPAD	Α	Invalid	Valid	Pop EDI, ESI, EBP, EBX, EDX, ECX, and EAX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Pops doublewords (POPAD) or words (POPA) from the stack into the general-purpose registers. The registers are loaded in the following order: EDI, ESI, EBP, EBX, EDX, ECX, and EAX (if the operand-size attribute is 32) and DI, SI, BP, BX, DX, CX, and AX (if the operand-size attribute is 16). (These instructions reverse the operation of the PUSHA/PUSHAD instructions.) The value on the stack for the ESP or SP register is ignored. Instead, the ESP or SP register is incremented after each register is loaded.

The POPA (pop all) and POPAD (pop all double) mnemonics reference the same opcode. The POPA instruction is intended for use when the operand-size attribute is 16 and the POPAD instruction for when the operand-size attribute is 32. Some assemblers may force the operand size to 16 when POPA is used and to 32 when POPAD is used (using the operand-size override prefix [66H] if necessary). Others may treat these mnemonics as synonyms (POPA/POPAD) and use the current setting of the operand-size attribute to determine the size of values to be popped from the stack, regardless of the mnemonic used. (The D flag in the current code segment's segment descriptor determines the operand-size attribute.)

This instruction executes as described in non-64-bit modes. It is not valid in 64-bit mode.

Operation

```
Increment ESP by 4; (* Skip next 4 bytes of stack *)
           EBX \leftarrow Pop();
           EDX \leftarrow Pop();
           ECX \leftarrow Pop();
           EAX \leftarrow Pop();
    ELSE (* OperandSize = 16, instruction = POPA *)
           DI \leftarrow Pop();
           SI \leftarrow Pop();
          BP \leftarrow Pop();
           Increment ESP by 2; (* Skip next 2 bytes of stack *)
           BX \leftarrow Pop();
           DX \leftarrow Pop();
           CX \leftarrow Pop();
           AX \leftarrow Pop();
    FI;
FI:
```

Flags Affected

None.

Protected Mode Exceptions

#SS(0) If the starting or ending stack address is not within the stack

segment.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#SS If the starting or ending stack address is not within the stack

segment.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#SS(0) If the starting or ending stack address is not within the stack

segment.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#UD If in 64-bit mode.

POPCNT — Return the Count of Number of Bits Set to 1

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F3 0F B8 /r	POPCNT <i>r16,</i> <i>r/m16</i>	Α	Valid	Valid	POPCNT on r/m16
F3 0F B8 /r	POPCNT <i>r32,</i> <i>r/m32</i>	Α	Valid	Valid	POPCNT on r/m32
F3 REX.W OF B8 /r	POPCNT r64, r/m64	Α	Valid	N.E.	POPCNT on r/m64

Instruction Operand Encoding

Ор	o/En Operand 1	Operand 2	Operand 3	Operand 4
	A ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

This instruction calculates of number of bits set to 1 in the second operand (source) and returns the count in the first operand (a destination register).

Operation

Flags Affected

OF, SF, ZF, AF, CF, PF are all cleared. ZF is set if SRC = 0, otherwise ZF is cleared

Intel C/C++ Compiler Intrinsic Equivalent

```
POPCNT int _mm_popcnt_u32(unsigned int a);

POPCNT int64_t _mm_popcnt_u64(unsigned __int64 a);
```

Protected Mode Exceptions

```
#GP(0) If a memory operand effective address is outside the CS, DS, ES, FS or GS segments.
```

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF (fault-code) For a page fault.

#UD If CPUID.01H:ECX.POPCNT [Bit 23] = 0.

If LOCK prefix is used.

Either the prefix REP (F3h) or REPN (F2H) is used.

Real Mode Exceptions

#GP(0) If any part of the operand lies outside of the effective address

space from 0 to 0FFFFH.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#UD If CPUID.01H:ECX.POPCNT [Bit 23] = 0.

If LOCK prefix is used.

Either the prefix REP (F3h) or REPN (F2H) is used.

Virtual 8086 Mode Exceptions

#GP(0) If any part of the operand lies outside of the effective address

space from 0 to 0FFFFH.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF (fault-code) For a page fault.

#UD If CPUID.01H: ECX.POPCNT [Bit 23] = 0.

If LOCK prefix is used.

Either the prefix REP (F3h) or REPN (F2H) is used.

Compatibility Mode Exceptions

Same exceptions as in Protected Mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#PF (fault-code) For a page fault.

#UD If CPUID.01H: ECX.POPCNT [Bit 23] = 0.

If LOCK prefix is used.

Either the prefix REP (F3h) or REPN (F2H) is used.

POPF/POPFD/POPFQ—Pop Stack into EFLAGS Register

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
9D	POPF	Α	Valid	Valid	Pop top of stack into lower 16 bits of EFLAGS.
9D	POPFD	Α	N.E.	Valid	Pop top of stack into EFLAGS.
REX.W + 9D	POPFQ	Α	Valid	N.E.	Pop top of stack and zero- extend into RFLAGS.

Instruction Operand Encoding

					٦.
Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	NA	NA	NA	NA	

Description

Pops a doubleword (POPFD) from the top of the stack (if the current operand-size attribute is 32) and stores the value in the EFLAGS register, or pops a word from the top of the stack (if the operand-size attribute is 16) and stores it in the lower 16 bits of the EFLAGS register (that is, the FLAGS register). These instructions reverse the operation of the PUSHF/PUSHFD instructions.

The POPF (pop flags) and POPFD (pop flags double) mnemonics reference the same opcode. The POPF instruction is intended for use when the operand-size attribute is 16; the POPFD instruction is intended for use when the operand-size attribute is 32. Some assemblers may force the operand size to 16 for POPF and to 32 for POPFD. Others may treat the mnemonics as synonyms (POPF/POPFD) and use the setting of the operand-size attribute to determine the size of values to pop from the stack.

The effect of POPF/POPFD on the EFLAGS register changes, depending on the mode of operation. When the processor is operating in protected mode at privilege level 0 (or in real-address mode, the equivalent to privilege level 0), all non-reserved flags in the EFLAGS register except RF¹, VIP, VIF, and VM may be modified. VIP, VIF and VM remain unaffected.

When operating in protected mode with a privilege level greater than 0, but less than or equal to IOPL, all flags can be modified except the IOPL field and VIP, VIF, and VM. Here, the IOPL flags are unaffected, the VIP and VIF flags are cleared, and the VM flag is unaffected. The interrupt flag (IF) is altered only when executing at a level at least as privileged as the IOPL. If a POPF/POPFD instruction is executed with insufficient privilege, an exception does not occur but privileged bits do not change.

^{1.} RF is always zero after the execution of POPF. This is because POPF, like all instructions, clears RF as it begins to execute.

When operating in virtual-8086 mode, the IOPL must be equal to 3 to use POPF/POPFD instructions; VM, RF, IOPL, VIP, and VIF are unaffected. If the IOPL is less than 3, POPF/POPFD causes a general-protection exception (#GP).

In 64-bit mode, use REX.W to pop the top of stack to RFLAGS. The mnemonic assigned is POPFQ (note that the 32-bit operand is not encodable). POPFQ pops 64 bits from the stack, loads the lower 32 bits into RFLAGS, and zero extends the upper bits of RFLAGS.

See Chapter 3 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for more information about the EFLAGS registers.

Operation

```
IF VM = 0 (* Not in Virtual-8086 Mode *)
   THEN IF CPL = 0
        THEN
             IF OperandSize = 32;
                  THEN
                       EFLAGS \leftarrow Pop(); (* 32-bit pop *)
                       (* All non-reserved flags except RF, VIP, VIF, and VM can be modified;
                       VIP and VIF are cleared; RF, VM, and all reserved bits are unaffected. *)
                  ELSE IF (Operandsize = 64)
                       RFLAGS = Pop(); (* 64-bit pop *)
                       (* All non-reserved flags except RF, VIP, VIF, and VM can be modified; VIP
                       and VIF are cleared; RF, VM, and all reserved bits are unaffected.*)
                  ELSE (* OperandSize = 16 *)
                       EFLAGS[15:0] \leftarrow Pop(); (* 16-bit pop *)
                       (* All non-reserved flags can be modified. *)
             FI:
        ELSE (* CPL > 0 *)
             IF OperandSize = 32
                  THEN
                       IF CPL > IOPL
                            THEN
                                 EFLAGS \leftarrow Pop(); (* 32-bit pop *)
                                 (* All non-reserved bits except IF, IOPL, RF, VIP, and
                                 VIF can be modified; IF, IOPL, RF, VM, and all reserved
                                 bits are unaffected: VIP and VIF are cleared. *)
                            ELSE
                                 EFLAGS \leftarrow Pop(); (* 32-bit pop *)
                                 (* All non-reserved bits except IOPL, RF, VIP, and VIF can be
                                  modified; IOPL, RF, VM, and all reserved bits are
                                  unaffected; VIP and VIF are cleared. *)
                       FI:
```

```
ELSE IF (Operandsize = 64)
                         IF CPL > IOPL
                              THEN
                                    RFLAGS \leftarrow Pop(); (* 64-bit pop *)
                                    (* All non-reserved bits except IF, IOPL, RF, VIP, and
                                    VIF can be modified; IF, IOPL, RF, VM, and all reserved
                                    bits are unaffected: VIP and VIF are cleared. *)
                              ELSE
                                    RFLAGS \leftarrow Pop(); (* 64-bit pop *)
                                    (* All non-reserved bits except IOPL, RF, VIP, and VIF can be
                                    modified; IOPL, RF, VM, and all reserved bits are
                                    unaffected; VIP and VIF are cleared. *)
                         FI:
                    ELSE (* OperandSize = 16 *)
                         \mathsf{EFLAGS}[15:0] \leftarrow \mathsf{Pop}(); (* 16-\mathsf{bit} \mathsf{pop} *)
                         (* All non-reserved bits except IOPL can be modified; IOPL and all
                         reserved bits are unaffected. *)
              FI:
         FI:
    ELSE (* In Virtual-8086 Mode *)
         IF IOPL = 3
              THEN IF OperandSize = 32
                    THEN
                         EFLAGS \leftarrow Pop();
                         (* All non-reserved bits except VM, RF, IOPL, VIP, and VIF can be
                         modified; VM, RF, IOPL, VIP, VIF, and all reserved bits are unaffected. *)
                    ELSE
                         \mathsf{EFLAGS[15:0]} \leftarrow \mathsf{Pop()}; \mathsf{FI};
                         (* All non-reserved bits except IOPL can be modified:
                         IOPL and all reserved bits are unaffected. *)
         ELSE (* IOPL < 3 *)
               #GP(0); (* Trap to virtual-8086 monitor. *)
         FI;
    FI;
FI:
```

Flags Affected

All flags may be affected; see the Operation section for details.

Protected Mode Exceptions

```
#SS(0) If the top of stack is not within the stack segment.
#PF(fault-code) If a page fault occurs.
```

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#SS If the top of stack is not within the stack segment.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If the I/O privilege level is less than 3.

If an attempt is made to execute the POPF/POPFD instruction

with an operand-size override prefix.

#SS(0) If the top of stack is not within the stack segment.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same as for protected mode exceptions.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form. #SS(0) If the stack address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

POR—Bitwise Logical OR

Opcode	Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F EB / <i>Γ</i> ¹		Α	V/V	MMX	Bitwise OR of mm/m64 and
POR mm, mm.	/m64				mm.
66 OF EB /r		Α	V/V	SSE2	Bitwise OR of xmm2/m128
POR xmm1, x	mm2/m128				and <i>xmm1</i> .
VEX.NDS.128	.66.0F.WIG EB /r	В	V/V	AVX	Bitwise OR of xmm2/m128
VPOR xmm1,	xmm2, xmm3/m128				and xmm3.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical OR operation on the source operand (second operand) and the destination operand (first operand) and stores the result in the destination operand. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. Each bit of the result is set to 1 if either or both of the corresponding bits of the first and second operands are 1; otherwise, it is set to 0.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

POR (128-bit Legacy SSE version)

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

DEST ← DEST OR SRC
DEST[VLMAX-1:128] (Unmodified)

VPOR (VEX.128 encoded version)

DEST \leftarrow SRC1 OR SRC2 DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
POR __m64 _mm_or_si64(__m64 m1, __m64 m2)
POR __m128i _mm_or_si128(__m128i m1, __m128i m2)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

١	D	D	F	F	E.	T	Н	h	—	P	-	Δ.	f	۵.	tr	ŀ	1	n	2	ŧ	2	n	t	1		2	c	h	Δ,	
	_	п		_	_		 п	ш	_	_	ш	_		-	u			L	М	ш	а				ι.	а			е,	٠.

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF 18 /1	PREFETCHTO m8	Α	Valid	Valid	Move data from <i>m8</i> closer to the processor using TO hint.
0F 18 /2	PREFETCHT1 m8	Α	Valid	Valid	Move data from <i>m8</i> closer to the processor using T1 hint.
OF 18 /3	PREFETCHT2 m8	Α	Valid	Valid	Move data from <i>m8</i> closer to the processor using T2 hint.
OF 18 /0	PREFETCHNTA m8	Α	Valid	Valid	Move data from <i>m8</i> closer to the processor using NTA hint.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r)	NA	NA	NA

Description

Fetches the line of data from memory that contains the byte specified with the source operand to a location in the cache hierarchy specified by a locality hint:

- T0 (temporal data)—prefetch data into all levels of the cache hierarchy.
 - Pentium III processor—1st- or 2nd-level cache.
 - Pentium 4 and Intel Xeon processors—2nd-level cache.
- T1 (temporal data with respect to first level cache)—prefetch data into level 2 cache and higher.
 - Pentium III processor—2nd-level cache.
 - Pentium 4 and Intel Xeon processors—2nd-level cache.
- T2 (temporal data with respect to second level cache)—prefetch data into level 2 cache and higher.
 - Pentium III processor—2nd-level cache.
 - Pentium 4 and Intel Xeon processors—2nd-level cache.
- NTA (non-temporal data with respect to all cache levels)—prefetch data into non-temporal cache structure and into a location close to the processor, minimizing cache pollution.
 - Pentium III processor—1st-level cache

Pentium 4 and Intel Xeon processors—2nd-level cache

The source operand is a byte memory location. (The locality hints are encoded into the machine level instruction using bits 3 through 5 of the ModR/M byte. Use of any ModR/M value other than the specified ones will lead to unpredictable behavior.)

If the line selected is already present in the cache hierarchy at a level closer to the processor, no data movement occurs. Prefetches from uncacheable or WC memory are ignored.

The $\mathsf{PREFETCH} h$ instruction is merely a hint and does not affect program behavior. If executed, this instruction moves data closer to the processor in anticipation of future use.

The implementation of prefetch locality hints is implementation-dependent, and can be overloaded or ignored by a processor implementation. The amount of data prefetched is also processor implementation-dependent. It will, however, be a minimum of 32 bytes.

It should be noted that processors are free to speculatively fetch and cache data from system memory regions that are assigned a memory-type that permits speculative reads (that is, the WB, WC, and WT memory types). A PREFETCHh instruction is considered a hint to this speculative behavior. Because this speculative fetching can occur at any time and is not tied to instruction execution, a PREFETCHh instruction is not ordered with respect to the fence instructions (MFENCE, SFENCE, and LFENCE) or locked memory references. A PREFETCHh instruction is also unordered with respect to CLFLUSH instructions, other PREFETCHh instructions, or any other general instruction. It is ordered with respect to serializing instructions such as CPUID, WRMSR, OUT, and MOV CR.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

FETCH (m8);

Intel C/C++ Compiler Intrinsic Equivalent

void _mm_prefetch(char *p, int i)

The argument "*p" gives the address of the byte (and corresponding cache line) to be prefetched. The value "i" gives a constant (_MM_HINT_T0, _MM_HINT_T1, _MM_HINT_T2, or _MM_HINT_NTA) that specifies the type of prefetch operation to be performed.

Numeric Exceptions

None.

Exceptions (All Operating Modes)

#UD If the LOCK prefix is used.

PSADBW—Compute Sum of Absolute Differences

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF F6 /r ¹ PSADBW mm1, mm2/m64	Α	V/V	SSE	Computes the absolute differences of the packed unsigned byte integers from mm2 /m64 and mm1; differences are then summed to produce an unsigned word integer result.
66 OF F6 /r PSADBW xmm1, xmm2/m128	A	V/V	SSE2	Computes the absolute differences of the packed unsigned byte integers from xmm2 /m128 and xmm1; the 8 low differences and 8 high differences are then summed separately to produce two unsigned word integer results.
VEX.NDS.128.66.0F.WIG F6 /r VPSADBW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Computes the absolute differences of the packed unsigned byte integers from xmm3 /m128 and xmm2; the 8 low differences and 8 high differences are then summed separately to produce two unsigned word integer results.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Computes the absolute value of the difference of 8 unsigned byte integers from the source operand (second operand) and from the destination operand (first operand). These 8 differences are then summed to produce an unsigned word integer result that is stored in the destination operand. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. Figure 4-6 shows the operation of the PSADBW instruction when using 64-bit operands.

When operating on 64-bit operands, the word integer result is stored in the low word of the destination operand, and the remaining bytes in the destination operand are cleared to all 0s.

When operating on 128-bit operands, two packed results are computed. Here, the 8 low-order bytes of the source and destination operands are operated on to produce a word result that is stored in the low word of the destination operand, and the 8 high-order bytes are operated on to produce a word result that is stored in bits 64 through 79 of the destination operand. The remaining bytes of the destination operand are cleared.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.




Figure 4-6. PSADBW Instruction Operation Using 64-bit Operands

Operation

PSADBW (when using 64-bit operands)

TEMP0 \leftarrow ABS(DEST[7:0] – SRC[7:0]); (* Repeat operation for bytes 2 through 6 *) TEMP7 \leftarrow ABS(DEST[63:56] – SRC[63:56]);

```
DEST[15:0] \leftarrow SUM(TEMP0:TEMP7);
DEST[63:16] \leftarrow 000000000000H;
```

PSADBW (when using 128-bit operands)

```
TEMP0 ← ABS(DEST[7:0] − SRC[7:0]);

(* Repeat operation for bytes 2 through 14 *)

TEMP15 ← ABS(DEST[127:120] − SRC[127:120]);

DEST[15:0] ← SUM(TEMP0:TEMP7);

DEST[63:16] ← 0000000000000H;

DEST[79:64] ← SUM(TEMP8:TEMP15);

DEST[127:80] ← 00000000000H;
```

DEST[VLMAX-1:128] (Unmodified)

VPSADBW (VEX.128 encoded version)

```
TEMP0 ← ABS(SRC1[7:0] - SRC2[7:0])

(* Repeat operation for bytes 2 through 14 *)

TEMP15 ← ABS(SRC1[127:120] - SRC2[127:120])

DEST[15:0] ← SUM(TEMP0:TEMP7)

DEST[63:16] ← 00000000000H

DEST[79:64] ← SUM(TEMP8:TEMP15)

DEST[127:80] ← 00000000000

DEST[VLMAX-1:128] ← 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PSADBW __m64 _mm_sad_pu8(__m64 a,__m64 b)
PSADBW __m128i _mm_sad_epu8(__m128i a, __m128i b)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PSHUFB — Packed Shuffle Bytes

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F 38 00 /r ¹ PSHUFB mm1, mm2/m64	Α	V/V	SSSE3	Shuffle bytes in mm1 according to contents of mm2/m64.
66 0F 38 00 /r PSHUFB xmm1, xmm2/m128	Α	V/V	SSSE3	Shuffle bytes in xmm1 according to contents of xmm2/m128.
VEX.NDS.128.66.0F38.WIG 00 /r VPSHUFB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Shuffle bytes in xmm2 according to contents of xmm3/m128.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PSHUFB performs in-place shuffles of bytes in the destination operand (the first operand) according to the shuffle control mask in the source operand (the second operand). The instruction permutes the data in the destination operand, leaving the shuffle mask unaffected. If the most significant bit (bit[7]) of each byte of the shuffle control mask is set, then constant zero is written in the result byte. Each byte in the shuffle control mask forms an index to permute the corresponding byte in the destination operand. The value of each index is the least significant 4 bits (128-bit operation) or 3 bits (64-bit operation) of the shuffle control byte. Both operands can be MMX register or XMM registers. When the source operand is a 128-bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

VEX.128 encoded version: The destination operand is the first operand, the first source operand is the second operand, the second source operand is the third operand. Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise the instruction will #UD.

Operation

PSHUFB (with 64 bit operands)

```
for i = 0 to 7 {
         if (SRC[(i * 8)+7] = 1) then
               DEST[(i*8)+7...(i*8)+0] \leftarrow 0;
         else
               index[2..0] \leftarrow SRC[(i*8)+2...(i*8)+0];
               DEST[(i*8)+7...(i*8)+0] \leftarrow DEST[(index*8+7)..(index*8+0)];
         endif:
    }
PSHUFB (with 128 bit operands)
    for i = 0 to 15 {
         if (SRC[(i * 8)+7] = 1) then
               DEST[(i*8)+7..(i*8)+0] \leftarrow 0;
          else
               index[3..0] \leftarrow SRC[(i*8)+3...(i*8)+0];
               DEST[(i*8)+7..(i*8)+0] \leftarrow DEST[(index*8+7)..(index*8+0)];
         endif
    }
DEST[VLMAX-1:128] \leftarrow 0
VPSHUFB (VEX.128 encoded version)
for i = 0 to 15 {
    if (SRC2[(i * 8)+7] = 1) then
         DEST[(i*8)+7..(i*8)+0] \leftarrow 0;
         else
         index[3..0] \leftarrow SRC2[(i*8)+3...(i*8)+0];
         DEST[(i*8)+7..(i*8)+0] \leftarrow SRC1[(index*8+7)..(index*8+0)];
    endif
DEST[VLMAX-1:128] \leftarrow 0
```




Figure 4-7. PSHUB with 64-Bit Operands

Intel C/C++ Compiler Intrinsic Equivalent

PSHUFB __m64 _mm_shuffle_pi8 (__m64 a, __m64 b)

PSHUFB __m128i _mm_shuffle_epi8 (__m128i a, __m128i b)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PSHUFD—Shuffle Packed Doublewords

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 70 /r ib PSHUFD xmm1, xmm2/m128, imm8	Α	V/V	SSE2	Shuffle the doublewords in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.
VEX.128.66.0F.WIG 70 /r ib VPSHUFD xmm1, xmm2/m128, imm8	Α	V/V	AVX	Shuffle the doublewords in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

Description

Copies doublewords from source operand (second operand) and inserts them in the destination operand (first operand) at the locations selected with the order operand (third operand). Figure 4-8 shows the operation of the PSHUFD instruction and the encoding of the order operand. Each 2-bit field in the order operand selects the contents of one doubleword location in the destination operand. For example, bits 0 and 1 of the order operand select the contents of doubleword 0 of the destination operand. The encoding of bits 0 and 1 of the order operand (see the field encoding in Figure 4-8) determines which doubleword from the source operand will be copied to doubleword 0 of the destination operand.




Figure 4-8. PSHUFD Instruction Operation

The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. The order operand is an 8-bit immediate. Note that this instruction permits a doubleword in the source operand to be copied to more than one doubleword location in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:1288) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PSHUFD (128-bit Legacy SSE version)

```
DEST[31:0] \leftarrow (SRC >> (ORDER[1:0] * 32))[31:0];
DEST[63:32] \leftarrow (SRC >> (ORDER[3:2] * 32))[31:0];
DEST[95:64] \leftarrow (SRC >> (ORDER[5:4] * 32))[31:0];
DEST[127:96] \leftarrow (SRC >> (ORDER[7:6] * 32))[31:0];
DEST[VLMAX-1:128] (Unmodified)
```

VPSHUFD (VEX.128 encoded version)

```
DEST[31:0] \leftarrow (SRC >> (ORDER[1:0] * 32))[31:0];

DEST[63:32] \leftarrow (SRC >> (ORDER[3:2] * 32))[31:0];

DEST[95:64] \leftarrow (SRC >> (ORDER[5:4] * 32))[31:0];

DEST[127:96] \leftarrow (SRC >> (ORDER[7:6] * 32))[31:0];

DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
PSHUFD __m128i _mm_shuffle_epi32(__m128i a, int n)
```

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally

#UD If VEX.L = 1.

If VEX.vvvv != 1111B.
```

PSHUFHW—Shuffle Packed High Words

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F3 OF 70 /r ib PSHUFHW xmm1, xmm2/ m128, imm8	Α	V/V	SSE2	Shuffle the high words in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.
VEX.128.F3.0F.WIG 70 /r ib VPSHUFHW xmm1, xmm2/m128, imm8	Α	V/V	AVX	Shuffle the high words in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

Description

Copies words from the high quadword of the source operand (second operand) and inserts them in the high quadword of the destination operand (first operand) at word locations selected with the order operand (third operand). This operation is similar to the operation used by the PSHUFD instruction, which is illustrated in Figure 4-8. For the PSHUFHW instruction, each 2-bit field in the order operand selects the contents of one word location in the high quadword of the destination operand. The binary encodings of the order operand fields select words (0, 1, 2 or 3, 4) from the high quadword of the source operand to be copied to the destination operand. The low quadword of the source operand is copied to the low quadword of the destination operand.

The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. The order operand is an 8-bit immediate. Note that this instruction permits a word in the high quadword of the source operand to be copied to more than one word location in the high quadword of the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise the instruction will #UD.

Operation

PSHUFHW (128-bit Legacy SSE version)

 $\begin{aligned} & \mathsf{DEST}[63:0] \leftarrow \mathsf{SRC}[63:0] \\ & \mathsf{DEST}[79:64] \leftarrow (\mathsf{SRC} >> (\mathsf{imm}[1:0] *16))[79:64] \\ & \mathsf{DEST}[95:80] \leftarrow (\mathsf{SRC} >> (\mathsf{imm}[3:2] * 16))[79:64] \\ & \mathsf{DEST}[111:96] \leftarrow (\mathsf{SRC} >> (\mathsf{imm}[5:4] * 16))[79:64] \\ & \mathsf{DEST}[127:112] \leftarrow (\mathsf{SRC} >> (\mathsf{imm}[7:6] * 16))[79:64] \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128]} \ (\mathsf{Unmodified}) \end{aligned}$

VPSHUFHW (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] DEST[79:64] \leftarrow (SRC1 >> (imm[1:0] *16))[79:64] DEST[95:80] \leftarrow (SRC1 >> (imm[3:2] * 16))[79:64] DEST[111:96] \leftarrow (SRC1 >> (imm[5:4] * 16))[79:64] DEST[127:112] \leftarrow (SRC1 >> (imm[7:6] * 16))[79:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PSHUFHW __m128i _mm_shufflehi_epi16(__m128i a, int n)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PSHUFLW—Shuffle Packed Low Words

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F2 OF 70 /r ib PSHUFLW xmm1, xmm2/m128, imm8	Α	V/V	SSE2	Shuffle the low words in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.
VEX.128.F2.0F.WIG 70 /r ib VPSHUFLW xmm1, xmm2/m128, imm8	Α	V/V	AVX	Shuffle the low words in xmm2/m128 based on the encoding in imm8 and store the result in xmm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

Description

Copies words from the low quadword of the source operand (second operand) and inserts them in the low quadword of the destination operand (first operand) at word locations selected with the order operand (third operand). This operation is similar to the operation used by the PSHUFD instruction, which is illustrated in Figure 4-8. For the PSHUFLW instruction, each 2-bit field in the order operand selects the contents of one word location in the low quadword of the destination operand. The binary encodings of the order operand fields select words (0, 1, 2, or 3) from the low quadword of the source operand to be copied to the destination operand. The high quadword of the source operand is copied to the high quadword of the destination operand.

The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. The order operand is an 8-bit immediate. Note that this instruction permits a word in the low quadword of the source operand to be copied to more than one word location in the low quadword of the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv is reserved and must be 1111b, VEX.L must be 0, otherwise instructions will #UD.

Operation

PSHUFLW (128-bit Legacy SSE version)

DEST[15:0] \leftarrow (SRC >> (imm[1:0] *16))[15:0] DEST[31:16] \leftarrow (SRC >> (imm[3:2] * 16))[15:0] DEST[47:32] \leftarrow (SRC >> (imm[5:4] * 16))[15:0] DEST[63:48] \leftarrow (SRC >> (imm[7:6] * 16))[15:0] DEST[127:64] \leftarrow SRC[127:64] DEST[VLMAX-1:128] (Unmodified)

VPSHUFLW (VEX.128 encoded version)

 $\begin{aligned} & \mathsf{DEST}[15:0] \leftarrow (\mathsf{SRC1} >> (\mathsf{imm}[1:0] *16))[15:0] \\ & \mathsf{DEST}[31:16] \leftarrow (\mathsf{SRC1} >> (\mathsf{imm}[3:2] * 16))[15:0] \\ & \mathsf{DEST}[47:32] \leftarrow (\mathsf{SRC1} >> (\mathsf{imm}[5:4] * 16))[15:0] \\ & \mathsf{DEST}[63:48] \leftarrow (\mathsf{SRC1} >> (\mathsf{imm}[7:6] * 16))[15:0] \\ & \mathsf{DEST}[127:64] \leftarrow \mathsf{SRC}[127:64] \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{aligned}$

Intel C/C++ Compiler Intrinsic Equivalent

PSHUFLW __m128i _mm_shufflelo_epi16(__m128i a, int n)

Flags Affected

None.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

If VEX.vvvv != 1111B.

PSHUFW—Shuffle Packed Words

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 70 /r ib	PSHUFW mm1, mm2/m64, imm8	Α	Valid	Valid	Shuffle the words in mm2/m64 based on the encoding in imm8 and store the result in mm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

Description

Copies words from the source operand (second operand) and inserts them in the destination operand (first operand) at word locations selected with the order operand (third operand). This operation is similar to the operation used by the PSHUFD instruction, which is illustrated in Figure 4-8. For the PSHUFW instruction, each 2-bit field in the order operand selects the contents of one word location in the destination operand. The encodings of the order operand fields select words from the source operand to be copied to the destination operand.

The source operand can be an MMX technology register or a 64-bit memory location. The destination operand is an MMX technology register. The order operand is an 8-bit immediate. Note that this instruction permits a word in the source operand to be copied to more than one word location in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Operation

```
DEST[15:0] \leftarrow (SRC >> (ORDER[1:0] * 16))[15:0];
DEST[31:16] \leftarrow (SRC >> (ORDER[3:2] * 16))[15:0];
DEST[47:32] \leftarrow (SRC >> (ORDER[5:4] * 16))[15:0];
DEST[63:48] \leftarrow (SRC >> (ORDER[7:6] * 16))[15:0];
```

Intel C/C++ Compiler Intrinsic Equivalent

PSHUFW __m64 _mm_shuffle_pi16(__m64 a, int n)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Table 19-7, "Exception Conditions for SIMD/MMX Instructions with Memory Reference," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

PSIGNB/PSIGNW/PSIGND — Packed SIGN

Opcode Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 38 08 /r ¹ PSIGNB mm1, mm2/m64	A	V/V	SSSE3	Negate/zero/preserve packed byte integers in mm1 depending on the corresponding sign in mm2/m64
66 OF 38 08 /r PSIGNB xmm1, xmm2/m128	A	V/V	SSSE3	Negate/zero/preserve packed byte integers in xmm1 depending on the corresponding sign in xmm2/m128.
OF 38 09 /r ¹ PSIGNW mm1, mm2/m64	A	V/V	SSSE3	Negate/zero/preserve packed word integers in mm1 depending on the corresponding sign in mm2/m128.
66 OF 38 09 /r PSIGNW xmm1, xmm2/m128	A	V/V	SSSE3	Negate/zero/preserve packed word integers in xmm1 depending on the corresponding sign in xmm2/m128.
OF 38 OA /r ¹ PSIGND mm1, mm2/m64	A	V/V	SSSE3	Negate/zero/preserve packed doubleword integers in mm1 depending on the corresponding sign in mm2/m128.
66 OF 38 OA /r PSIGND xmm1, xmm2/m128	A	V/V	SSSE3	Negate/zero/preserve packed doubleword integers in xmm1 depending on the corresponding sign in xmm2/m128.
VEX.NDS.128.66.0F38.WIG 08 /r VPSIGNB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Negate/zero/preserve packed byte integers in xmm2 depending on the corresponding sign in xmm3/m128.

Opcode	Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128 VPSIGNW xmr xmm3/m128	.66.0F38.WIG 09 /r m1, xmm2,	В	V/V	AVX	Negate/zero/preserve packed word integers in xmm2 depending on the corresponding sign in xmm3/m128.
VEX.NDS.128 VPSIGND xmn xmm3/m128	.66.0F38.WIG OA /r n1, xmm2,	В	V/V	AVX	Negate/zero/preserve packed doubleword integers in xmm2 depending on the corresponding sign in xmm3/m128.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

PSIGNB/PSIGNW/PSIGND negates each data element of the destination operand (the first operand) if the signed integer value of the corresponding data element in the source operand (the second operand) is less than zero. If the signed integer value of a data element in the source operand is positive, the corresponding data element in the destination operand is unchanged. If a data element in the source operand is zero, the corresponding data element in the destination operand is set to zero.

PSIGNB operates on signed bytes. PSIGNW operates on 16-bit signed words. PSIGND operates on signed 32-bit integers. Both operands can be MMX register or XMM registers. When the source operand is a 128bit memory operand, the operand must be aligned on a 16-byte boundary or a general-protection exception (#GP) will be generated.

In 64-bit mode, use the REX prefix to access additional registers.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSIGNB (with 64 bit operands)

```
IF (SRC[7:0] < 0)
         DEST[7:0] \leftarrow Neq(DEST[7:0])
   ELSEIF (SRC[7:0] = 0)
         DEST[7:0] \leftarrow 0
   ELSEIF (SRC[7:0] > 0)
         DEST[7:0] \leftarrow DEST[7:0]
   Repeat operation for 2nd through 7th bytes
   IF (SRC[63:56] < 0)
         DEST[63:56] \leftarrow Neg(DEST[63:56])
   ELSEIF (SRC[63:56] = 0)
         DEST[63:56] \leftarrow 0
   ELSEIF (SRC[63:56] > 0)
         DEST[63:56] \leftarrow DEST[63:56]
PSIGNB (with 128 bit operands)
   IF (SRC[7:0] < 0)
         DEST[7:0] \leftarrow Neg(DEST[7:0])
   ELSEIF (SRC[7:0] = 0)
         DEST[7:0] \leftarrow 0
   ELSEIF (SRC[7:0] > 0)
         DEST[7:0] \leftarrow DEST[7:0]
   Repeat operation for 2nd through 15th bytes
   IF (SRC[127:120] < 0)
         \mathsf{DEST}[127:120] \leftarrow \mathsf{Neg}(\mathsf{DEST}[127:120])
   ELSEIF (SRC[127:120] = 0)
         DEST[127:120] \leftarrow 0
   ELSEIF (SRC[127:120] > 0)
         DEST[127:120] \leftarrow DEST[127:120]
   IF (SRC[15:0] < 0)
```

PSIGNW (with 64 bit operands)

```
DEST[15:0] \leftarrow Neg(DEST[15:0])
ELSEIF (SRC[15:0] = 0)
     DEST[15:0] \leftarrow 0
ELSEIF (SRC[15:0] > 0)
```

```
DEST[15:0] \leftarrow DEST[15:0]
Repeat operation for 2nd through 3rd words
   IF (SRC[63:48] < 0)
        DEST[63:48] \leftarrow Neg(DEST[63:48])
   ELSEIF (SRC[63:48] = 0)
        DEST[63:48] \leftarrow 0
   ELSEIF (SRC[63:48] > 0)
        DEST[63:48] \leftarrow DEST[63:48]
PSIGNW (with 128 bit operands)
   IF (SRC[15:0] < 0)
        DEST[15:0] \leftarrow Neg(DEST[15:0])
   ELSEIF (SRC[15:0] = 0)
        DEST[15:0] \leftarrow 0
   ELSEIF (SRC[15:0] > 0)
        DEST[15:0] \leftarrow DEST[15:0]
   Repeat operation for 2nd through 7th words
   IF (SRC[127:112] < 0)
        DEST[127:112] \leftarrow Neg(DEST[127:112])
   ELSEIF (SRC[127:112] = 0)
        DEST[127:112] \leftarrow 0
   ELSEIF (SRC[127:112] > 0)
        DEST[127:112] \leftarrow DEST[127:112]
PSIGND (with 64 bit operands)
   IF (SRC[31:0] < 0)
        DEST[31:0] \leftarrow Neq(DEST[31:0])
   ELSEIF (SRC[31:0] = 0)
        DEST[31:0] \leftarrow 0
   ELSEIF (SRC[31:0] > 0)
        DEST[31:0] \leftarrow DEST[31:0]
   IF (SRC[63:32] < 0)
        DEST[63:32] \leftarrow Neg(DEST[63:32])
   ELSEIF (SRC[63:32] = 0)
        DEST[63:32] \leftarrow 0
   ELSEIF (SRC[63:32] > 0)
        DEST[63:32] \leftarrow DEST[63:32]
PSIGND (with 128 bit operands)
   IF (SRC[31:0] < 0)
        DEST[31:0] \leftarrow Neq(DEST[31:0])
   ELSEIF (SRC[31:0] = 0)
```

```
DEST[31:0] ← 0

ELSEIF (SRC[31:0] > 0 )

DEST[31:0] ← DEST[31:0]

Repeat operation for 2nd through 3rd double words

IF (SRC[127:96] < 0 )

DEST[127:96] ← Neg(DEST[127:96])

ELSEIF (SRC[127:96] = 0 )

DEST[127:96] ← 0

ELSEIF (SRC[127:96] > 0 )

DEST[127:96] ← DEST[127:96]
```

VPSIGNB (VEX.128 encoded version)

DEST[127:0] \leftarrow BYTE_SIGN(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSIGNW (VEX.128 encoded version)

DEST[127:0] \leftarrow WORD_SIGN(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSIGND (VEX.128 encoded version)

DEST[127:0] \leftarrow DWORD_SIGN(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PSIGNB __m64 _mm_sign_pi8 (__m64 a, __m64 b)

PSIGNB __m128i _mm_sign_epi8 (__m128i a, __m128i b)

PSIGNW __m64 _mm_sign_pi16 (__m64 a, __m64 b)

PSIGNW __m128i _mm_sign_epi16 (__m128i a, __m128i b)

PSIGND __m64 _mm_sign_pi32 (__m64 a, __m64 b)

PSIGND __m128i _mm_sign_epi32 (__m128i a, __m128i b)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PSLLDQ—Shift Double Quadword Left Logical

_			J	
Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 73 /7 ib PSLLDQ <i>xmm1</i> , <i>imm8</i>	Α	V/V	SSE2	Shift xmm1 left by imm8 bytes while shifting in Os.
VEX.NDD.128.66.0F.WIG 73 /7 i VPSLLDQ xmm1, xmm2, imm8	b B	V/V	AVX	Shift xmm2 left by imm8 bytes while shifting in 0s and store result in xmm1.

Instruction Operand Encoding

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r, w)	imm8	NA	NA
В	VEX.vvvv (w)	ModRM:r/m (r)	NA	NA

Description

Shifts the destination operand (first operand) to the left by the number of bytes specified in the count operand (second operand). The empty low-order bytes are cleared (set to all 0s). If the value specified by the count operand is greater than 15, the destination operand is set to all 0s. The destination operand is an XMM register. The count operand is an 8-bit immediate.

128-bit Legacy SSE version: The source and destination operands are the same. Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv encodes the destination register, and VEX.B + ModRM.r/m encodes the source register. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSLLDQ(128-bit Legacy SSE version)

TEMP \leftarrow COUNT IF (TEMP > 15) THEN TEMP \leftarrow 16; FI DEST \leftarrow DEST << (TEMP * 8) DEST[VLMAX-1:128] (Unmodified)

VPSLLDQ (VEX.128 encoded version)

TEMP \leftarrow COUNT IF (TEMP > 15) THEN TEMP \leftarrow 16; FI DEST \leftarrow SRC << (TEMP * 8) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

PSLLDQ __m128i _mm_slli_si128 (__m128i a, int imm)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 7; additionally #UD If VEX.L = 1.

PSLLW/PSLLD/PSLLQ—Shift Packed Data Left Logical

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
0F F1 /r ¹	Α	V/V	MMX	Shift words in mm left
PSLLW mm, mm/m64				<i>mm/m64</i> while shifting in Os.
66 0F F1 /r	Α	V/V	SSE2	Shift words in xmm1 left by
PSLLW xmm1, xmm2/m128				xmm2/m128 while shifting in 0s.
0F 71 /6 ib	В	V/V	MMX	Shift words in <i>mm</i> left by
PSLLW xmm1, imm8				imm8 while shifting in 0s.
66 0F 71 /6 ib	В	V/V	SSE2	Shift words in xmm1 left by
PSLLW xmm1, imm8				imm8 while shifting in 0s.
0F F2 /r ¹	Α	V/V	MMX	Shift doublewords in mm
PSLLD mm, mm/m64				left by mm/m64 while shifting in 0s.
66 0F F2 /r	Α	V/V	SSE2	Shift doublewords in xmm1
PSLLD xmm1, xmm2/m128				left by xmm2/m128 while shifting in 0s.
0F 72 /6 ib ¹	В	V/V	MMX	Shift doublewords in mm
PSLLD mm, imm8				left by <i>imm8</i> while shifting in 0s.
66 0F 72 /6 ib	В	V/V	SSE2	Shift doublewords in xmm1
PSLLD xmm1, imm8				left by <i>imm8</i> while shifting in Os.
0F F3 /r ¹	Α	V/V	MMX	Shift quadword in mm left
PSLLQ mm, mm/m64				by <i>mm/m64</i> while shifting in Os.
66 0F F3 /r	Α	V/V	SSE2	Shift quadwords in xmm1
PSLLQ xmm1, xmm2/m128				left by xmm2/m128 while shifting in 0s.
0F 73 /6 ib ¹	В	V/V	MMX	Shift quadword in mm left
PSLLQ mm, imm8				by imm8 while shifting in 0s.
66 0F 73 /6 ib	В	V/V	SSE2	Shift quadwords in xmm1
PSLLQ xmm1, imm8				left by <i>imm8</i> while shifting in 0s.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128.66.0F.WIG F1 /r VPSLLW xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift words in xmm2 left by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 71 /6 ib VPSLLW xmm1, xmm2, imm8	D	V/V	AVX	Shift words in xmm2 left by imm8 while shifting in 0s.
VEX.NDS.128.66.0F.WIG F2 /r VPSLLD xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift doublewords in xmm2 left by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 72 /6 ib VPSLLD xmm1, xmm2, imm8	D	V/V	AVX	Shift doublewords in xmm2 left by imm8 while shifting in 0s.
VEX.NDS.128.66.0F.WIG F3 /r VPSLLQ xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift quadwords in xmm2 left by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 73 /6 ib VPSLLQ xmm1, xmm2, imm8	D	V/V	AVX	Shift quadwords in xmm2 left by imm8 while shifting in 0s.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:r/m (r, w)	imm8	NA	NA
С	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA
D	VEX.vvvv (w)	ModRM:r/m (r)	NA	NA

Description

Shifts the bits in the individual data elements (words, doublewords, or quadword) in the destination operand (first operand) to the left by the number of bits specified in the count operand (second operand). As the bits in the data elements are shifted left,

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

the empty low-order bits are cleared (set to 0). If the value specified by the count operand is greater than 15 (for words), 31 (for doublewords), or 63 (for a quadword), then the destination operand is set to all 0s. Figure 4-9 gives an example of shifting words in a 64-bit operand.

The destination operand may be an MMX technology register or an XMM register; the count operand can be either an MMX technology register or an 64-bit memory location, an XMM register or a 128-bit memory location, or an 8-bit immediate. Note that only the first 64-bits of a 128-bit count operand are checked to compute the count.




Figure 4-9. PSLLW, PSLLD, and PSLLQ Instruction Operation Using 64-bit Operand

The PSLLW instruction shifts each of the words in the destination operand to the left by the number of bits specified in the count operand; the PSLLD instruction shifts each of the doublewords in the destination operand; and the PSLLQ instruction shifts the quadword (or quadwords) in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. For shifts with an immediate count (VEX.128.66.0F 71-73 /6), VEX.vvvv encodes the destination register, and VEX.B + ModRM.r/m encodes the source register. VEX.L must be 0, otherwise instructions will #UD. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

Operation

PSLLW (with 64-bit operand)

```
IF (COUNT > 15)
THEN
DEST[64:0] \leftarrow 000000000000000H;
ELSE
DEST[15:0] \leftarrow ZeroExtend(DEST[15:0] << COUNT);
(* Repeat shift operation for 2nd and 3rd words *)
DEST[63:48] \leftarrow ZeroExtend(DEST[63:48] << COUNT);
```

```
FI:
PSLLD (with 64-bit operand)
  IF (COUNT > 31)
  THEN
       DEST[64:0] \leftarrow 0000000000000000H;
  FLSE
       DEST[31:0] \leftarrow ZeroExtend(DEST[31:0] << COUNT);
       DEST[63:32] \leftarrow ZeroExtend(DEST[63:32] << COUNT);
  FI:
PSLLQ (with 64-bit operand)
  IF (COUNT > 63)
  THEN
       DEST[64:0] \leftarrow 000000000000000H;
  ELSE
       DEST \leftarrow ZeroExtend(DEST << COUNT);
  FI:
PSLLW (with 128-bit operand)
  COUNT ← COUNT SOURCE[63:0];
  IF (COUNT > 15)
  THEN
       ELSE
       DEST[15:0] \leftarrow ZeroExtend(DEST[15:0] << COUNT);
       (* Repeat shift operation for 2nd through 7th words *)
       DEST[127:112] \leftarrow ZeroExtend(DEST[127:112] << COUNT);
  FI:
PSLLD (with 128-bit operand)
  COUNT \leftarrow COUNT_SOURCE[63:0];
  IF (COUNT > 31)
  THEN
       ELSE
       DEST[31:0] \leftarrow ZeroExtend(DEST[31:0] << COUNT);
       (* Repeat shift operation for 2nd and 3rd doublewords *)
       DEST[127:96] \leftarrow ZeroExtend(DEST[127:96] << COUNT);
  FI:
PSLLQ (with 128-bit operand)
  COUNT \leftarrow COUNT_SOURCE[63:0];
  IF (COUNT > 63)
  THEN
```

PSLLW (xmm, xmm, xmm/m128)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_WORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

PSLLW (xmm, imm8)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_WORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)

VPSLLD (xmm, xmm, xmm/m128)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_DWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSLLD (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_DWORDS(SRC1, imm8) DEST[VLMAX-1:128] \leftarrow 0

PSLLD (xmm, xmm, xmm/m128)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_DWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

PSLLD (xmm, imm8)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_DWORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)

VPSLLQ (xmm, xmm, xmm/m128)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_QWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSLLQ (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_QWORDS(SRC1, imm8) DEST[VLMAX-1:128] \leftarrow 0

PSLLQ (xmm, xmm, xmm/m128)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_QWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

PSLLQ (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_QWORDS(DEST, imm8) DEST[VLMAX-1:128] (Unmodified)

VPSLLW (xmm, xmm, xmm/m128)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_WORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSLLW (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_WORDS(SRC1, imm8) DEST[VLMAX-1:128] \leftarrow 0

PSLLW (xmm, xmm, xmm/m128)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_WORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

PSLLW (xmm, imm8)

DEST[127:0] ← LOGICAL_LEFT_SHIFT_WORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)

VPSLLD (xmm, xmm, xmm/m128)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_DWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSLLD (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_LEFT_SHIFT_DWORDS(SRC1, imm8) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

PSLLW __m64 _mm_slli_pi16 (__m64 m, int count) **PSLLW** m64 mm sll pi16(m64 m, m64 count) **PSLLW** m128i mm slli pi16(m64 m, int count) **PSLLW** m128i mm slli pi16(m128i m, m128i count) **PSLLD** __m64 _mm_slli_pi32(__m64 m, int count) **PSLLD** __m64 _mm_sll_pi32(__m64 m, __m64 count) **PSLLD** __m128i _mm_slli_epi32(__m128i m, int count) **PSLLD** __m128i _mm_sll_epi32(__m128i m, __m128i count) __m64 _mm_slli_si64(__m64 m, int count) **PSLLO PSLLO** __m64 _mm_sll_si64(__m64 m, __m64 count) **PSLLO** __m128i _mm_slli_epi64(__m128i m, int count) **PSLLQ** m128i mm sll epi64(m128i m, m128i count)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4 and 7 for non-VEX-encoded instructions.

#UD If VEX.L = 1.

PSRAW/PSRAD—Shift Packed Data Right Arithmetic

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF E1 /r ¹ PSRAW mm, mm/m64	Α	V/V	MMX	Shift words in <i>mm</i> right by <i>mm/m64</i> while shifting in sign bits.
66 OF E1 /r PSRAW xmm1, xmm2/m128	Α	V/V	SSE2	Shift words in xmm1 right by xmm2/m128 while shifting in sign bits.
OF 71 /4 ib ¹ PSRAW <i>mm, imm8</i>	В	V/V	MMX	Shift words in <i>mm</i> right by <i>imm8</i> while shifting in sign bits
66 0F 71 /4 ib PSRAW <i>xmm1</i> , imm8	В	V/V	SSE2	Shift words in <i>xmm1</i> right by imm8 while shifting in sign bits
OF E2 /r ¹ PSRAD mm, mm/m64	Α	V/V	MMX	Shift doublewords in <i>mm</i> right by <i>mm/m64</i> while shifting in sign bits.
66 OF E2 /r PSRAD xmm1, xmm2/m128	Α	V/V	SSE2	Shift doubleword in xmm1 right by xmm2 /m128 while shifting in sign bits.
OF 72 /4 ib ¹ PSRAD <i>mm, imm8</i>	В	V/V	MMX	Shift doublewords in <i>mm</i> right by <i>imm8</i> while shifting in sign bits.
66 0F 72 /4 ib PSRAD <i>xmm1</i> , imm8	В	V/V	SSE2	Shift doublewords in xmm1 right by imm8 while shifting in sign bits.
VEX.NDS.128.66.0F.WIG E1 /r VPSRAW xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift words in xmm2 right by amount specified in xmm3/m128 while shifting in sign bits.
VEX.NDD.128.66.0F.WIG 71 /4 ib VPSRAW xmm1, xmm2, imm8	D	V/V	AVX	Shift words in xmm2 right by imm8 while shifting in sign bits.
VEX.NDS.128.66.0F.WIG E2 /r VPSRAD xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift doublewords in xmm2 right by amount specified in xmm3/m128 while shifting in sign bits.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDD.128.66.0F.WIG 72 /4 ib VPSRAD xmm1, xmm2, imm8	D	V/V	AVX	Shift doublewords in xmm2 right by imm8 while shifting in sign bits.

NOTES:

1. See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

lı	nstruc	tion (Operand	Encod	ing
----	--------	--------	---------	-------	-----

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:r/m (r, w)	imm8	NA	NA
С	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA
D	VEX.vvvv (w)	ModRM:r/m (r)	NA	NA

Description

Shifts the bits in the individual data elements (words or doublewords) in the destination operand (first operand) to the right by the number of bits specified in the count operand (second operand). As the bits in the data elements are shifted right, the empty high-order bits are filled with the initial value of the sign bit of the data element. If the value specified by the count operand is greater than 15 (for words) or 31 (for doublewords), each destination data element is filled with the initial value of the sign bit of the element. (Figure 4-10 gives an example of shifting words in a 64-bit operand.)




Figure 4-10. PSRAW and PSRAD Instruction Operation Using a 64-bit Operand

The destination operand may be an MMX technology register or an XMM register; the count operand can be either an MMX technology register or an 64-bit memory location, an XMM register or a 128-bit memory location, or an 8-bit immediate. Note that only the first 64-bits of a 128-bit count operand are checked to compute the count.

The PSRAW instruction shifts each of the words in the destination operand to the right by the number of bits specified in the count operand, and the PSRAD instruction shifts each of the doublewords in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. For shifts with an immediate count (VEX.128.66.0F 71-73 /4), VEX.vvvv encodes the destination register, and VEX.B + ModRM.r/m encodes the source register. VEX.L must be 0, otherwise instructions will #UD.: Bits (255:128) of the corresponding YMM destination register remain unchanged. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

Operation

PSRAW (with 64-bit operand)

```
IF (COUNT > 15)

THEN COUNT \leftarrow 16;

FI;

DEST[15:0] \leftarrow SignExtend(DEST[15:0] >> COUNT);

(* Repeat shift operation for 2nd and 3rd words *)

DEST[63:48] \leftarrow SignExtend(DEST[63:48] >> COUNT);
```

PSRAD (with 64-bit operand)

```
IF (COUNT > 31)

THEN COUNT \leftarrow 32;

FI;

DEST[31:0] \leftarrow SignExtend(DEST[31:0] >> COUNT);

DEST[63:32] \leftarrow SignExtend(DEST[63:32] >> COUNT);
```

PSRAW (with 128-bit operand)

```
\begin{aligned} & \text{COUNT} \leftarrow \text{COUNT\_SOURCE[63:0];} \\ & \text{IF (COUNT} > 15) \\ & & \text{THEN COUNT} \leftarrow 16; \\ & \text{FI;} \\ & \text{DEST[15:0]} \leftarrow & \text{SignExtend(DEST[15:0]} >> & \text{COUNT);} \end{aligned}
```

```
(* Repeat shift operation for 2nd through 7th words *)
DEST[127:112] ← SignExtend(DEST[127:112] >> COUNT);
```

PSRAD (with 128-bit operand)

```
COUNT ← COUNT_SOURCE[63:0];

IF (COUNT > 31)

THEN COUNT ← 32;

FI;

DEST[31:0] ← SignExtend(DEST[31:0] >> COUNT);

(* Repeat shift operation for 2nd and 3rd doublewords *)

DEST[127:96] ← SignExtend(DEST[127:96] >> COUNT);
```

PSRAW (xmm, xmm, xmm/m128)

DEST[127:0] ← ARITHMETIC_RIGHT_SHIFT_WORDS(DEST, SRC) DEST[VLMAX-1:128] (Unmodified)

PSRAW (xmm, imm8)

DEST[127:0] ← ARITHMETIC_RIGHT_SHIFT_WORDS(DEST, imm8) DEST[VLMAX-1:128] (Unmodified)

VPSRAW (xmm, xmm, xmm/m128)

$$\label{eq:destination} \begin{split} \mathsf{DEST}[127:0] \leftarrow \mathsf{ARITHMETIC_RIGHT_SHIFT_WORDS}(\mathsf{SRC1}, \mathsf{SRC2}) \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{split}$$

VPSRAW (xmm, imm8)

$$\label{eq:destination} \begin{split} \mathsf{DEST}[127:0] &\leftarrow \mathsf{ARITHMETIC_RIGHT_SHIFT_WORDS}(\mathsf{SRC1}, \mathsf{imm8}) \\ \mathsf{DEST}[\mathsf{VLMAX-}1:128] &\leftarrow 0 \end{split}$$

PSRAD (xmm, xmm, xmm/m128)

DEST[127:0] ← ARITHMETIC_RIGHT_SHIFT_DWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

PSRAD (xmm, imm8)

DEST[127:0] ← ARITHMETIC_RIGHT_SHIFT_DWORDS(DEST, imm8) DEST[VLMAX-1:128] (Unmodified)

VPSRAD (xmm, xmm, xmm/m128)

$$\label{eq:destination} \begin{split} \mathsf{DEST}[127:0] &\leftarrow \mathsf{ARITHMETIC_RIGHT_SHIFT_DWORDS}(\mathsf{SRC1}, \mathsf{SRC2}) \\ \mathsf{DEST}[\mathsf{VLMAX-}1:128] &\leftarrow 0 \end{split}$$

VPSRAD (xmm, imm8)

$$\label{eq:destimate} \begin{split} \mathsf{DEST}[127:0] \leftarrow \mathsf{ARITHMETIC_RIGHT_SHIFT_DWORDS}(\mathsf{SRC1}, \mathsf{imm8}) \\ \mathsf{DEST}[\mathsf{VLMAX-}1:128] \leftarrow 0 \end{split}$$

Intel C/C++ Compiler Intrinsic Equivalents

```
PSRAW
         __m64 _mm_srai_pi16 (__m64 m, int count)
PSRAW
         __m64 _mm_sra_pi16 (__m64 m, __m64 count)
PSRAD
         __m64 _mm_srai_pi32 (__m64 m, int count)
PSRAD
         __m64 _mm_sra_pi32 (__m64 m, __m64 count)
         __m128i _mm_srai_epi16(__m128i m, int count)
PSRAW
         __m128i _mm_sra_epi16(__m128i m, __m128i count))
PSRAW
PSRAD
         __m128i _mm_srai_epi32 (__m128i m, int count)
PSRAD
         __m128i _mm_sra_epi32 (__m128i m, __m128i count)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4 and 7 for non-VEX-encoded instructions. #UD If VEX.L = 1.

PSRLDQ—Shift Double Quadword Right Logical

•		_	_	
Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 73 /3 ib PSRLDQ <i>xmm1</i> , <i>imm8</i>	Α	V/V	SSE2	Shift xmm1 right by imm8 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 73 /3 ib VPSRLDQ xmm1, xmm2, imm8	В	V/V	AVX	Shift xmm2 right by imm8 bytes while shifting in 0s.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r, w)	imm8	NA	NA
В	VEX.vvvv (w)	ModRM:r/m (r)	NA	NA

Description

Shifts the destination operand (first operand) to the right by the number of bytes specified in the count operand (second operand). The empty high-order bytes are cleared (set to all 0s). If the value specified by the count operand is greater than 15, the destination operand is set to all 0s. The destination operand is an XMM register. The count operand is an 8-bit immediate.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The source and destination operands are the same. Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.vvvv encodes the destination register, and VEX.B + ModRM.r/m encodes the source register. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSRLDQ(128-bit Legacy SSE version)

TEMP ← COUNT

IF (TEMP > 15) THEN TEMP ← 16; FI

DEST ← DEST >> (TEMP * 8)

DEST[VLMAX-1:128] (Unmodified)

VPSRLDQ (VEX.128 encoded version)

TEMP \leftarrow COUNT IF (TEMP > 15) THEN TEMP \leftarrow 16; FI DEST \leftarrow SRC >> (TEMP * 8) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

PSRLDQ __m128i _mm_srli_si128 (__m128i a, int imm)

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 7; additionally #UD If VEX.L = 1.

PSRLW/PSRLD/PSRLQ—Shift Packed Data Right Logical

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF D1 /r ¹ PSRLW <i>mm, mm/m64</i>	Α	V/V	MMX	Shift words in <i>mm</i> right by amount specified in <i>mm/m64</i> while shifting in Os.
66 OF D1 /r PSRLW xmm1, xmm2/m128	Α	V/V	SSE2	Shift words in <i>xmm1</i> right by amount specified in <i>xmm2/m128</i> while shifting in 0s.
OF 71 /2 ib ¹ PSRLW <i>mm, imm8</i>	В	V/V	MMX	Shift words in <i>mm</i> right by <i>imm8</i> while shifting in 0s.
66 0F 71 /2 ib PSRLW xmm1, imm8	В	V/V	SSE2	Shift words in xmm1 right by imm8 while shifting in 0s.
OF D2 /r ¹ PSRLD mm, mm/m64	Α	V/V	MMX	Shift doublewords in <i>mm</i> right by amount specified in <i>mm/m64</i> while shifting in Os.
66 OF D2 /r PSRLD xmm1, xmm2/m128	Α	V/V	SSE2	Shift doublewords in xmm1 right by amount specified in xmm2 /m128 while shifting in 0s.
OF 72 /2 ib ¹ PSRLD <i>mm, imm8</i>	В	V/V	MMX	Shift doublewords in <i>mm</i> right by <i>imm8</i> while shifting in 0s.
66 0F 72 /2 ib PSRLD <i>xmm1</i> , imm8	В	V/V	SSE2	Shift doublewords in xmm1 right by imm8 while shifting in 0s.
OF D3 /r ¹ PSRLQ <i>mm, mm/m64</i>	Α	V/V	MMX	Shift <i>mm</i> right by amount specified in <i>mm/m64</i> while shifting in Os.
66 OF D3 /r PSRLQ xmm1, xmm2/m128	Α	V/V	SSE2	Shift quadwords in xmm1 right by amount specified in xmm2/m128 while shifting in 0s.
OF 73 /2 ib ¹ PSRLQ <i>mm, imm8</i>	В	V/V	MMX	Shift <i>mm</i> right by <i>imm8</i> while shifting in Os.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 0F 73 /2 ib PSRLQ <i>xmm1</i> , <i>imm8</i>	В	V/V	SSE2	Shift quadwords in xmm1 right by imm8 while shifting in 0s.
VEX.NDS.128.66.0F.WIG D1 /r VPSRLW xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift words in xmm2 right by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 71 /2 ib VPSRLW xmm1, xmm2, imm8	D	V/V	AVX	Shift words in xmm2 right by imm8 while shifting in 0s.
VEX.NDS.128.66.0F.WIG D2 /r VPSRLD xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift doublewords in xmm2 right by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 72 /2 ib VPSRLD xmm1, xmm2, imm8	D	V/V	AVX	Shift doublewords in xmm2 right by imm8 while shifting in 0s.
VEX.NDS.128.66.0F.WIG D3 /r VPSRLQ xmm1, xmm2, xmm3/m128	С	V/V	AVX	Shift quadwords in xmm2 right by amount specified in xmm3/m128 while shifting in 0s.
VEX.NDD.128.66.0F.WIG 73 /2 ib VPSRLQ xmm1, xmm2, imm8	D	V/V	AVX	Shift quadwords in xmm2 right by imm8 while shifting in 0s.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:r/m (r, w)	imm8	NA	NA
С	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA
D	VEX.vvvv (w)	ModRM:r/m (r)	NA	NA

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Description

Shifts the bits in the individual data elements (words, doublewords, or quadword) in the destination operand (first operand) to the right by the number of bits specified in the count operand (second operand). As the bits in the data elements are shifted right, the empty high-order bits are cleared (set to 0). If the value specified by the count operand is greater than 15 (for words), 31 (for doublewords), or 63 (for a quadword), then the destination operand is set to all 0s. Figure 4-11 gives an example of shifting words in a 64-bit operand.

The destination operand may be an MMX technology register or an XMM register; the count operand can be either an MMX technology register or an 64-bit memory location, an XMM register or a 128-bit memory location, or an 8-bit immediate. Note that only the first 64-bits of a 128-bit count operand are checked to compute the count.




Figure 4-11. PSRLW, PSRLD, and PSRLQ Instruction Operation Using 64-bit Operand

The PSRLW instruction shifts each of the words in the destination operand to the right by the number of bits specified in the count operand; the PSRLD instruction shifts each of the doublewords in the destination operand; and the PSRLQ instruction shifts the quadword (or quadwords) in the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. For shifts with an immediate count (VEX.128.66.0F 71-73 /2), VEX.vvvv encodes the destination register, and VEX.B + ModRM.r/m encodes the source register. VEX.L must be 0, otherwise instructions will #UD. If the count operand is a memory address, 128 bits are loaded but the upper 64 bits are ignored.

Operation

PSRLW (with 64-bit operand)

IF (COUNT > 15) THEN

```
DEST[64:0] \leftarrow 0000000000000000H
   ELSE
       DEST[15:0] \leftarrow ZeroExtend(DEST[15:0] >> COUNT);
       (* Repeat shift operation for 2nd and 3rd words *)
       DEST[63:48] \leftarrow ZeroExtend(DEST[63:48] >> COUNT);
   FI;
PSRLD (with 64-bit operand)
   IF (COUNT > 31)
   THEN
       DEST[64:0] \leftarrow 0000000000000000H
   ELSE
       DEST[31:0] \leftarrow ZeroExtend(DEST[31:0] >> COUNT);
       DEST[63:32] \leftarrow ZeroExtend(DEST[63:32] >> COUNT);
   FI:
PSRLQ (with 64-bit operand)
   IF (COUNT > 63)
   THEN
       DEST[64:0] \leftarrow 00000000000000000
   ELSE
       DEST \leftarrow ZeroExtend(DEST >> COUNT);
   FI:
PSRLW (with 128-bit operand)
   COUNT \leftarrow COUNT_SOURCE[63:0];
   IF (COUNT > 15)
   THEN
       ELSE
       DEST[15:0] \leftarrow ZeroExtend(DEST[15:0] >> COUNT);
       (* Repeat shift operation for 2nd through 7th words *)
       DEST[127:112] \leftarrow ZeroExtend(DEST[127:112] >> COUNT);
   FI:
PSRLD (with 128-bit operand)
   COUNT \leftarrow COUNT_SOURCE[63:0];
   IF (COUNT > 31)
   THEN
       ELSE
       DEST[31:0] \leftarrow ZeroExtend(DEST[31:0] >> COUNT);
       (* Repeat shift operation for 2nd and 3rd doublewords *)
       DEST[127:96] \leftarrow ZeroExtend(DEST[127:96] >> COUNT);
   FI:
```

```
PSRLQ (with 128-bit operand)
   COUNT ← COUNT SOURCE[63:0];
   IF (COUNT > 15)
   THEN
       ELSE
       DEST[63:0] \leftarrow ZeroExtend(DEST[63:0] >> COUNT);
       DEST[127:64] \leftarrow ZeroExtend(DEST[127:64] >> COUNT);
   FI:
PSRLW (xmm, xmm, xmm/m128)
DEST[127:0] ← LOGICAL RIGHT SHIFT WORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)
PSRLW (xmm, imm8)
DEST[127:0] ← LOGICAL RIGHT SHIFT WORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)
VPSRLW (xmm, xmm, xmm/m128)
DEST[127:0] ← LOGICAL RIGHT SHIFT WORDS(SRC1, SRC2)
DEST[VLMAX-1:128] \leftarrow 0
VPSRLW (xmm, imm8)
DEST[127:0] ← LOGICAL RIGHT SHIFT WORDS(SRC1, imm8)
DEST[VLMAX-1:128] \leftarrow 0
PSRLD (xmm, xmm, xmm/m128)
DEST[127:0] ← LOGICAL RIGHT SHIFT DWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)
PSRLD (xmm, imm8)
DEST[127:0] ← LOGICAL_RIGHT_SHIFT_DWORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)
VPSRLD (xmm, xmm, xmm/m128)
DEST[127:0] \leftarrow LOGICAL_RIGHT_SHIFT_DWORDS(SRC1, SRC2)
DEST[VLMAX-1:128] \leftarrow 0
VPSRLD (xmm, imm8)
DEST[127:0] ← LOGICAL_RIGHT_SHIFT_DWORDS(SRC1, imm8)
DEST[VLMAX-1:128] \leftarrow 0
```

PSRLQ (xmm, xmm, xmm/m128)

```
DEST[127:0] ← LOGICAL_RIGHT_SHIFT_QWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)
```

PSRLQ (xmm, imm8)

DEST[127:0] ← LOGICAL_RIGHT_SHIFT_QWORDS(DEST, imm8)
DEST[VLMAX-1:128] (Unmodified)

VPSRLQ (xmm, xmm, xmm/m128)

DEST[127:0] \leftarrow LOGICAL_RIGHT_SHIFT_QWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPSRLQ (xmm, imm8)

DEST[127:0] \leftarrow LOGICAL_RIGHT_SHIFT_QWORDS(SRC1, imm8) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
PSRLW
         m64 mm srli pi16( m64 m, int count)
         __m64 _mm_srl_pi16 (__m64 m, __m64 count)
PSRLW
PSRLW
         m128i mm srli epi16 ( m128i m, int count)
PSRLW
         m128i mm srl epi16 ( m128i m, m128i count)
         __m64 _mm_srli_pi32 (__m64 m, int count)
PSRLD
PSRLD
         __m64 _mm_srl_pi32 (__m64 m, __m64 count)
PSRLD
         __m128i _mm_srli_epi32 (__m128i m, int count)
PSRLD
         __m128i _mm_srl_epi32 (__m128i m, __m128i count)
         __m64 _mm_srli_si64 (__m64 m, int count)
PSRLQ
         m64 mm srl si64 ( m64 m, m64 count)
PSRLO
         __m128i _mm_srli_epi64 (__m128i m, int count)
PSRLO
PSRLO
         __m128i _mm_srl_epi64 (__m128i m, __m128i count)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4 and 7 for non-VEX-encoded instructions.
#UD If VEX.L = 1.

PSUBB/PSUBW/PSUBD—Subtract Packed Integers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF F8 /r ¹ PSUBB <i>mm, mm/m64</i>		V/V	MMX	Subtract packed byte integers in <i>mm/m64</i> from packed byte integers in <i>mm</i> .
66 OF F8 /r PSUBB xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed byte integers in xmm2/m128 from packed byte integers in xmm1.
OF F9 /r ¹ PSUBW <i>mm, mm/m64</i>	Α	V/V	MMX	Subtract packed word integers in <i>mm/m64</i> from packed word integers in <i>mm.</i>
66 0F F9 /r PSUBW xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed word integers in xmm2/m128 from packed word integers in xmm1.
OF FA /r ¹ PSUBD mm, mm/m64	Α	V/V	MMX	Subtract packed doubleword integers in <i>mm/m64</i> from packed doubleword integers in <i>mm</i> .
66 OF FA /r PSUBD xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed doubleword integers in <i>xmm2/mem128</i> from packed doubleword integers in <i>xmm1</i> .
VEX.NDS.128.66.0F.WIG F8 /r VPSUBB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed byte integers in xmm3/m128 from xmm2.
VEX.NDS.128.66.0F.WIG F9 /r VPSUBW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed word integers in xmm3/m128 from xmm2.
VEX.NDS.128.66.0F.WIG FA /r VPSUBD xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed doubleword integers in xmm3/m128 from xmm2.

NOTES:

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

		madaction operana c	ricoding	
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Instruction Operand Encoding

Description

Performs a SIMD subtract of the packed integers of the source operand (second operand) from the packed integers of the destination operand (first operand), and stores the packed integer results in the destination operand. See Figure 9-4 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for an illustration of a SIMD operation. Overflow is handled with wraparound, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

The PSUBB instruction subtracts packed byte integers. When an individual result is too large or too small to be represented in a byte, the result is wrapped around and the low 8 bits are written to the destination element.

The PSUBW instruction subtracts packed word integers. When an individual result is too large or too small to be represented in a word, the result is wrapped around and the low 16 bits are written to the destination element.

The PSUBD instruction subtracts packed doubleword integers. When an individual result is too large or too small to be represented in a doubleword, the result is wrapped around and the low 32 bits are written to the destination element.

Note that the PSUBB, PSUBW, and PSUBD instructions can operate on either unsigned or signed (two's complement notation) packed integers; however, it does not set bits in the EFLAGS register to indicate overflow and/or a carry. To prevent undetected overflow conditions, software must control the ranges of values upon which it operates.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSUBB (with 64-bit operands)

DEST[7:0] \leftarrow DEST[7:0] – SRC[7:0]; (* Repeat subtract operation for 2nd through 7th byte *) DEST[63:56] \leftarrow DEST[63:56] – SRC[63:56];

PSUBB (with 128-bit operands)

DEST[7:0] \leftarrow DEST[7:0] – SRC[7:0]; (* Repeat subtract operation for 2nd through 14th byte *) DEST[127:120] \leftarrow DEST[111:120] – SRC[127:120];

PSUBW (with 64-bit operands)

DEST[15:0] \leftarrow DEST[15:0] – SRC[15:0]; (* Repeat subtract operation for 2nd and 3rd word *) DEST[63:48] \leftarrow DEST[63:48] – SRC[63:48];

PSUBW (with 128-bit operands)

DEST[15:0] \leftarrow DEST[15:0] – SRC[15:0]; (* Repeat subtract operation for 2nd through 7th word *) DEST[127:112] \leftarrow DEST[127:112] – SRC[127:112];

PSUBD (with 64-bit operands)

DEST[31:0] \leftarrow DEST[31:0] - SRC[31:0]; DEST[63:32] \leftarrow DEST[63:32] - SRC[63:32];

PSUBD (with 128-bit operands)

DEST[31:0] ← DEST[31:0] – SRC[31:0]; (* Repeat subtract operation for 2nd and 3rd doubleword *) DEST[127:96] ← DEST[127:96] – SRC[127:96];

VPSUBB (VEX.128 encoded version)

DEST[7:0] \leftarrow SRC1[7:0]-SRC2[7:0]
DEST[15:8] \leftarrow SRC1[15:8]-SRC2[15:8]
DEST[23:16] \leftarrow SRC1[23:16]-SRC2[23:16]
DEST[31:24] \leftarrow SRC1[31:24]-SRC2[31:24]
DEST[39:32] \leftarrow SRC1[39:32]-SRC2[39:32]
DEST[47:40] \leftarrow SRC1[47:40]-SRC2[47:40]
DEST[55:48] \leftarrow SRC1[55:48]-SRC2[55:48]
DEST[63:56] \leftarrow SRC1[63:56]-SRC2[63:56]
DEST[71:64] \leftarrow SRC1[71:64]-SRC2[71:64]
DEST[79:72] \leftarrow SRC1[79:72]-SRC2[79:72]
DEST[87:80] \leftarrow SRC1[87:80]-SRC2[87:80]
DEST[95:88] \leftarrow SRC1[103:96]-SRC2[103:96]

```
DEST[111:104] \leftarrow SRC1[111:104]-SRC2[111:104]
DEST[119:112] \leftarrow SRC1[119:112]-SRC2[119:112]
DEST[127:120] \leftarrow SRC1[127:120]-SRC2[127:120]
DEST[VLMAX-1:128] \leftarrow 00
```

VPSUBW (VEX.128 encoded version)

```
DEST[15:0] \leftarrow SRC1[15:0]-SRC2[15:0]

DEST[31:16] \leftarrow SRC1[31:16]-SRC2[31:16]

DEST[47:32] \leftarrow SRC1[47:32]-SRC2[47:32]

DEST[63:48] \leftarrow SRC1[63:48]-SRC2[63:48]

DEST[79:64] \leftarrow SRC1[79:64]-SRC2[79:64]

DEST[95:80] \leftarrow SRC1[95:80]-SRC2[95:80]

DEST[111:96] \leftarrow SRC1[111:96]-SRC2[111:96]

DEST[127:112] \leftarrow SRC1[127:112]-SRC2[127:112]

DEST[VLMAX-1:128] \leftarrow 0
```

VPSUBD (VEX.128 encoded version)

```
DEST[31:0] \leftarrow SRC1[31:0]-SRC2[31:0]
DEST[63:32] \leftarrow SRC1[63:32]-SRC2[63:32]
DEST[95:64] \leftarrow SRC1[95:64]-SRC2[95:64]
DEST[127:96] \leftarrow SRC1[127:96]-SRC2[127:96]
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PSUBB __m64 _mm_sub_pi8(__m64 m1, __m64 m2)
PSUBW __m64 _mm_sub_pi16(__m64 m1, __m64 m2)
PSUBD __m64 _mm_sub_pi32(__m64 m1, __m64 m2)
PSUBB __m128i _mm_sub_epi8 ( __m128i a, __m128i b)
PSUBW __m128i _mm_sub_epi16 ( __m128i a, __m128i b)
PSUBD __m128i _mm_sub_epi32 ( __m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PSUBQ—Subtra	ct Packed	Quadword	Integers
--------------	-----------	----------	----------

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF FB /r ¹ PSUBQ mm1, mm2/m64	Α	V/V	SSE2	Subtract quadword integer in <i>mm1</i> from <i>mm2</i> / <i>m64</i> .
66 OF FB /r PSUBQ xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed quadword integers in <i>xmm1</i> from <i>xmm2 /m128</i> .
VEX.NDS.128.66.0F.WIG FB/r VPSUBQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed quadword integers in xmm3/m128 from xmm2.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Subtracts the second operand (source operand) from the first operand (destination operand) and stores the result in the destination operand. The source operand can be a quadword integer stored in an MMX technology register or a 64-bit memory location, or it can be two packed quadword integers stored in an XMM register or an 128-bit memory location. The destination operand can be a quadword integer stored in an MMX technology register or two packed quadword integers stored in an XMM register. When packed quadword operands are used, a SIMD subtract is performed. When a quadword result is too large to be represented in 64 bits (overflow), the result is wrapped around and the low 64 bits are written to the destination element (that is, the carry is ignored).

Note that the PSUBQ instruction can operate on either unsigned or signed (two's complement notation) integers; however, it does not set bits in the EFLAGS register to indicate overflow and/or a carry. To prevent undetected overflow conditions, software must control the ranges of the values upon which it operates.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSUBQ (with 64-Bit operands)

```
DEST[63:0] \leftarrow DEST[63:0] - SRC[63:0];
```

PSUBQ (with 128-Bit operands)

```
DEST[63:0] \leftarrow DEST[63:0] – SRC[63:0];
DEST[127:64] \leftarrow DEST[127:64] – SRC[127:64];
```

VPSUBQ (VEX.128 encoded version)

```
DEST[63:0] \leftarrow SRC1[63:0]-SRC2[63:0]
DEST[127:64] \leftarrow SRC1[127:64]-SRC2[127:64]
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PSUBQ __m64 _mm_sub_si64(__m64 m1, __m64 m2)
PSUBO m128i mm sub_epi64(_m128i m1, __m128i m2)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PSUBSB/PSUBSW—Subtract Packed Signed Integers with Signed Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF E8 /r ¹ PSUBSB mm, mm/m64	Α	V/V	MMX	Subtract signed packed bytes in <i>mm/m64</i> from signed packed bytes in <i>mm</i> and saturate results.
66 OF E8 /r PSUBSB xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed signed byte integers in xmm2/m128 from packed signed byte integers in xmm1 and saturate results.
OF E9 /r ¹ PSUBSW mm, mm/m64	Α	V/V	MMX	Subtract signed packed words in <i>mm/m64</i> from signed packed words in <i>mm</i> and saturate results.
66 OF E9 /r PSUBSW xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed signed word integers in xmm2/m128 from packed signed word integers in xmm1 and saturate results.
VEX.NDS.128.66.0F.WIG E8 /r VPSUBSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed signed byte integers in xmm3/m128 from packed signed byte integers in xmm2 and saturate results.
VEX.NDS.128.66.0F.WIG E9 /r VPSUBSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed signed word integers in xmm3/m128 from packed signed word integers in xmm2 and saturate results.

NOTES:

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

		mod control operation	mooding .	
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Instruction Operand Encoding

Description

Performs a SIMD subtract of the packed signed integers of the source operand (second operand) from the packed signed integers of the destination operand (first operand), and stores the packed integer results in the destination operand. See Figure 9-4 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD operation. Overflow is handled with signed saturation, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

The PSUBSB instruction subtracts packed signed byte integers. When an individual byte result is beyond the range of a signed byte integer (that is, greater than 7FH or less than 80H), the saturated value of 7FH or 80H, respectively, is written to the destination operand.

The PSUBSW instruction subtracts packed signed word integers. When an individual word result is beyond the range of a signed word integer (that is, greater than 7FFFH or less than 8000H), the saturated value of 7FFFH or 8000H, respectively, is written to the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSUBSB (with 64-bit operands)

DEST[7:0] \leftarrow SaturateToSignedByte (DEST[7:0] – SRC (7:0]); (* Repeat subtract operation for 2nd through 7th bytes *) DEST[63:56] \leftarrow SaturateToSignedByte (DEST[63:56] – SRC[63:56]);

PSUBSB (with 128-bit operands)

DEST[7:0] \leftarrow SaturateToSignedByte (DEST[7:0] - SRC[7:0]);

```
(* Repeat subtract operation for 2nd through 14th bytes *)
DEST[127:120] ← SaturateToSignedByte (DEST[127:120] − SRC[127:120]);
```

PSUBSW (with 64-bit operands)

```
DEST[15:0] \leftarrow SaturateToSignedWord (DEST[15:0] – SRC[15:0]); (* Repeat subtract operation for 2nd and 7th words *) DEST[63:48] \leftarrow SaturateToSignedWord (DEST[63:48] – SRC[63:48]);
```

PSUBSW (with 128-bit operands)

```
DEST[15:0] \leftarrow SaturateToSignedWord (DEST[15:0] – SRC[15:0]); (* Repeat subtract operation for 2nd through 7th words *) DEST[127:112] \leftarrow SaturateToSignedWord (DEST[127:112] – SRC[127:112]);
```

VPSUBSB

```
DEST[7:0] \leftarrow SaturateToSignedByte (SRC1[7:0] - SRC2[7:0]); (* Repeat subtract operation for 2nd through 14th bytes *) DEST[127:120] \leftarrow SaturateToSignedByte (SRC1[127:120] - SRC2[127:120]); DEST[VLMAX-1:128] \leftarrow 0
```

VPSUBSW

```
DEST[15:0] \leftarrow SaturateToSignedWord (SRC1[15:0] - SRC2[15:0]); (* Repeat subtract operation for 2nd through 7th words *) DEST[127:112] \leftarrow SaturateToSignedWord (SRC1[127:112] - SRC2[127:112]); DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PSUBSB __m64 _mm_subs_pi8(__m64 m1, __m64 m2)

PSUBSB __m128i _mm_subs_epi8(__m128i m1, __m128i m2)

PSUBSW __m64 _mm_subs_pi16(__m64 m1, __m64 m2)

PSUBSW __m128i _mm_subs_epi16(__m128i m1, __m128i m2)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PSUBUSB/PSUBUSW—Subtract Packed Unsigned Integers with Unsigned Saturation

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF D8 /r ¹ PSUBUSB mm, mm/m64	А	V/V	MMX	Subtract unsigned packed bytes in <i>mm/m64</i> from unsigned packed bytes in <i>mm</i> and saturate result.
66 OF D8 /r PSUBUSB xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed unsigned byte integers in xmm2/m128 from packed unsigned byte integers in xmm1 and saturate result.
OF D9 /r ¹ PSUBUSW mm, mm/m64	А	V/V	MMX	Subtract unsigned packed words in <i>mm/m64</i> from unsigned packed words in <i>mm</i> and saturate result.
66 OF D9 /r PSUBUSW xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed unsigned word integers in xmm2/m128 from packed unsigned word integers in xmm1 and saturate result.
VEX.NDS.128.66.0F.WIG D8 /r VPSUBUSB xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed unsigned byte integers in xmm3/m128 from packed unsigned byte integers in xmm2 and saturate result.
VEX.NDS.128.66.0F.WIG D9 /r VPSUBUSW xmm1, xmm2, xmm3/m128	В	V/V	AVX	Subtract packed unsigned word integers in xmm3/m128 from packed unsigned word integers in xmm2 and saturate result.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (г, w)	ModRM:r/m (r)	NA	NA

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD subtract of the packed unsigned integers of the source operand (second operand) from the packed unsigned integers of the destination operand (first operand), and stores the packed unsigned integer results in the destination operand. See Figure 9-4 in the *Intel*® 64 and *IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD operation. Overflow is handled with unsigned saturation, as described in the following paragraphs.

These instructions can operate on either 64-bit or 128-bit operands. When operating on 64-bit operands, the destination operand must be an MMX technology register and the source operand can be either an MMX technology register or a 64-bit memory location. When operating on 128-bit operands, the destination operand must be an XMM register and the source operand can be either an XMM register or a 128-bit memory location.

The PSUBUSB instruction subtracts packed unsigned byte integers. When an individual byte result is less than zero, the saturated value of 00H is written to the destination operand.

The PSUBUSW instruction subtracts packed unsigned word integers. When an individual word result is less than zero, the saturated value of 0000H is written to the destination operand.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PSUBUSB (with 64-bit operands)

```
\label{eq:DEST[7:0]} $\leftarrow$ SaturateToUnsignedByte (DEST[7:0] - SRC (7:0] ); $$(* Repeat add operation for 2nd through 7th bytes *) $$DEST[63:56] $\leftarrow$ SaturateToUnsignedByte (DEST[63:56] - SRC[63:56]; $$
```

PSUBUSB (with 128-bit operands)

```
DEST[7:0] ← SaturateToUnsignedByte (DEST[7:0] – SRC[7:0]);
(* Repeat add operation for 2nd through 14th bytes *)
DEST[127:120] ← SaturateToUnSignedByte (DEST[127:120] – SRC[127:120]);
```

PSUBUSW (with 64-bit operands)

DEST[15:0] \leftarrow SaturateToUnsignedWord (DEST[15:0] – SRC[15:0]);

```
(* Repeat add operation for 2nd and 3rd words *)
DEST[63:48] ← SaturateToUnsignedWord (DEST[63:48] − SRC[63:48]);
```

PSUBUSW (with 128-bit operands)

```
DEST[15:0] ← SaturateToUnsignedWord (DEST[15:0] – SRC[15:0]); (* Repeat add operation for 2nd through 7th words *)
DEST[127:112] ← SaturateToUnSignedWord (DEST[127:112] – SRC[127:112]);
```

VPSUBUSB

```
DEST[7:0] \leftarrow SaturateToUnsignedByte (SRC1[7:0] - SRC2[7:0]); (* Repeat subtract operation for 2nd through 14th bytes *) DEST[127:120] \leftarrow SaturateToUnsignedByte (SRC1[127:120] - SRC2[127:120]); DEST[VLMAX-1:128] \leftarrow 0
```

VPSUBUSW

```
\label{eq:def:DEST[15:0]} \begin{split} & \mathsf{CST}[15:0] \leftarrow \mathsf{SaturateToUnsignedWord} \ (\mathsf{SRC1}[15:0] - \mathsf{SRC2}[15:0]); \\ & (\mathsf{*Repeat} \ \mathsf{subtract} \ \mathsf{operation} \ \mathsf{for} \ \mathsf{2nd} \ \mathsf{through} \ \mathsf{7th} \ \mathsf{words} \ \mathsf{*}) \\ & \mathsf{DEST}[127:112] \leftarrow \mathsf{SaturateToUnsignedWord} \ (\mathsf{SRC1}[127:112] - \mathsf{SRC2}[127:112]); \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow \mathsf{0} \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalents

```
PSUBUSB __m64 _mm_subs_pu8(__m64 m1, __m64 m2)
PSUBUSB __m128i _mm_subs_epu8(__m128i m1, __m128i m2)
PSUBUSW __m64 _mm_subs_pu16(__m64 m1, __m64 m2)
PSUBUSW __m128i _mm_subs_epu16(__m128i m1, __m128i m2)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

```
See Exceptions Type 4; additionally #UD If VEX.L = 1.
```

PTEST- Logical Compare

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 38 17 /r PTEST xmm1, xmm2/m128	Α	V/V	SSE4_1	Set ZF if xmm2/m128 AND xmm1 result is all 0s. Set CF if xmm2/m128 AND NOT xmm1 result is all 0s.
VEX.128.66.0F38.WIG 17 /r VPTEST xmm1, xmm2/m128	А	V/V	AVX	Set ZF and CF depending on bitwise AND and ANDN of sources.
VEX.256.66.0F38.WIG 17 /r VPTEST ymm1, ymm2/m256	A	V/V	AVX	Set ZF and CF depending on bitwise AND and ANDN of sources.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	NA	NA

Description

PTEST and VPTEST set the ZF flag if all bits in the result are 0 of the bitwise AND of the first source operand (first operand) and the second source operand (second operand). VPTEST sets the CF flag if all bits in the result are 0 of the bitwise AND of the second source operand (second operand) and the logical NOT of the destination operand.

The first source register is specified by the ModR/M reg field.

128-bit versions: The first source register is an XMM register. The second source register can be an XMM register or a 128-bit memory location. The destination register is not modified.

VEX.256 encoded version: The first source register is a YMM register. The second source register can be a YMM register or a 256-bit memory location. The destination register is not modified.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

(V)PTEST (128-bit version)

IF (SRC[127:0] BITWISE AND DEST[127:0] = 0) THEN ZF \leftarrow 1; ELSE ZF \leftarrow 0;

```
IF (SRC[127:0] BITWISE AND NOT DEST[127:0] = 0)
   THEN CF \leftarrow 1;
   ELSE CF \leftarrow 0:
DEST (unmodified)
AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O;
VPTEST (VEX.256 encoded version)
IF (SRC[255:0] BITWISE AND DEST[255:0] = 0) THEN ZF \leftarrow 1;
   ELSE ZF \leftarrow 0;
IF (SRC[255:0] BITWISE AND NOT DEST[255:0] = 0) THEN CF \leftarrow 1;
   ELSE CF \leftarrow 0;
DEST (unmodified)
AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O;
Intel C/C++ Compiler Intrinsic Equivalent
PTEST int _mm_testz_si128 (__m128i s1, __m128i s2);
        int _mm_testc_si128 (__m128i s1, __m128i s2);
        int _mm_testnzc_si128 (__m128i s1, __m128i s2);
VPTEST
int _mm256_testz_si256 (__m256i s1, __m256i s2);
int mm256 testc si256 ( m256i s1, m256i s2);
int _mm256_testnzc_si256 (__m256i s1, __m256i s2);
int _mm_testz_si128 (__m128i s1, __m128i s2);
int _mm_testc_si128 (__m128i s1, __m128i s2);
int _mm_testnzc_si128 (__m128i s1, __m128i s2);
Flags Affected
The OF, AF, PF, SF flags are cleared and the ZF, CF flags are set according to the oper-
ation.
SIMD Floating-Point Exceptions
None.
Other Exceptions
See Exceptions Type 4; additionally
#UD
                        If VEX.vvvv != 1111B.
```

PUNPCKHBW/PUNPCKHWD/PUNPCKHDQ/PUNPCKHQDQ— Unpack High Data

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 68 /r ¹ PUNPCKHBW mm, mm/m64	Α	V/V	MMX	Unpack and interleave highorder bytes from <i>mm</i> and <i>mm/m64</i> into <i>mm</i> .
66 OF 68 /r PUNPCKHBW xmm1, xmm2/m128	Α	V/V	SSE2	Unpack and interleave high- order bytes from <i>xmm1</i> and <i>xmm2/m128</i> into <i>xmm1</i> .
OF 69 /r ¹ PUNPCKHWD mm, mm/m64	Α	V/V	MMX	Unpack and interleave highorder words from <i>mm</i> and <i>mm/m64</i> into <i>mm</i> .
66 0F 69 /r PUNPCKHWD xmm1, xmm2/m128	Α	V/V	SSE2	Unpack and interleave high- order words from <i>xmm1</i> and <i>xmm2/m128</i> into <i>xmm1</i> .
OF 6A /r ¹ PUNPCKHDQ mm, mm/m64	Α	V/V	MMX	Unpack and interleave high- order doublewords from <i>mm</i> and <i>mm/m64</i> into <i>mm</i> .
66 OF 6A /r PUNPCKHDQ xmm1, xmm2/m128	Α	V/V	SSE2	Unpack and interleave high- order doublewords from xmm1 and xmm2/m128 into xmm1.
66 OF 6D /r PUNPCKHQDQ xmm1, xmm2/m128	Α	V/V	SSE2	Unpack and interleave high- order quadwords from xmm1 and xmm2/m128 into xmm1.
VEX.NDS.128.66.0F.WIG 68/r VPUNPCKHBW xmm1,xmm2, xmm3/m128	В	V/V	AVX	Interleave high-order bytes from xmm2 and xmm3/m128 into xmm1.
VEX.NDS.128.66.0F.WIG 69/r VPUNPCKHWD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Interleave high-order words from xmm2 and xmm3/m128 into xmm1.
VEX.NDS.128.66.0F.WIG 6A/r VPUNPCKHDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Interleave high-order doublewords from xmm2 and xmm3/m128 into xmm1.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128.66.0F.WIG 6D/r VPUNPCKHQDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Interleave high-order quadword from xmm2 and xmm3/m128 into xmm1 register.

NOTES:

1. See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Unpacks and interleaves the high-order data elements (bytes, words, doublewords, or quadwords) of the destination operand (first operand) and source operand (second operand) into the destination operand. Figure 4-12 shows the unpack operation for bytes in 64-bit operands. The low-order data elements are ignored.




Figure 4-12. PUNPCKHBW Instruction Operation Using 64-bit Operands

The source operand can be an MMX technology register or a 64-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. When the source data comes from a 64-bit memory operand, the full 64-bit operand is accessed from memory, but the instruction uses only the high-order 32 bits. When the source data comes from a

128-bit memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to a 16-byte boundary and normal segment checking will still be enforced.

The PUNPCKHBW instruction interleaves the high-order bytes of the source and destination operands, the PUNPCKHWD instruction interleaves the high-order words of the source and destination operands, the PUNPCKHDQ instruction interleaves the high-order doubleword (or doublewords) of the source and destination operands, and the PUNPCKHQDQ instruction interleaves the high-order quadwords of the source and destination operands.

These instructions can be used to convert bytes to words, words to doublewords, doublewords to quadwords, and quadwords to double quadwords, respectively, by placing all 0s in the source operand. Here, if the source operand contains all 0s, the result (stored in the destination operand) contains zero extensions of the high-order data elements from the original value in the destination operand. For example, with the PUNPCKHBW instruction the high-order bytes are zero extended (that is, unpacked into unsigned word integers), and with the PUNPCKHWD instruction, the high-order words are zero extended (unpacked into unsigned doubleword integers).

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE versions: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded versions: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

```
PUNPCKHBW instruction with 64-bit operands:
```

DEST[7:0] \leftarrow DEST[39:32];

DEST[15:8] \leftarrow SRC[39:32];

DEST[23:16] \leftarrow DEST[47:40];

DEST[31:24] \leftarrow SRC[47:40];

DEST[39:32] \leftarrow DEST[55:48];

DEST[47:40] \leftarrow SRC[55:48];

DEST[55:48] \leftarrow DEST[63:56];

DEST[63:56] \leftarrow SRC[63:56];

PUNPCKHW instruction with 64-bit operands:

DEST[15:0] \leftarrow DEST[47:32];

DEST[31:16] \leftarrow SRC[47:32];

DEST[47:32] \leftarrow DEST[63:48];

DEST[63:48] \leftarrow SRC[63:48];

PUNPCKHDQ instruction with 64-bit operands:

DEST[31:0] \leftarrow DEST[63:32];

```
DEST[63:32] \leftarrow SRC[63:32];
PUNPCKHBW instruction with 128-bit operands:
    DEST[7:0]← DEST[71:64];
   DEST[15:8] \leftarrow SRC[71:64];
    DEST[23:16] \leftarrow DEST[79:72];
   DEST[31:24] \leftarrow SRC[79:72];
   DEST[39:32] \leftarrow DEST[87:80];
   DEST[47:40] \leftarrow SRC[87:80];
   DEST[55:48] \leftarrow DEST[95:88];
   DEST[63:56] \leftarrow SRC[95:88];
   DEST[71:64] \leftarrow DEST[103:96];
   DEST[79:72] \leftarrow SRC[103:96];
   DEST[87:80] \leftarrow DEST[111:104];
   DEST[95:88] \leftarrow SRC[111:104];
   DEST[103:96] \leftarrow DEST[119:112];
   DEST[111:104] \leftarrow SRC[119:112];
   DEST[119:112] \leftarrow DEST[127:120];
   DEST[127:120] \leftarrow SRC[127:120];
PUNPCKHWD instruction with 128-bit operands:
   DEST[15:0] \leftarrow DEST[79:64];
   DEST[31:16] \leftarrow SRC[79:64];
   DEST[47:32] \leftarrow DEST[95:80];
   DEST[63:48] \leftarrow SRC[95:80];
   DEST[79:64] \leftarrow DEST[111:96];
   DEST[95:80] \leftarrow SRC[111:96];
   DEST[111:96] \leftarrow DEST[127:112];
   DEST[127:112] \leftarrow SRC[127:112];
PUNPCKHDQ instruction with 128-bit operands:
    DEST[31:0] \leftarrow DEST[95:64];
   DEST[63:32] \leftarrow SRC[95:64]:
    DEST[95:64] \leftarrow DEST[127:96];
   DEST[127:96] \leftarrow SRC[127:96];
PUNPCKHQDQ instruction:
    DEST[63:0] \leftarrow DEST[127:64];
   DEST[127:64] \leftarrow SRC[127:64];
PUNPCKHBW
DEST[127:0] ← INTERLEAVE HIGH BYTES(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)
```

VPUNPCKHBW

DEST[127:0] \leftarrow INTERLEAVE_HIGH_BYTES(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

PUNPCKHWD

DEST[127:0] ← INTERLEAVE_HIGH_WORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

VPUNPCKHWD

 $\begin{aligned} & \mathsf{DEST}[127:0] \leftarrow \mathsf{INTERLEAVE_HIGH_WORDS}(\mathsf{SRC1}, \mathsf{SRC2}) \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{aligned}$

PUNPCKHDO

DEST[127:0] ← INTERLEAVE_HIGH_DWORDS(DEST, SRC)
DEST[VLMAX-1:128] (Unmodified)

VPUNPCKHDQ

DEST[127:0] \leftarrow INTERLEAVE_HIGH_DWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

PUNPCKHQDQ

DEST[127:0] ← INTERLEAVE_HIGH_QWORDS(DEST, SRC) DEST[VLMAX-1:128] (Unmodified)

VPUNPCKHQDQ

DEST[127:0] ← INTERLEAVE HIGH QWORDS(SRC1, SRC2)

DEST[VLMAX-1:128] $\leftarrow 0$

Intel C/C++ Compiler Intrinsic Equivalents

```
        PUNPCKHBW
        __m64 _mm_unpackhi_pi8(__m64 m1, __m64 m2)

        PUNPCKHBW
        __m128i _mm_unpackhi_epi8(__m128i m1, __m128i m2)

        PUNPCKHWD
        __m64 _mm_unpackhi_pi16(__m64 m1, __m64 m2)

        PUNPCKHWD
        __m128i _mm_unpackhi_epi16(__m128i m1, __m128i m2)

        PUNPCKHDQ
        __m64 _mm_unpackhi_epi32(__m64 m1, __m64 m2)

        PUNPCKHDQ
        _m128i _mm_unpackhi_epi32(__m128i m1, __m128i m2)

        PUNPCKHQDQ
        m128i _mm_unpackhi_epi64 (__m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

PUNPCKLBW/PUNPCKLWD/PUNPCKLDQ/PUNPCKLQDQ— Unpack Low Data

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 60 /r ¹ PUNPCKLBW mm, mm/m32	Α	V/V	MMX	Interleave low-order bytes from <i>mm</i> and <i>mm/m32</i> into <i>mm</i> .
66 OF 60 /r PUNPCKLBW xmm1, xmm2/m128	Α	V/V	SSE2	Interleave low-order bytes from xmm1 and xmm2/m128 into xmm1.
OF 61 /r ¹ PUNPCKLWD mm, mm/m32	Α	V/V	MMX	Interleave low-order words from <i>mm</i> and <i>mm/m32</i> into <i>mm</i> .
66 OF 61 /r PUNPCKLWD xmm1, xmm2/m128	Α	V/V	SSE2	Interleave low-order words from xmm1 and xmm2/m128 into xmm1.
OF 62 /r ¹ PUNPCKLDQ mm, mm/m32	Α	V/V	MMX	Interleave low-order doublewords from <i>mm</i> and <i>mm/m32</i> into <i>mm</i> .
66 OF 62 /r PUNPCKLDQ xmm1, xmm2/m128	Α	V/V	SSE2	Interleave low-order doublewords from xmm1 and xmm2/m128 into xmm1.
66 OF 6C /r PUNPCKLQDQ xmm1, xmm2/m128	Α	V/V	SSE2	Interleave low-order quadword from xmm1 and xmm2/m128 into xmm1 register.
VEX.NDS.128.66.0F.WIG 60/r VPUNPCKLBW xmm1,xmm2, xmm3/m128	В	V/V	AVX	Interleave low-order bytes from xmm2 and xmm3/m128 into xmm1.
VEX.NDS.128.66.0F.WIG 61/r VPUNPCKLWD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Interleave low-order words from xmm2 and xmm3/m128 into xmm1.
VEX.NDS.128.66.0F.WIG 62/r VPUNPCKLDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Interleave low-order doublewords from xmm2 and xmm3/m128 into xmm1.

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128.66.0F.WIG 6C/r VPUNPCKLQDQ xmm1, xmm2, xmm3/m128	В	V/V	AVX	Interleave low-order quadword from xmm2 and xmm3/m128 into xmm1 register.

NOTES:

1. See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Unpacks and interleaves the low-order data elements (bytes, words, doublewords, and quadwords) of the destination operand (first operand) and source operand (second operand) into the destination operand. (Figure 4-13 shows the unpack operation for bytes in 64-bit operands.). The high-order data elements are ignored.




Figure 4-13. PUNPCKLBW Instruction Operation Using 64-bit Operands

The source operand can be an MMX technology register or a 32-bit memory location, or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. When the source data comes from a 128-bit memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to a 16-byte boundary and normal segment checking will still be enforced.

The PUNPCKLBW instruction interleaves the low-order bytes of the source and destination operands, the PUNPCKLWD instruction interleaves the low-order words of the source and destination operands, the PUNPCKLDQ instruction interleaves the low-order doubleword (or doublewords) of the source and destination operands, and the PUNPCKLQDQ instruction interleaves the low-order quadwords of the source and destination operands.

These instructions can be used to convert bytes to words, words to doublewords, doublewords to quadwords, and quadwords to double quadwords, respectively, by placing all 0s in the source operand. Here, if the source operand contains all 0s, the result (stored in the destination operand) contains zero extensions of the high-order data elements from the original value in the destination operand. For example, with the PUNPCKLBW instruction the high-order bytes are zero extended (that is, unpacked into unsigned word integers), and with the PUNPCKLWD instruction, the high-order words are zero extended (unpacked into unsigned doubleword integers).

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE versions: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded versions: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

```
PUNPCKLBW instruction with 64-bit operands:
    DEST[63:56] \leftarrow SRC[31:24];
    DEST[55:48] \leftarrow DEST[31:24];
    DEST[47:40] \leftarrow SRC[23:16];
    DEST[39:32] \leftarrow DEST[23:16];
    DEST[31:24] \leftarrow SRC[15:8];
    DEST[23:16] \leftarrow DEST[15:8];
    DEST[15:8] \leftarrow SRC[7:0];
    DEST[7:0] \leftarrow DEST[7:0];
PUNPCKLWD instruction with 64-bit operands:
    DEST[63:48] \leftarrow SRC[31:16];
    DEST[47:32] \leftarrow DEST[31:16];
    DEST[31:16] \leftarrow SRC[15:0];
    DEST[15:0] \leftarrow DEST[15:0];
PUNPCKLDQ instruction with 64-bit operands:
    DEST[63:32] \leftarrow SRC[31:0];
    DEST[31:0] \leftarrow DEST[31:0];
PUNPCKLBW instruction with 128-bit operands:
    DEST[7:0] \leftarrow DEST[7:0];
```

```
DEST[15:8] \leftarrow SRC[7:0];
    DEST[23:16] \leftarrow DEST[15:8];
    DEST[31:24] \leftarrow SRC[15:8];
    DEST[39:32] \leftarrow DEST[23:16];
    DEST[47:40] \leftarrow SRC[23:16];
    DEST[55:48] \leftarrow DEST[31:24];
    DEST[63:56] \leftarrow SRC[31:24];
    DEST[71:64] \leftarrow DEST[39:32];
    DEST[79:72] \leftarrow SRC[39:32];
    DEST[87:80] \leftarrow DEST[47:40];
    DEST[95:88] \leftarrow SRC[47:40];
    DEST[103:96] \leftarrow DEST[55:48];
    DEST[111:104] \leftarrow SRC[55:48];
    DEST[119:112] \leftarrow DEST[63:56];
    DEST[127:120] \leftarrow SRC[63:56];
PUNPCKLWD instruction with 128-bit operands:
    DEST[15:0] \leftarrow DEST[15:0];
    DEST[31:16] \leftarrow SRC[15:0];
    DEST[47:32] \leftarrow DEST[31:16];
    DEST[63:48] \leftarrow SRC[31:16];
    DEST[79:64] \leftarrow DEST[47:32];
    DEST[95:80] \leftarrow SRC[47:32];
    DEST[111:96] \leftarrow DEST[63:48];
    DEST[127:112] \leftarrow SRC[63:48];
PUNPCKLDQ instruction with 128-bit operands:
    DEST[31:0] \leftarrow DEST[31:0];
    DEST[63:32] \leftarrow SRC[31:0];
    DEST[95:64] \leftarrow DEST[63:32];
    DEST[127:96] \leftarrow SRC[63:32];
PUNPCKLQDQ
    DEST[63:0] \leftarrow DEST[63:0];
    DEST[127:64] \leftarrow SRC[63:0];
VPUNPCKLBW
DEST[127:0] ← INTERLEAVE BYTES(SRC1, SRC2)
DEST[VLMAX-1:128] \leftarrow 0
```

VPUNPCKLWD

DEST[127:0] \leftarrow INTERLEAVE_WORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPUNPCKLDQ

DEST[127:0] \leftarrow INTERLEAVE_DWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

VPUNPCKLQDQ

DEST[127:0] \leftarrow INTERLEAVE_QWORDS(SRC1, SRC2) DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalents

```
        PUNPCKLBW
        __m64 _mm_unpacklo_pi8 (__m64 m1, __m64 m2)

        PUNPCKLBW
        __m128i _mm_unpacklo_epi8 (__m128i m1, __m128i m2)

        PUNPCKLWD
        __m64 _mm_unpacklo_pi16 (__m64 m1, __m64 m2)

        PUNPCKLWD
        __m128i _mm_unpacklo_epi16 (__m128i m1, __m128i m2)

        PUNPCKLDQ
        __m64 _mm_unpacklo_epi32 (__m64 m1, __m64 m2)

        PUNPCKLDQ
        __m128i _mm_unpacklo_epi32 (__m128i m1, __m128i m2)

        PUNPCKLQDQ
        __m128i _mm_unpacklo_epi64 (__m128i m1, __m128i m2)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
FF /6	PUSH r/m16	Α	Valid	Valid	Push <i>r/m16</i> .
FF /6	PUSH r/m32	Α	N.E.	Valid	Push <i>r/m32.</i>
FF /6	PUSH r/m64	Α	Valid	N.E.	Push r/m64.
50+ <i>rw</i>	PUSH r16	В	Valid	Valid	Push <i>r16</i> .
50+ <i>rd</i>	PUSH <i>r32</i>	В	N.E.	Valid	Push <i>r32.</i>
50+ <i>rd</i>	PUSH r64	В	Valid	N.E.	Push <i>r64</i> .
6A	PUSH imm8	С	Valid	Valid	Push imm8.
68	PUSH imm16	С	Valid	Valid	Push imm16.
68	PUSH imm32	С	Valid	Valid	Push imm32.
0E	PUSH CS	D	Invalid	Valid	Push CS.
16	PUSH SS	D	Invalid	Valid	Push SS.
1E	PUSH DS	D	Invalid	Valid	Push DS.
06	PUSH ES	D	Invalid	Valid	Push ES.
OF AO	PUSH FS	D	Valid	Valid	Push FS.
0F A8	PUSH GS	D	Valid	Valid	Push GS.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r)	NA	NA	NA
В	reg (r)	NA	NA	NA
С	imm8/16/32	NA	NA	NA
D	NA	NA	NA	NA

Description

Decrements the stack pointer and then stores the source operand on the top of the stack. Address and operand sizes are determined and used as follows:

• Address size. The D flag in the current code-segment descriptor determines the default address size; it may be overridden by an instruction prefix (67H).

The address size is used only when referencing a source operand in memory.

^{*} See IA-32 Architecture Compatibility section below.

 Operand size. The D flag in the current code-segment descriptor determines the default operand size; it may be overridden by instruction prefixes (66H or REX.W).

The operand size (16, 32, or 64 bits) determines the amount by which the stack pointer is decremented (2, 4 or 8).

If the source operand is an immediate and its size is less than the operand size, a sign-extended value is pushed on the stack. If the source operand is a segment register (16 bits) and the operand size is greater than 16 bits, a zero-extended value is pushed on the stack.

• Stack-address size. Outside of 64-bit mode, the B flag in the current stacksegment descriptor determines the size of the stack pointer (16 or 32 bits); in 64-bit mode, the size of the stack pointer is always 64 bits.

The stack-address size determines the width of the stack pointer when writing to the stack in memory and when decrementing the stack pointer. (As stated above, the amount by which the stack pointer is decremented is determined by the operand size.)

If the operand size is less than the stack-address size, the PUSH instruction may result in a misaligned stack pointer (a stack pointer that is not aligned on a doubleword or quadword boundary).

The PUSH ESP instruction pushes the value of the ESP register as it existed before the instruction was executed. If a PUSH instruction uses a memory operand in which the ESP register is used for computing the operand address, the address of the operand is computed before the ESP register is decremented.

If the ESP or SP register is 1 when the PUSH instruction is executed in real-address mode, a stack-fault exception (#SS) is generated (because the limit of the stack segment is violated). Its delivery encounters a second stack-fault exception (for the same reason), causing generation of a double-fault exception (#DF). Delivery of the double-fault exception encounters a third stack-fault exception, and the logical processor enters shutdown mode. See the discussion of the double-fault exception in Chapter 6 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

IA-32 Architecture Compatibility

For IA-32 processors from the Intel 286 on, the PUSH ESP instruction pushes the value of the ESP register as it existed before the instruction was executed. (This is also true for Intel 64 architecture, real-address and virtual-8086 modes of IA-32 architecture.) For the Intel[®] 8086 processor, the PUSH SP instruction pushes the new value of the SP register (that is the value after it has been decremented by 2).

Operation

IF SRC is a segment register THEN

```
IF operand size = 16
              THEN TEMP \leftarrow SRC;
              ELSE TEMP \leftarrow ZeroExtend(SRC);
                                                        (* extend to operand size *)
         FI:
ELSE IF SRC is immediate byte
    THEN TEMP \leftarrow SignExtend(SRC);
                                                        (* extend to operand size *)
ELSE IF SRC is immediate word
                                                        (* operand size is 16 *)
   THEN TEMP \leftarrow SRC:
ELSE IF SRC is immediate doubleword
                                                        (* operand size is 32 or 64 *)
   THEN
         IF operand size = 32
              THEN TEMP \leftarrow SRC:
              ELSE TEMP \leftarrow SignExtend(SRC);
                                                        (* extend to operand size of 64 *)
         FI:
ELSE IF SRC is in memory
   THEN TEMP \leftarrow SRC;
                                                        (* use address and operand sizes *)
   ELSE TEMP \leftarrow SRC;
                                                        (* SRC is register; use operand size *)
FI;
IF in 64-bit mode
                                                        (* stack-address size = 64 *)
   THEN
         IF operand size = 64
              THEN
                   RSP \leftarrow RSP - 8;
                   Memorv[RSP] \leftarrow TEMP;
                                                        (* Push quadword *)
              ELSE
                                                        (* operand size = 16 *)
                   RSP \leftarrow RSP - 2;
                   Memory[RSP] \leftarrow TEMP;
                                                        (* Push word *)
         FI:
ELSE IF stack-address size = 32
   THEN
         IF operand size = 32
              THEN
                   ESP \leftarrow ESP - 4;
                   \mathsf{Memory}[\mathsf{SS}:\mathsf{ESP}] \leftarrow \mathsf{TEMP};
                                                        (* Push doubleword *)
              ELSE
                                                        (* operand size = 16 *)
                   ESP \leftarrow ESP - 2;
                   Memory[SS:ESP] \leftarrow TEMP;
                                                        (* Push word *)
         FI:
   ELSE
                                                        (* stack-address size = 16 *)
         IF operand size = 32
              THEN
                   SP \leftarrow SP - 4;
                   Memory[SS:SP] \leftarrow TEMP;
                                                        (* Push doubleword *)
```

```
ELSE (* operand size = 16 *)  SP \leftarrow SP - 2; \\ Memory[SS:SP] \leftarrow TEMP; (* Push word *) \\ FI; \\ FI;
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

If the new value of the SP or ESP register is outside the stack

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form. #SS(0) If the stack address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

PUSHA/PUSHAD—Push All General-Purpose Registers

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
60	PUSHA	Α	Invalid	Valid	Push AX, CX, DX, BX, original SP, BP, SI, and DI.
60	PUSHAD	A	Invalid	Valid	Push EAX, ECX, EDX, EBX, original ESP, EBP, ESI, and EDI.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Pushes the contents of the general-purpose registers onto the stack. The registers are stored on the stack in the following order: EAX, ECX, EDX, EBX, ESP (original value), EBP, ESI, and EDI (if the current operand-size attribute is 32) and AX, CX, DX, BX, SP (original value), BP, SI, and DI (if the operand-size attribute is 16). These instructions perform the reverse operation of the POPA/POPAD instructions. The value pushed for the ESP or SP register is its value before prior to pushing the first register (see the "Operation" section below).

The PUSHA (push all) and PUSHAD (push all double) mnemonics reference the same opcode. The PUSHA instruction is intended for use when the operand-size attribute is 16 and the PUSHAD instruction for when the operand-size attribute is 32. Some assemblers may force the operand size to 16 when PUSHA is used and to 32 when PUSHAD is used. Others may treat these mnemonics as synonyms (PUSHA/PUSHAD) and use the current setting of the operand-size attribute to determine the size of values to be pushed from the stack, regardless of the mnemonic used.

In the real-address mode, if the ESP or SP register is 1, 3, or 5 when PUSHA/PUSHAD executes: an #SS exception is generated but not delivered (the stack error reported prevents #SS delivery). Next, the processor generates a #DF exception and enters a shutdown state as described in the #DF discussion in Chapter 6 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

This instruction executes as described in compatibility mode and legacy mode. It is not valid in 64-bit mode.

Operation

IF 64-bit Mode

THEN #UD

```
FI:
IF OperandSize = 32 (* PUSHAD instruction *)
   THEN
        Temp \leftarrow (ESP);
        Push(EAX);
        Push(ECX);
        Push(EDX);
        Push(EBX);
        Push(Temp);
        Push(EBP);
        Push(ESI):
        Push(EDI);
   ELSE (* OperandSize = 16, PUSHA instruction *)
        Temp \leftarrow (SP);
        Push(AX);
        Push(CX);
        Push(DX);
        Push(BX);
        Push(Temp);
        Push(BP);
        Push(SI);
        Push(DI);
FI:
```

Flags Affected

None.

Protected Mode Exceptions

#SS(0) If the starting or ending stack address is outside the stack

seament limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If the ESP or SP register contains 7, 9, 11, 13, or 15.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If the ESP or SP register contains 7, 9, 11, 13, or 15.

INSTRUCTION SET REFERENCE, N-Z

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#UD If in 64-bit mode.

PUSHF/PUSHFD—Push EFLAGS Register onto the Stack

			_		
Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
9C	PUSHF	Α	Valid	Valid	Push lower 16 bits of EFLAGS.
9C	PUSHFD	Α	N.E.	Valid	Push EFLAGS.
9C	PUSHFQ	Α	Valid	N.E.	Push RFLAGS.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Decrements the stack pointer by 4 (if the current operand-size attribute is 32) and pushes the entire contents of the EFLAGS register onto the stack, or decrements the stack pointer by 2 (if the operand-size attribute is 16) and pushes the lower 16 bits of the EFLAGS register (that is, the FLAGS register) onto the stack. These instructions reverse the operation of the POPF/POPFD instructions.

When copying the entire EFLAGS register to the stack, the VM and RF flags (bits 16 and 17) are not copied; instead, the values for these flags are cleared in the EFLAGS image stored on the stack. See Chapter 3 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for more information about the EFLAGS register.

The PUSHF (push flags) and PUSHFD (push flags double) mnemonics reference the same opcode. The PUSHF instruction is intended for use when the operand-size attribute is 16 and the PUSHFD instruction for when the operand-size attribute is 32. Some assemblers may force the operand size to 16 when PUSHF is used and to 32 when PUSHFD is used. Others may treat these mnemonics as synonyms (PUSHF/PUSHFD) and use the current setting of the operand-size attribute to determine the size of values to be pushed from the stack, regardless of the mnemonic used.

In 64-bit mode, the instruction's default operation is to decrement the stack pointer (RSP) by 8 and pushes RFLAGS on the stack. 16-bit operation is supported using the operand size override prefix 66H. 32-bit operand size cannot be encoded in this mode. When copying RFLAGS to the stack, the VM and RF flags (bits 16 and 17) are not copied; instead, values for these flags are cleared in the RFLAGS image stored on the stack.

When in virtual-8086 mode and the I/O privilege level (IOPL) is less than 3, the PUSHF/PUSHFD instruction causes a general protection exception (#GP).

In the real-address mode, if the ESP or SP register is 1 when PUSHF/PUSHFD instruction executes: an #SS exception is generated but not delivered (the stack error reported prevents #SS delivery). Next, the processor generates a #DF exception and enters a shutdown state as described in the #DF discussion in Chapter 6 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Operation

```
IF (PE = 0) or (PE = 1) and (VM = 0) or (VM = 1) and (VM = 3)
(* Real-Address Mode, Protected mode, or Virtual-8086 mode with IOPL equal to 3 *)
   THEN
        IF OperandSize = 32
            THEN
                 push (EFLAGS AND 00FCFFFFH);
                 (* VM and RF EFLAG bits are cleared in image stored on the stack *)
            ELSE
                 push (EFLAGS); (* Lower 16 bits only *)
        FI:
   ELSE IF 64-bit MODE (* In 64-bit Mode *)
        IF OperandSize = 64
            THFN
                 push (RFLAGS AND 00000000_00FCFFFFH);
                 (* VM and RF RFLAG bits are cleared in image stored on the stack; *)
            FLSE
                 push (EFLAGS); (* Lower 16 bits only *)
        FI:
   ELSE (* In Virtual-8086 Mode with IOPL less than 3 *)
        #GP(0); (* Trap to virtual-8086 monitor *)
FI;
```

Flags Affected

None.

Protected Mode Exceptions

#SS(0) If the new value of the ESP register is outside the stack segment

boundary.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If the I/O privilege level is less than 3.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while alignment

checking is enabled.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form. #SS(0) If the stack address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory reference is made while the current

privilege level is 3 and alignment checking is enabled.

#UD If the LOCK prefix is used.

PXOR—Logical Exclusive OR

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF EF /r ¹ PXOR mm, mm/m64	Α	V/V	MMX	Bitwise XOR of <i>mm/m64</i> and <i>mm</i> .
66 OF EF /r PXOR xmm1, xmm2/m128	Α	V/V	SSE2	Bitwise XOR of xmm2/m128 and xmm1.
VEX.NDS.128.66.0F.WIG EF /r VPXOR xmm1, xmm2, xmm3/m128	В	V/V	AVX	Bitwise XOR of xmm3/m128 and xmm2.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical exclusive-OR (XOR) operation on the source operand (second operand) and the destination operand (first operand) and stores the result in the destination operand. The source operand can be an MMX technology register or a 64-bit memory location or it can be an XMM register or a 128-bit memory location. The destination operand can be an MMX technology register or an XMM register. Each bit of the result is 1 if the corresponding bits of the two operands are different; each bit is 0 if the corresponding bits of the operands are the same.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: Bits (VLMAX-1:128) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed. VEX.L must be 0, otherwise instructions will #UD.

Operation

PXOR (128-bit Legacy SSE version)

^{1.} See note in Section 2.4, "Instruction Exception Specification" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A and Section 19.25.3, "Exception Conditions of Legacy SIMD Instructions Operating on MMX Registers" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

DEST ← DEST XOR SRC
DEST[VLMAX-1:128] (Unmodified)

VPXOR (VEX.128 encoded version)

DEST \leftarrow SRC1 XOR SRC2 DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
PXOR __m64 _mm_xor_si64 (__m64 m1, __m64 m2)
PXOR __m128i _mm_xor_si128 ( __m128i a, __m128i b)
```

Flags Affected

None.

Numeric Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.L = 1.

RCL/RCR/ROL/ROR-—Rotate

Opcode**	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
D0 /2	RCL <i>r/m8</i> , 1	Α	Valid	Valid	Rotate 9 bits (CF, r/m8) left once.
REX + D0 /2	RCL <i>r/m8*</i> , 1	Α	Valid	N.E.	Rotate 9 bits (CF, r/m8) left once.
D2 /2	RCL r/m8, CL	В	Valid	Valid	Rotate 9 bits (CF, r/m8) left CL times.
REX + D2 /2	RCL r/m8*, CL	В	Valid	N.E.	Rotate 9 bits (CF, r/m8) left CL times.
CO /2 ib	RCL r/m8, imm8	С	Valid	Valid	Rotate 9 bits (CF, r/m8) left imm8 times.
REX + CO /2 ib	RCL r/m8*, imm8	С	Valid	N.E.	Rotate 9 bits (CF, r/m8) left imm8 times.
D1 /2	RCL <i>r/m16</i> , 1	Α	Valid	Valid	Rotate 17 bits (CF, <i>r/m16</i>) left once.
D3 /2	RCL <i>r/m16</i> , CL	В	Valid	Valid	Rotate 17 bits (CF, r/m16) left CL times.
C1 /2 ib	RCL r/m16, imm8	С	Valid	Valid	Rotate 17 bits (CF, r/m16) left imm8 times.
D1 /2	RCL <i>r/m32</i> , 1	Α	Valid	Valid	Rotate 33 bits (CF, <i>r/m32</i>) left once.
REX.W + D1 /2	RCL <i>r/m64</i> , 1	Α	Valid	N.E.	Rotate 65 bits (CF, <i>r/m64</i>) left once. Uses a 6 bit count.
D3 /2	RCL <i>r/m32</i> , CL	В	Valid	Valid	Rotate 33 bits (CF, <i>r/m32</i>) left CL times.
REX.W + D3 /2	RCL r/m64, CL	В	Valid	N.E.	Rotate 65 bits (CF, r/m64) left CL times. Uses a 6 bit count.
C1 /2 ib	RCL r/m32, imm8	С	Valid	Valid	Rotate 33 bits (CF, r/m32) left imm8 times.
REX.W + C1 /2 ib	RCL r/m64, imm8	С	Valid	N.E.	Rotate 65 bits (CF, r/m64) left imm8 times. Uses a 6 bit count.
D0 /3	RCR <i>r/m8</i> , 1	Α	Valid	Valid	Rotate 9 bits (CF, <i>r/m8</i>) right once.
REX + D0 /3	RCR <i>r/m8*</i> , 1	Α	Valid	N.E.	Rotate 9 bits (CF, r/m8) right once.

Opcode**	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
D2 /3	RCR r/m8, CL	В	Valid	Valid	Rotate 9 bits (CF, r/m8) right CL times.
REX + D2 /3	RCR r/m8*, CL	В	Valid	N.E.	Rotate 9 bits (CF, r/m8) right CL times.
CO /3 ib	RCR r/m8, imm8	С	Valid	Valid	Rotate 9 bits (CF, r/m8) right imm8 times.
REX + CO /3 ib	RCR r/m8*, imm8	С	Valid	N.E.	Rotate 9 bits (CF, r/m8) right imm8 times.
D1 /3	RCR <i>r/m16</i> , 1	Α	Valid	Valid	Rotate 17 bits (CF, r/m16) right once.
D3 /3	RCR <i>r/m16</i> , CL	В	Valid	Valid	Rotate 17 bits (CF, r/m16) right CL times.
C1 /3 ib	RCR r/m16, imm8	С	Valid	Valid	Rotate 17 bits (CF, r/m16) right imm8 times.
D1 /3	RCR <i>r/m32</i> , 1	Α	Valid	Valid	Rotate 33 bits (CF, r/m32) right once. Uses a 6 bit count.
REX.W + D1 /3	RCR <i>r/m64</i> , 1	Α	Valid	N.E.	Rotate 65 bits (CF, r/m64) right once. Uses a 6 bit count.
D3 /3	RCR <i>r/m32</i> , CL	В	Valid	Valid	Rotate 33 bits (CF, r/m32) right CL times.
REX.W + D3 /3	RCR r/m64, CL	В	Valid	N.E.	Rotate 65 bits (CF, r/m64) right CL times. Uses a 6 bit count.
C1 /3 ib	RCR r/m32, imm8	С	Valid	Valid	Rotate 33 bits (CF, r/m32) right imm8 times.
REX.W + C1 /3 ib	RCR r/m64, imm8	С	Valid	N.E.	Rotate 65 bits (CF, r/m64) right imm8 times. Uses a 6 bit count.
D0 /0	ROL <i>r/m8</i> , 1	Α	Valid	Valid	Rotate 8 bits <i>r/m8</i> left once.
REX + D0 /0	ROL <i>r/m8*</i> , 1	Α	Valid	N.E.	Rotate 8 bits <i>r/m8</i> left once
D2 /0	ROL <i>r/m8</i> , CL	В	Valid	Valid	Rotate 8 bits <i>r/m8</i> left CL times.
REX + D2 /0	ROL r/m8*, CL	В	Valid	N.E.	Rotate 8 bits <i>r/m8</i> left CL times.
CO /O ib	ROL r/m8, imm8	С	Valid	Valid	Rotate 8 bits <i>r/m8</i> left <i>imm8</i> times.

Opcode**	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
REX + CO /O ib	ROL r/m8*, imm8	С	Valid	N.E.	Rotate 8 bits <i>r/m8</i> left <i>imm8</i> times.
D1 /0	ROL <i>r/m16</i> , 1	Α	Valid	Valid	Rotate 16 bits <i>r/m16</i> left once.
D3 /0	ROL <i>r/m16</i> , CL	В	Valid	Valid	Rotate 16 bits <i>r/m16</i> left CL times.
C1 /0 ib	ROL r/m16, imm8	С	Valid	Valid	Rotate 16 bits <i>r/m16</i> left <i>imm8</i> times.
D1 /0	ROL <i>r/m32</i> , 1	Α	Valid	Valid	Rotate 32 bits <i>r/m32</i> left once.
REX.W + D1 /0	ROL <i>r/m64</i> , 1	Α	Valid	N.E.	Rotate 64 bits <i>r/m64</i> left once. Uses a 6 bit count.
D3 /0	ROL <i>r/m32</i> , CL	В	Valid	Valid	Rotate 32 bits <i>r/m32</i> left CL times.
REX.W + D3 /0	ROL <i>r/m64</i> , CL	В	Valid	N.E.	Rotate 64 bits r/m64 left CL times. Uses a 6 bit count.
C1 /0 ib	ROL r/m32, imm8	С	Valid	Valid	Rotate 32 bits <i>r/m32</i> left <i>imm8</i> times.
C1 /0 ib	ROL r/m64, imm8	С	Valid	N.E.	Rotate 64 bits <i>r/m64</i> left <i>imm8</i> times. Uses a 6 bit count.
D0 /1	ROR <i>r/m8,</i> 1	Α	Valid	Valid	Rotate 8 bits <i>r/m8</i> right once.
REX + D0 /1	ROR <i>r/m8*</i> , 1	Α	Valid	N.E.	Rotate 8 bits <i>r/m8</i> right once.
D2 /1	ROR r/m8, CL	В	Valid	Valid	Rotate 8 bits <i>r/m8</i> right CL times.
REX + D2 /1	ROR r/m8*, CL	В	Valid	N.E.	Rotate 8 bits <i>r/m8</i> right CL times.
CO /1 ib	ROR r/m8, imm8	С	Valid	Valid	Rotate 8 bits <i>r/m16</i> right <i>imm8</i> times.
REX + CO /1 ib	ROR r/m8*, imm8	С	Valid	N.E.	Rotate 8 bits <i>r/m16</i> right <i>imm8</i> times.
D1 /1	ROR <i>r/m16,</i> 1	Α	Valid	Valid	Rotate 16 bits <i>r/m16</i> right once.
D3 /1	ROR <i>r/m16</i> , CL	В	Valid	Valid	Rotate 16 bits <i>r/m16</i> right CL times.

Opcode**	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
C1 /1 ib	ROR r/m16, imm8	С	Valid	Valid	Rotate 16 bits <i>r/m16</i> right <i>imm8</i> times.
D1 /1	ROR <i>r/m32</i> , 1	Α	Valid	Valid	Rotate 32 bits <i>r/m32</i> right once.
REX.W + D1 /1	ROR <i>r/m64</i> , 1	Α	Valid	N.E.	Rotate 64 bits <i>r/m64</i> right once. Uses a 6 bit count.
D3 /1	ROR <i>r/m32</i> , CL	В	Valid	Valid	Rotate 32 bits <i>r/m32</i> right CL times.
REX.W + D3 /1	ROR r/m64, CL	В	Valid	N.E.	Rotate 64 bits <i>r/m64</i> right CL times. Uses a 6 bit count.
C1 /1 ib	ROR r/m32, imm8	С	Valid	Valid	Rotate 32 bits <i>r/m32</i> right <i>imm8</i> times.
REX.W + C1 /1 ib	ROR r/m64, imm8	С	Valid	N.E.	Rotate 64 bits <i>r/m64</i> right <i>imm8</i> times. Uses a 6 bit count.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	1	NA	NA
В	ModRM:r/m (w)	CL (r)	NA	NA
С	ModRM:r/m (w)	imm8	NA	NA

Description

Shifts (rotates) the bits of the first operand (destination operand) the number of bit positions specified in the second operand (count operand) and stores the result in the destination operand. The destination operand can be a register or a memory location; the count operand is an unsigned integer that can be an immediate or a value in the CL register. In legacy and compatibility mode, the processor restricts the count to a number between 0 and 31 by masking all the bits in the count operand except the 5 least-significant bits.

The rotate left (ROL) and rotate through carry left (RCL) instructions shift all the bits toward more-significant bit positions, except for the most-significant bit, which is rotated to the least-significant bit location. The rotate right (ROR) and rotate through

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH. BH. CH. DH.

^{**} See IA-32 Architecture Compatibility section below.

carry right (RCR) instructions shift all the bits toward less significant bit positions, except for the least-significant bit, which is rotated to the most-significant bit location.

The RCL and RCR instructions include the CF flag in the rotation. The RCL instruction shifts the CF flag into the least-significant bit and shifts the most-significant bit into the CF flag. The RCR instruction shifts the CF flag into the most-significant bit and shifts the least-significant bit into the CF flag. For the ROL and ROR instructions, the original value of the CF flag is not a part of the result, but the CF flag receives a copy of the bit that was shifted from one end to the other.

The OF flag is defined only for the 1-bit rotates; it is undefined in all other cases (except that a zero-bit rotate does nothing, that is affects no flags). For left rotates, the OF flag is set to the exclusive OR of the CF bit (after the rotate) and the most-significant bit of the result. For right rotates, the OF flag is set to the exclusive OR of the two most-significant bits of the result.

In 64-bit mode, using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Use of REX.W promotes the first operand to 64 bits and causes the count operand to become a 6-bit counter.

IA-32 Architecture Compatibility

The 8086 does not mask the rotation count. However, all other IA-32 processors (starting with the Intel 286 processor) do mask the rotation count to 5 bits, resulting in a maximum count of 31. This masking is done in all operating modes (including the virtual-8086 mode) to reduce the maximum execution time of the instructions.

Operation

```
(* RCL and RCR instructions *)
SIZE \leftarrow OperandSize;
CASE (determine count) OF
    SIZE \leftarrow 8:
                   tempCOUNT \leftarrow (COUNT AND 1FH) MOD 9;
    SIZE \leftarrow 16: tempCOUNT \leftarrow (COUNT AND 1FH) MOD 17;
    SIZE \leftarrow 32: tempCOUNT \leftarrow COUNT AND 1FH;
    SIZE \leftarrow 64: tempCOUNT \leftarrow COUNT AND 3FH;
ESAC;
(* RCL instruction operation *)
WHILE (tempCOUNT \neq 0)
    DO
         tempCF \leftarrow MSB(DEST);
         DEST \leftarrow (DEST * 2) + CF;
         CF \leftarrow tempCF;
         tempCOUNT \leftarrow tempCOUNT - 1;
    OD;
```

```
ELIHW;
IF COUNT = 1
   THEN OF \leftarrow MSB(DEST) XOR CF;
   ELSE OF is undefined;
FI:
(* RCR instruction operation *)
IF COUNT = 1
   THEN OF \leftarrow MSB(DEST) XOR CF;
   ELSE OF is undefined;
FI;
WHILE (tempCOUNT \neq 0)
   DO
         tempCF \leftarrow LSB(SRC);
        DEST \leftarrow (DEST / 2) + (CF * 2<sup>SIZE</sup>):
        CF \leftarrow tempCF;
        tempCOUNT \leftarrow tempCOUNT - 1;
   OD;
(* ROL and ROR instructions *)
IF OperandSize = 64
   THEN COUNTMASK = 3FH;
   ELSE COUNTMASK = 1FH;
FI;
(* ROL instruction operation *)
IF (COUNT & COUNTMASK) > 0 (* Prevents updates to CF *)
   tempCOUNT \leftarrow (COUNT MOD SIZE)
   WHILE (tempCOUNT \neq 0)
         DO
              tempCF \leftarrow MSB(DEST);
              DEST \leftarrow (DEST * 2) + tempCF;
              tempCOUNT \leftarrow tempCOUNT - 1;
        OD;
   ELIHW;
   CF \leftarrow LSB(DEST);
   IF COUNT = 1
        THEN OF \leftarrow MSB(DEST) XOR CF;
        ELSE OF is undefined;
   FI;
FI;
```

```
(* ROR instruction operation *)
IF (COUNT & COUNTMASK) > 0 (* Prevents updates to CF *)
    tempCOUNT \leftarrow (COUNT MOD SIZE)
    WHILE (tempCOUNT \neq 0)
         DO
              tempCF \leftarrow LSB(SRC);
              DEST \leftarrow (DEST / 2) + (tempCF * 2<sup>SIZE</sup>);
              tempCOUNT \leftarrow tempCOUNT - 1;
         OD:
    ELIHW;
    CF \leftarrow MSB(DEST);
    IF COUNT = 1
         THEN OF \leftarrow MSB(DEST) XOR MSB – 1(DEST);
         ELSE OF is undefined;
    FI:
FI:
```

Flags Affected

The CF flag contains the value of the bit shifted into it. The OF flag is affected only for single-bit rotates (see "Description" above); it is undefined for multi-bit rotates. The SF, ZF, AF, and PF flags are not affected.

Protected Mode Exceptions

#GP(0) If the source operand is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

seament limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

seament limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the source operand is located in a nonwritable segment.

If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

RCPPS—Compute Reciprocals of Packed Single-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 53 /r RCPPS xmm1, xmm2/m128	A	V/V	SSE	Computes the approximate reciprocals of the packed single-precision floating-point values in xmm2/m128 and stores the results in xmm1.
VEX.128.0F.WIG 53 /r VRCPPS xmm1, xmm2/m128	Α	V/V	AVX	Computes the approximate reciprocals of packed single-precision values in xmm2/mem and stores the results in xmm1.
VEX.256.0F.WIG 53 /r VRCPPS ymm1, ymm2/m256	Α	V/V	AVX	Computes the approximate reciprocals of packed single-precision values in ymm2/mem and stores the results in ymm1.

Instruction Operand Encoding

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Performs a SIMD computation of the approximate reciprocals of the four packed single-precision floating-point values in the source operand (second operand) stores the packed single-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 10-5 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for an illustration of a SIMD single-precision floating-point operation.

The relative error for this approximation is:

|Relative Error|
$$\leq 1.5 * 2^{-12}$$

 results; input values less than or equal to |1.00000000001100000000018*2¹²⁶| are guaranteed to produce tiny results, which are in turn flushed to 0.0; and input values in between this range may or may not produce tiny results, depending on the implementation.) When a source value is an SNaN or QNaN, the SNaN is converted to a QNaN or the source QNaN is returned.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

RCPPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow APPROXIMATE(1/SRC[31:0])

DEST[63:32] \leftarrow APPROXIMATE(1/SRC[63:32])

DEST[95:64] \leftarrow APPROXIMATE(1/SRC[95:64])

DEST[127:96] \leftarrow APPROXIMATE(1/SRC[127:96])

DEST[VLMAX-1:128] (Unmodified)

VRCPPS (VEX.128 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SRC[31:0])

DEST[63:32] \leftarrow APPROXIMATE(1/SRC[63:32])

DEST[95:64] \leftarrow APPROXIMATE(1/SRC[95:64])

DEST[127:96] \leftarrow APPROXIMATE(1/SRC[127:96])

DEST[VLMAX-1:128] \leftarrow 0

VRCPPS (VEX.256 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SRC[31:0])

DEST[63:32] \leftarrow APPROXIMATE(1/SRC[63:32])

DEST[95:64] \leftarrow APPROXIMATE(1/SRC[95:64])

DEST[127:96] \leftarrow APPROXIMATE(1/SRC[127:96])

DEST[159:128] \leftarrow APPROXIMATE(1/SRC[159:128])

DEST[191:160] \leftarrow APPROXIMATE(1/SRC[191:160])

INSTRUCTION SET REFERENCE, N-Z

DEST[223:192] ← APPROXIMATE(1/SRC[223:192])
DEST[255:224] ← APPROXIMATE(1/SRC[255:224])

Intel C/C++ Compiler Intrinsic Equivalent

RCCPS __m128 _mm_rcp_ps(__m128 a)

RCPPS __m256 _mm256_rcp_ps (__m256 a);

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.vvvv != 1111B.

RCPSS—Compute Reciprocal of Scalar Single-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F3 0F 53 /r RCPSS xmm1, xmm2/m32	Α	V/V	SSE	Computes the approximate reciprocal of the scalar single-precision floating-point value in xmm2/m32 and stores the result in xmm1.
VEX.NDS.LIG.F3.0F.WIG 53 /r VRCPSS xmm1, xmm2, xmm3/m32	В	V/V	AVX	Computes the approximate reciprocal of the scalar single-precision floating-point value in xmm3/m32 and stores the result in xmm1. Also, upper single precision floating-point values (bits[127:32]) from xmm2 are copied to xmm1[127:32].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Computes of an approximate reciprocal of the low single-precision floating-point value in the source operand (second operand) and stores the single-precision floating-point result in the destination operand. The source operand can be an XMM register or a 32-bit memory location. The destination operand is an XMM register. The three high-order doublewords of the destination operand remain unchanged. See Figure 10-6 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for an illustration of a scalar single-precision floating-point operation.

The relative error for this approximation is:

|Relative Error| $\leq 1.5 * 2^{-12}$

The RCPSS instruction is not affected by the rounding control bits in the MXCSR register. When a source value is a 0.0, an ∞ of the sign of the source value is returned. A denormal source value is treated as a 0.0 (of the same sign). Tiny results

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:32) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

RCPSS (128-bit Legacy SSE version)

DEST[31:0] ← APPROXIMATE(1/SRC[31:0])
DEST[VLMAX-1:32] (Unmodified)

VRCPSS (VEX.128 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SRC2[31:0]) DEST[127:32] \leftarrow SRC1[127:32] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

RCPSS m128 mm rcp ss(m128 a)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5.

RDMSR—Read from Model Specific Register

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 32	RDMSR	Α	Valid	Valid	Read MSR specified by ECX into EDX:EAX.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Reads the contents of a 64-bit model specific register (MSR) specified in the ECX register into registers EDX:EAX. (On processors that support the Intel 64 architecture, the high-order 32 bits of RCX are ignored.) The EDX register is loaded with the high-order 32 bits of the MSR and the EAX register is loaded with the low-order 32 bits. (On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX and RDX are cleared.) If fewer than 64 bits are implemented in the MSR being read, the values returned to EDX:EAX in unimplemented bit locations are undefined.

This instruction must be executed at privilege level 0 or in real-address mode; otherwise, a general protection exception #GP(0) will be generated. Specifying a reserved or unimplemented MSR address in ECX will also cause a general protection exception.

The MSRs control functions for testability, execution tracing, performance-monitoring, and machine check errors. Appendix B, "Model-Specific Registers (MSRs)," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, lists all the MSRs that can be read with this instruction and their addresses. Note that each processor family has its own set of MSRs.

The CPUID instruction should be used to determine whether MSRs are supported (CPUID.01H:EDX[5] = 1) before using this instruction.

IA-32 Architecture Compatibility

The MSRs and the ability to read them with the RDMSR instruction were introduced into the IA-32 Architecture with the Pentium processor. Execution of this instruction by an IA-32 processor earlier than the Pentium processor results in an invalid opcode exception #UD.

^{*} See IA-32 Architecture Compatibility section below.

See "Changes to Instruction Behavior in VMX Non-Root Operation" in Chapter 22 of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 3B*, for more information about the behavior of this instruction in VMX non-root operation.

Operation

 $EDX:EAX \leftarrow MSR[ECX];$

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the value in ECX specifies a reserved or unimplemented MSR

address.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If the value in ECX specifies a reserved or unimplemented MSR

address.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) The RDMSR instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the value in ECX or RCX specifies a reserved or unimple-

mented MSR address.

#UD If the LOCK prefix is used.

RDPMC—Read Performance-Monitoring Counters

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 33	RDPMC	Α	Valid	Valid	Read performance- monitoring counter specified by ECX into EDX:EAX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

The EAX register is loaded with the low-order 32 bits. The EDX register is loaded with the supported high-order bits of the counter. The number of high-order bits loaded into EDX is implementation specific on processors that do no support architectural performance monitoring. The width of fixed-function and general-purpose performance counters on processors supporting architectural performance monitoring are reported by CPUID 0AH leaf. See below for the treatment of the EDX register for "fast" reads.

The ECX register selects one of two type of performance counters, specifies the index relative to the base of each counter type, and selects "fast" read mode if supported. The two counter types are :

- General-purpose or special-purpose performance counters: The number of general-purpose counters is model specific if the processor does not support architectural performance monitoring, see Chapter 30 of Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. Special-purpose counters are available only in selected processor members, see Section 30.13, 30.14 of Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. This counter type is selected if ECX[30] is clear.
- Fixed-function performance counter. The number fixed-function performance counters is enumerated by CPUID 0AH leaf. See Chapter 30 of Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. This counter type is selected if ECX[30] is set.

ECX[29:0] specifies the index. The width of general-purpose performance counters are 40-bits for processors that do not support architectural performance monitoring counters. The width of special-purpose performance counters are implementation specific. The width of fixed-function performance counters and general-purpose performance counters on processor supporting architectural performance monitoring are reported by CPUID 0AH leaf.

Table 4-12 lists valid indices of the general-purpose and special-purpose performance counters according to the derived DisplayFamily_DisplayModel values of CPUID encoding for each processor family (see CPUID instruction in Chapter 3, "Instruction Set Reference, A-M" in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A).

Table 4-12. Valid General and Special Purpose Performance Counter Index Range for RDPMC

Processor Family	DisplayFamily_Display Model/ Other Signatures	Valid PMC Index Range	General- purpose Counters			
P6	06H_01H, 06H_03H, 06H_05H, 06H_06H, 06H_07H, 06H_08H, 06H_0AH, 06H_0BH	0, 1	0, 1			
Pentium [®] 4, Intel [®] Xeon processors	0FH_00H, 0FH_01H, 0FH_02H	≥ 0 and ≤ 17	≥ 0 and ≤ 17			
Pentium 4, Intel Xeon processors	(OFH_03H, OFH_04H, OFH_06H) and (L3 is absent)	≥ 0 and ≤ 17	≥ 0 and ≤ 17			
Pentium M processors	06H_09H, 06H_0DH	0, 1	0, 1			
64-bit Intel Xeon processors with L3	OFH_03H, OFH_04H) and (L3 is present)	≥ 0 and ≤ 25	≥ 0 and ≤ 17			
Intel [®] Core [™] Solo and Intel [®] Core [™] Duo processors, Dual-core Intel [®] Xeon [®] processor LV	06H_0EH	0, 1	0, 1			
Intel [®] Core™2 Duo processor, Intel Xeon processor 3000, 5100, 5300, 7300 Series - general-purpose PMC	06H_0FH	0, 1	0, 1			
Intel Xeon processors 7100 series with L3	(0FH_06H) and (L3 is present)	≥ 0 and ≤ 25	≥ 0 and ≤ 17			
Intel [®] Core™2 Duo processor family, Intel Xeon processor family - general-purpose PMC	06H_17H	0, 1	0, 1			
Intel Xeon processors 7400 series	(06H_1DH)	≥ 0 and ≤ 9	0, 1			
Intel [®] Atom [™] processor family	06H_1CH	0, 1	0, 1			
Intel [®] Core™i7 processor, Intel Xeon processors 5500 series	06H_1AH, 06H_1EH, 06H_1FH, 06H_2EH	0-3	0, 1, 2, 3			

The Pentium 4 and Intel Xeon processors also support "fast" (32-bit) and "slow" (40-bit) reads on the first 18 performance counters. Selected this option using

ECX[31]. If bit 31 is set, RDPMC reads only the low 32 bits of the selected performance counter. If bit 31 is clear, all 40 bits are read. A 32-bit result is returned in EAX and EDX is set to 0. A 32-bit read executes faster on Pentium 4 processors and Intel Xeon processors than a full 40-bit read.

On 64-bit Intel Xeon processors with L3, performance counters with indices 18-25 are 32-bit counters. EDX is cleared after executing RDPMC for these counters. On Intel Xeon processor 7100 series with L3, performance counters with indices 18-25 are also 32-bit counters.

In Intel Core 2 processor family, Intel Xeon processor 3000, 5100, 5300 and 7400 series, the fixed-function performance counters are 40-bits wide; they can be accessed by RDMPC with ECX between from 4000_000H and 4000_0002H.

On Intel Xeon processor 7400 series, there are eight 32-bit special-purpose counters addressable with indices 2-9, ECX[30]=0.

When in protected or virtual 8086 mode, the performance-monitoring counters enabled (PCE) flag in register CR4 restricts the use of the RDPMC instruction as follows. When the PCE flag is set, the RDPMC instruction can be executed at any privilege level; when the flag is clear, the instruction can only be executed at privilege level 0. (When in real-address mode, the RDPMC instruction is always enabled.)

The performance-monitoring counters can also be read with the RDMSR instruction, when executing at privilege level 0.

The performance-monitoring counters are event counters that can be programmed to count events such as the number of instructions decoded, number of interrupts received, or number of cache loads. Appendix A, "Performance Monitoring Events," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, lists the events that can be counted for various processors in the Intel 64 and IA-32 architecture families.

The RDPMC instruction is not a serializing instruction; that is, it does not imply that all the events caused by the preceding instructions have been completed or that events caused by subsequent instructions have not begun. If an exact event count is desired, software must insert a serializing instruction (such as the CPUID instruction) before and/or after the RDPMC instruction.

In the Pentium 4 and Intel Xeon processors, performing back-to-back fast reads are not guaranteed to be monotonic. To guarantee monotonicity on back-to-back reads, a serializing instruction must be placed between the two RDPMC instructions.

The RDPMC instruction can execute in 16-bit addressing mode or virtual-8086 mode; however, the full contents of the ECX register are used to select the counter, and the event count is stored in the full EAX and EDX registers. The RDPMC instruction was introduced into the IA-32 Architecture in the Pentium Pro processor and the Pentium processor with MMX technology. The earlier Pentium processors have performance-monitoring counters, but they must be read with the RDMSR instruction.

Operation

```
(* Intel Core i7 processor family and Intel Xeon processor 3400, 5500 series*)
Most significant counter bit (MSCB) = 47
IF ((CR4.PCE = 1) \text{ or } (CPL = 0) \text{ or } (CR0.PE = 0))
   THEN IF (ECX[30] = 1 and ECX[29:0] in valid fixed-counter range)
         EAX \leftarrow IA32\_FIXED\_CTR(ECX)[30:0];
         EDX \leftarrow IA32 FIXED CTR(ECX)[MSCB:32];
   ELSE IF (ECX[30] = 0 and ECX[29:0] in valid general-purpose counter range)
         EAX \leftarrow PMC(ECX[30:0])[31:0];
         EDX \leftarrow PMC(ECX[30:0])[MSCB:32];
   ELSE (* ECX is not valid or CR4.PCE is 0 and CPL is 1, 2, or 3 and CR0.PE is 1 *)
         #GP(0);
FI:
(* Intel Core 2 Duo processor family and Intel Xeon processor 3000, 5100, 5300, 7400 series*)
Most significant counter bit (MSCB) = 39
IF ((CR4.PCE = 1) \text{ or } (CPL = 0) \text{ or } (CR0.PE = 0))
   THEN IF (ECX[30] = 1 and ECX[29:0] in valid fixed-counter range)
         EAX \leftarrow IA32 FIXED CTR(ECX)[30:0];
         EDX \leftarrow IA32 FIXED CTR(ECX)[MSCB:32];
   ELSE IF (ECX[30] = 0 and ECX[29:0] in valid general-purpose counter range)
         EAX \leftarrow PMC(ECX[30:0])[31:0];
         EDX \leftarrow PMC(ECX[30:0])[MSCB:32];
   ELSE IF (ECX[30] = 0 and ECX[29:0] in valid special-purpose counter range)
         EAX \leftarrow PMC(ECX[30:0])[31:0]; (* 32-bit read *)
   ELSE (* ECX is not valid or CR4.PCE is 0 and CPL is 1, 2, or 3 and CR0.PE is 1 *)
         #GP(0);
FI:
(* P6 family processors and Pentium processor with MMX technology *)
IF (ECX = 0 \text{ or } 1) and ((CR4.PCE = 1) \text{ or } (CPL = 0) \text{ or } (CR0.PE = 0))
   THEN
         EAX \leftarrow PMC(ECX)[31:0];
         EDX \leftarrow PMC(ECX)[39:32];
   ELSE (* ECX is not 0 or 1 or CR4.PCE is 0 and CPL is 1, 2, or 3 and CR0.PE is 1 *)
         #GP(0);
FI:
(* Processors with CPUID family 15 *)
```

```
IF ((CR4.PCE = 1) \text{ or } (CPL = 0) \text{ or } (CR0.PE = 0))
    THEN IF (ECX[30:0] = 0:17)
         THEN IF ECX[31] = 0
              THEN
                   EAX \leftarrow PMC(ECX[30:0])[31:0]; (* 40-bit read *)
                   EDX \leftarrow PMC(ECX[30:0])[39:32];
         ELSE (* ECX[31] = 1*)
              THEN
                   EAX \leftarrow PMC(ECX[30:0])[31:0]; (* 32-bit read *)
                   EDX \leftarrow 0;
         FI:
   ELSE IF (*64-bit Intel Xeon processor with L3 *)
         THEN IF (ECX[30:0] = 18:25)
              EAX \leftarrow PMC(ECX[30:0])[31:0]; (* 32-bit read *)
              EDX \leftarrow 0;
         FI:
   ELSE IF (*Intel Xeon processor 7100 series with L3 *)
         THEN IF (ECX[30:0] = 18:25)
              EAX \leftarrow PMC(ECX[30:0])[31:0]; (* 32-bit read *)
              EDX \leftarrow 0;
         FI:
   ELSE (* Invalid PMC index in ECX[30:0], see Table 4-15. *)
   FI;
ELSE (* CR4.PCE = 0 and (CPL = 1, 2, or 3) and CR0.PE = 1 *)
   #GP(0);
FI:
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0 and the PCE flag in the CR4

register is clear.

If an invalid performance counter index is specified (see

Table 4-12).

(Pentium 4 and Intel Xeon processors) If the value in ECX[30:0]

is not within the valid range.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If an invalid performance counter index is specified (see

Table 4-12).

(Pentium 4 and Intel Xeon processors) If the value in ECX[30:0]

is not within the valid range.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If the PCE flag in the CR4 register is clear.

If an invalid performance counter index is specified (see

Table 4-12).

(Pentium 4 and Intel Xeon processors) If the value in ECX[30:0]

is not within the valid range.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0 and the PCE flag in the CR4

register is clear.

If an invalid performance counter index is specified in ECX[30:0]

(see Table 4-12).

#UD If the LOCK prefix is used.

RDTSC—Read Time-Stamp Counter

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 31	RDTSC	Α	Valid	Valid	Read time-stamp counter into EDX:EAX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Loads the current value of the processor's time-stamp counter (a 64-bit MSR) into the EDX:EAX registers. The EDX register is loaded with the high-order 32 bits of the MSR and the EAX register is loaded with the low-order 32 bits. (On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX and RDX are cleared.)

The processor monotonically increments the time-stamp counter MSR every clock cycle and resets it to 0 whenever the processor is reset. See "Time Stamp Counter" in Chapter 16 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, for specific details of the time stamp counter behavior.

When in protected or virtual 8086 mode, the time stamp disable (TSD) flag in register CR4 restricts the use of the RDTSC instruction as follows. When the TSD flag is clear, the RDTSC instruction can be executed at any privilege level; when the flag is set, the instruction can only be executed at privilege level 0. (When in real-address mode, the RDTSC instruction is always enabled.)

The time-stamp counter can also be read with the RDMSR instruction, when executing at privilege level 0.

The RDTSC instruction is not a serializing instruction. It does not necessarily wait until all previous instructions have been executed before reading the counter. Similarly, subsequent instructions may begin execution before the read operation is performed. If software requires RDTSC to be executed only after all previous instructions have completed locally, it can either use RDTSCP (if the processor supports that instruction) or execute the sequence LFENCE; RDTSC.

This instruction was introduced by the Pentium processor.

See "Changes to Instruction Behavior in VMX Non-Root Operation" in Chapter 22 of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 3B*, for more information about the behavior of this instruction in VMX non-root operation.

Operation

IF (CR4.TSD = 0) or (CPL = 0) or (CR0.PE = 0)

```
THEN EDX:EAX \leftarrow TimeStampCounter;
ELSE (* CR4.TSD = 1 and (CPL = 1, 2, or 3) and CR0.PE = 1 *)
#GP(0);
FI;
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the TSD flag in register CR4 is set and the CPL is greater than

0.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If the TSD flag in register CR4 is set.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

RDTSCP—Read Time-Stamp Counter and Processor ID

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 F9	RDTSCP	Α	Valid	Valid	Read 64-bit time-stamp counter and 32-bit IA32_TSC_AUX value into EDX:EAX and ECX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Loads the current value of the processor's time-stamp counter (a 64-bit MSR) into the EDX:EAX registers and also loads the IA32_TSC_AUX MSR (address C000_0103H) into the ECX register. The EDX register is loaded with the high-order 32 bits of the IA32_TSC MSR; the EAX register is loaded with the low-order 32 bits of the IA32_TSC MSR; and the ECX register is loaded with the low-order 32-bits of IA32_TSC_AUX MSR. On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX, RDX, and RCX are cleared.

The processor monotonically increments the time-stamp counter MSR every clock cycle and resets it to 0 whenever the processor is reset. See "Time Stamp Counter" in Chapter 16 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, for specific details of the time stamp counter behavior.

When in protected or virtual 8086 mode, the time stamp disable (TSD) flag in register CR4 restricts the use of the RDTSCP instruction as follows. When the TSD flag is clear, the RDTSCP instruction can be executed at any privilege level; when the flag is set, the instruction can only be executed at privilege level 0. (When in real-address mode, the RDTSCP instruction is always enabled.)

The RDTSCP instruction waits until all previous instructions have been executed before reading the counter. However, subsequent instructions may begin execution before the read operation is performed.

The presence of the RDTSCP instruction is indicated by CPUID leaf 80000001H, EDX bit 27. If the bit is set to 1 then RDTSCP is present on the processor.

See "Changes to Instruction Behavior in VMX Non-Root Operation" in Chapter 22 of the *Intel*® *64* and *IA-32* Architectures Software Developer's Manual, Volume 3B, for more information about the behavior of this instruction in VMX non-root operation.

Operation

IF (CR4.TSD = 0) or (CPL = 0) or (CR0.PE = 0)

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the TSD flag in register CR4 is set and the CPL is greater than

0.

#UD If the LOCK prefix is used.

If CPUID.80000001H:EDX.RDTSCP[bit 27] = 0.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

If CPUID.80000001H:EDX.RDTSCP[bit 27] = 0.

Virtual-8086 Mode Exceptions

#GP(0) If the TSD flag in register CR4 is set.

#UD If the LOCK prefix is used.

If CPUID.80000001H:EDX.RDTSCP[bit 27] = 0.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

REP/REPE/REPZ/REPNE/REPNZ—Repeat String Operation Prefix

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F3 6C	REP INS <i>m8</i> , DX	Α	Valid	Valid	Input (E)CX bytes from port DX into ES:[(E)DI].
F3 6C	REP INS m8, DX	Α	Valid	N.E.	Input RCX bytes from port DX into [RDI].
F3 6D	REP INS m16, DX	Α	Valid	Valid	Input (E)CX words from port DX into ES:[(E)DI.]
F3 6D	REP INS <i>m32</i> , DX	Α	Valid	Valid	Input (E)CX doublewords from port DX into ES:[(E)DI].
F3 6D	REP INS r/m32, DX	Α	Valid	N.E.	Input RCX default size from port DX into [RDI].
F3 A4	REP MOVS m8, m8	Α	Valid	Valid	Move (E)CX bytes from DS:[(E)SI] to ES:[(E)DI].
F3 REX.W A4	REP MOVS m8, m8	Α	Valid	N.E.	Move RCX bytes from [RSI] to [RDI].
F3 A5	REP MOVS m16, m16	Α	Valid	Valid	Move (E)CX words from DS:[(E)SI] to ES:[(E)DI].
F3 A5	REP MOVS m32, m32	Α	Valid	Valid	Move (E)CX doublewords from DS:[(E)SI] to ES:[(E)DI].
F3 REX.W A5	REP MOVS <i>m64,</i> m64	Α	Valid	N.E.	Move RCX quadwords from [RSI] to [RDI].
F3 6E	REP OUTS DX, r/m8	Α	Valid	Valid	Output (E)CX bytes from DS:[(E)SI] to port DX.
F3 REX.W 6E	REP OUTS DX, r/m8*	Α	Valid	N.E.	Output RCX bytes from [RSI] to port DX.
F3 6F	REP OUTS DX, r/m16	Α	Valid	Valid	Output (E)CX words from DS:[(E)SI] to port DX.
F3 6F	REP OUTS DX, r/m32	Α	Valid	Valid	Output (E)CX doublewords from DS:[(E)SI] to port DX.
F3 REX.W 6F	REP OUTS DX, r/m32	Α	Valid	N.E.	Output RCX default size from [RSI] to port DX.
F3 AC	REP LODS AL	Α	Valid	Valid	Load (E)CX bytes from DS:[(E)SI] to AL.
F3 REX.W AC	REP LODS AL	Α	Valid	N.E.	Load RCX bytes from [RSI] to AL.
F3 AD	REP LODS AX	Α	Valid	Valid	Load (E)CX words from DS:[(E)SI] to AX.

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F3 AD	REP LODS EAX	Α	Valid	Valid	Load (E)CX doublewords from DS:[(E)SI] to EAX.
F3 REX.W AD	REP LODS RAX	Α	Valid	N.E.	Load RCX quadwords from [RSI] to RAX.
F3 AA	REP STOS m8	Α	Valid	Valid	Fill (E)CX bytes at ES:[(E)DI] with AL.
F3 REX.W AA	REP STOS m8	Α	Valid	N.E.	Fill RCX bytes at [RDI] with AL.
F3 AB	REP STOS m16	Α	Valid	Valid	Fill (E)CX words at ES:[(E)DI] with AX.
F3 AB	REP STOS m32	Α	Valid	Valid	Fill (E)CX doublewords at ES:[(E)DI] with EAX.
F3 REX.W AB	REP STOS m64	Α	Valid	N.E.	Fill RCX quadwords at [RDI] with RAX.
F3 A6	REPE CMPS <i>m8,</i> <i>m8</i>	Α	Valid	Valid	Find nonmatching bytes in ES:[(E)DI] and DS:[(E)SI].
F3 REX.W A6	REPE CMPS <i>m8,</i> <i>m8</i>	Α	Valid	N.E.	Find non-matching bytes in [RDI] and [RSI].
F3 A7	REPE CMPS m16, m16	Α	Valid	Valid	Find nonmatching words in ES:[(E)DI] and DS:[(E)SI].
F3 A7	REPE CMPS m32, m32	Α	Valid	Valid	Find nonmatching doublewords in ES:[(E)DI] and DS:[(E)SI].
F3 REX.W A7	REPE CMPS m64, m64	Α	Valid	N.E.	Find non-matching quadwords in [RDI] and [RSI].
F3 AE	REPE SCAS m8	Α	Valid	Valid	Find non-AL byte starting at ES:[(E)DI].
F3 REX.W AE	REPE SCAS m8	Α	Valid	N.E.	Find non-AL byte starting at [RDI].
F3 AF	REPE SCAS m16	Α	Valid	Valid	Find non-AX word starting at ES:[(E)DI].
F3 AF	REPE SCAS m32	Α	Valid	Valid	Find non-EAX doubleword starting at ES:[(E)DI].
F3 REX.W AF	REPE SCAS m64	Α	Valid	N.E.	Find non-RAX quadword starting at [RDI].
F2 A6	REPNE CMPS m8, m8	Α	Valid	Valid	Find matching bytes in ES:[(E)DI] and DS:[(E)SI].

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F2 REX.W A6	REPNE CMPS <i>m8,</i> <i>m8</i>	Α	Valid	N.E.	Find matching bytes in [RDI] and [RSI].
F2 A7	REPNE CMPS m16, m16	Α	Valid	Valid	Find matching words in ES:[(E)DI] and DS:[(E)SI].
F2 A7	REPNE CMPS m32, m32	Α	Valid	Valid	Find matching doublewords in ES:[(E)DI] and DS:[(E)SI].
F2 REX.W A7	REPNE CMPS m64, m64	Α	Valid	N.E.	Find matching doublewords in [RDI] and [RSI].
F2 AE	REPNE SCAS m8	Α	Valid	Valid	Find AL, starting at ES:[(E)DI].
F2 REX.W AE	REPNE SCAS m8	Α	Valid	N.E.	Find AL, starting at [RDI].
F2 AF	REPNE SCAS m16	Α	Valid	Valid	Find AX, starting at ES:[(E)DI].
F2 AF	REPNE SCAS m32	Α	Valid	Valid	Find EAX, starting at ES:[(E)DI].
F2 REX.W AF	REPNE SCAS m64	Α	Valid	N.E.	Find RAX, starting at [RDI].

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Repeats a string instruction the number of times specified in the count register or until the indicated condition of the ZF flag is no longer met. The REP (repeat), REPE (repeat while equal), REPNE (repeat while not equal), REPZ (repeat while zero), and REPNZ (repeat while not zero) mnemonics are prefixes that can be added to one of the string instructions. The REP prefix can be added to the INS, OUTS, MOVS, LODS, and STOS instructions, and the REPE, REPNE, REPZ, and REPNZ prefixes can be added to the CMPS and SCAS instructions. (The REPZ and REPNZ prefixes are synonymous forms of the REPE and REPNE prefixes, respectively.) The behavior of the REP prefix is undefined when used with non-string instructions.

The REP prefixes apply only to one string instruction at a time. To repeat a block of instructions, use the LOOP instruction or another looping construct. All of these repeat prefixes cause the associated instruction to be repeated until the count in register is decremented to 0. See Table 4-13.

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

	Table 4 15. Repeat Felixes										
Repeat Prefix	Termination Condition 1*	Termination Condition 2									
REP	RCX or (E)CX = 0	None									
REPE/REPZ	RCX or (E)CX = 0	ZF = 0									
REPNE/REPN7	RCX or $(F)CX = 0$	7F = 1									

Table 4-13. Repeat Prefixes

NOTES:

The REPE, REPNE, REPZ, and REPNZ prefixes also check the state of the ZF flag after each iteration and terminate the repeat loop if the ZF flag is not in the specified state. When both termination conditions are tested, the cause of a repeat termination can be determined either by testing the count register with a JECXZ instruction or by testing the ZF flag (with a JZ, JNZ, or JNE instruction).

When the REPE/REPZ and REPNE/REPNZ prefixes are used, the ZF flag does not require initialization because both the CMPS and SCAS instructions affect the ZF flag according to the results of the comparisons they make.

A repeating string operation can be suspended by an exception or interrupt. When this happens, the state of the registers is preserved to allow the string operation to be resumed upon a return from the exception or interrupt handler. The source and destination registers point to the next string elements to be operated on, the EIP register points to the string instruction, and the ECX register has the value it held following the last successful iteration of the instruction. This mechanism allows long string operations to proceed without affecting the interrupt response time of the system.

When a fault occurs during the execution of a CMPS or SCAS instruction that is prefixed with REPE or REPNE, the EFLAGS value is restored to the state prior to the execution of the instruction. Since the SCAS and CMPS instructions do not use EFLAGS as an input, the processor can resume the instruction after the page fault handler.

Use the REP INS and REP OUTS instructions with caution. Not all I/O ports can handle the rate at which these instructions execute. Note that a REP STOS instruction is the fastest way to initialize a large block of memory.

In 64-bit mode, the operand size of the count register is associated with the address size attribute. Thus the default count register is RCX; REX.W has no effect on the address size and the count register. In 64-bit mode, if 67H is used to override address size attribute, the count register is ECX and any implicit source/destination operand will use the corresponding 32-bit index register. See the summary chart at the beginning of this section for encoding data and limits.

^{*} Count register is CX, ECX or RCX by default, depending on attributes of the operating modes.

Operation

```
IF AddressSize = 16
  THFN
    Use CX for CountReg;
    Implicit Source/Dest operand for memory use of SI/DI;
  ELSE IF AddressSize = 64
    THEN Use RCX for CountReg;
    Implicit Source/Dest operand for memory use of RSI/RDI;
  ELSE
    Use ECX for CountReg;
    Implicit Source/Dest operand for memory use of ESI/EDI;
FI:
WHILE CountReq \neq 0
   DO
        Service pending interrupts (if any);
        Execute associated string instruction;
        CountReg \leftarrow (CountReg - 1);
        IF CountReq = 0
             THEN exit WHILE loop; FI;
        IF (Repeat prefix is REPZ or REPE) and (ZF = 0)
        or (Repeat prefix is REPNZ or REPNE) and (ZF = 1)
            THEN exit WHILE loop; FI;
   OD:
```

Flags Affected

None; however, the CMPS and SCAS instructions do set the status flags in the EFLAGS register.

Exceptions (All Operating Modes)

Exceptions may be generated by an instruction associated with the prefix.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

-		_													•							
J	- 1	Г—	u	יםי	ш	ш	м	П.	т	п		m	n	-	,		1	о.	м	ш	16	_
•	_	_	1		L	ч I	ш				u	ш				·	,,	. $\overline{}$		ı		_

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
C3	RET	Α	Valid	Valid	Near return to calling procedure.
СВ	RET	Α	Valid	Valid	Far return to calling procedure.
C2 iw	RET imm16	В	Valid	Valid	Near return to calling procedure and pop <i>imm16</i> bytes from stack.
CA iw	RET imm16	В	Valid	Valid	Far return to calling procedure and pop <i>imm16</i> bytes from stack.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA
В	imm16	NA	NA	NA

Description

Transfers program control to a return address located on the top of the stack. The address is usually placed on the stack by a CALL instruction, and the return is made to the instruction that follows the CALL instruction.

The optional source operand specifies the number of stack bytes to be released after the return address is popped; the default is none. This operand can be used to release parameters from the stack that were passed to the called procedure and are no longer needed. It must be used when the CALL instruction used to switch to a new procedure uses a call gate with a non-zero word count to access the new procedure. Here, the source operand for the RET instruction must specify the same number of bytes as is specified in the word count field of the call gate.

The RET instruction can be used to execute three different types of returns:

- Near return A return to a calling procedure within the current code segment (the segment currently pointed to by the CS register), sometimes referred to as an intrasegment return.
- **Far return** A return to a calling procedure located in a different segment than the current code segment, sometimes referred to as an intersegment return.
- Inter-privilege-level far return A far return to a different privilege level than that of the currently executing program or procedure.

The inter-privilege-level return type can only be executed in protected mode. See the section titled "Calling Procedures Using Call and RET" in Chapter 6 of the *Intel*® *64* and *IA-32 Architectures Software Developer's Manual, Volume 1*, for detailed information on near, far, and inter-privilege-level returns.

When executing a near return, the processor pops the return instruction pointer (offset) from the top of the stack into the EIP register and begins program execution at the new instruction pointer. The CS register is unchanged.

When executing a far return, the processor pops the return instruction pointer from the top of the stack into the EIP register, then pops the segment selector from the top of the stack into the CS register. The processor then begins program execution in the new code segment at the new instruction pointer.

The mechanics of an inter-privilege-level far return are similar to an intersegment return, except that the processor examines the privilege levels and access rights of the code and stack segments being returned to determine if the control transfer is allowed to be made. The DS, ES, FS, and GS segment registers are cleared by the RET instruction during an inter-privilege-level return if they refer to segments that are not allowed to be accessed at the new privilege level. Since a stack switch also occurs on an inter-privilege level return, the ESP and SS registers are loaded from the stack.

If parameters are passed to the called procedure during an inter-privilege level call, the optional source operand must be used with the RET instruction to release the parameters on the return. Here, the parameters are released both from the called procedure's stack and the calling procedure's stack (that is, the stack being returned to).

In 64-bit mode, the default operation size of this instruction is the stack-address size, i.e. 64 bits.

Operation

```
(* Near return *)

IF instruction = near return

THEN;

IF OperandSize = 32

THEN

IF top 4 bytes of stack not within stack limits

THEN \#SS(0); FI;

EIP \leftarrow Pop();

ELSE

IF OperandSize = 64

THEN

IF top 8 bytes of stack not within stack limits

THEN \#SS(0); FI;

RIP \leftarrow Pop();

ELSE (* OperandSize = 16 *)
```

```
IF top 2 bytes of stack not within stack limits
                                   THEN #SS(0); FI;
                              tempEIP \leftarrow Pop();
                              tempEIP ← tempEIP AND 0000FFFFH;
                             IF tempEIP not within code segment limits
                                   THEN #GP(0); FI;
                             EIP \leftarrow tempEIP;
                   FI;
         FI:
    IF instruction has immediate operand
         THEN (* Release parameters from stack *)
              IF StackAddressSize = 32
                   THEN
                        ESP \leftarrow ESP + SRC;
                   FLSE
                        IF StackAddressSize = 64
                             THEN
                                  RSP \leftarrow RSP + SRC:
                             ELSE (* StackAddressSize = 16 *)
                                  SP \leftarrow SP + SRC:
                        FI:
              FI:
    FI:
FI:
(* Real-address mode or virtual-8086 mode *)
IF ((PE = 0) \text{ or } (PE = 1 \text{ AND VM} = 1)) and instruction = far return
    THEN
         IF OperandSize = 32
              THEN
                   IF top 8 bytes of stack not within stack limits
                        THEN #SS(0); FI;
                   EIP \leftarrow Pop():
                   CS \leftarrow Pop(); (* 32-bit pop, high-order 16 bits discarded *)
              ELSE (* OperandSize = 16 *)
                   IF top 4 bytes of stack not within stack limits
                        THEN #SS(0); FI;
                   tempEIP \leftarrow Pop():
                   tempEIP ← tempEIP AND 0000FFFFH;
                   IF tempEIP not within code segment limits
                        THEN #GP(0); FI;
                   EIP \leftarrow tempEIP:
                   CS \leftarrow Pop(); (* 16-bit pop *)
```

```
FI:
   IF instruction has immediate operand
        THEN (* Release parameters from stack *)
            SP \leftarrow SP + (SRC AND FFFFH);
   FI:
FI:
(* Protected mode, not virtual-8086 mode *)
IF (PE = 1 and VM = 0 and IA32 EFER.LMA = 0) and instruction = far return
   THEN
        IF OperandSize = 32
            THEN
                 IF second doubleword on stack is not within stack limits
                      THEN #SS(0); FI;
            ELSE (* OperandSize = 16 *)
                 IF second word on stack is not within stack limits
                      THEN #SS(0); FI;
        FI.
   IF return code segment selector is NULL
        THEN #GP(0); FI;
   IF return code segment selector addresses descriptor beyond descriptor table limit
        THEN #GP(selector); FI;
   Obtain descriptor to which return code segment selector points from descriptor table;
   IF return code segment descriptor is not a code segment
        THEN #GP(selector); FI;
   IF return code segment selector RPL < CPL
        THEN #GP(selector); FI;
   IF return code segment descriptor is conforming
   and return code segment DPL > return code segment selector RPL
        THEN #GP(selector); FI;
   IF return code segment descriptor is non-conforming and return code
   segment DPL ≠ return code segment selector RPL
        THEN #GP(selector); FI;
   IF return code segment descriptor is not present
        THEN #NP(selector); FI:
   IF return code seament selector RPL > CPL
        THEN GOTO RETURN-OUTER-PRIVILEGE-LEVEL:
        ELSE GOTO RETURN-TO-SAME-PRIVILEGE-LEVEL:
   FI:
FI:
RETURN-SAME-PRIVILEGE-LEVEL:
   IF the return instruction pointer is not within the return code segment limit
        THEN #GP(0); FI;
```

```
IF OperandSize = 32
        THEN
             EIP \leftarrow Pop();
             CS \leftarrow Pop(); (* 32-bit pop, high-order 16 bits discarded *)
        ELSE (* OperandSize = 16 *)
             EIP \leftarrow Pop();
             EIP ← EIP AND 0000FFFFH;
             CS \leftarrow Pop(); (* 16-bit pop *)
   FI:
   IF instruction has immediate operand
        THEN (* Release parameters from stack *)
             IF StackAddressSize = 32
                  THEN
                       ESP \leftarrow ESP + SRC;
                  ELSE (* StackAddressSize = 16 *)
                       SP \leftarrow SP + SRC;
             FI:
   FI:
RETURN-OUTER-PRIVILEGE-LEVEL:
   IF top (16 + SRC) bytes of stack are not within stack limits (OperandSize = 32)
   or top (8 + SRC) bytes of stack are not within stack limits (OperandSize = 16)
             THEN #SS(0); FI;
   Read return segment selector;
   IF stack segment selector is NULL
        THEN #GP(0); FI;
   IF return stack segment selector index is not within its descriptor table limits
        THEN #GP(selector); FI;
   Read segment descriptor pointed to by return segment selector;
   IF stack segment selector RPL ≠ RPL of the return code segment selector
   or stack segment is not a writable data segment
   or stack segment descriptor DPL ≠ RPL of the return code segment selector
             THEN #GP(selector); FI;
   IF stack segment not present
        THEN #SS(StackSegmentSelector); FI;
   IF the return instruction pointer is not within the return code segment limit
        THEN #GP(0); FI;
   CPL ← ReturnCodeSegmentSelector(RPL);
   IF OperandSize = 32
        THEN
             EIP \leftarrow Pop();
             CS ← Pop(); (* 32-bit pop, high-order 16 bits discarded; segment descriptor loaded *)
             CS(RPL) \leftarrow CPL;
```

```
IF instruction has immediate operand
               THEN (* Release parameters from called procedure's stack *)
                    IF StackAddressSize = 32
                          THEN
                               ESP \leftarrow ESP + SRC:
                          ELSE (* StackAddressSize = 16 *)
                               SP \leftarrow SP + SRC;
                    FI:
          FI;
          tempESP \leftarrow Pop();
          tempSS ← Pop(); (* 32-bit pop, high-order 16 bits discarded; seg. descriptor loaded *)
          ESP \leftarrow tempESP;
          SS \leftarrow tempSS;
     ELSE (* OperandSize = 16 *)
          EIP \leftarrow Pop();
          EIP \leftarrow EIP \text{ AND } 0000FFFFH;
          CS ← Pop(); (* 16-bit pop; segment descriptor loaded *)
          CS(RPL) \leftarrow CPL;
          IF instruction has immediate operand
               THEN (* Release parameters from called procedure's stack *)
                    IF StackAddressSize = 32
                          THEN
                               ESP \leftarrow ESP + SRC;
                          ELSE (* StackAddressSize = 16 *)
                               SP \leftarrow SP + SRC;
                    FI;
          FI:
          tempESP \leftarrow Pop();
          tempSS \leftarrow Pop(); (* 16-bit pop; segment descriptor loaded *)
          ESP \leftarrow tempESP;
          SS \leftarrow tempSS;
FI;
FOR each of segment register (ES, FS, GS, and DS)
     DO
          IF segment register points to data or non-conforming code segment
          and CPL > segment descriptor DPL (* DPL in hidden part of segment register *)
               THEN SegmentSelector \leftarrow 0; (* Segment selector invalid *)
          FI:
     OD;
IF instruction has immediate operand
     THEN (* Release parameters from calling procedure's stack *)
```

```
IF StackAddressSize = 32
                 THEN
                      ESP \leftarrow ESP + SRC:
                 ELSE (* StackAddressSize = 16 *)
                      SP \leftarrow SP + SRC;
            FI;
   FI;
(* IA-32e Mode *)
   IF (PE = 1 and VM = 0 and IA32 EFER.LMA = 1) and instruction = far return
        THEN
            IF OperandSize = 32
                 THEN
                      IF second doubleword on stack is not within stack limits
                           THEN #SS(0); FI;
                      IF first or second doubleword on stack is not in canonical space
                           THEN #SS(0); FI;
                 ELSE
                      IF OperandSize = 16
                           THEN
                                IF second word on stack is not within stack limits
                                     THEN #SS(0); FI;
                                IF first or second word on stack is not in canonical space
                                     THEN #SS(0); FI;
                           ELSE (* OperandSize = 64 *)
                                IF first or second quadword on stack is not in canonical space
                                     THEN #SS(0); FI;
                      FΙ
            FI;
        IF return code segment selector is NULL
             THEN GP(0); FI;
        IF return code segment selector addresses descriptor beyond descriptor table limit
             THEN GP(selector); FI;
        IF return code segment selector addresses descriptor in non-canonical space
             THEN GP(selector); FI;
        Obtain descriptor to which return code segment selector points from descriptor table;
        IF return code segment descriptor is not a code segment
             THEN #GP(selector); FI;
        IF return code segment descriptor has L-bit = 1 and D-bit = 1
             THEN #GP(selector); FI;
        IF return code segment selector RPL < CPL
             THEN #GP(selector); FI;
        IF return code segment descriptor is conforming
```

```
and return code segment DPL > return code segment selector RPL
             THEN #GP(selector); FI;
        IF return code segment descriptor is non-conforming
        and return code segment DPL ≠ return code segment selector RPL
             THEN #GP(selector); FI;
        IF return code segment descriptor is not present
             THEN #NP(selector); FI:
        IF return code segment selector RPL > CPL
             THEN GOTO IA-32E-MODE-RETURN-OUTER-PRIVILEGE-LEVEL;
             ELSE GOTO IA-32E-MODE-RETURN-SAME-PRIVILEGE-LEVEL;
        FI;
   FI:
IA-32E-MODE-RETURN-SAME-PRIVILEGE-LEVEL:
IF the return instruction pointer is not within the return code segment limit
   THEN #GP(0); FI;
IF the return instruction pointer is not within canonical address space
   THEN #GP(0); FI;
IF OperandSize = 32
   THEN
        EIP \leftarrow Pop();
        CS ← Pop(); (* 32-bit pop, high-order 16 bits discarded *)
   ELSE
        IF OperandSize = 16
             THEN
                  EIP \leftarrow Pop();
                  EIP ← EIP AND 0000FFFFH;
                  CS \leftarrow Pop(); (* 16-bit pop *)
             ELSE (* OperandSize = 64 *)
                  RIP \leftarrow Pop();
                  CS \leftarrow Pop(); (* 64-bit pop, high-order 48 bits discarded *)
        FI:
FI;
IF instruction has immediate operand
   THEN (* Release parameters from stack *)
        IF StackAddressSize = 32
             THEN
                  ESP \leftarrow ESP + SRC;
             ELSE
                  IF StackAddressSize = 16
                      THEN
                           SP \leftarrow SP + SRC;
                      ELSE (* StackAddressSize = 64 *)
```

```
RSP \leftarrow RSP + SRC:
                  FI:
        FI:
FI:
IA-32E-MODE-RETURN-OUTER-PRIVILEGE-LEVEL:
IF top (16 + SRC) bytes of stack are not within stack limits (OperandSize = 32)
or top (8 + SRC) bytes of stack are not within stack limits (OperandSize = 16)
   THEN #SS(0); FI;
IF top (16 + SRC) bytes of stack are not in canonical address space (OperandSize = 32)
or top (8 + SRC) bytes of stack are not in canonical address space (OperandSize = 16)
or top (32 + SRC) bytes of stack are not in canonical address space (OperandSize = 64)
   THEN #SS(0); FI;
Read return stack segment selector;
IF stack segment selector is NULL
   THEN
        IF new CS descriptor L-bit = 0
             THEN #GP(selector);
        IF stack segment selector RPL = 3
             THEN #GP(selector);
FI:
IF return stack segment descriptor is not within descriptor table limits
        THEN #GP(selector); FI;
IF return stack segment descriptor is in non-canonical address space
        THEN #GP(selector); FI;
Read segment descriptor pointed to by return segment selector;
IF stack segment selector RPL ≠ RPL of the return code segment selector
or stack segment is not a writable data segment
or stack segment descriptor DPL \neq RPL of the return code segment selector
   THEN #GP(selector); FI;
IF stack segment not present
   THEN #SS(StackSegmentSelector); FI;
IF the return instruction pointer is not within the return code segment limit
   THEN #GP(0); FI:
IF the return instruction pointer is not within canonical address space
   THEN #GP(0); FI;
CPL ← ReturnCodeSegmentSelector(RPL);
IF OperandSize = 32
   THEN
        EIP \leftarrow Pop();
        CS ← Pop(); (* 32-bit pop, high-order 16 bits discarded, segment descriptor loaded *)
        CS(RPL) \leftarrow CPL;
        IF instruction has immediate operand
```

```
THEN (* Release parameters from called procedure's stack *)
               IF StackAddressSize = 32
                    THEN
                          ESP \leftarrow ESP + SRC;
                    ELSE
                          IF StackAddressSize = 16
                               THEN
                                    SP \leftarrow SP + SRC;
                               ELSE (* StackAddressSize = 64 *)
                                    RSP \leftarrow RSP + SRC;
                          FI;
               FI:
     FI:
     tempESP \leftarrow Pop();
     tempSS ← Pop(); (* 32-bit pop, high-order 16 bits discarded, segment descriptor loaded *)
     ESP \leftarrow tempESP;
     SS \leftarrow tempSS;
ELSE
     IF OperandSize = 16
          THEN
               EIP \leftarrow Pop();
               EIP ← EIP AND 0000FFFFH;
               CS ← Pop(); (* 16-bit pop; segment descriptor loaded *)
               CS(RPL) \leftarrow CPL;
               IF instruction has immediate operand
                    THEN (* Release parameters from called procedure's stack *)
                          IF StackAddressSize = 32
                               THEN
                                    ESP \leftarrow ESP + SRC;
                               ELSE
                                    IF StackAddressSize = 16
                                         THEN
                                              SP \leftarrow SP + SRC;
                                         ELSE (* StackAddressSize = 64 *)
                                              RSP \leftarrow RSP + SRC;
                                    FI;
                          FI;
               FI;
               tempESP \leftarrow Pop();
               tempSS \leftarrow Pop(); (* 16-bit pop; segment descriptor loaded *)
               ESP \leftarrow tempESP;
               SS \leftarrow tempSS;
          ELSE (* OperandSize = 64 *)
```

```
RIP \leftarrow Pop();
                   CS \leftarrow Pop(); (* 64-bit pop; high-order 48 bits discarded; seq. descriptor loaded *)
                   CS(RPL) \leftarrow CPL;
                   IF instruction has immediate operand
                        THEN (* Release parameters from called procedure's stack *)
                             RSP \leftarrow RSP + SRC;
                   FI;
                   tempESP \leftarrow Pop();
                   tempSS ← Pop(); (* 64-bit pop; high-order 48 bits discarded; seg. desc. loaded *)
                   ESP \leftarrow tempESP;
                   SS \leftarrow tempSS;
         FI:
FI:
FOR each of segment register (ES, FS, GS, and DS)
         IF segment register points to data or non-conforming code segment
         and CPL > segment descriptor DPL; (* DPL in hidden part of segment register *)
              THEN SegmentSelector \leftarrow 0; (* SegmentSelector invalid *)
         FI;
    OD:
IF instruction has immediate operand
    THEN (* Release parameters from calling procedure's stack *)
         IF StackAddressSize = 32
              THEN
                   ESP \leftarrow ESP + SRC;
              ELSE
                   IF StackAddressSize = 16
                        THEN
                             SP \leftarrow SP + SRC;
                        ELSE (* StackAddressSize = 64 *)
                             RSP \leftarrow RSP + SRC;
                   FI;
         FI;
FI:
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the return code or stack segment selector NULL.

If the return instruction pointer is not within the return code

segment limit

#GP(selector) If the RPL of the return code segment selector is less then the

CPL.

If the return code or stack segment selector index is not within

its descriptor table limits.

If the return code segment descriptor does not indicate a code

segment.

If the return code segment is non-conforming and the segment selector's DPL is not equal to the RPL of the code segment's

segment selector

If the return code segment is conforming and the segment selector's DPL greater than the RPL of the code segment's

segment selector

If the stack segment is not a writable data segment.

If the stack segment selector RPL is not equal to the RPL of the

return code segment selector.

If the stack segment descriptor DPL is not equal to the RPL of

the return code segment selector.

#SS(0) If the top bytes of stack are not within stack limits.

If the return stack segment is not present.

#NP(selector) If the return code segment is not present.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory access occurs when the CPL is 3 and

alignment checking is enabled.

Real-Address Mode Exceptions

#GP If the return instruction pointer is not within the return code

segment limit

#SS If the top bytes of stack are not within stack limits.

Virtual-8086 Mode Exceptions

#GP(0) If the return instruction pointer is not within the return code

segment limit

#SS(0) If the top bytes of stack are not within stack limits.

#PF(fault-code) If a page fault occurs.

#AC(0) If an unaligned memory access occurs when alignment checking

is enabled.

Compatibility Mode Exceptions

Same as 64-bit mode exceptions.

64-Bit Mode Exceptions

#GP(0) If the return instruction pointer is non-canonical.

If the return instruction pointer is not within the return code segment limit.

If the stack segment selector is NULL going back to compatibility mode.

If the stack segment selector is NULL going back to CPL3 64-bit mode.

If a NULL stack segment selector RPL is not equal to CPL going back to non-CPL3 64-bit mode.

If the return code segment selector is NULL.

#GP(selector) If the proposed segment descriptor for a code segment does not indicate it is a code segment.

If the proposed new code segment descriptor has both the D-bit and L-bit set.

If the DPL for a nonconforming-code segment is not equal to the RPL of the code segment selector.

If CPL is greater than the RPL of the code segment selector. If the DPL of a conforming-code segment is greater than the

return code segment selector RPL.

If a segment selector index is outside its descriptor table limits.

If a segment descriptor memory address is non-canonical.

If the stack segment is not a writable data segment.

If the stack segment descriptor DPL is not equal to the RPL of the return code segment selector.

If the stack segment selector RPL is not equal to the RPL of the $\ensuremath{\mathsf{RPL}}$

return code segment selector.

#SS(0) If an attempt to pop a value off the stack violates the SS limit.

If an attempt to pop a value off the stack causes a non-canonical

address to be referenced.

#NP(selector) If the return code or stack segment is not present.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

ROUNDPD — Round Packed Double Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A O9 /r ib ROUNDPD xmm1, xmm2/m128, imm8	Α	V/V	SSE4_1	Round packed double precision floating-point values in xmm2/m128 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.128.66.0F3A.WIG 09 /r ib VROUNDPD xmm1, xmm2/m128, imm8	A	V/V	AVX	Round packed double- precision floating-point values in xmm2/m128 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.256.66.0F3A.WIG 09 /r ib VROUNDPD ymm1, ymm2/m256, imm8	Α	V/V	AVX	Round packed double- precision floating-point values in ymm2/m256 and place the result in ymm1. The rounding mode is determined by imm8.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA

Description

Round the 2 double-precision floating-point values in the source operand (second operand) using the rounding mode specified in the immediate operand (third operand) and place the results in the destination operand (first operand). The rounding process rounds each input floating-point value to an integer value and returns the integer result as a single-precision floating-point value.

The immediate operand specifies control fields for the rounding operation, three bit fields are defined and shown in Figure 4-14. Bit 3 of the immediate byte controls processor behavior for a precision exception, bit 2 selects the source of rounding mode control. Bits 1:0 specify a non-sticky rounding-mode value (Table 4-14 lists the encoded values for rounding-mode field).

The Precision Floating-Point Exception is signaled according to the immediate operand. If any source operand is an SNaN then it will be converted to a QNaN. If DAZ is set to '1 then denormals will be converted to zero before rounding.

128-bit Legacy SSE version: The second source can be an XMM register or 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the source operand second source operand or a 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The source operand is a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.




Figure 4-14. Bit Control Fields of Immediate Byte for ROUNDxx Instruction

Rounding Mode	RC Field Setting	Description
Round to nearest (even)	00B	Rounded result is the closest to the infinitely precise result. If two values are equally close, the result is the even value (i.e., the integer value with the least-significant bit of zero).
Round down (toward –∞)	01B	Rounded result is closest to but no greater than the infinitely precise result.
Round up (toward +∞)	10B	Rounded result is closest to but no less than the infinitely precise result.
Round toward zero (Truncate)	11B	Rounded result is closest to but no greater in absolute value than the infinitely precise result.

Table 4-14. Rounding Modes and Encoding of Rounding Control (RC) Field

Operation

```
IF (imm[2] = '1)

THEN  // rounding mode is determined by MXCSR.RC

DEST[63:0] ← ConvertDPFPToInteger_M(SRC[63:0]);

DEST[127:64] ← ConvertDPFPToInteger_M(SRC[127:64]);
```

```
ELSE // rounding mode is determined by IMM8.RC

DEST[63:0] ← ConvertDPFPToInteger_Imm(SRC[63:0]);

DEST[127:64] ← ConvertDPFPToInteger_Imm(SRC[127:64]);

FI
```

ROUNDPD (128-bit Legacy SSE version)

DEST[63:0] ← RoundToInteger(SRC[63:0]], ROUND_CONTROL)
DEST[127:64] ← RoundToInteger(SRC[127:64]], ROUND_CONTROL)
DEST[VLMAX-1:128] (Unmodified)

VROUNDPD (VEX.128 encoded version)

 $\begin{aligned} & \mathsf{DEST}[63:0] \leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[63:0]], \mathsf{ROUND_CONTROL}) \\ & \mathsf{DEST}[127:64] \leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[127:64]], \mathsf{ROUND_CONTROL}) \\ & \mathsf{DEST}[\mathsf{VLMAX-1:128}] \leftarrow 0 \end{aligned}$

VROUNDPD (VEX.256 encoded version)

DEST[63:0] \leftarrow RoundToInteger(SRC[63:0], ROUND_CONTROL)
DEST[127:64] \leftarrow RoundToInteger(SRC[127:64]], ROUND_CONTROL)
DEST[191:128] \leftarrow RoundToInteger(SRC[191:128]], ROUND_CONTROL)
DEST[255:192] \leftarrow RoundToInteger(SRC[255:192]], ROUND_CONTROL)

Intel C/C++ Compiler Intrinsic Equivalent

```
__m128 _mm_round_pd(__m128d s1, int iRoundMode);
__m128 _mm_floor_pd(__m128d s1);
__m128 _mm_ceil_pd(__m128d s1)
__m256 _mm256_round_pd(__m256d s1, int iRoundMode);
__m256 _mm256_floor_pd(__m256d s1);
__m256 _mm256_ceil_pd(__m256d s1)
```

SIMD Floating-Point Exceptions

Invalid (signaled only if SRC = SNaN)

Precision (signaled only if imm[3] = 0; if imm[3] = 1, then the Precision Mask in the MXSCSR is ignored and precision exception is not signaled.)

Note that Denormal is not signaled by ROUNDPD.

Other Exceptions

```
See Exceptions Type 2; additionally #UD If VEX.vvvv != 1111B.
```

ROUNDPS — Round Packed Single Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A 08 /r ib ROUNDPS xmm1, xmm2/m128, imm8	A	V/V	SSE4_1	Round packed single precision floating-point values in xmm2/m128 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.128.66.0F3A.WIG 08 /r ib VROUNDPS xmm1, xmm2/m128, imm8	Α	V/V	AVX	Round packed single- precision floating-point values in xmm2/m128 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.256.66.0F3A.WIG 08 /r ib VROUNDPS ymm1, ymm2/m256, imm8	Α	V/V	AVX	Round packed single- precision floating-point values in ymm2/m256 and place the result in ymm1. The rounding mode is determined by imm8.

Instruction Operand Encoding

					_
Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA	

Description

Round the 4 single-precision floating-point values in the source operand (second operand) using the rounding mode specified in the immediate operand (third operand) and place the results in the destination operand (first operand). The rounding process rounds each input floating-point value to an integer value and returns the integer result as a single-precision floating-point value.

The immediate operand specifies control fields for the rounding operation, three bit fields are defined and shown in Figure 4-14. Bit 3 of the immediate byte controls processor behavior for a precision exception, bit 2 selects the source of rounding mode control. Bits 1:0 specify a non-sticky rounding-mode value (Table 4-14 lists the encoded values for rounding-mode field).

The Precision Floating-Point Exception is signaled according to the immediate operand. If any source operand is an SNaN then it will be converted to a QNaN. If DAZ is set to '1 then denormals will be converted to zero before rounding.

128-bit Legacy SSE version: The second source can be an XMM register or 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the source operand second source operand or a 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The source operand is a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD.

Operation

```
IF (imm[2] = '1)

THEN  // rounding mode is determined by MXCSR.RC

DEST[31:0] ← ConvertSPFPToInteger_M(SRC[31:0]);

DEST[63:32] ← ConvertSPFPToInteger_M(SRC[63:32]);

DEST[95:64] ← ConvertSPFPToInteger_M(SRC[95:64]);

DEST[127:96] ← ConvertSPFPToInteger_M(SRC[127:96]);

ELSE  // rounding mode is determined by IMM8.RC

DEST[31:0] ← ConvertSPFPToInteger_Imm(SRC[31:0]);

DEST[63:32] ← ConvertSPFPToInteger_Imm(SRC[63:32]);

DEST[95:64] ← ConvertSPFPToInteger_Imm(SRC[95:64]);

DEST[127:96] ← ConvertSPFPToInteger_Imm(SRC[127:96]);

FI;
```

ROUNDPS(128-bit Legacy SSE version)

```
\begin{split} \mathsf{DEST}[31:0] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[31:0], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[63:32] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[63:32], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[95:64] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[95:64]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[127:96] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[127:96]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] & (\mathsf{Unmodified}) \end{split}
```

VROUNDPS (VEX.128 encoded version)

```
\begin{split} \mathsf{DEST}[31:0] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[31:0], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[63:32] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[63:32], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[95:64] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[95:64]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[127:96] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[127:96]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] &\leftarrow \mathsf{O} \end{split}
```

VROUNDPS (VEX.256 encoded version)

DEST[31:0] ← RoundToInteger(SRC[31:0], ROUND_CONTROL)

```
\begin{aligned} \mathsf{DEST}[63:32] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[63:32], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[95:64] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[95:64]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[127:96] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[127:96]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[159:128] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[159:128]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[191:160] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[191:160]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[223:192] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[223:192]], \mathsf{ROUND\_CONTROL}) \\ \mathsf{DEST}[255:224] &\leftarrow \mathsf{RoundToInteger}(\mathsf{SRC}[255:224]], \mathsf{ROUND\_CONTROL}) \end{aligned}
```

Intel C/C++ Compiler Intrinsic Equivalent

```
__m128 _mm_round_ps(__m128 s1, int iRoundMode);
__m128 _mm_floor_ps(__m128 s1);
__m128 _mm_ceil_ps(__m128 s1)
__m256 _mm256_round_ps(__m256 s1, int iRoundMode);
__m256 _mm256_floor_ps(__m256 s1);
__m256 _mm256_ceil_ps(__m256 s1)
```

SIMD Floating-Point Exceptions

Invalid (signaled only if SRC = SNaN)

Precision (signaled only if imm[3] = `0; if imm[3] = `1, then the Precision Mask in the MXSCSR is ignored and precision exception is not signaled.)

Note that Denormal is not signaled by ROUNDPS.

Other Exceptions

```
See Exceptions Type 2; additionally #UD If VEX.vvvv != 1111B.
```

ROUNDSD — Round Scalar Double Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A OB /r ib ROUNDSD xmm1, xmm2/m64, imm8	Α	V/V	SSE4_1	Round the low packed double precision floating-point value in xmm2/m64 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.NDS.LIG.66.0F3A.WIG 0B /r ib VROUNDSD xmm1, xmm2, xmm3/m64, imm8	В	V/V	AVX	Round the low packed double precision floating-point value in xmm3/m64 and place the result in xmm1. The rounding mode is determined by imm8. Upper packed double precision floating-point value (bits[127:64]) from xmm2 is copied to xmm1[127:64].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Round the DP FP value in the lower qword of the source operand (second operand) using the rounding mode specified in the immediate operand (third operand) and place the result in the destination operand (first operand). The rounding process rounds a double-precision floating-point input to an integer value and returns the integer result as a double precision floating-point value in the lowest position. The upper double precision floating-point value in the destination is retained.

The immediate operand specifies control fields for the rounding operation, three bit fields are defined and shown in Figure 4-14. Bit 3 of the immediate byte controls processor behavior for a precision exception, bit 2 selects the source of rounding mode control. Bits 1:0 specify a non-sticky rounding-mode value (Table 4-14 lists the encoded values for rounding-mode field).

The Precision Floating-Point Exception is signaled according to the immediate operand. If any source operand is an SNaN then it will be converted to a QNaN. If DAZ is set to '1 then denormals will be converted to zero before rounding.

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:64) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

ROUNDSD (128-bit Legacy SSE version)

DEST[63:0] ← RoundToInteger(SRC[63:0], ROUND_CONTROL)
DEST[VLMAX-1:64] (Unmodified)

VROUNDSD (VEX.128 encoded version)

```
DEST[63:0] \leftarrow RoundToInteger(SRC2[63:0], ROUND_CONTROL)
DEST[127:64] \leftarrow SRC1[127:64]
DEST[VLMAX-1:128] \leftarrow 0
```

Intel C/C++ Compiler Intrinsic Equivalent

```
ROUNDSD __m128d mm_round_sd(__m128d dst, __m128d s1, int iRoundMode);
   __m128d mm_floor_sd(__m128d dst, __m128d s1);
   __m128d mm_ceil_sd(__m128d dst, __m128d s1);
```

SIMD Floating-Point Exceptions

Invalid (signaled only if SRC = SNaN)

Precision (signaled only if imm[3] = `0; if imm[3] = `1, then the Precision Mask in the MXSCSR is ignored and precision exception is not signaled.)

Note that Denormal is not signaled by ROUNDSD.

Other Exceptions

See Exceptions Type 3.

ROUNDSS — Round Scalar Single Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 3A OA /r ib ROUNDSS xmm1, xmm2/m32, imm8	Α	V/V	SSE4_1	Round the low packed single precision floating-point value in xmm2/m32 and place the result in xmm1. The rounding mode is determined by imm8.
VEX.NDS.LIG.66.0F3A.WIG OA ib VROUNDSS xmm1, xmm2, xmm3/m32, imm8	В	V/V	AVX	Round the low packed single precision floating-point value in xmm3/m32 and place the result in xmm1. The rounding mode is determined by imm8. Also, upper packed single precision floating-point values (bits[127:32]) from xmm2 are copied to xmm1[127:32].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Round the single-precision floating-point value in the lowest dword of the source operand (second operand) using the rounding mode specified in the immediate operand (third operand) and place the result in the destination operand (first operand). The rounding process rounds a single-precision floating-point input to an integer value and returns the result as a single-precision floating-point value in the lowest position. The upper three single-precision floating-point values in the destination are retained.

The immediate operand specifies control fields for the rounding operation, three bit fields are defined and shown in Figure 4-14. Bit 3 of the immediate byte controls processor behavior for a precision exception, bit 2 selects the source of rounding mode control. Bits 1:0 specify a non-sticky rounding-mode value (Table 4-14 lists the encoded values for rounding-mode field).

The Precision Floating-Point Exception is signaled according to the immediate operand. If any source operand is an SNaN then it will be converted to a QNaN. If DAZ is set to '1 then denormals will be converted to zero before rounding.

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:32) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

ROUNDSS (128-bit Legacy SSE version)

DEST[31:0] ← RoundToInteger(SRC[31:0], ROUND_CONTROL)
DEST[VLMAX-1:32] (Unmodified)

VROUNDSS (VEX.128 encoded version)

DEST[31:0] \leftarrow RoundToInteger(SRC2[31:0], ROUND_CONTROL) DEST[127:32] \leftarrow SRC1[127:32] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

```
ROUNDSS __m128 mm_round_ss(__m128 dst, __m128 s1, int iRoundMode);

__m128 mm_floor_ss(__m128 dst, __m128 s1);

__m128 mm_ceil_ss(__m128 dst, __m128 s1);
```

SIMD Floating-Point Exceptions

Invalid (signaled only if SRC = SNaN)

Precision (signaled only if imm[3] = `0; if imm[3] = `1, then the Precision Mask in the MXSCSR is ignored and precision exception is not signaled.)

Note that Denormal is not signaled by ROUNDSS.

Other Exceptions

See Exceptions Type 3.

RSM—Resume from System Management Mode

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF AA	RSM	Α	Invalid	Valid	Resume operation of interrupted program.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	NA	NA	NA	NA	

Description

Returns program control from system management mode (SMM) to the application program or operating-system procedure that was interrupted when the processor received an SMM interrupt. The processor's state is restored from the dump created upon entering SMM. If the processor detects invalid state information during state restoration, it enters the shutdown state. The following invalid information can cause a shutdown:

- Any reserved bit of CR4 is set to 1.
- Any illegal combination of bits in CR0, such as (PG=1 and PE=0) or (NW=1 and CD=0).
- (Intel Pentium and Intel486[™] processors only.) The value stored in the state dump base field is not a 32-KByte aligned address.

The contents of the model-specific registers are not affected by a return from SMM.

The SMM state map used by RSM supports resuming processor context for non-64-bit modes and 64-bit mode.

See Chapter 26, "System Management," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, for more information about SMM and the behavior of the RSM instruction.

Operation

ReturnFromSMM:

```
 \begin{tabular}{l} IF (IA-32e mode supported) or (CPUID DisplayFamily\_DisplayModel = 06H\_OCH) \\ THEN \\ ProcessorState \leftarrow Restore(SMMDump(IA-32e SMM STATE MAP)); \\ Else \\ \end{tabular}
```

ProcessorState ← Restore(SMMDump(Non-32-Bit-Mode SMM STATE MAP));

FΙ

Flags Affected

All.

Protected Mode Exceptions

#UD If an attempt is made to execute this instruction when the

processor is not in SMM. If the LOCK prefix is used.

Real-Address Mode Exceptions

Same exceptions as in protected mode.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

RSQRTPS—Compute Reciprocals of Square Roots of Packed Single-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 52 /r RSQRTPS xmm1, xmm2/m128	Α	V/V	SSE	Computes the approximate reciprocals of the square roots of the packed single-precision floating-point values in xmm2/m128 and stores the results in xmm1.
VEX.128.0F.WIG 52 /r VRSQRTPS xmm1, xmm2/m128	Α	V/V	AVX	Computes the approximate reciprocals of the square roots of packed single-precision values in xmm2/mem and stores the results in xmm1.
VEX.256.0F.WIG 52 /r VRSQRTPS ymm1, ymm2/m256	Α	V/V	AVX	Computes the approximate reciprocals of the square roots of packed single-precision values in ymm2/mem and stores the results in ymm1.

Instruction Operand Encoding

		monoconom operant an		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Performs a SIMD computation of the approximate reciprocals of the square roots of the four packed single-precision floating-point values in the source operand (second operand) and stores the packed single-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 10-5 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for an illustration of a SIMD single-precision floating-point operation.

The relative error for this approximation is:

|Relative Error| $\leq 1.5 * 2^{-12}$

The RSQRTPS instruction is not affected by the rounding control bits in the MXCSR register. When a source value is a 0.0, an ∞ of the sign of the source value is returned. A denormal source value is treated as a 0.0 (of the same sign). When a

source value is a negative value (other than -0.0), a floating-point indefinite is returned. When a source value is an SNaN or QNaN, the SNaN is converted to a QNaN or the source QNaN is returned.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

RSQRTPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow APPROXIMATE(1/SQRT(SRC[31:0]))

DEST[63:32] \leftarrow APPROXIMATE(1/SQRT(SRC1[63:32]))

DEST[95:64] \leftarrow APPROXIMATE(1/SQRT(SRC1[95:64]))

DEST[127:96] \leftarrow APPROXIMATE(1/SQRT(SRC2[127:96]))

DEST[VLMAX-1:128] (Unmodified)

VRSQRTPS (VEX.128 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SQRT(SRC[31:0]))

DEST[63:32] \leftarrow APPROXIMATE(1/SQRT(SRC1[63:32]))

DEST[95:64] \leftarrow APPROXIMATE(1/SQRT(SRC1[95:64]))

DEST[127:96] \leftarrow APPROXIMATE(1/SQRT(SRC2[127:96]))

DEST[VLMAX-1:128] \leftarrow 0

VRSQRTPS (VEX.256 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SQRT(SRC[31:0]))

DEST[63:32] \leftarrow APPROXIMATE(1/SQRT(SRC1[63:32]))

DEST[95:64] \leftarrow APPROXIMATE(1/SQRT(SRC1[95:64]))

DEST[127:96] \leftarrow APPROXIMATE(1/SQRT(SRC2[127:96]))

DEST[159:128] \leftarrow APPROXIMATE(1/SQRT(SRC2[159:128]))

DEST[191:160] \leftarrow APPROXIMATE(1/SQRT(SRC2[191:160]))

DEST[223:192] \leftarrow APPROXIMATE(1/SQRT(SRC2[223:192]))

DEST[255:224] \leftarrow APPROXIMATE(1/SQRT(SRC2[255:224]))

Intel C/C++ Compiler Intrinsic Equivalent

RSQRTPS __m128 _mm_rsqrt_ps(__m128 a) RSQRTPS __m256 _mm256_rsqrt_ps (__m256 a);

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally #UD If VEX.vvvv != 1111B.

RSQRTSS—Compute Reciprocal of Square Root of Scalar Single-Precision Floating-Point Value

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F3 OF 52 /r RSQRTSS xmm1, xmm2/m32	Α	V/V	SSE	Computes the approximate reciprocal of the square root of the low single-precision floating-point value in xmm2/m32 and stores the results in xmm1.
VEX.NDS.LIG.F3.0F.WIG 52 /r VRSQRTSS xmm1, xmm2, xmm3/m32	В	V/V	AVX	Computes the approximate reciprocal of the square root of the low single precision floating-point value in xmm3/m32 and stores the results in xmm1. Also, upper single precision floating-point values (bits[127:32]) from xmm2 are copied to xmm1[127:32].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Computes an approximate reciprocal of the square root of the low single-precision floating-point value in the source operand (second operand) stores the single-precision floating-point result in the destination operand. The source operand can be an XMM register or a 32-bit memory location. The destination operand is an XMM register. The three high-order doublewords of the destination operand remain unchanged. See Figure 10-6 in the <code>Intel</code>® 64 and <code>IA-32</code> Architectures Software <code>Developer's Manual, Volume 1,</code> for an illustration of a scalar single-precision floating-point operation.

The relative error for this approximation is:

|Relative Error|
$$\leq 1.5 * 2^{-12}$$

The RSQRTSS instruction is not affected by the rounding control bits in the MXCSR register. When a source value is a 0.0, an ∞ of the sign of the source value is returned. A denormal source value is treated as a 0.0 (of the same sign). When a

source value is a negative value (other than -0.0), a floating-point indefinite is returned. When a source value is an SNaN or QNaN, the SNaN is converted to a QNaN or the source QNaN is returned.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:32) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

RSQRTSS (128-bit Legacy SSE version)

DEST[31:0] ← APPROXIMATE(1/SQRT(SRC2[31:0]))
DEST[VLMAX-1:32] (Unmodified)

VRSQRTSS (VEX.128 encoded version)

DEST[31:0] \leftarrow APPROXIMATE(1/SQRT(SRC2[31:0])) DEST[127:32] \leftarrow SRC1[31:0] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

RSQRTSS __m128 _mm_rsqrt_ss(__m128 a)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5.

SAHF—Store AH into Flags

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
9E	SAHF	Α	Invalid*	Valid	Loads SF, ZF, AF, PF, and CF from AH into EFLAGS register.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Loads the SF, ZF, AF, PF, and CF flags of the EFLAGS register with values from the corresponding bits in the AH register (bits 7, 6, 4, 2, and 0, respectively). Bits 1, 3, and 5 of register AH are ignored; the corresponding reserved bits (1, 3, and 5) in the EFLAGS register remain as shown in the "Operation" section below.

This instruction executes as described above in compatibility mode and legacy mode. It is valid in 64-bit mode only if CPUID.80000001H:ECX.LAHF-SAHF[bit 0] = 1.

Operation

Flags Affected

The SF, ZF, AF, PF, and CF flags are loaded with values from the AH register. Bits 1, 3, and 5 of the EFLAGS register are unaffected, with the values remaining 1, 0, and 0, respectively.

^{*} Valid in specific steppings. See Description section.

Protected Mode Exceptions

None.

Real-Address Mode Exceptions

None.

Virtual-8086 Mode Exceptions

None.

Compatibility Mode Exceptions

None.

64-Bit Mode Exceptions

#UD If CPUID.80000001H.ECX[0] = 0.

If the LOCK prefix is used.

SAL/SAR/SHL/SHR—Shift

Opcode***	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
D0 /4	SAL <i>r/m8</i> , 1	Α	Valid	Valid	Multiply r/m8 by 2, once.
REX + D0 /4	SAL <i>r/m8**</i> , 1	Α	Valid	N.E.	Multiply r/m8 by 2, once.
D2 /4	SAL r/m8, CL	В	Valid	Valid	Multiply r/m8 by 2, CL times.
REX + D2 /4	SAL <i>r/m8**</i> , CL	В	Valid	N.E.	Multiply r/m8 by 2, CL times.
CO /4 ib	SAL r/m8, imm8	С	Valid	Valid	Multiply <i>r/m8</i> by 2, <i>imm8</i> times.
REX + CO /4 ib	SAL r/m8**, imm8	С	Valid	N.E.	Multiply <i>r/m8</i> by 2, <i>imm8</i> times.
D1 /4	SAL <i>r/m16</i> , 1	Α	Valid	Valid	Multiply r/m16 by 2, once.
D3 /4	SAL r/m16, CL	В	Valid	Valid	Multiply <i>r/m16</i> by 2, CL times.
C1 /4 ib	SAL r/m16, imm8	С	Valid	Valid	Multiply <i>r/m16</i> by 2, <i>imm8</i> times.
D1 /4	SAL <i>r/m32</i> , 1	Α	Valid	Valid	Multiply <i>r/m32</i> by 2, once.
REX.W + D1 /4	SAL <i>r/m64</i> , 1	Α	Valid	N.E.	Multiply r/m64 by 2, once.
D3 /4	SAL <i>r/m32</i> , CL	В	Valid	Valid	Multiply <i>r/m32</i> by 2, CL times.
REX.W + D3 /4	SAL r/m64, CL	В	Valid	N.E.	Multiply <i>r/m64</i> by 2, CL times.
C1 /4 ib	SAL r/m32, imm8	С	Valid	Valid	Multiply <i>r/m32</i> by 2, <i>imm8</i> times.
REX.W + C1 /4 ib	SAL r/m64, imm8	С	Valid	N.E.	Multiply <i>r/m64</i> by 2, <i>imm8</i> times.
D0 /7	SAR <i>r/m8</i> , 1	Α	Valid	Valid	Signed divide* <i>r/m8</i> by 2, once.
REX + D0 /7	SAR <i>r/m8**</i> , 1	Α	Valid	N.E.	Signed divide* <i>r/m8</i> by 2, once.
D2 /7	SAR r/m8, CL	В	Valid	Valid	Signed divide* r/m8 by 2, CL times.
REX + D2 /7	SAR r/m8**, CL	В	Valid	N.E.	Signed divide* <i>r/m8</i> by 2, CL times.
CO /7 ib	SAR r/m8, imm8	С	Valid	Valid	Signed divide* <i>r/m8</i> by 2, imm8 time.
REX + CO /7 ib	SAR r/m8**, imm8	С	Valid	N.E.	Signed divide* r/m8 by 2, imm8 times.

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
D1 /7	SAR <i>r/m16</i> ,1	Α	Valid	Valid	Signed divide* r/m16 by 2, once.
D3 /7	SAR <i>r/m16</i> , CL	В	Valid	Valid	Signed divide* r/m16 by 2, CL times.
C1 /7 ib	SAR r/m16, imm8	С	Valid	Valid	Signed divide* r/m16 by 2, imm8 times.
D1 /7	SAR <i>r/m32</i> , 1	Α	Valid	Valid	Signed divide* <i>r/m32</i> by 2, once.
REX.W + D1 /7	SAR <i>r/m64</i> , 1	Α	Valid	N.E.	Signed divide* r/m64 by 2, once.
D3 /7	SAR <i>r/m32</i> , CL	В	Valid	Valid	Signed divide* <i>r/m32</i> by 2, CL times.
REX.W + D3 /7	SAR <i>r/m64</i> , CL	В	Valid	N.E.	Signed divide* r/m64 by 2, CL times.
C1 /7 ib	SAR r/m32, imm8	С	Valid	Valid	Signed divide* <i>r/m32</i> by 2, <i>imm8</i> times.
REX.W + C1 /7 ib	SAR r/m64, imm8	С	Valid	N.E.	Signed divide* r/m64 by 2, imm8 times
D0 /4	SHL <i>r/m8</i> , 1	Α	Valid	Valid	Multiply <i>r/m8</i> by 2, once.
REX + D0 /4	SHL <i>r/m8**</i> , 1	Α	Valid	N.E.	Multiply <i>r/m8</i> by 2, once.
D2 /4	SHL r/m8, CL	В	Valid	Valid	Multiply <i>r/m8</i> by 2, CL times.
REX + D2 /4	SHL r/m8**, CL	В	Valid	N.E.	Multiply <i>r/m8</i> by 2, CL times.
CO /4 ib	SHL r/m8, imm8	С	Valid	Valid	Multiply <i>r/m8</i> by 2, <i>imm8</i> times.
REX + CO /4 ib	SHL r/m8**, imm8	С	Valid	N.E.	Multiply <i>r/m8</i> by 2, <i>imm8</i> times.
D1 /4	SHL <i>r/m16</i> ,1	Α	Valid	Valid	Multiply <i>r/m16</i> by 2, once.
D3 /4	SHL r/m16, CL	В	Valid	Valid	Multiply <i>r/m16</i> by 2, CL times.
C1 /4 ib	SHL r/m16, imm8	С	Valid	Valid	Multiply <i>r/m16</i> by 2, <i>imm8</i> times.
D1 /4	SHL <i>r/m32</i> ,1	Α	Valid	Valid	Multiply <i>r/m32</i> by 2, once.
REX.W + D1 /4	SHL <i>r/m64</i> ,1	Α	Valid	N.E.	Multiply <i>r/m64</i> by 2, once.
D3 /4	SHL r/m32, CL	В	Valid	Valid	Multiply <i>r/m32</i> by 2, CL times.
REX.W + D3 /4	SHL <i>r/m64</i> , CL	В	Valid	N.E.	Multiply <i>r/m64</i> by 2, CL times.

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
C1 /4 ib	SHL r/m32, imm8	С	Valid	Valid	Multiply <i>r/m32</i> by 2, <i>imm8</i> times.
REX.W + C1 /4 ib	SHL r/m64, imm8	С	Valid	N.E.	Multiply <i>r/m64</i> by 2, <i>imm8</i> times.
D0 /5	SHR <i>r/m8</i> ,1	Α	Valid	Valid	Unsigned divide <i>r/m8</i> by 2, once.
REX + D0 /5	SHR <i>r/m8**</i> , 1	Α	Valid	N.E.	Unsigned divide <i>r/m8</i> by 2, once.
D2 /5	SHR <i>r/m8</i> , CL	В	Valid	Valid	Unsigned divide <i>r/m8</i> by 2, CL times.
REX + D2 /5	SHR <i>r/m8**</i> , CL	В	Valid	N.E.	Unsigned divide <i>r/m8</i> by 2, CL times.
CO /5 ib	SHR r/m8, imm8	С	Valid	Valid	Unsigned divide r/m8 by 2, imm8 times.
REX + CO /5 ib	SHR r/m8**, imm8	С	Valid	N.E.	Unsigned divide r/m8 by 2, imm8 times.
D1 /5	SHR <i>r/m16</i> , 1	Α	Valid	Valid	Unsigned divide <i>r/m16</i> by 2, once.
D3 /5	SHR <i>r/m16</i> , CL	В	Valid	Valid	Unsigned divide <i>r/m16</i> by 2, CL times
C1 /5 ib	SHR r/m16, imm8	С	Valid	Valid	Unsigned divide <i>r/m16</i> by 2, <i>imm8</i> times.
D1 /5	SHR <i>r/m32</i> , 1	Α	Valid	Valid	Unsigned divide <i>r/m32</i> by 2, once.
REX.W + D1 /5	SHR <i>r/m64</i> , 1	Α	Valid	N.E.	Unsigned divide <i>r/m64</i> by 2, once.
D3 /5	SHR r/m32, CL	В	Valid	Valid	Unsigned divide <i>r/m32</i> by 2, CL times.
REX.W + D3 /5	SHR <i>r/m64</i> , CL	В	Valid	N.E.	Unsigned divide <i>r/m64</i> by 2, CL times.
C1 /5 ib	SHR r/m32, imm8	С	Valid	Valid	Unsigned divide <i>r/m32</i> by 2, <i>imm8</i> times.
REX.W + C1 /5 ib	SHR r/m64, imm8	С	Valid	N.E.	Unsigned divide <i>r/m64</i> by 2, <i>imm8</i> times.

NOTES:

- * Not the same form of division as IDIV; rounding is toward negative infinity.
- ** In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH. BH. CH. DH.
- ***See IA-32 Architecture Compatibility section below.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r, w)	1	NA	NA
В	ModRM:r/m (r, w)	CL (r)	NA	NA
С	ModRM:r/m (r, w)	imm8	NA	NA

Description

Shifts the bits in the first operand (destination operand) to the left or right by the number of bits specified in the second operand (count operand). Bits shifted beyond the destination operand boundary are first shifted into the CF flag, then discarded. At the end of the shift operation, the CF flag contains the last bit shifted out of the destination operand.

The destination operand can be a register or a memory location. The count operand can be an immediate value or the CL register. The count is masked to 5 bits (or 6 bits if in 64-bit mode and REX.W is used). The count range is limited to 0 to 31 (or 63 if 64-bit mode and REX.W is used). A special opcode encoding is provided for a count of 1.

The shift arithmetic left (SAL) and shift logical left (SHL) instructions perform the same operation; they shift the bits in the destination operand to the left (toward more significant bit locations). For each shift count, the most significant bit of the destination operand is shifted into the CF flag, and the least significant bit is cleared (see Figure 7-7 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1).

The shift arithmetic right (SAR) and shift logical right (SHR) instructions shift the bits of the destination operand to the right (toward less significant bit locations). For each shift count, the least significant bit of the destination operand is shifted into the CF flag, and the most significant bit is either set or cleared depending on the instruction type. The SHR instruction clears the most significant bit (see Figure 7-8 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1); the SAR instruction sets or clears the most significant bit to correspond to the sign (most significant bit) of the original value in the destination operand. In effect, the SAR instruction fills the empty bit position's shifted value with the sign of the unshifted value (see Figure 7-9 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1).

The SAR and SHR instructions can be used to perform signed or unsigned division, respectively, of the destination operand by powers of 2. For example, using the SAR instruction to shift a signed integer 1 bit to the right divides the value by 2.

Using the SAR instruction to perform a division operation does not produce the same result as the IDIV instruction. The quotient from the IDIV instruction is rounded toward zero, whereas the "quotient" of the SAR instruction is rounded toward negative infinity. This difference is apparent only for negative numbers. For example, when the IDIV instruction is used to divide -9 by 4, the result is -2 with a remainder of -1. If the SAR instruction is used to shift -9 right by two bits, the result is -3 and the "remainder" is +3; however, the SAR instruction stores only the most significant bit of the remainder (in the CF flag).

The OF flag is affected only on 1-bit shifts. For left shifts, the OF flag is set to 0 if the most-significant bit of the result is the same as the CF flag (that is, the top two bits of the original operand were the same); otherwise, it is set to 1. For the SAR instruction, the OF flag is cleared for all 1-bit shifts. For the SHR instruction, the OF flag is set to the most-significant bit of the original operand.

In 64-bit mode, the instruction's default operation size is 32 bits and the mask width for CL is 5 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64-bits and sets the mask width for CL to 6 bits. See the summary chart at the beginning of this section for encoding data and limits.

IA-32 Architecture Compatibility

The 8086 does not mask the shift count. However, all other IA-32 processors (starting with the Intel 286 processor) do mask the shift count to 5 bits, resulting in a maximum count of 31. This masking is done in all operating modes (including the virtual-8086 mode) to reduce the maximum execution time of the instructions.

Operation

```
IF 64-Bit Mode and using REX.W

THEN

countMASK ← 3FH;

ELSE

countMASK ← 1FH;

FI

tempCOUNT ← (COUNT AND countMASK);
tempDEST ← DEST;

WHILE (tempCOUNT ≠ 0)

DO

IF instruction is SAL or SHL

THEN

CF ← MSB(DEST);
```

```
ELSE (* Instruction is SAR or SHR *)
             CF \leftarrow LSB(DEST);
   FI:
   IF instruction is SAL or SHL
        THEN
             DEST \leftarrow DEST * 2;
        ELSE
             IF instruction is SAR
                  THEN
                       DEST ← DEST / 2; (* Signed divide, rounding toward negative infinity *)
                  ELSE (* Instruction is SHR *)
                       DEST ← DEST / 2; (* Unsigned divide *)
             FI;
   FI:
   tempCOUNT \leftarrow tempCOUNT - 1;
OD;
(* Determine overflow for the various instructions *)
IF (COUNT and countMASK) = 1
   THEN
        IF instruction is SAL or SHL
             THEN
                  OF \leftarrow MSB(DEST) XOR CF;
             ELSE
                  IF instruction is SAR
                       THEN
                            0F \leftarrow 0;
                       ELSE (* Instruction is SHR *)
                            OF \leftarrow MSB(tempDEST);
                  FI:
        FI;
   ELSE IF (COUNT AND countMASK) = 0
        THEN
             All flags unchanged;
        ELSE (* COUNT not 1 or 0 *)
             OF ← undefined:
   FI;
FI:
```

Flags Affected

The CF flag contains the value of the last bit shifted out of the destination operand; it is undefined for SHL and SHR instructions where the count is greater than or equal to the size (in bits) of the destination operand. The OF flag is affected only for 1-bit

shifts (see "Description" above); otherwise, it is undefined. The SF, ZF, and PF flags are set according to the result. If the count is 0, the flags are not affected. For a non-zero count, the AF flag is undefined.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

If alignment checking is enabled and an unaligned memory reference is made while the current privilege level is 3. #AC(0)

If the LOCK prefix is used. #UD

SBB—Integer Subtraction with Borrow

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
1C ib	SBB AL, imm8	Α	Valid	Valid	Subtract with borrow <i>imm8</i> from AL.
1D <i>iw</i>	SBB AX, imm16	Α	Valid	Valid	Subtract with borrow imm16 from AX.
1D id	SBB EAX, imm32	Α	Valid	Valid	Subtract with borrow imm32 from EAX.
REX.W + 1D id	SBB RAX, imm32	Α	Valid	N.E.	Subtract with borrow signextended <i>imm.32 to 64-bits</i> from RAX.
80 /3 ib	SBB r/m8, imm8	В	Valid	Valid	Subtract with borrow <i>imm8</i> from <i>r/m8</i> .
REX + 80 /3 ib	SBB r/m8*, imm8	В	Valid	N.E.	Subtract with borrow <i>imm8</i> from <i>r/m8</i> .
81 /3 iw	SBB r/m16, imm16	В	Valid	Valid	Subtract with borrow imm16 from r/m16.
81 /3 id	SBB r/m32, imm32	В	Valid	Valid	Subtract with borrow imm32 from r/m32.
REX.W + 81 /3 id	SBB r/m64, imm32	В	Valid	N.E.	Subtract with borrow signextended <i>imm32 to 64-bits</i> from <i>r/m64</i> .
83 /3 ib	SBB r/m16, imm8	В	Valid	Valid	Subtract with borrow signextended <i>imm8</i> from <i>r/m16</i> .
83 /3 ib	SBB r/m32, imm8	В	Valid	Valid	Subtract with borrow signextended <i>imm8</i> from <i>r/m32</i> .
REX.W + 83 /3 ib	SBB r/m64, imm8	В	Valid	N.E.	Subtract with borrow signextended <i>imm8</i> from <i>r/m64</i> .
18 /r	SBB r/m8, r8	С	Valid	Valid	Subtract with borrow <i>r8</i> from <i>r/m8</i> .
REX + 18 /r	SBB r/m8*, r8	С	Valid	N.E.	Subtract with borrow <i>r8</i> from <i>r/m8</i> .
19 /r	SBB r/m16, r16	С	Valid	Valid	Subtract with borrow <i>r16</i> from <i>r/m16</i> .
19 /r	SBB r/m32, r32	С	Valid	Valid	Subtract with borrow <i>r32</i> from <i>r/m32</i> .
REX.W + 19 /r	SBB r/m64, r64	С	Valid	N.E.	Subtract with borrow <i>r64</i> from <i>r/m64</i> .

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
1A /r	SBB r8, r/m8	D	Valid	Valid	Subtract with borrow <i>r/m8</i> from <i>r8</i> .
REX + 1A /r	SBB <i>r8*, r/m8*</i>	D	Valid	N.E.	Subtract with borrow <i>r/m8</i> from <i>r8.</i>
1B /r	SBB r16, r/m16	D	Valid	Valid	Subtract with borrow <i>r/m16</i> from <i>r16</i> .
1B /r	SBB <i>r32, r/m32</i>	D	Valid	Valid	Subtract with borrow <i>r/m32</i> from <i>r32</i> .
REX.W + 1B /r	SBB <i>r64, r/m64</i>	D	Valid	N.E.	Subtract with borrow <i>r/m64</i> from <i>r64</i> .

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	AL/AX/EAX/RAX	imm8/16/32	NA	NA
В	ModRM:r/m (w)	imm8/16/32	NA	NA
С	ModRM:r/m (w)	ModRM:reg (r)	NA	NA
D	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Adds the source operand (second operand) and the carry (CF) flag, and subtracts the result from the destination operand (first operand). The result of the subtraction is stored in the destination operand. The destination operand can be a register or a memory location; the source operand can be an immediate, a register, or a memory location. (However, two memory operands cannot be used in one instruction.) The state of the CF flag represents a borrow from a previous subtraction.

When an immediate value is used as an operand, it is sign-extended to the length of the destination operand format.

The SBB instruction does not distinguish between signed or unsigned operands. Instead, the processor evaluates the result for both data types and sets the OF and CF flags to indicate a borrow in the signed or unsigned result, respectively. The SF flag indicates the sign of the signed result.

The SBB instruction is usually executed as part of a multibyte or multiword subtraction in which a SUB instruction is followed by a SBB instruction.

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

 $DEST \leftarrow (DEST - (SRC + CF));$

Flags Affected

The OF, SF, ZF, AF, PF, and CF flags are set according to the result.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

SCAS/SCASB/SCASW/SCASD—Scan String

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
AE	SCAS m8	Α	Valid	Valid	Compare AL with byte at ES:(E)DI or RDI, then set status flags.*
AF	SCAS m16	Α	Valid	Valid	Compare AX with word at ES:(E)DI or RDI, then set status flags.*
AF	SCAS m32	Α	Valid	Valid	Compare EAX with doubleword at ES(E)DI or RDI then set status flags.*
REX.W + AF	SCAS m64	Α	Valid	N.E.	Compare RAX with quadword at RDI or EDI then set status flags.
AE	SCASB	Α	Valid	Valid	Compare AL with byte at ES:(E)DI or RDI then set status flags.*
AF	SCASW	Α	Valid	Valid	Compare AX with word at ES:(E)DI or RDI then set status flags.*
AF	SCASD	Α	Valid	Valid	Compare EAX with doubleword at ES:(E)DI or RDI then set status flags.*
REX.W + AF	SCASQ	Α	Valid	N.E.	Compare RAX with quadword at RDI or EDI then set status flags.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

In non-64-bit modes and in default 64-bit mode: this instruction compares a byte, word, doubleword or quadword specified using a memory operand with the value in AL, AX, or EAX. It then sets status flags in EFLAGS recording the results. The memory operand address is read from ES:(E)DI register (depending on the address-size

^{*} In 64-bit mode, only 64-bit (RDI) and 32-bit (EDI) address sizes are supported. In non-64-bit mode, only 32-bit (EDI) and 16-bit (DI) address sizes are supported.

attribute of the instruction and the current operational mode). Note that ES cannot be overridden with a segment override prefix.

At the assembly-code level, two forms of this instruction are allowed. The explicit-operand form and the no-operands form. The explicit-operand form (specified using the SCAS mnemonic) allows a memory operand to be specified explicitly. The memory operand must be a symbol that indicates the size and location of the operand value. The register operand is then automatically selected to match the size of the memory operand (AL register for byte comparisons, AX for word comparisons, EAX for doubleword comparisons). The explicit-operand form is provided to allow documentation. Note that the documentation provided by this form can be misleading. That is, the memory operand symbol must specify the correct type (size) of the operand (byte, word, or doubleword) but it does not have to specify the correct location. The location is always specified by ES:(E)DI.

The no-operands form of the instruction uses a short form of SCAS. Again, ES:(E)DI is assumed to be the memory operand and AL, AX, or EAX is assumed to be the register operand. The size of operands is selected by the mnemonic: SCASB (byte comparison), SCASW (word comparison), or SCASD (doubleword comparison).

After the comparison, the (E)DI register is incremented or decremented automatically according to the setting of the DF flag in the EFLAGS register. If the DF flag is 0, the (E)DI register is incremented; if the DF flag is 1, the (E)DI register is decremented. The register is incremented or decremented by 1 for byte operations, by 2 for word operations, and by 4 for doubleword operations.

SCAS, SCASB, SCASW, SCASD, and SCASQ can be preceded by the REP prefix for block comparisons of ECX bytes, words, doublewords, or quadwords. Often, however, these instructions will be used in a LOOP construct that takes some action based on the setting of status flags. See "REP/REPE/REPZ /REPNE/REPNZ—Repeat String Operation Prefix" in this chapter for a description of the REP prefix.

In 64-bit mode, the instruction's default address size is 64-bits, 32-bit address size is supported using the prefix 67H. Using a REX prefix in the form of REX.W promotes operation on doubleword operand to 64 bits. The 64-bit no-operand mnemonic is SCASQ. Address of the memory operand is specified in either RDI or EDI, and AL/AX/EAX/RAX may be used as the register operand. After a comparison, the destination register is incremented or decremented by the current operand size (depending on the value of the DF flag). See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
Non-64-bit Mode:

IF (Byte cmparison)

THEN

temp \leftarrow AL - SRC;

SetStatusFlags(temp);

THEN IF DF = 0
```

```
THEN (E)DI \leftarrow (E)DI + 1;
                     ELSE (E)DI \leftarrow (E)DI - 1; FI;
    ELSE IF (Word comparison)
         THEN
               temp \leftarrow AX – SRC;
               SetStatusFlags(temp);
               IF DF = 0
                     THEN (E)DI \leftarrow (E)DI + 2;
                     ELSE (E)DI \leftarrow (E)DI - 2; FI;
         FI;
    ELSE IF (Doubleword comparison)
         THEN
               temp \leftarrow EAX - SRC;
               SetStatusFlags(temp);
               IF DF = 0
                     THEN (E)DI \leftarrow (E)DI + 4;
                     ELSE (E)DI \leftarrow (E)DI - 4; FI;
         FI;
FI;
64-bit Mode:
IF (Byte cmparison)
    THEN
         temp \leftarrow AL – SRC;
         SetStatusFlags(temp);
               THEN IF DF = 0
                     THEN (RIE)DI \leftarrow (RIE)DI + 1;
                    ELSE (RIE)DI \leftarrow (RIE)DI - 1; FI;
    ELSE IF (Word comparison)
         THEN
               temp \leftarrow AX – SRC;
               SetStatusFlags(temp);
               IF DF = 0
                     THEN (RIE)DI \leftarrow (RIE)DI + 2;
                     ELSE (R|E)DI \leftarrow (R|E)DI - 2; FI;
         FI:
    ELSE IF (Doubleword comparison)
         THEN
               temp \leftarrow EAX - SRC;
               SetStatusFlags(temp);
               IF DF = 0
                     THEN (RIE)DI \leftarrow (RIE)DI + 4;
                     ELSE (RIE)DI \leftarrow (RIE)DI - 4; FI;
```

```
FI; ELSE IF (Quadword comparison using REX.W ) THEN  temp \leftarrow RAX - SRC; \\ SetStatusFlags(temp); \\ IF DF = 0 \\ THEN (R|E)DI \leftarrow (R|E)DI + 8; \\ ELSE (R|E)DI \leftarrow (R|E)DI - 8; \\ FI; \\ FI; \\ FI; \\ FI; \\ \label{eq:entropy}
```

Flags Affected

The OF, SF, ZF, AF, PF, and CF flags are set according to the temporary result of the comparison.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the limit of the

ES segment.

If the ES register contains a NULL segment selector. If an illegal memory operand effective address in the ES

segment is given.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

INSTRUCTION SET REFERENCE, N-Z

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

SETcc—Set Byte on Condition

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 97	SETA r/m8	Α	Valid	Valid	Set byte if above (CF=0 and ZF=0).
REX + 0F 97	SETA r/m8*	Α	Valid	N.E.	Set byte if above (CF=0 and ZF=0).
0F 93	SETAE r/m8	Α	Valid	Valid	Set byte if above or equal (CF=0).
REX + 0F 93	SETAE r/m8*	Α	Valid	N.E.	Set byte if above or equal (CF=0).
0F 92	SETB r/m8	Α	Valid	Valid	Set byte if below (CF=1).
REX + 0F 92	SETB r/m8*	Α	Valid	N.E.	Set byte if below (CF=1).
0F 96	SETBE r/m8	Α	Valid	Valid	Set byte if below or equal (CF=1 or ZF=1).
REX + 0F 96	SETBE r/m8*	Α	Valid	N.E.	Set byte if below or equal (CF=1 or ZF=1).
0F 92	SETC r/m8	Α	Valid	Valid	Set byte if carry (CF=1).
REX + 0F 92	SETC r/m8*	Α	Valid	N.E.	Set byte if carry (CF=1).
0F 94	SETE r/m8	Α	Valid	Valid	Set byte if equal (ZF=1).
REX + 0F 94	SETE r/m8*	Α	Valid	N.E.	Set byte if equal (ZF=1).
OF 9F	SETG r/m8	Α	Valid	Valid	Set byte if greater (ZF=0 and SF=OF).
REX + OF 9F	SETG r/m8*	Α	Valid	N.E.	Set byte if greater (ZF=0 and SF=OF).
OF 9D	SETGE r/m8	Α	Valid	Valid	Set byte if greater or equal (SF=0F).
REX + OF 9D	SETGE r/m8*	Α	Valid	N.E.	Set byte if greater or equal (SF=0F).
0F 9C	SETL r/m8	Α	Valid	Valid	Set byte if less (SF≠ OF).
REX + 0F 9C	SETL r/m8*	Α	Valid	N.E.	Set byte if less (SF≠ OF).
0F 9E	SETLE r/m8	Α	Valid	Valid	Set byte if less or equal $(ZF=1 \text{ or } SF \neq OF)$.
REX + 0F 9E	SETLE r/m8*	Α	Valid	N.E.	Set byte if less or equal $(ZF=1 \text{ or } SF \neq OF)$.
0F 96	SETNA r/m8	Α	Valid	Valid	Set byte if not above (CF=1 or ZF=1).

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
REX + 0F 96	SETNA r/m8*	Α	Valid	N.E.	Set byte if not above (CF=1 or ZF=1).
0F 92	SETNAE r/m8	Α	Valid	Valid	Set byte if not above or equal (CF=1).
REX + 0F 92	SETNAE r/m8*	Α	Valid	N.E.	Set byte if not above or equal (CF=1).
0F 93	SETNB r/m8	Α	Valid	Valid	Set byte if not below (CF=0).
REX + 0F 93	SETNB r/m8*	Α	Valid	N.E.	Set byte if not below (CF=0).
0F 97	SETNBE r/m8	Α	Valid	Valid	Set byte if not below or equal (CF=0 and ZF=0).
REX + 0F 97	SETNBE r/m8*	Α	Valid	N.E.	Set byte if not below or equal (CF=0 and ZF=0).
0F 93	SETNC r/m8	Α	Valid	Valid	Set byte if not carry (CF=0).
REX + 0F 93	SETNC r/m8*	Α	Valid	N.E.	Set byte if not carry (CF=0).
0F 95	SETNE r/m8	Α	Valid	Valid	Set byte if not equal (ZF=0).
REX + 0F 95	SETNE r/m8*	Α	Valid	N.E.	Set byte if not equal (ZF=0).
0F 9E	SETNG r/m8	Α	Valid	Valid	Set byte if not greater (ZF=1 or SF \neq OF)
REX + 0F 9E	SETNG r/m8*	Α	Valid	N.E.	Set byte if not greater $(ZF=1 \text{ or } SF \neq OF)$.
0F 9C	SETNGE r/m8	Α	Valid	Valid	Set byte if not greater or equal ($SF \neq OF$).
REX + 0F 9C	SETNGE r/m8*	Α	Valid	N.E.	Set byte if not greater or equal ($SF \neq OF$).
0F 9D	SETNL r/m8	Α	Valid	Valid	Set byte if not less (SF=OF).
REX + OF 9D	SETNL r/m8*	Α	Valid	N.E.	Set byte if not less (SF=OF).
OF 9F	SETNLE r/m8	Α	Valid	Valid	Set byte if not less or equal (ZF=0 and SF=OF).
REX + OF 9F	SETNLE r/m8*	Α	Valid	N.E.	Set byte if not less or equal (ZF=0 and SF=OF).
0F 91	SETNO r/m8	Α	Valid	Valid	Set byte if not overflow (OF=0).
REX + 0F 91	SETNO r/m8*	Α	Valid	N.E.	Set byte if not overflow (OF=0).
0F 9B	SETNP r/m8	Α	Valid	Valid	Set byte if not parity (PF=0).

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
REX + OF 9B	SETNP r/m8*	Α	Valid	N.E.	Set byte if not parity (PF=0).
0F 99	SETNS r/m8	Α	Valid	Valid	Set byte if not sign (SF=0).
REX + 0F 99	SETNS r/m8*	Α	Valid	N.E.	Set byte if not sign (SF=0).
0F 95	SETNZ r/m8	Α	Valid	Valid	Set byte if not zero (ZF=0).
REX + 0F 95	SETNZ r/m8*	Α	Valid	N.E.	Set byte if not zero (ZF=0).
0F 90	SETO r/m8	Α	Valid	Valid	Set byte if overflow (OF=1)
REX + 0F 90	SETO r/m8*	Α	Valid	N.E.	Set byte if overflow (OF=1).
OF 9A	SETP r/m8	Α	Valid	Valid	Set byte if parity (PF=1).
REX + OF 9A	SETP r/m8*	Α	Valid	N.E.	Set byte if parity (PF=1).
OF 9A	SETPE r/m8	Α	Valid	Valid	Set byte if parity even (PF=1).
REX + OF 9A	SETPE r/m8*	Α	Valid	N.E.	Set byte if parity even (PF=1).
OF 9B	SETPO r/m8	Α	Valid	Valid	Set byte if parity odd (PF=0).
REX + 0F 9B	SETPO r/m8*	Α	Valid	N.E.	Set byte if parity odd (PF=0).
0F 98	SETS r/m8	Α	Valid	Valid	Set byte if sign (SF=1).
REX + 0F 98	SETS r/m8*	Α	Valid	N.E.	Set byte if sign (SF=1).
0F 94	SETZ r/m8	Α	Valid	Valid	Set byte if zero (ZF=1).
REX + 0F 94	SETZ r/m8*	Α	Valid	N.E.	Set byte if zero (ZF=1).

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r)	NA	NA	NA

Description

Sets the destination operand to 0 or 1 depending on the settings of the status flags (CF, SF, OF, ZF, and PF) in the EFLAGS register. The destination operand points to a byte register or a byte in memory. The condition code suffix (cc) indicates the condition being tested for.

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

The terms "above" and "below" are associated with the CF flag and refer to the relationship between two unsigned integer values. The terms "greater" and "less" are associated with the SF and OF flags and refer to the relationship between two signed integer values.

Many of the SETcc instruction opcodes have alternate mnemonics. For example, SETG (set byte if greater) and SETNLE (set if not less or equal) have the same opcode and test for the same condition: ZF equals 0 and SF equals OF. These alternate mnemonics are provided to make code more intelligible. Appendix B, "EFLAGS Condition Codes," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1, shows the alternate mnemonics for various test conditions.

Some languages represent a logical one as an integer with all bits set. This representation can be obtained by choosing the logically opposite condition for the SET*cc* instruction, then decrementing the result. For example, to test for overflow, use the SETNO instruction, then decrement the result.

In IA-64 mode, the operand size is fixed at 8 bits. Use of REX prefix enable uniform addressing to additional byte registers. Otherwise, this instruction's operation is the same as in legacy mode and compatibility mode.

Operation

```
 \begin{tabular}{ll} \mbox{F condition} \\ \mbox{THEN DEST} \leftarrow 1; \\ \mbox{ELSE DEST} \leftarrow 0; \\ \mbox{FI}; \\ \end{tabular}
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

SFENCE—Store Fence

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF AE /7	SFENCE	Α	Valid	Valid	Serializes store operations.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Performs a serializing operation on all store-to-memory instructions that were issued prior the SFENCE instruction. This serializing operation guarantees that every store instruction that precedes the SFENCE instruction in program order becomes globally visible before any store instruction that follows the SFENCE instruction. The SFENCE instruction is ordered with respect to store instructions, other SFENCE instructions, any LFENCE and MFENCE instructions, and any serializing instructions (such as the CPUID instruction). It is not ordered with respect to load instructions.

Weakly ordered memory types can be used to achieve higher processor performance through such techniques as out-of-order issue, write-combining, and write-collapsing. The degree to which a consumer of data recognizes or knows that the data is weakly ordered varies among applications and may be unknown to the producer of this data. The SFENCE instruction provides a performance-efficient way of ensuring store ordering between routines that produce weakly-ordered results and routines that consume this data.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

Wait On Following Stores Until(preceding stores globally visible);

Intel C/C++ Compiler Intrinsic Equivalent

void _mm_sfence(void)

Exceptions (All Operating Modes)

#UD If CPUID.01H:EDX.SSE2[bit 26] = 0.

If the LOCK prefix is used.

SGDT—Store Global Descriptor Table Register

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 /0	SGDT m	Α	Valid	Valid	Store GDTR to m.

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

Stores the content of the global descriptor table register (GDTR) in the destination operand. The destination operand specifies a memory location.

In legacy or compatibility mode, the destination operand is a 6-byte memory location. If the operand-size attribute is 16 bits, the limit is stored in the low 2 bytes and the 24-bit base address is stored in bytes 3-5, and byte 6 is zero-filled. If the operand-size attribute is 32 bits, the 16-bit limit field of the register is stored in the low 2 bytes of the memory location and the 32-bit base address is stored in the high 4 bytes.

In IA-32e mode, the operand size is fixed at 8+2 bytes. The instruction stores an 8-byte base and a 2-byte limit.

SGDT is useful only by operating-system software. However, it can be used in application programs without causing an exception to be generated. See "LGDT/LIDT—Load Global/Interrupt Descriptor Table Register" in Chapter 3, *Intel*® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A, for information on loading the GDTR and IDTR.

IA-32 Architecture Compatibility

The 16-bit form of the SGDT is compatible with the Intel 286 processor if the upper 8 bits are not referenced. The Intel 286 processor fills these bits with 1s; the Pentium 4, Intel Xeon, P6 processor family, Pentium, Intel486, and Intel386[™] processors fill these bits with 0s.

Operation

```
IF instruction is SGDT

IF OperandSize = 16

THEN

DEST[0:15] \leftarrow GDTR(Limit);
```

^{*} See IA-32 Architecture Compatibility section below.

```
\begin{array}{c} \text{DEST[16:39]} \leftarrow \text{GDTR(Base); (* 24 bits of base address stored *)} \\ \text{DEST[40:47]} \leftarrow 0; \\ \text{ELSE IF (32-bit Operand Size)} \\ \text{DEST[0:15]} \leftarrow \text{GDTR(Limit);} \\ \text{DEST[16:47]} \leftarrow \text{GDTR(Base); (* Full 32-bit base address stored *)} \\ \text{FI;} \\ \text{ELSE (* 64-bit Operand Size *)} \\ \text{DEST[0:15]} \leftarrow \text{GDTR(Limit);} \\ \text{DEST[16:79]} \leftarrow \text{GDTR(Base); (* Full 64-bit base address stored *)} \\ \text{FI;} \\ \text{FI:} \end{array}
```

Flags Affected

None.

Protected Mode Exceptions

#UD If the destination operand is a register.

If the LOCK prefix is used.

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

Real-Address Mode Exceptions

#UD If the destination operand is a register.

If the LOCK prefix is used.

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

Virtual-8086 Mode Exceptions

#UD If the destination operand is a register.

If the LOCK prefix is used.

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#UD If the destination operand is a register.

If the LOCK prefix is used.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

							CI :C.	
\sim \sim	 1		אוחו	U	DCIC!		Shift	LOTT
211		JUU	IDIC		CLIS	IUII	JIIIIL	LEIL

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF A4	SHLD r/m16, r16, imm8	Α	Valid	Valid	Shift <i>r/m16</i> to left <i>imm8</i> places while shifting bits from <i>r16</i> in from the right.
0F A5	SHLD <i>r/m16, r16,</i> CL	В	Valid	Valid	Shift $r/m16$ to left CL places while shifting bits from $r16$ in from the right.
OF A4	SHLD r/m32, r32, imm8	Α	Valid	Valid	Shift <i>r/m32</i> to left <i>imm8</i> places while shifting bits from <i>r32</i> in from the right.
REX.W + 0F A4	SHLD r/m64, r64, imm8	Α	Valid	N.E.	Shift <i>r/m64</i> to left <i>imm8</i> places while shifting bits from <i>r64</i> in from the right.
OF A5	SHLD <i>r/m32, r32,</i> CL	В	Valid	Valid	Shift $r/m32$ to left CL places while shifting bits from $r32$ in from the right.
REX.W + OF A5	SHLD <i>r/m64, r64,</i> CL	В	Valid	N.E.	Shift <i>r/m64</i> to left CL places while shifting bits from <i>r64</i> in from the right.

Instruction Operand Encoding

		•			_
Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	ModRM:r/m (w)	ModRM:reg (r)	imm8	NA	
В	ModRM:r/m (w)	ModRM:reg (r)	CL	NA	

Description

The SHLD instruction is used for multi-precision shifts of 64 bits or more.

The instruction shifts the first operand (destination operand) to the left the number of bits specified by the third operand (count operand). The second operand (source operand) provides bits to shift in from the right (starting with bit 0 of the destination operand).

The destination operand can be a register or a memory location; the source operand is a register. The count operand is an unsigned integer that can be stored in an immediate byte or in the CL register. If the count operand is CL, the shift count is the logical AND of CL and a count mask. In non-64-bit modes and default 64-bit mode; only bits 0 through 4 of the count are used. This masks the count to a value between 0 and 31. If a count is greater than the operand size, the result is undefined.

If the count is 1 or greater, the CF flag is filled with the last bit shifted out of the destination operand. For a 1-bit shift, the OF flag is set if a sign change occurred; otherwise, it is cleared. If the count operand is 0, flags are not affected.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits (upgrading the count mask to 6 bits). See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
IF (In 64-Bit Mode and REX.W = 1)
   THEN COUNT ← COUNT MOD 64:
   FLSE COUNT \leftarrow COUNT MOD 32:
FΙ
SIZE \leftarrow OperandSize;
IF COUNT = 0
   THEN
        No operation;
   FLSE
        IF COUNT > SIZE
             THEN (* Bad parameters *)
                  DEST is undefined:
                  CF, OF, SF, ZF, AF, PF are undefined;
             ELSE (* Perform the shift *)
                  CF \leftarrow BITIDEST, SIZE - COUNT1:
                  (* Last bit shifted out on exit *)
                  FOR i ← SIZE - 1 DOWN TO COUNT
                       DO
                            Bit(DEST, i) \leftarrow Bit(DEST, i - COUNT);
                       OD:
                  FOR i \leftarrow COUNT - 1 DOWN TO 0
                       DO
                            BIT[DEST, i] \leftarrow BIT[SRC, i - COUNT + SIZE];
                       OD:
        FI:
FI:
```

Flags Affected

If the count is 1 or greater, the CF flag is filled with the last bit shifted out of the destination operand and the SF, ZF, and PF flags are set according to the value of the result. For a 1-bit shift, the OF flag is set if a sign change occurred; otherwise, it is cleared. For shifts greater than 1 bit, the OF flag is undefined. If a shift occurs, the AF

flag is undefined. If the count operand is 0, the flags are not affected. If the count is greater than the operand size, the flags are undefined.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

If alignment checking is enabled and an unaligned memory reference is made while the current privilege level is 3. #AC(0)

If the LOCK prefix is used. #UD

SHRD—	Double	Precision	Shift	Riaht

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF AC	SHRD r/m16, r16, imm8	Α	Valid	Valid	Shift $r/m16$ to right $imm8$ places while shifting bits from $r16$ in from the left.
OF AD	SHRD <i>r/m16, r16,</i> CL	В	Valid	Valid	Shift $r/m16$ to right CL places while shifting bits from $r16$ in from the left.
OF AC	SHRD r/m32, r32, imm8	Α	Valid	Valid	Shift <i>r/m32</i> to right <i>imm8</i> places while shifting bits from <i>r32</i> in from the left.
REX.W + OF AC	SHRD r/m64, r64, imm8	Α	Valid	N.E.	Shift <i>r/m64</i> to right <i>imm8</i> places while shifting bits from <i>r64</i> in from the left.
OF AD	SHRD r/m32, r32, CL	В	Valid	Valid	Shift <i>r/m32</i> to right CL places while shifting bits from <i>r32</i> in from the left.
REX.W + OF AD	SHRD <i>r/m64, r64</i> , CL	В	Valid	N.E.	Shift <i>r/m64</i> to right CL places while shifting bits from <i>r64</i> in from the left.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	l
Α	ModRM:r/m (w)	ModRM:reg (r)	imm8	NA	
В	ModRM:r/m (w)	ModRM:reg (r)	CL	NA	

Description

The SHRD instruction is useful for multi-precision shifts of 64 bits or more.

The instruction shifts the first operand (destination operand) to the right the number of bits specified by the third operand (count operand). The second operand (source operand) provides bits to shift in from the left (starting with the most significant bit of the destination operand).

The destination operand can be a register or a memory location; the source operand is a register. The count operand is an unsigned integer that can be stored in an immediate byte or the CL register. If the count operand is CL, the shift count is the logical AND of CL and a count mask. In non-64-bit modes and default 64-bit mode, the width of the count mask is 5 bits. Only bits 0 through 4 of the count register are used (masking the count to a value between 0 and 31). If the count is greater than the operand size, the result is undefined.

If the count is 1 or greater, the CF flag is filled with the last bit shifted out of the destination operand. For a 1-bit shift, the OF flag is set if a sign change occurred; otherwise, it is cleared. If the count operand is 0, flags are not affected.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits (upgrading the count mask to 6 bits). See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
IF (In 64-Bit Mode and REX.W = 1)
   THEN COUNT ← COUNT MOD 64:
   FLSE COUNT \leftarrow COUNT MOD 32:
FΙ
SIZE \leftarrow OperandSize;
IF COUNT = 0
   THEN
        No operation;
   FLSE
        IF COUNT > SIZE
             THEN (* Bad parameters *)
                  DEST is undefined:
                  CF, OF, SF, ZF, AF, PF are undefined;
             ELSE (* Perform the shift *)
                  CF ← BIT[DEST, COUNT – 1]; (* Last bit shifted out on exit *)
                  FOR i \leftarrow 0 TO SIZE – 1 – COUNT
                       DO
                            BIT[DEST, i] \leftarrow BIT[DEST, i + COUNT];
                       OD:
                  FOR i ← SIZE - COUNT TO SIZE - 1
                       DO
                            BIT[DEST,i] \leftarrow BIT[SRC, i + COUNT - SIZE];
                       OD:
        FI:
FI:
```

Flags Affected

If the count is 1 or greater, the CF flag is filled with the last bit shifted out of the destination operand and the SF, ZF, and PF flags are set according to the value of the result. For a 1-bit shift, the OF flag is set if a sign change occurred; otherwise, it is cleared. For shifts greater than 1 bit, the OF flag is undefined. If a shift occurs, the AF flag is undefined. If the count operand is 0, the flags are not affected. If the count is greater than the operand size, the flags are undefined.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

SHUFPD—Shuffle Packed Double-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF C6 /r ib SHUFPD xmm1, xmm2/m128, imm8	Α	V/V	SSE2	Shuffle packed double- precision floating-point values selected by imm8 from xmm1 and xmm2/m128 to xmm1.
VEX.NDS.128.66.0F.WIG C6 /r ib VSHUFPD xmm1, xmm2, xmm3/m128, imm8	В	V/V	AVX	Shuffle Packed double- precision floating-point values selected by imm8 from xmm2 and xmm3/mem.
VEX.NDS.256.66.0F.WIG C6 /r ib VSHUFPD ymm1, ymm2, ymm3/m256, imm8	В	V/V	AVX	Shuffle Packed double- precision floating-point values selected by imm8 from ymm2 and ymm3/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Moves either of the two packed double-precision floating-point values from destination operand (first operand) into the low quadword of the destination operand; moves either of the two packed double-precision floating-point values from the source operand into to the high quadword of the destination operand (see Figure 4-15). The select operand (third operand) determines which values are moved to the destination operand.

128-bit Legacy SSE version: The source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.




Figure 4-15. SHUFPD Shuffle Operation

The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. The select operand is an 8-bit immediate: bit 0 selects which value is moved from the destination operand to the result (where 0 selects the low quadword and 1 selects the high quadword) and bit 1 selects which value is moved from the source operand to the result. Bits 2 through 7 of the select operand are reserved and must be set to 0.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Operation

IF IMM0[1] = 0

```
IF SELECT[0] = 0
    THEN DEST[63:0] ← DEST[63:0];
    ELSE DEST[63:0] ← DEST[127:64]; FI;

IF SELECT[1] = 0
    THEN DEST[127:64] ← SRC[63:0];
    ELSE DEST[127:64] ← SRC[127:64]; FI;

SHUFPD (128-bit Legacy SSE version)

IF IMM0[0] = 0
    THEN DEST[63:0] ← SRC1[63:0]
    ELSE DEST[63:0] ← SRC1[127:64] FI;
```

THEN DEST[127:64] \leftarrow SRC2[63:0]

```
ELSE DEST[127:64] \leftarrow SRC2[127:64] FI; DEST[VLMAX-1:128] (Unmodified)
```

VSHUFPD (VEX.128 encoded version)

```
IF IMM0[0] = 0

THEN DEST[63:0] \leftarrow SRC1[63:0]

ELSE DEST[63:0] \leftarrow SRC1[127:64] FI;

IF IMM0[1] = 0

THEN DEST[127:64] \leftarrow SRC2[63:0]

ELSE DEST[127:64] \leftarrow SRC2[127:64] FI;

DEST[VLMAX-1:128] \leftarrow 0
```

VSHUFPD (VEX.256 encoded version)

```
IF IMM0[0] = 0
   THEN DEST[63:0] \leftarrow SRC1[63:0]
   ELSE DEST[63:0] \leftarrow SRC1[127:64] FI;

IF IMM0[1] = 0
   THEN DEST[127:64] \leftarrow SRC2[63:0]
   ELSE DEST[127:64] \leftarrow SRC2[127:64] FI;

IF IMM0[2] = 0
   THEN DEST[191:128] \leftarrow SRC1[191:128]
   ELSE DEST[191:128] \leftarrow SRC1[255:192] FI;

IF IMM0[3] = 0
   THEN DEST[255:192] \leftarrow SRC2[191:128]
   ELSE DEST[255:192] \leftarrow SRC2[255:192] FI;
```

Intel C/C++ Compiler Intrinsic Equivalent

```
SHUFPD __m128d _mm_shuffle_pd(__m128d a, __m128d b, unsigned int imm8) VSHUFPD __m256d _mm256_shuffle_pd (__m256d a, __m256d b, const int select);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

SHUFPS—Shuffle Packed Single-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF C6 /r ib SHUFPS xmm1, xmm2/m128, imm8	A	V/V	SSE	Shuffle packed single- precision floating-point values selected by imm8 from xmm1 and xmm1/m128 to xmm1.
VEX.NDS.128.0F.WIG C6 /r ib VSHUFPS xmm1, xmm2, xmm3/m128, imm8	В	V/V	AVX	Shuffle Packed single- precision floating-point values selected by imm8 from xmm2 and xmm3/mem.
VEX.NDS.256.0F.WIG C6 /r ib VSHUFPS ymm1, ymm2, ymm3/m256, imm8	В	V/V	AVX	Shuffle Packed single- precision floating-point values selected by imm8 from ymm2 and ymm3/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (г, w)	ModRM:r/m (r)	imm8	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Moves two of the four packed single-precision floating-point values from the destination operand (first operand) into the low quadword of the destination operand; moves two of the four packed single-precision floating-point values from the source operand (second operand) into to the high quadword of the destination operand (see Figure 4-16). The select operand (third operand) determines which values are moved to the destination operand.

128-bit Legacy SSE version: The source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

determines which values are moved to the destination operand.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.




Figure 4-16. SHUFPS Shuffle Operation

The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. The select operand is an 8-bit immediate: bits 0 and 1 select the value to be moved from the destination operand to the low doubleword of the result, bits 2 and 3 select the value to be moved from the destination operand to the second doubleword of the result, bits 4 and 5 select the value to be moved from the source operand to the third doubleword of the result, and bits 6 and 7 select the value to be moved from the source operand to the high doubleword of the result.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Operation

CASE (SELECT[1:0]) OF

- 0: DEST[31:0] \leftarrow DEST[31:0];
- 1: DEST[31:0] \leftarrow DEST[63:32];
- 2: DEST[31:0] ← DEST[95:64];
- 3: DEST[31:0] \leftarrow DEST[127:96];

ESAC:

CASE (SELECT[3:21) OF

- 0: DEST[63:32] \leftarrow DEST[31:0];
- 1: DEST[63:32] \leftarrow DEST[63:32];
- 2: DEST[63:32] ← DEST[95:64];
- 3: DEST[63:32] \leftarrow DEST[127:96];

ESAC:

CASE (SELECT[5:4]) OF

- 0: DEST[95:64] \leftarrow SRC[31:0];
- 1: DEST[95:64] \leftarrow SRC[63:32];
- 2: DEST[95:64] ← SRC[95:64];
- 3: DEST[95:64] ← SRC[127:96];

ESAC:

CASE (SELECT[7:61) OF

- 0: DEST[127:96] \leftarrow SRC[31:0];
- 1: DEST[127:96] \leftarrow SRC[63:32];
- 2: DEST[127:96] ← SRC[95:64];
- 3: DEST[127:96] \leftarrow SRC[127:96];

ESAC:

SHUFPS (128-bit Legacy SSE version)

```
DEST[31:0] \leftarrow Select4(SRC1[127:0], imm8[1:0]);
```

 $DEST[63:32] \leftarrow Select4(SRC1[127:0], imm8[3:2]);$

DEST[95:64] \leftarrow Select4(SRC2[127:0], imm8[5:4]);

DEST[127:96] \leftarrow Select4(SRC2[127:0], imm8[7:6]);

DEST[VLMAX-1:128] (Unmodified)

VSHUFPS (VEX.128 encoded version)

```
DEST[31:0] \leftarrow Select4(SRC1[127:0], imm8[1:0]);
```

DEST[63:32] \leftarrow Select4(SRC1[127:0], imm8[3:2]);

DEST[95:64] \leftarrow Select4(SRC2[127:0], imm8[5:4]);

DEST[127:96] \leftarrow Select4(SRC2[127:0], imm8[7:6]);

DEST[VLMAX-1:128] \leftarrow 0

VSHUFPS (VEX.256 encoded version)

DEST[31:0] \leftarrow Select4(SRC1[127:0], imm8[1:0]);

DEST[63:32] \leftarrow Select4(SRC1[127:0], imm8[3:2]);

DEST[95:64] \leftarrow Select4(SRC2[127:0], imm8[5:4]);

DEST[127:96] \leftarrow Select4(SRC2[127:0], imm8[7:6]);

DEST[159:128] \leftarrow Select4(SRC1[255:128], imm8[1:0]);

DEST[191:160] ← Select4(SRC1[255:128], imm8[3:2]);

DEST[223:192] \leftarrow Select4(SRC2[255:128], imm8[5:4]);

DEST[255:224] \leftarrow Select4(SRC2[255:128], imm8[7:6]);

Intel C/C++ Compiler Intrinsic Equivalent

SHUFPS __m128 _mm_shuffle_ps(__m128 a, __m128 b, unsigned int imm8) VSHUFPS __m256 _mm256 _shuffle_ps (__m256 a, __m256 b, const int select);

INSTRUCTION SET REFERENCE, N-Z

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

SIDT—Store Interrupt Descriptor Table Register

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 /1	SIDT m	Α	Valid	Valid	Store IDTR to m.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

Stores the content the interrupt descriptor table register (IDTR) in the destination operand. The destination operand specifies a 6-byte memory location.

In non-64-bit modes, if the operand-size attribute is 32 bits, the 16-bit limit field of the register is stored in the low 2 bytes of the memory location and the 32-bit base address is stored in the high 4 bytes. If the operand-size attribute is 16 bits, the limit is stored in the low 2 bytes and the 24-bit base address is stored in the third, fourth, and fifth byte, with the sixth byte filled with 0s.

In 64-bit mode, the operand size fixed at 8+2 bytes. The instruction stores 8-byte base and 2-byte limit values.

SIDT is only useful in operating-system software; however, it can be used in application programs without causing an exception to be generated. See "LGDT/LIDT—Load Global/Interrupt Descriptor Table Register" in Chapter 3, *Intel*® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A, for information on loading the GDTR and IDTR.

IA-32 Architecture Compatibility

The 16-bit form of SIDT is compatible with the Intel 286 processor if the upper 8 bits are not referenced. The Intel 286 processor fills these bits with 1s; the Pentium 4, Intel Xeon, P6 processor family, Pentium, Intel 486, and Intel 386 processors fill these bits with 0s.

Operation

```
IF instruction is SIDT  
THEN  
IF OperandSize = 16  
THEN  
DEST[0:15] \leftarrow IDTR(Limit);  
DEST[16:39] \leftarrow IDTR(Base); (* 24 bits of base address stored; *)  
DEST[40:47] \leftarrow 0;
```

```
ELSE IF (32-bit Operand Size)
DEST[0:15] \leftarrow IDTR(Limit);
DEST[16:47] \leftarrow IDTR(Base); FI; (* Full 32-bit base address stored *)
ELSE (* 64-bit Operand Size *)
DEST[0:15] \leftarrow IDTR(Limit);
DEST[16:79] \leftarrow IDTR(Base); (* Full 64-bit base address stored *)
FI;
```

FI:

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#UD If the destination operand is a register.

If the LOCK prefix is used.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

SLDT—Store Local Descriptor Table Register

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 00 /0	SLDT r/m16	Α	Valid	Valid	Stores segment selector from LDTR in <i>r/m16</i> .
REX.W + 0F 00 /0	SLDT <i>r64/m16</i>	Α	Valid	Valid	Stores segment selector from LDTR in <i>r64/m16</i> .

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

Stores the segment selector from the local descriptor table register (LDTR) in the destination operand. The destination operand can be a general-purpose register or a memory location. The segment selector stored with this instruction points to the segment descriptor (located in the GDT) for the current LDT. This instruction can only be executed in protected mode.

Outside IA-32e mode, when the destination operand is a 32-bit register, the 16-bit segment selector is copied into the low-order 16 bits of the register. The high-order 16 bits of the register are cleared for the Pentium 4, Intel Xeon, and P6 family processors. They are undefined for Pentium, Intel486, and Intel386 processors. When the destination operand is a memory location, the segment selector is written to memory as a 16-bit quantity, regardless of the operand size.

In compatibility mode, when the destination operand is a 32-bit register, the 16-bit segment selector is copied into the low-order 16 bits of the register. The high-order 16 bits of the register are cleared. When the destination operand is a memory location, the segment selector is written to memory as a 16-bit quantity, regardless of the operand size.

In 64-bit mode, using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). The behavior of SLDT with a 64-bit register is to zero-extend the 16-bit selector and store it in the register. If the destination is memory and operand size is 64, SLDT will write the 16-bit selector to memory as a 16-bit quantity, regardless of the operand size

Operation

 $DEST \leftarrow LDTR(SegmentSelector);$

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD The SLDT instruction is not recognized in real-address mode.

If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#UD The SLDT instruction is not recognized in virtual-8086 mode.

If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

CMCIVI	-Store	Machine	Statue	Mord

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF 01 /4	SMSW r/m16	Α	Valid	Valid	Store machine status word to r/m16.
0F 01 /4	SMSW <i>r32/m16</i>	Α	Valid	Valid	Store machine status word in low-order 16 bits of <i>r32/m16</i> ; high-order 16 bits of <i>r32</i> are undefined.
REX.W + 0F 01 /4	SMSW r64/m16	Α	Valid	Valid	Store machine status word in low-order 16 bits of <i>r64/m16</i> ; high-order 16 bits of <i>r32</i> are undefined.

Instruction Operand Encoding

					-
Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	ModRM:r/m (w)	NA	NA	NA	

Description

Stores the machine status word (bits 0 through 15 of control register CR0) into the destination operand. The destination operand can be a general-purpose register or a memory location.

In non-64-bit modes, when the destination operand is a 32-bit register, the low-order 16 bits of register CR0 are copied into the low-order 16 bits of the register and the high-order 16 bits are undefined. When the destination operand is a memory location, the low-order 16 bits of register CR0 are written to memory as a 16-bit quantity, regardless of the operand size.

In 64-bit mode, the behavior of the SMSW instruction is defined by the following examples:

- SMSW r16 operand size 16, store CR0[15:0] in r16
- SMSW r32 operand size 32, zero-extend CR0[31:0], and store in r32
- SMSW r64 operand size 64, zero-extend CR0[63:0], and store in r64
- SMSW m16 operand size 16, store CR0[15:0] in m16
- SMSW m16 operand size 32, store CR0[15:0] in m16 (not m32)
- SMSW m16 operands size 64, store CR0[15:0] in m16 (not m64)

SMSW is only useful in operating-system software. However, it is not a privileged instruction and can be used in application programs. The is provided for compatibility with the Intel 286 processor. Programs and procedures intended to run on the

Pentium 4, Intel Xeon, P6 family, Pentium, Intel486, and Intel386 processors should use the MOV (control registers) instruction to load the machine status word.

See "Changes to Instruction Behavior in VMX Non-Root Operation" in Chapter 22 of the *Intel*® 64 and *IA-32 Architectures Software Developer's Manual, Volume 3B*, for more information about the behavior of this instruction in VMX non-root operation.

Operation

DEST \leftarrow CR0[15:0]; (* Machine status word *)

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

INSTRUCTION SET REFERENCE, N-Z

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

SQRTPD—Compute Square Roots of Packed Double-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 51 /r SQRTPD xmm1, xmm2/m128	Α	V/V	SSE2	Computes square roots of the packed double-precision floating-point values in xmm2/m128 and stores the results in xmm1.
VEX.128.66.0F.WIG 51 /r VSQRTPD xmm1, xmm2/m128	A	V/V	AVX	Computes Square Roots of the packed double-precision floating-point values in xmm2/m128 and stores the result in xmm1.
VEX.256.66.0F.WIG 51/r VSQRTPD ymm1, ymm2/m256	Α	V/V	AVX	Computes Square Roots of the packed double-precision floating-point values in ymm2/m256 and stores the result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Performs a SIMD computation of the square roots of the two packed double-precision floating-point values in the source operand (second operand) stores the packed double-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 11-3 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD double-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the source operand second source operand or a 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The source operand is a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD.

Operation

SQRTPD (128-bit Legacy SSE version)

DEST[63:0] \leftarrow SQRT(SRC[63:0]) DEST[127:64] \leftarrow SQRT(SRC[127:64]) DEST[VLMAX-1:128] (Unmodified)

VSQRTPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SQRT(SRC[63:0]) DEST[127:64] \leftarrow SQRT(SRC[127:64]) DEST[VLMAX-1:128] \leftarrow 0

VSQRTPD (VEX.256 encoded version)

DEST[63:0] ← SQRT(SRC[63:0])

DEST[127:64] ← SQRT(SRC[127:64])

DEST[191:128] ← SQRT(SRC[191:128])

DEST[255:192] ← SQRT(SRC[255:192])

Intel C/C++ Compiler Intrinsic Equivalent

SQRTPD __m128d _mm_sqrt_pd (m128d a)
SQRTPD __m256d _mm256_sqrt_pd (__m256d a);

SIMD Floating-Point Exceptions

Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 2; additionally #UD If VEX.vvvv != 1111B.

SQRTPS—Compute Square Roots of Packed Single-Precision Floating-Point Values

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 51 /r SQRTPS xmm1, xmm2/m128	Α	V/V	SSE	Computes square roots of the packed single-precision floating-point values in xmm2/m128 and stores the results in xmm1.
VEX.128.0F.WIG 51 /r VSQRTPS xmm1, xmm2/m128	Α	V/V	AVX	Computes Square Roots of the packed single-precision floating-point values in xmm2/m128 and stores the result in xmm1.
VEX.256.0F.WIG 51/r VSQRTPS ymm1, ymm2/m256	Α	V/V	AVX	Computes Square Roots of the packed single-precision floating-point values in ymm2/m256 and stores the result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Performs a SIMD computation of the square roots of the four packed single-precision floating-point values in the source operand (second operand) stores the packed single-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 10-5 in the Intel @ 64 and IA-32 Architectures Software Developer's Manual, Volume 1, for an illustration of a SIMD single-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the source operand second source operand or a 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The source operand is a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD.

Operation

SQRTPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SQRT(SRC[31:0])

DEST[63:32] \leftarrow SQRT(SRC[63:32])

DEST[95:64] \leftarrow SQRT(SRC[95:64])

 $DEST[127:96] \leftarrow SQRT(SRC[127:96])$

DEST[VLMAX-1:128] (Unmodified)

VSQRTPS (VEX.128 encoded version)

DEST[31:0] \leftarrow SQRT(SRC[31:0])

DEST[63:32] \leftarrow SQRT(SRC[63:32])

DEST[95:64] \leftarrow SQRT(SRC[95:64])

 $\mathsf{DEST}[127:96] \leftarrow \mathsf{SQRT}(\mathsf{SRC}[127:96])$

DEST[VLMAX-1:128] \leftarrow 0

VSQRTPS (VEX.256 encoded version)

 $\mathsf{DEST[31:0]} \leftarrow \mathsf{SQRT(SRC[31:0])}$

 $\mathsf{DEST}[63:32] \leftarrow \mathsf{SQRT}(\mathsf{SRC}[63:32])$

 $DEST[95:64] \leftarrow SQRT(SRC[95:64])$

DEST[127:96] ← SQRT(SRC[127:96])

DEST[159:128] \leftarrow SQRT(SRC[159:128]) DEST[191:160] \leftarrow SQRT(SRC[191:160])

DEST[223:192] ← SQRT(SRC[223:192])

 $\mathsf{DEST}[\mathsf{255}.\mathsf{224}] \leftarrow \mathsf{SQRT}(\mathsf{SRC}[\mathsf{255}.\mathsf{224}])$

Intel C/C++ Compiler Intrinsic Equivalent

SQRTPS __m128 _mm_sqrt_ps(__m128 a)

SQRTPS __m256 _mm256_sqrt_ps (__m256 a);

SIMD Floating-Point Exceptions

Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 2; additionally

#UD If VEX.vvvv != 1111B.

SQRTSD—Compute Square Root of Scalar Double-Precision Floating-Point Value

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F2 OF 51 /r SQRTSD xmm1, xmm2/m64	Α	V/V	SSE2	Computes square root of the low double-precision floating-point value in xmm2/m64 and stores the results in xmm1.
VEX.NDS.LIG.F2.0F.WIG 51/ VSQRTSD xmm1,xmm2, xmm3/m64	В	V/V	AVX	Computes square root of the low double-precision floating point value in xmm3/m64 and stores the results in xmm2. Also, upper double precision floating-point value (bits[127:64]) from xmm2 is copied to xmm1[127:64].

Instruction Operand Encoding

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Computes the square root of the low double-precision floating-point value in the source operand (second operand) and stores the double-precision floating-point result in the destination operand. The source operand can be an XMM register or a 64-bit memory location. The destination operand is an XMM register. The high quadword of the destination operand remains unchanged. See Figure 11-4 in the *Intel*® 64 and *IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a scalar double-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:64) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

SQRTSD (128-bit Legacy SSE version)

DEST[63:0] \leftarrow SQRT(SRC[63:0]) DEST[VLMAX-1:64] (Unmodified)

VSQRTSD (VEX.128 encoded version)

DEST[63:0] \leftarrow SQRT(SRC2[63:0]) DEST[127:64] \leftarrow SRC1[127:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

SQRTSD __m128d _mm_sqrt_sd (m128d a, m128d b)

SIMD Floating-Point Exceptions

Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 3.

SQRTSS—Compute Square Root of Scalar Single-Precision Floating-Point Value

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F3 0F 51 /r SQRTSS xmm1, xmm2/m32	A	V/V	SSE	Computes square root of the low single-precision floating-point value in xmm2/m32 and stores the results in xmm1.
VEX.NDS.LIG.F3.0F.WIG 51 VSQRTSS xmm1, xmm2, xmm3/m32	В	V/V	AVX	Computes square root of the low single-precision floating-point value in xmm3/m32 and stores the results in xmm1. Also, upper single precision floating- point values (bits[127:32]) from xmm2 are copied to xmm1[127:32].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Computes the square root of the low single-precision floating-point value in the source operand (second operand) and stores the single-precision floating-point result in the destination operand. The source operand can be an XMM register or a 32-bit memory location. The destination operand is an XMM register. The three high-order doublewords of the destination operand remain unchanged. See Figure 10-6 in the *Intel*® 64 and *IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a scalar single-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The first source operand and the destination operand are the same. Bits (VLMAX-1:32) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

SQRTSS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SQRT(SRC2[31:0]) DEST[VLMAX-1:32] (Unmodified)

VSQRTSS (VEX.128 encoded version)

DEST[31:0] \leftarrow SQRT(SRC2[31:0]) DEST[127:32] \leftarrow SRC1[127:32] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

SQRTSS __m128 _mm_sqrt_ss(__m128 a)

SIMD Floating-Point Exceptions

Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 3.

STC—Set Carry Flag

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
F9	STC	Α	Valid	Valid	Set CF flag.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Sets the CF flag in the EFLAGS register.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

 $CF \leftarrow 1$:

Flags Affected

The CF flag is set. The OF, ZF, SF, AF, and PF flags are unaffected.

Exceptions (All Operating Modes)

STD—Set Direction Flag

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
FD	STD	Α	Valid	Valid	Set DF flag.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Sets the DF flag in the EFLAGS register. When the DF flag is set to 1, string operations decrement the index registers (ESI and/or EDI).

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

 $DF \leftarrow 1$;

Flags Affected

The DF flag is set. The CF, OF, ZF, SF, AF, and PF flags are unaffected.

Exceptions (All Operating Modes)

STI—Set Interrupt Flag

Opcode*	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
FB	STI	А	Valid	Valid	Set interrupt flag; external, maskable interrupts enabled at the end of the next instruction.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

If protected-mode virtual interrupts are not enabled, STI sets the interrupt flag (IF) in the EFLAGS register. After the IF flag is set, the processor begins responding to external, maskable interrupts after the next instruction is executed. The delayed effect of this instruction is provided to allow interrupts to be enabled just before returning from a procedure (or subroutine). For instance, if an STI instruction is followed by an RET instruction, the RET instruction is allowed to execute before external interrupts are recognized¹. If the STI instruction is followed by a CLI instruction (which clears the IF flag), the effect of the STI instruction is negated.

The IF flag and the STI and CLI instructions do not prohibit the generation of exceptions and NMI interrupts. NMI interrupts (and SMIs) may be blocked for one macroinstruction following an STI.

When protected-mode virtual interrupts are enabled, CPL is 3, and IOPL is less than 3; STI sets the VIF flag in the EFLAGS register, leaving IF unaffected.

Table 4-15 indicates the action of the STI instruction depending on the processor's mode of operation and the CPL/IOPL settings of the running program or procedure.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

In the following instruction sequence, interrupts may be recognized before RET executes:

STI

STI

RFT

The STI instruction delays recognition of interrupts only if it is executed with EFLAGS.IF = 0. In a sequence of STI instructions, only the first instruction in the sequence is guaranteed to delay interrupts.

DC	1/14					101 511	
PE	VM	IOPL	CPL	PVI	VIP	VME	STI Result
0	Х	Х	Χ	Х	Х	X	IF = 1
1	0	≥ CPL	Х	Х	Х	Х	IF = 1
1	0	< CPL	3	1	0	Х	VIF = 1
1	0	< CPL	< 3	Х	Х	Х	GP Fault
1	0	< CPL	Х	0	Х	Х	GP Fault
1	0	< CPL	Х	Х	1	Х	GP Fault
1	1	3	Х	Х	Х	Х	IF = 1
1	1	< 3	Х	Х	0	1	VIF = 1
1	1	< 3	Х	Х	1	Х	GP Fault
1	1	< 3	Х	Х	Х	0	GP Fault

Table 4-15. Decision Table for STI Results

NOTES:

X = This setting has no impact.

Operation

```
IF PE = 0 (* Executing in real-address mode *)
   THEN
        IF \leftarrow 1; (* Set Interrupt Flag *)
   ELSE (* Executing in protected mode or virtual-8086 mode *)
        IF VM = 0 (* Executing in protected mode*)
             THEN
                  IF IOPL ≥ CPL
                       THEN
                            IF \leftarrow 1; (* Set Interrupt Flag *)
                  ELSE
                       IF (IOPL < CPL) and (CPL = 3) and (VIP = 0)
                            THEN
                                 VIF ← 1; (* Set Virtual Interrupt Flag *)
                            ELSE
                                 #GP(0);
                       FI:
                  FI:
             ELSE (* Executing in Virtual-8086 mode *)
                  IF IOPl = 3
                       THEN
                            IF \leftarrow 1; (* Set Interrupt Flag *)
                  ELSE
                       IF ((IOPL < 3) and (VIP = 0) and (VME = 1))
                            THEN
```

```
\label{eq:VIF} VIF \leftarrow 1; \ (* \mbox{ Set Virtual Interrupt Flag *)} \\ \mbox{ELSE} \\ \mbox{$\#\text{GP}(0)$; (* Trap to virtual-8086 monitor *)} \\ \mbox{$F\text{I}$;} \\ \mbox{$F\text{I}$;
```

Flags Affected

The IF flag is set to 1; or the VIF flag is set to 1.

Protected Mode Exceptions

#GP(0) If the CPL is greater (has less privilege) than the IOPL of the

current program or procedure.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

STMXCSR—Store MXCSR Register State

Opcode*/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF AE /3 STMXCSR <i>m32</i>	Α	V/V	SSE	Store contents of MXCSR register to <i>m32</i> .
VEX.LZ.0F.WIG AE /3 VSTMXCSR <i>m32</i>	Α	V/V	AVX	Store contents of MXCSR register to <i>m32</i> .

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

Stores the contents of the MXCSR control and status register to the destination operand. The destination operand is a 32-bit memory location. The reserved bits in the MXCSR register are stored as 0s.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

VEX.L must be 0, otherwise instructions will #UD.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

m32 ← MXCSR:

Intel C/C++ Compiler Intrinsic Equivalent

_mm_getcsr(void)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 5; additionally #UD If VEX.L= 1,

II VEX.L= 1,

If VEX.vvvv != 1111B.

STOS/STOSB/STOSW/STOSD/STOSQ—Store String

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
AA	STOS m8	Α	Valid	Valid	For legacy mode, store AL at address ES:(E)DI; For 64-bit mode store AL at address RDI or EDI.
AB	STOS m16	Α	Valid	Valid	For legacy mode, store AX at address ES:(E)DI; For 64-bit mode store AX at address RDI or EDI.
АВ	STOS m32	Α	Valid	Valid	For legacy mode, store EAX at address ES:(E)DI; For 64-bit mode store EAX at address RDI or EDI.
REX.W + AB	STOS m64	Α	Valid	N.E.	Store RAX at address RDI or EDI.
AA	STOSB	Α	Valid	Valid	For legacy mode, store AL at address ES:(E)DI; For 64-bit mode store AL at address RDI or EDI.
AB	STOSW	Α	Valid	Valid	For legacy mode, store AX at address ES:(E)DI; For 64-bit mode store AX at address RDI or EDI.
AB	STOSD	Α	Valid	Valid	For legacy mode, store EAX at address ES:(E)DI; For 64-bit mode store EAX at address RDI or EDI.
REX.W + AB	STOSQ	Α	Valid	N.E.	Store RAX at address RDI or EDI.

Instruction Operand Encoding

Op/En Operand 1		Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

In non-64-bit and default 64-bit mode; stores a byte, word, or doubleword from the AL, AX, or EAX register (respectively) into the destination operand. The destination operand is a memory location, the address of which is read from either the ES:EDI or ES:DI register (depending on the address-size attribute of the instruction and the

mode of operation). The ES segment cannot be overridden with a segment override prefix.

At the assembly-code level, two forms of the instruction are allowed: the "explicit-operands" form and the "no-operands" form. The explicit-operands form (specified with the STOS mnemonic) allows the destination operand to be specified explicitly. Here, the destination operand should be a symbol that indicates the size and location of the destination value. The source operand is then automatically selected to match the size of the destination operand (the AL register for byte operands, AX for word operands, EAX for doubleword operands). The explicit-operands form is provided to allow documentation; however, note that the documentation provided by this form can be misleading. That is, the destination operand symbol must specify the correct **type** (size) of the operand (byte, word, or doubleword), but it does not have to specify the correct **location**. The location is always specified by the ES:(E)DI register. These must be loaded correctly before the store string instruction is executed.

The no-operands form provides "short forms" of the byte, word, doubleword, and quadword versions of the STOS instructions. Here also ES:(E)DI is assumed to be the destination operand and AL, AX, or EAX is assumed to be the source operand. The size of the destination and source operands is selected by the mnemonic: STOSB (byte read from register AL), STOSW (word from AX), STOSD (doubleword from EAX).

After the byte, word, or doubleword is transferred from the register to the memory location, the (E)DI register is incremented or decremented according to the setting of the DF flag in the EFLAGS register. If the DF flag is 0, the register is incremented; if the DF flag is 1, the register is decremented (the register is incremented or decremented by 1 for byte operations, by 2 for word operations, by 4 for doubleword operations).

In 64-bit mode, the default address size is 64 bits, 32-bit address size is supported using the prefix 67H. Using a REX prefix in the form of REX.W promotes operation on doubleword operand to 64 bits. The promoted no-operand mnemonic is STOSQ. STOSQ (and its explicit operands variant) store a quadword from the RAX register into the destination addressed by RDI or EDI. See the summary chart at the beginning of this section for encoding data and limits.

The STOS, STOSB, STOSW, STOSD, STOSQ instructions can be preceded by the REP prefix for block loads of ECX bytes, words, or doublewords. More often, however, these instructions are used within a LOOP construct because data needs to be moved into the AL, AX, or EAX register before it can be stored. See "REP/REPE/REPZ/REPNE/REPNZ—Repeat String Operation Prefix" in this chapter for a description of the REP prefix.

Operation

Non-64-bit Mode:

IF (Byte store)

```
THEN
          \mathsf{DEST} \leftarrow \mathsf{AL};
                THEN IF DF = 0
                      THEN (E)DI \leftarrow (E)DI + 1;
                     ELSE (E)DI \leftarrow (E)DI – 1;
                FI;
    ELSE IF (Word store)
          THEN
                DEST \leftarrow AX;
                      THEN IF DF = 0
                            THEN (E)DI \leftarrow (E)DI + 2;
                            ELSE (E)DI \leftarrow (E)DI - 2;
                     FI;
          FI;
    ELSE IF (Doubleword store)
          THEN
                DEST \leftarrow EAX;
                      THEN IF DF = 0
                            THEN (E)DI \leftarrow (E)DI + 4;
                            ELSE (E)DI \leftarrow (E)DI - 4;
                      FI;
          FI;
FI;
64-bit Mode:
IF (Byte store)
    THEN
          DEST \leftarrow AL;
                THEN IF DF = 0
                      THEN (RIE)DI \leftarrow (RIE)DI + 1;
                     ELSE (R|E)DI \leftarrow (R|E)DI - 1;
                FI:
    ELSE IF (Word store)
          THEN
                DEST \leftarrow AX;
                      THEN IF DF = 0
                            THEN (RIE)DI \leftarrow (RIE)DI + 2;
                            ELSE (R|E)DI \leftarrow (R|E)DI - 2;
                     FI;
          FI;
    ELSE IF (Doubleword store)
          THEN
                DEST \leftarrow EAX:
```

```
THEN IF DF = 0
 THEN (R|E)DI \leftarrow (R|E)DI + 4;
 ELSE (R|E)DI \leftarrow (R|E)DI - 4;
 FI;
 FI;
 ELSE IF (Quadword store using REX.W)
 THEN
 DEST \leftarrow RAX;
 THEN IF DF = 0
 THEN (R|E)DI \leftarrow (R|E)DI + 8;
 ELSE (R|E)DI \leftarrow (R|E)DI - 8;
 FI;
 FI;
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the limit of the

ES segment.

If the ES register contains a NULL segment selector.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the ES

seament limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the ES

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

STR—Store Task Register

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF 00 /1	STR r/m16	Α	Valid	Valid	Stores segment selector from TR in <i>r/m16</i> .

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

Stores the segment selector from the task register (TR) in the destination operand. The destination operand can be a general-purpose register or a memory location. The segment selector stored with this instruction points to the task state segment (TSS) for the currently running task.

When the destination operand is a 32-bit register, the 16-bit segment selector is copied into the lower 16 bits of the register and the upper 16 bits of the register are cleared. When the destination operand is a memory location, the segment selector is written to memory as a 16-bit quantity, regardless of operand size.

In 64-bit mode, operation is the same. The size of the memory operand is fixed at 16 bits. In register stores, the 2-byte TR is zero extended if stored to a 64-bit register.

The STR instruction is useful only in operating-system software. It can only be executed in protected mode.

Operation

DEST \leftarrow TR(SegmentSelector);

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the destination is a memory operand that is located in a non-

writable segment or if the effective address is outside the CS,

DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

seament limit.

#PF(fault-code) If a page fault occurs.

INSTRUCTION SET REFERENCE, N-Z

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD The STR instruction is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD The STR instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form. #SS(U) If the stack address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

SUB—Subtract

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
2C ib	SUB AL, imm8	Α	Valid	Valid	Subtract imm8 from AL.
2D iw	SUB AX, imm16	Α	Valid	Valid	Subtract imm16 from AX.
2D id	SUB EAX, imm32	Α	Valid	Valid	Subtract <i>imm32</i> from EAX.
REX.W + 2D id	SUB RAX, imm32	Α	Valid	N.E.	Subtract <i>imm32</i> sign- extended to 64-bits from RAX.
80 /5 ib	SUB r/m8, imm8	В	Valid	Valid	Subtract imm8 from r/m8.
REX + 80 /5 ib	SUB r/m8*, imm8	В	Valid	N.E.	Subtract imm8 from r/m8.
81 /5 iw	SUB r/m16, imm16	В	Valid	Valid	Subtract imm16 from r/m16.
81 /5 id	SUB r/m32, imm32	В	Valid	Valid	Subtract <i>imm32</i> from r/m32.
REX.W + 81 /5 id	SUB r/m64, imm32	В	Valid	N.E.	Subtract <i>imm32</i> sign- extended to 64-bits from <i>r/m64</i> .
83 /5 ib	SUB r/m16, imm8	В	Valid	Valid	Subtract sign-extended imm8 from r/m16.
83 /5 ib	SUB r/m32, imm8	В	Valid	Valid	Subtract sign-extended imm8 from r/m32.
REX.W + 83 /5 ib	SUB r/m64, imm8	В	Valid	N.E.	Subtract sign-extended imm8 from r/m64.
28 /r	SUB r/m8, r8	С	Valid	Valid	Subtract r8 from r/m8.
REX + 28 /r	SUB r/m8*, r8*	С	Valid	N.E.	Subtract r8 from r/m8.
29 /r	SUB r/m16, r16	С	Valid	Valid	Subtract r16 from r/m16.
29 /r	SUB r/m32, r32	С	Valid	Valid	Subtract <i>r32</i> from <i>r/m32</i> .
REX.W + 29 /r	SUB r/m64, r32	С	Valid	N.E.	Subtract r64 from r/m64.
2A /r	SUB <i>r8, r/m8</i>	D	Valid	Valid	Subtract <i>r/m8</i> from <i>r8.</i>
REX + 2A /r	SUB r8*, r/m8*	D	Valid	N.E.	Subtract <i>r/m8</i> from <i>r8.</i>
2B /r	SUB <i>r16, r/</i> m16	D	Valid	Valid	Subtract r/m16 from r16.
2B /r	SUB <i>r32, r/m32</i>	D	Valid	Valid	Subtract <i>r/m32</i> from <i>r32.</i>
REX.W + 2B /r	SUB <i>r64, r/m64</i>	D	Valid	N.E.	Subtract r/m64 from r64.

NOTES:

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

	modection operand chessing							
Op/En	Operand 1	Operand 2	Operand 3	Operand 4				
Α	AL/AX/EAX/RAX	imm8/26/32	NA	NA				
В	ModRM:r/m (r, w)	imm8/26/32	NA	NA				
С	ModRM:r/m (r, w)	ModRM:reg (r)	NA	NA				
D	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA				

Instruction Operand Encoding

Description

Subtracts the second operand (source operand) from the first operand (destination operand) and stores the result in the destination operand. The destination operand can be a register or a memory location; the source operand can be an immediate, register, or memory location. (However, two memory operands cannot be used in one instruction.) When an immediate value is used as an operand, it is sign-extended to the length of the destination operand format.

The SUB instruction performs integer subtraction. It evaluates the result for both signed and unsigned integer operands and sets the OF and CF flags to indicate an overflow in the signed or unsigned result, respectively. The SF flag indicates the sign of the signed result.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

Operation

 $DEST \leftarrow (DEST - SRC);$

Flags Affected

The OF, SF, ZF, AF, PF, and CF flags are set according to the result.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

SUBPD—Subtract Packed Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 5C /r SUBPD xmm1, xmm2/m128	Α	V/V	SSE2	Subtract packed double-precision floating-point values in <i>xmm2/m128</i> from <i>xmm1</i> .
VEX.NDS.128.66.0F.WIG 5C /r VSUBPD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Subtract packed double- precision floating-point values in xmm3/mem from xmm2 and stores result in xmm1.
VEX.NDS.256.66.0F.WIG 5C /r VSUBPD ymm1, ymm2, ymm3/m256	В	V/V	AVX	Subtract packed double- precision floating-point values in ymm3/mem from ymm2 and stores result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD subtract of the two packed double-precision floating-point values in the source operand (second operand) from the two packed double-precision floating-point values in the destination operand (first operand), and stores the packed double-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 11-3 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD double-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: T second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Operation

SUBPD (128-bit Legacy SSE version)

DEST[63:0] ← DEST[63:0] - SRC[63:0]
DEST[127:64] ← DEST[127:64] - SRC[127:64]
DEST[VLMAX-1:128] (Unmodified)

VSUBPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] - SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] - SRC2[127:64] DEST[VLMAX-1:128] \leftarrow 0

VSUBPD (VEX.256 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] - SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] - SRC2[127:64] DEST[191:128] \leftarrow SRC1[191:128] - SRC2[191:128] DEST[255:192] \leftarrow SRC1[255:192] - SRC2[255:192]

Intel C/C++ Compiler Intrinsic Equivalent

```
SUBPD __m128d _mm_sub_pd (m128d a, m128d b)

VSUBPD __m256d _mm256_sub_pd (__m256d a, __m256d b);
```

SIMD Floating-Point Exceptions

Overflow, Underflow, Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 2.

SUBPS—Subtract Packed Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 5C /r SUBPS xmm1 xmm2/m128	Α	V/V	SSE	Subtract packed single- precision floating-point values in <i>xmm2/mem</i> from <i>xmm1</i> .
VEX.NDS.128.0F.WIG 5C /r VSUBPS xmm1,xmm2, xmm3/m128	В	V/V	AVX	Subtract packed single- precision floating-point values in xmm3/mem from xmm2 and stores result in xmm1.
VEX.NDS.256.0F.WIG 5C /r VSUBPS ymm1, ymm2, ymm3/m256	В	V/V	AVX	Subtract packed single- precision floating-point values in ymm3/mem from ymm2 and stores result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a SIMD subtract of the four packed single-precision floating-point values in the source operand (second operand) from the four packed single-precision floating-point values in the destination operand (first operand), and stores the packed single-precision floating-point results in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register. See Figure 10-5 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a SIMD double-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Operation

SUBPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SRC1[31:0] - SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] - SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] - SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] - SRC2[127:96] DEST[VLMAX-1:128] (Unmodified)

VSUBPS (VEX.128 encoded version)

DEST[31:0] \leftarrow SRC1[31:0] - SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] - SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] - SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] - SRC2[127:96] DEST[VLMAX-1:128] \leftarrow 0

VSUBPS (VEX.256 encoded version)

DEST[31:0] \leftarrow SRC1[31:0] - SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] - SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] - SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] - SRC2[127:96] DEST[159:128] \leftarrow SRC1[159:128] - SRC2[159:128] DEST[191:160] \leftarrow SRC1[191:160] - SRC2[191:160] DEST[223:192] \leftarrow SRC1[223:192] - SRC2[223:192] DEST[255:224] \leftarrow SRC1[255:224] - SRC2[255:224].

Intel C/C++ Compiler Intrinsic Equivalent

```
SUBPS __m128 _mm_sub_ps(__m128 a, __m128 b)
VSUBPS m256 mm256 sub ps ( m256 a,  m256 b);
```

SIMD Floating-Point Exceptions

Overflow, Underflow, Invalid, Precision, Denormal.

INSTRUCTION SET REFERENCE, N-Z

Other Exceptions

See Exceptions Type 2.

SUBSD—Subtract Scalar Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F2 OF 5C /r SUBSD xmm1, xmm2/m64	Α	V/V	SSE2	Subtracts the low double- precision floating-point values in xmm2/mem64 from xmm1.
VEX.NDS.LIG.F2.0F.WIG 5C /r VSUBSD xmm1,xmm2, xmm3/m64	В	V/V	AVX	Subtract the low double- precision floating-point value in xmm3/mem from xmm2 and store the result in xmm1.

Instruction Operand Encoding

		-		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Subtracts the low double-precision floating-point value in the source operand (second operand) from the low double-precision floating-point value in the destination operand (first operand), and stores the double-precision floating-point result in the destination operand. The source operand can be an XMM register or a 64-bit memory location. The destination operand is an XMM register. The high quadword of the destination operand remains unchanged. See Figure 11-4 in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for an illustration of a scalar double-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The destination and first source operand are the same. Bits (VLMAX-1:64) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (127:64) of the XMM register destination are copied from corresponding bits in the first source operand. Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

SUBSD (128-bit Legacy SSE version)

DEST[63:0] ← DEST[63:0] - SRC[63:0] DEST[VLMAX-1:64] (Unmodified)

VSUBSD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] - SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

SUBSD __m128d _mm_sub_sd (m128d a, m128d b)

SIMD Floating-Point Exceptions

Overflow, Underflow, Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 3.

SUBSS—Subtract Scalar Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
F3 OF 5C /r SUBSS xmm1, xmm2/m32	Α	V/V	SSE	Subtract the lower single- precision floating-point values in xmm2/m32 from xmm1.
VEX.NDS.LIG.F3.0F.WIG 5C /r VSUBSS xmm1,xmm2, xmm3/m32	В	V/V	AVX	Subtract the low single- precision floating-point value in xmm3/mem from xmm2 and store the result in xmm1.

Instruction Operand Encoding

		•		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Subtracts the low single-precision floating-point value in the source operand (second operand) from the low single-precision floating-point value in the destination operand (first operand), and stores the single-precision floating-point result in the destination operand. The source operand can be an XMM register or a 32-bit memory location. The destination operand is an XMM register. The three high-order doublewords of the destination operand remain unchanged. See Figure 10-6 in the <code>Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 1</code>, for an illustration of a scalar single-precision floating-point operation.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The destination and first source operand are the same. Bits (VLMAX-1:32) of the corresponding YMM destination register remain unchanged.

VEX.128 encoded version: Bits (127:32) of the XMM register destination are copied from corresponding bits in the first source operand. Bits (VLMAX-1:128) of the destination YMM register are zeroed.

Operation

SUBSS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow DEST[31:0] - SRC[31:0] DEST[VLMAX-1:32] (Unmodified)

VSUBSS (VEX.128 encoded version)

DEST[31:0] \leftarrow SRC1[31:0] - SRC2[31:0] DEST[127:32] \leftarrow SRC1[127:32] DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

SUBSS __m128 _mm_sub_ss(__m128 a, __m128 b)

SIMD Floating-Point Exceptions

Overflow, Underflow, Invalid, Precision, Denormal.

Other Exceptions

See Exceptions Type 3.

SWAPGS—Swap GS Base Register

	•	_			
Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 /7	SWAPGS	А	Valid	Invalid	Exchanges the current GS base register value with the value contained in MSR address C0000102H.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

SWAPGS exchanges the current GS base register value with the value contained in MSR address C0000102H (MSR_KERNELGSbase). KernelGSbase is guaranteed to be canonical; so SWAPGS does not perform a canonical check. The SWAPGS instruction is a privileged instruction intended for use by system software.

When using SYSCALL to implement system calls, there is no kernel stack at the OS entry point. Neither is there a straightforward method to obtain a pointer to kernel structures from which the kernel stack pointer could be read. Thus, the kernel can't save general purpose registers or reference memory.

By design, SWAPGS does not require any general purpose registers or memory operands. No registers need to be saved before using the instruction. SWAPGS exchanges the CPL 0 data pointer from the KernelGSbase MSR with the GS base register. The kernel can then use the GS prefix on normal memory references to access kernel data structures. Similarly, when the OS kernel is entered using an interrupt or exception (where the kernel stack is already set up), SWAPGS can be used to quickly get a pointer to the kernel data structures.

The KernelGSbase MSR itself is only accessible using RDMSR/WRMSR instructions. Those instructions are only accessible at privilege level 0. WRMSR will cause a #GP(0) if the value to be written to KernelGSbase MSR is non-canonical.

See Table 4-16.

Table 4-16. SWAPGS Operation Parameters

Opcode	ModR/M Byte			Instr	uction
	MOD	REG R/M		Not 64-bit Mode	64-bit Mode
OF 01	MOD ≠ 11	111	xxx	INVLPG	INVLPG
	11	111	000	#UD	SWAPGS
	11	111	≠000	#UD	#UD

Operation

```
IF CS.L \neq 1 (* Not in 64-Bit Mode *)

THEN

#UD; FI;

IF CPL \neq 0

THEN #GP(0); FI;

tmp \leftarrow GS(BASE);

GS(BASE) \leftarrow KERNELGSbase;

KERNELGSbase \leftarrow tmp;
```

Flags Affected

None

Protected Mode Exceptions

#UD If Mode \neq 64-Bit.

Real-Address Mode Exceptions

#UD If Mode \neq 64-Bit.

Virtual-8086 Mode Exceptions

#UD If Mode \neq 64-Bit.

Compatibility Mode Exceptions

#UD If Mode \neq 64-Bit.

64-Bit Mode Exceptions

#GP(0) If $CPL \neq 0$.

If the LOCK prefix is used.

SYSCALL—Fast System Call

	•				
Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 05	SYSCALL	Α	Valid	Invalid	Fast call to privilege level 0 system procedures.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

SYSCALL saves the RIP of the instruction following SYSCALL to RCX and loads a new RIP from the IA32_LSTAR (64-bit mode). Upon return, SYSRET copies the value saved in RCX to the RIP.

SYSCALL saves RFLAGS (lower 32 bit only) in R11. It then masks RFLAGS with an OS-defined value using the IA32_FMASK (MSR C000_0084). The actual mask value used by the OS is the complement of the value written to the IA32_FMASK MSR. None of the bits in RFLAGS are automatically cleared (except for RF). SYSRET restores RFLAGS from R11 (the lower 32 bits only).

Software should not alter the CS or SS descriptors in a manner that violates the following assumptions made by SYSCALL/SYSRET:

- The CS and SS base and limit remain the same for all processes, including the operating system (the base is 0H and the limit is 0FFFFFFFH).
- The CS of the SYSCALL target has a privilege level of 0.
- The CS of the SYSRET target has a privilege level of 3.

SYSCALL/SYSRET do not check for violations of these assumptions.

Operation

```
IF (CS.L \neq 1 ) or (IA32_EFER.LMA \neq 1) or (IA32_EFER.SCE \neq 1) (* Not in 64-Bit Mode or SYSCALL/SYSRET not enabled in IA32_EFER *)  
THEN #UD; FI;

RCX \leftarrow RIP;

RIP \leftarrow LSTAR_MSR;

R11 \leftarrow EFLAGS;

EFLAGS \leftarrow (EFLAGS MASKED BY IA32_FMASK);

CPL \leftarrow 0;

CS(SEL) \leftarrow IA32_STAR_MSR[47:32];

CS(DPL) \leftarrow 0;

CS(BASE) \leftarrow 0;
```

INSTRUCTION SET REFERENCE, N-Z

$$\begin{split} & \mathsf{CS}(\mathsf{LIMIT}) \leftarrow \mathsf{0xFFFFF}; \\ & \mathsf{CS}(\mathsf{GRANULAR}) \leftarrow \mathsf{1}; \\ & \mathsf{SS}(\mathsf{SEL}) \leftarrow \mathsf{IA32_STAR_MSR[47:32]} + \mathsf{8}; \\ & \mathsf{SS}(\mathsf{DPL}) \leftarrow \mathsf{0}; \\ & \mathsf{SS}(\mathsf{BASE}) \leftarrow \mathsf{0}; \\ & \mathsf{SS}(\mathsf{LIMIT}) \leftarrow \mathsf{0xFFFFF}; \\ & \mathsf{SS}(\mathsf{GRANULAR}) \leftarrow \mathsf{1}; \end{split}$$

Flags Affected

All.

Protected Mode Exceptions

#UD If Mode \neq 64-bit.

Real-Address Mode Exceptions

#UD If Mode \neq 64-bit.

Virtual-8086 Mode Exceptions

#UD If Mode \neq 64-bit.

Compatibility Mode Exceptions

#UD If Mode \neq 64-bit.

64-Bit Mode Exceptions

#UD If $IA32_EFER.SCE = 0$.

If the LOCK prefix is used.

SYSENTER—Fast System Call

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 34	SYSENTER	Α	Valid	Valid	Fast call to privilege level 0 system procedures.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Executes a fast call to a level 0 system procedure or routine. SYSENTER is a companion instruction to SYSEXIT. The instruction is optimized to provide the maximum performance for system calls from user code running at privilege level 3 to operating system or executive procedures running at privilege level 0.

Prior to executing the SYSENTER instruction, software must specify the privilege level 0 code segment and code entry point, and the privilege level 0 stack segment and stack pointer by writing values to the following MSRs:

- IA32_SYSENTER_CS Contains a 32-bit value, of which the lower 16 bits are the segment selector for the privilege level 0 code segment. This value is also used to compute the segment selector of the privilege level 0 stack segment.
- IA32_SYSENTER_EIP Contains the 32-bit offset into the privilege level 0 code segment to the first instruction of the selected operating procedure or routine.
- IA32_SYSENTER_ESP Contains the 32-bit stack pointer for the privilege level 0 stack.

These MSRs can be read from and written to using RDMSR/WRMSR. Register addresses are listed in Table 4-17. The addresses are defined to remain fixed for future Intel 64 and IA-32 processors.

Table 4-17. MSRs Used By the SYSENTER and SYSEXIT Instructions

MSR	Address
IA32_SYSENTER_CS	174H
IA32_SYSENTER_ESP	175H
IA32_SYSENTER_EIP	176H

When SYSENTER is executed, the processor:

- 1. Loads the segment selector from the IA32_SYSENTER_CS into the CS register.
- 2. Loads the instruction pointer from the IA32 SYSENTER EIP into the EIP register.
- 3. Adds 8 to the value in IA32_SYSENTER_CS and loads it into the SS register.

INSTRUCTION SET REFERENCE, N-Z

- 4. Loads the stack pointer from the IA32 SYSENTER ESP into the ESP register.
- 5. Switches to privilege level 0.
- 6. Clears the VM flag in the EFLAGS register, if the flag is set.
- 7. Begins executing the selected system procedure.

The processor does not save a return IP or other state information for the calling procedure.

The SYSENTER instruction always transfers program control to a protected-mode code segment with a DPL of 0. The instruction requires that the following conditions are met by the operating system:

- The segment descriptor for the selected system code segment selects a flat, 32-bit code segment of up to 4 GBytes, with execute, read, accessed, and nonconforming permissions.
- The segment descriptor for selected system stack segment selects a flat 32-bit stack segment of up to 4 GBytes, with read, write, accessed, and expand-up permissions.

The SYSENTER instruction can be invoked from all operating modes except real-address mode.

The SYSENTER and SYSEXIT instructions are companion instructions, but they do not constitute a call/return pair. When executing a SYSENTER instruction, the processor does not save state information for the user code, and neither the SYSENTER nor the SYSEXIT instruction supports passing parameters on the stack.

To use the SYSENTER and SYSEXIT instructions as companion instructions for transitions between privilege level 3 code and privilege level 0 operating system procedures, the following conventions must be followed:

- The segment descriptors for the privilege level 0 code and stack segments and for the privilege level 3 code and stack segments must be contiguous in the global descriptor table. This convention allows the processor to compute the segment selectors from the value entered in the SYSENTER_CS_MSR MSR.
- The fast system call "stub" routines executed by user code (typically in shared libraries or DLLs) must save the required return IP and processor state information if a return to the calling procedure is required. Likewise, the operating system or executive procedures called with SYSENTER instructions must have access to and use this saved return and state information when returning to the user code.

The SYSENTER and SYSEXIT instructions were introduced into the IA-32 architecture in the Pentium II processor. The availability of these instructions on a processor is indicated with the SYSENTER/SYSEXIT present (SEP) feature flag returned to the EDX register by the CPUID instruction. An operating system that qualifies the SEP flag must also qualify the processor family and model to ensure that the SYSENTER/SYSEXIT instructions are actually present. For example:

IF CPUID SEP bit is set

```
THEN IF (Family = 6) and (Model < 3) and (Stepping < 3)
THEN
SYSENTER/SYSEXIT_Not_Supported; FI;
ELSE
SYSENTER/SYSEXIT_Supported; FI;
FI:
```

When the CPUID instruction is executed on the Pentium Pro processor (model 1), the processor returns a the SEP flag as set, but does not support the SYSENTER/SYSEXIT instructions.

Operation

```
IF CRO.PE = 0 THEN \#GP(0); FI;
IF SYSENTER_CS_MSR[15:2] = 0 THEN \#GP(0); FI;
EFLAGS.VM \leftarrow 0;
                                                      (* ensures protected mode execution *)
EFLAGS.IF \leftarrow 0;
                                                      (* Mask interrupts *)
EFLAGS.RF \leftarrow 0;
CS.SEL \leftarrow SYSENTER\_CS\_MSR
                                                      (* Operating system provides CS *)
(* Set rest of CS to a fixed value *)
CS.SEL.RPL \leftarrow 0:
CS.BASE \leftarrow 0:
                                                      (* Flat segment *)
CS.ARbyte.G \leftarrow 1;
                                                      (* 4-KByte granularity *)
CS.ARbyte.S \leftarrow 1;
CS.ARbyte.TYPE \leftarrow 1011B;
                                                      (* Execute + Read, Accessed *)
CS.ARbvte.D \leftarrow 1:
                                                      (* 32-bit code segment*)
CS.ARbyte.DPL \leftarrow 0;
CS.ARbyte.P \leftarrow 1;
CS.LIMIT \leftarrow FFFFFH;
                                                      (* with 4-KByte granularity, implies a 4-GByte limit *)
CPL \leftarrow 0:
SS.SEL \leftarrow CS.SEL + 8;
(* Set rest of SS to a fixed value *)
SS.SEL.RPL \leftarrow 0;
SS.BASE \leftarrow 0;
                                                      (* Flat segment *)
SS.ARbyte.G \leftarrow 1;
                                                      (* 4-KByte granularity *)
SS.ARbyte.S \leftarrow 1;
                                                      (* Read/Write, Accessed *)
SS.ARbyte.TYPE \leftarrow 0011B;
SS.ARbyte.D \leftarrow 1;
                                                      (* 32-bit stack segment*)
SS.ARbyte.DPL \leftarrow 0;
SS.ARbyte.P \leftarrow 1;
SS.LIMIT \leftarrow FFFFFH;
                                                      (* with 4-KByte granularity, implies a 4-GByte limit *)
ESP \leftarrow SYSENTER ESP MSR;
```

 $EIP \leftarrow SYSENTER EIP MSR;$

IA-32e Mode Operation

In IA-32e mode, SYSENTER executes a fast system calls from user code running at privilege level 3 (in compatibility mode or 64-bit mode) to 64-bit executive procedures running at privilege level 0. This instruction is a companion instruction to the SYSEXIT instruction.

In IA-32e mode, the IA32_SYSENTER_EIP and IA32_SYSENTER_ESP MSRs hold 64-bit addresses and must be in canonical form; IA32_SYSENTER_CS must not contain a NULL selector.

When SYSENTER transfers control, the following fields are generated and bits set:

- Target code segment Reads non-NULL selector from IA32 SYSENTER CS.
- New CS attributes L-bit = 1 (go to 64-bit mode); CS base = 0, CS limit = FFFFFFFFH.
- Target instruction Reads 64-bit canonical address from IA32_SYSENTER_EIP.
- Stack segment Computed by adding 8 to the value from IA32 SYSENTER CS.
- Stack pointer Reads 64-bit canonical address from IA32_SYSENTER_ESP.
- New SS attributes SS base = 0, SS limit = FFFFFFFH.

Flags Affected

VM, IF, RF (see Operation above)

Protected Mode Exceptions

#GP(0) If IA32_SYSENTER_CS[15:2] = 0.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If protected mode is not enabled.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

SYSEXIT—Fast Return from Fast System Call

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 35	SYSEXIT	Α	Valid	Valid	Fast return to privilege level 3 user code.
REX.W + 0F 35	SYSEXIT	Α	Valid	Valid	Fast return to 64-bit mode privilege level 3 user code.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Executes a fast return to privilege level 3 user code. SYSEXIT is a companion instruction to the SYSENTER instruction. The instruction is optimized to provide the maximum performance for returns from system procedures executing at protections levels 0 to user procedures executing at protection level 3. It must be executed from code executing at privilege level 0.

Prior to executing SYSEXIT, software must specify the privilege level 3 code segment and code entry point, and the privilege level 3 stack segment and stack pointer by writing values into the following MSR and general-purpose registers:

- **IA32_SYSENTER_CS** Contains a 32-bit value, of which the lower 16 bits are the segment selector for the privilege level 0 code segment in which the processor is currently executing. This value is used to compute the segment selectors for the privilege level 3 code and stack segments.
- **EDX** Contains the 32-bit offset into the privilege level 3 code segment to the first instruction to be executed in the user code.
- **ECX** Contains the 32-bit stack pointer for the privilege level 3 stack.

The IA32_SYSENTER_CS MSR can be read from and written to using RDMSR/WRMSR. The register address is listed in Table 4-17. This address is defined to remain fixed for future Intel 64 and IA-32 processors.

When SYSEXIT is executed, the processor:

- Adds 16 to the value in IA32_SYSENTER_CS and loads the sum into the CS selector register.
- 2. Loads the instruction pointer from the EDX register into the EIP register.
- 3. Adds 24 to the value in IA32_SYSENTER_CS and loads the sum into the SS selector register.
- 4. Loads the stack pointer from the ECX register into the ESP register.

- 5. Switches to privilege level 3.
- 6. Begins executing the user code at the EIP address.

See "SWAPGS—Swap GS Base Register" in this chapter for information about using the SYSENTER and SYSEXIT instructions as companion call and return instructions.

The SYSEXIT instruction always transfers program control to a protected-mode code segment with a DPL of 3. The instruction requires that the following conditions are met by the operating system:

- The segment descriptor for the selected user code segment selects a flat, 32-bit code segment of up to 4 GBytes, with execute, read, accessed, and nonconforming permissions.
- The segment descriptor for selected user stack segment selects a flat, 32-bit stack segment of up to 4 GBytes, with expand-up, read, write, and accessed permissions.

The SYSEXIT instruction can be invoked from all operating modes except real-address mode and virtual 8086 mode.

The SYSENTER and SYSEXIT instructions were introduced into the IA-32 architecture in the Pentium II processor. The availability of these instructions on a processor is indicated with the SYSENTER/SYSEXIT present (SEP) feature flag returned to the EDX register by the CPUID instruction. An operating system that qualifies the SEP flag must also qualify the processor family and model to ensure that the SYSENTER/SYSEXIT instructions are actually present. For example:

```
IF CPUID SEP bit is set
   THEN IF (Family = 6) and (Model < 3) and (Stepping < 3)
   THEN
        SYSENTER/SYSEXIT_Not_Supported; FI;
   ELSE
        SYSENTER/SYSEXIT_Supported; FI;
FI:</pre>
```

When the CPUID instruction is executed on the Pentium Pro processor (model 1), the processor returns a the SEP flag as set, but does not support the SYSENTER/SYSEXIT instructions.

Operation

```
IF SYSENTER_CS_MSR[15:2] = 0 THEN #GP(0); FI;

IF CR0.PE = 0 THEN #GP(0); FI;

IF CPL \neq 0 THEN #GP(0); FI;

CS.SEL \leftarrow (SYSENTER_CS_MSR + 16); (* Segment selector for return CS *)

(* Set rest of CS to a fixed value *)

CS.SEL.RPL \leftarrow 3;

CS.BASE \leftarrow 0; (* Flat segment *)
```

```
CS.ARbyte.G \leftarrow 1;
                                                      (* 4-KByte granularity *)
CS.ARbyte.S \leftarrow 1;
CS.ARbyte.TYPE \leftarrow 1011B;
                                                      (* Execute, Read, Non-Conforming Code *)
                                                      (* 32-bit code segment*)
CS.ARbyte.D \leftarrow 1;
CS.ARbyte.DPL \leftarrow 3;
CS.ARbyte.P \leftarrow 1;
CS.LIMIT \leftarrow FFFFFH;
                                                      (* with 4-KByte granularity, implies a 4-GByte limit *)
CPL \leftarrow 3:
                                                      (* Segment selector for return SS *)
SS.SEL \leftarrow (SYSENTER\_CS\_MSR + 24);
(* Set rest of SS to a fixed value *);
SS.SEL.RPL \leftarrow 3:
SS.BASE \leftarrow 0:
                                                       (* Flat segment *)
SS.ARbyte.G \leftarrow1;
                                                      (* 4-KByte granularity *)
SS.ARbyte.S \leftarrow 1;
SS.ARbvte.TYPE \leftarrow 0011B:
                                                      (* Expand Up, Read/Write, Data *)
SS.ARbvte.D \leftarrow 1:
                                                      (* 32-bit stack segment*)
SS.ARbyte.DPL \leftarrow 3;
SS.ARbyte.P \leftarrow 1;
SS.LIMIT \leftarrow FFFFFH:
                                                      (* with 4-KByte granularity, implies a 4-GByte limit *)
ESP \leftarrow ECX:
EIP \leftarrow EDX:
```

IA-32e Mode Operation

In IA-32e mode, SYSEXIT executes a fast system calls from a 64-bit executive procedures running at privilege level 0 to user code running at privilege level 3 (in compatibility mode or 64-bit mode). This instruction is a companion instruction to the SYSENTER instruction.

In IA-32e mode, the IA32_SYSENTER_EIP and IA32_SYSENTER_ESP MSRs hold 64-bit addresses and must be in canonical form; IA32_SYSENTER_CS must not contain a NULL selector.

When the SYSEXIT instruction transfers control to 64-bit mode user code using REX.W, the following fields are generated and bits set:

- Target code segment Computed by adding 32 to the value in the IA32_SYSENTER_CS.
- New CS attributes L-bit = 1 (go to 64-bit mode).
- Target instruction Reads 64-bit canonical address in RDX.
- Stack segment Computed by adding 8 to the value of CS selector.
- Stack pointer Update RSP using 64-bit canonical address in RCX.

When SYSEXIT transfers control to compatibility mode user code when the operand size attribute is 32 bits, the following fields are generated and bits set:

- Target code segment Computed by adding 16 to the value in IA32 SYSENTER CS.
- **New CS attributes** L-bit = 0 (go to compatibility mode).
- Target instruction Fetch the target instruction from 32-bit address in EDX.
- Stack segment Computed by adding 24 to the value in IA32_SYSENTER_CS.
- Stack pointer Update ESP from 32-bit address in ECX.

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If IA32_SYSENTER_CS[15:2] = 0.

If CPL \neq 0.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If protected mode is not enabled.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) Always.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If IA32_SYSENTER_CS = 0.

If $CPL \neq 0$.

If ECX or EDX contains a non-canonical address.

#UD If the LOCK prefix is used.

SYSRET—Return From Fast System Call

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 07	SYSRET	Α	Valid	Invalid	Return to compatibility mode from fast system call
REX.W + 0F 07	SYSRET	Α	Valid	Invalid	Return to 64-bit mode from fast system call

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

SYSCALL saves the RIP of the instruction following the SYSCALL into RCX and loads the new RIP from the LSTAR (64-bit mode only). Upon return, SYSRET copies the value saved in RCX to the RIP.

In a return to 64-bit mode using Osize 64, SYSRET sets the CS selector value to MSR IA32 STAR[63:48] +16. The SS is set to IA32 STAR[63:48] + 8.

SYSRET transfer control to compatibility mode using Osize 32. The CS selector value is set to MSR IA32_STAR[63:48]. The SS is set to IA32_STAR[63:48] + 8.

It is the responsibility of the OS to keep descriptors in the GDT/LDT that correspond to selectors loaded by SYSCALL/SYSRET consistent with the base, limit and attribute values forced by the these instructions.

Software should not alter the CS or SS descriptors in a manner that violates the following assumptions made by SYSCALL/SYSRET:

- CS and SS base and limit remain the same for all processes, including the operating system.
- CS of the SYSCALL target has a privilege level of 0.
- CS of the SYSRET target has a privilege level of 3.

SYSCALL/SYSRET do not check for violations of these assumptions.

Operation

```
IF (CS.L ≠ 1 ) or (IA32_EFER.LMA ≠ 1) or (IA32_EFER.SCE ≠ 1)
(* Not in 64-Bit Mode or SYSCALL/SYSRET not enabled in IA32_EFER *)
    THEN #UD; FI;
IF (CPL ≠ 0)
    THEN #GP(0); FI;
IF (RCX ≠ CANONICAL_ADDRESS)
```

```
THEN #GP(0); FI;
IF (OPERAND SIZE = 64)
   THEN (* Return to 64-Bit Mode *)
        EFLAGS \leftarrow R11;
        CPL \leftarrow 0x3;
        CS(SEL) \leftarrow IA32\_STAR[63:48] + 16;
        CS(PL) \leftarrow 0x3;
        SS(SEL) \leftarrow IA32\_STAR[63:48] + 8;
        SS(PL) \leftarrow 0x3;
        RIP \leftarrow RCX;
   ELSE (* Return to Compatibility Mode *)
        EFLAGS ← R11:
        CPL \leftarrow 0x3;
        CS(SEL) \leftarrow IA32\_STAR[63:48];
        CS(PL) \leftarrow 0x3;
        SS(SEL) \leftarrow IA32\_STAR[63:48] + 8;
        SS(PL) \leftarrow 0x3;
        \mathsf{EIP} \leftarrow \mathsf{ECX};
FI;
Flags Affected
VM, IF, RF.
Protected Mode Exceptions
#UD
                         If Mode \neq 64-Bit.
Real-Address Mode Exceptions
#UD
                         If Mode \neq 64-Bit.
Virtual-8086 Mode Exceptions
#UD
                         If Mode \neq 64-Bit.
Compatibility Mode Exceptions
#UD
                         If Mode \neq 64-Bit.
64-Bit Mode Exceptions
#UD
                         If IA32 EFER.SCE bit = 0.
                         If the LOCK prefix is used.
                         If CPL \neq 0.
#GP(0)
                         If ECX contains a non-canonical address.
```

TEST—Logical Compare

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
A8 <i>ib</i>	TEST AL, imm8	Α	Valid	Valid	AND <i>imm8</i> with AL; set SF, ZF, PF according to result.
A9 iw	TEST AX, imm16	Α	Valid	Valid	AND <i>imm16</i> with AX; set SF, ZF, PF according to result.
A9 id	TEST EAX, imm32	Α	Valid	Valid	AND <i>imm32</i> with EAX; set SF, ZF, PF according to result.
REX.W + A9 id	TEST RAX, imm32	Α	Valid	N.E.	AND <i>imm32</i> sign-extended to 64-bits with RAX; set SF, ZF, PF according to result.
F6 /0 ib	TEST r/m8, imm8	В	Valid	Valid	AND <i>imm8</i> with <i>r/m8</i> ; set SF, ZF, PF according to result.
REX + F6 /0 ib	TEST r/m8*, imm8	В	Valid	N.E.	AND <i>imm8</i> with <i>r/m8</i> ; set SF, ZF, PF according to result.
F7 /0 iw	TEST r/m16, imm16	В	Valid	Valid	AND <i>imm16</i> with <i>r/m16</i> ; set SF, ZF, PF according to result.
F7 /0 id	TEST r/m32, imm32	В	Valid	Valid	AND <i>imm32</i> with <i>r/m32</i> ; set SF, ZF, PF according to result.
REX.W + F7 /0 id	TEST r/m64, imm32	В	Valid	N.E.	AND <i>imm32</i> sign-extended to 64-bits with <i>r/m64</i> ; set SF, ZF, PF according to result.
84 <i>/</i> r	TEST r/m8, r8	С	Valid	Valid	AND <i>r8</i> with <i>r/m8</i> ; set SF, ZF, PF according to result.
REX + 84 /r	TEST r/m8*, r8*	С	Valid	N.E.	AND <i>r8</i> with <i>r/m8</i> ; set SF, ZF, PF according to result.
85 /r	TEST r/m16, r16	С	Valid	Valid	AND <i>r16</i> with <i>r/m16</i> ; set SF, ZF, PF according to result.
85 /r	TEST r/m32, r32	С	Valid	Valid	AND <i>r32</i> with <i>r/m32</i> ; set SF, ZF, PF according to result.
REX.W + 85 /r	TEST r/m64, r64	С	Valid	N.E.	AND <i>r64</i> with <i>r/m64</i> ; set SF, ZF, PF according to result.

NOTES:

* In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

Instruction (Operand	Encoding
III3 ti uctioni v	operaniu	Circounty

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	AL/AX/EAX/RAX	imm8/16/32	NA	NA
В	ModRM:r/m (r)	imm8/16/32	NA	NA
С	ModRM:r/m (r)	ModRM:reg (r)	NA	NA

Description

Computes the bit-wise logical AND of first operand (source 1 operand) and the second operand (source 2 operand) and sets the SF, ZF, and PF status flags according to the result. The result is then discarded.

In 64-bit mode, using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

```
TEMP \leftarrow SRC1 AND SRC2;

SF \leftarrow MSB(TEMP);

IF TEMP = 0

THEN ZF \leftarrow 1;

ELSE ZF \leftarrow 0;

FI:

PF \leftarrow BitwiseXNOR(TEMP[0:7]);

CF \leftarrow 0;

OF \leftarrow 0;

(* AF is undefined *)
```

Flags Affected

The OF and CF flags are set to 0. The SF, ZF, and PF flags are set according to the result (see the "Operation" section above). The state of the AF flag is undefined.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

UCOMISD—Unordered Compare Scalar Double-Precision Floating-Point Values and Set EFLAGS

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 2E /r UCOMISD xmm1, xmm2/m64	Α	V/V	SSE2	Compares (unordered) the low double-precision floating-point values in xmm1 and xmm2/m64 and set the EFLAGS accordingly.
VEX.LIG.66.0F.WIG 2E /r VUCOMISD xmm1, xmm2/m64	Α	V/V	AVX	Compare low double precision floating-point values in xmm1 and xmm2/mem64 and set the EFLAGS flags accordingly.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	NA	NA

Description

Performs and unordered compare of the double-precision floating-point values in the low quadwords of source operand 1 (first operand) and source operand 2 (second operand), and sets the ZF, PF, and CF flags in the EFLAGS register according to the result (unordered, greater than, less than, or equal). The OF, SF and AF flags in the EFLAGS register are set to 0. The unordered result is returned if either source operand is a NaN (QNaN or SNaN).

Source operand 1 is an XMM register; source operand 2 can be an XMM register or a 64 bit memory location.

The UCOMISD instruction differs from the COMISD instruction in that it signals a SIMD floating-point invalid operation exception (#I) only when a source operand is an SNaN. The COMISD instruction signals an invalid operation exception if a source operand is either a QNaN or an SNaN.

The EFLAGS register is not updated if an unmasked SIMD floating-point exception is generated.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

```
\label{eq:result} \begin{split} & \text{RESULT} \leftarrow \text{UnorderedCompare}(\text{SRC1[63:0]} <> \text{SRC2[63:0]}) \, \{\\ & \text{(* Set EFLAGS *)} \\ & \text{CASE (RESULT) OF} \\ & \text{UNORDERED:} & \text{ZF, PF, CF} \leftarrow 111; \\ & \text{GREATER\_THAN:} & \text{ZF, PF, CF} \leftarrow 000; \\ & \text{LESS\_THAN:} & \text{ZF, PF, CF} \leftarrow 001; \\ & \text{EQUAL:} & \text{ZF, PF, CF} \leftarrow 100; \\ & \text{ESAC;} \\ & \text{OF, AF, SF} \leftarrow 0; \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

```
int _mm_ucomieq_sd(__m128d a, __m128d b)
int _mm_ucomilt_sd(__m128d a, __m128d b)
int _mm_ucomile_sd(__m128d a, __m128d b)
int _mm_ucomigt_sd(__m128d a, __m128d b)
int _mm_ucomige_sd(__m128d a, __m128d b)
int _mm_ucomineq_sd(__m128d a, __m128d b)
```

SIMD Floating-Point Exceptions

Invalid (if SNaN operands), Denormal.

Other Exceptions

```
See Exceptions Type 3; additionally #UD If VEX.vvvv != 1111B.
```

UCOMISS—Unordered Compare Scalar Single-Precision Floating-Point Values and Set EFLAGS

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 2E /r UCOMISS xmm1, xmm2/m32	Α	V/V	SSE	Compare lower single- precision floating-point value in xmm1 register with lower single-precision floating-point value in xmm2/mem and set the status flags accordingly.
VEX.LIG.0F.WIG 2E /r VUCOMISS xmm1, xmm2/m32	A	V/V	AVX	Compare low single precision floating-point values in xmm1 and xmm2/mem32 and set the EFLAGS flags accordingly.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r)	ModRM:r/m (r)	NA	NA

Description

Performs and unordered compare of the single-precision floating-point values in the low doublewords of the source operand 1 (first operand) and the source operand 2 (second operand), and sets the ZF, PF, and CF flags in the EFLAGS register according to the result (unordered, greater than, less than, or equal). In The OF, SF and AF flags in the EFLAGS register are set to 0. The unordered result is returned if either source operand is a NaN (QNaN or SNaN).

Source operand 1 is an XMM register; source operand 2 can be an XMM register or a 32 bit memory location.

The UCOMISS instruction differs from the COMISS instruction in that it signals a SIMD floating-point invalid operation exception (#I) only when a source operand is an SNaN. The COMISS instruction signals an invalid operation exception if a source operand is either a QNaN or an SNaN.

The EFLAGS register is not updated if an unmasked SIMD floating-point exception is generated.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

```
\label{eq:result} \begin{split} & \text{RESULT} \leftarrow \text{UnorderedCompare}(\text{SRC1[31:0]} <> \text{SRC2[31:0]}) \, \{\\ & \text{(* Set EFLAGS *)} \\ & \text{CASE (RESULT) OF} \\ & \text{UNORDERED:} & \text{ZF,PF,CF} \leftarrow 111; \\ & \text{GREATER\_THAN:} & \text{ZF,PF,CF} \leftarrow 000; \\ & \text{LESS\_THAN:} & \text{ZF,PF,CF} \leftarrow 001; \\ & \text{EQUAL:} & \text{ZF,PF,CF} \leftarrow 100; \\ & \text{ESAC;} \\ & \text{OF,AF,SF} \leftarrow 0; \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

```
int _mm_ucomieq_ss(__m128 a, __m128 b)
int _mm_ucomilt_ss(__m128 a, __m128 b)
int _mm_ucomile_ss(__m128 a, __m128 b)
int _mm_ucomigt_ss(__m128 a, __m128 b)
int _mm_ucomige_ss(__m128 a, __m128 b)
int _mm_ucomineq_ss(__m128 a, __m128 b)
```

SIMD Floating-Point Exceptions

Invalid (if SNaN operands), Denormal.

Other Exceptions

```
See Exceptions Type 3; additionally #UD If VEX.vvvv != 1111B.
```

UD2—Undefined Instruction

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF OB	UD2	Α	Valid	Valid	Raise invalid opcode exception.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	NA	NA	NA	NA	

Description

Generates an invalid opcode exception. This instruction is provided for software testing to explicitly generate an invalid opcode exception. The opcode for this instruction is reserved for this purpose.

Other than raising the invalid opcode exception, this instruction has no effect on processor state or memory.

Even though it is the execution of the UD2 instruction that causes the invalid opcode exception, the instruction pointer saved by delivery of the exception references the UD2 instruction (and not the following instruction).

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

#UD (* Generates invalid opcode exception *);

Flags Affected

None.

Exceptions (All Operating Modes)

#UD Raises an invalid opcode exception in all operating modes.

UNPCKHPD—Unpack and Interleave High Packed Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 15 /r UNPCKHPD xmm1, xmm2/m128	Α	V/V	SSE2	Unpacks and Interleaves double-precision floating-point values from high quadwords of xmm1 and xmm2/m128.
VEX.NDS.128.66.0F.WIG 15 /r VUNPCKHPD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Unpacks and Interleaves double precision floating-point values from high quadwords of xmm2 and xmm3/m128.
VEX.NDS.256.66.0F.WIG 15 /r VUNPCKHPD ymm1,ymm2, ymm3/m256	В	V/V	AVX	Unpacks and Interleaves double precision floating-point values from high quadwords of ymm2 and ymm3/m256.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an interleaved unpack of the high double-precision floating-point values from the source operand (second operand) and the destination operand (first operand). See Figure 4-17.




Figure 4-17. UNPCKHPD Instruction High Unpack and Interleave Operation

When unpacking from a memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to 16-byte boundary and normal segment checking will still be enforced.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

Operation

UNPCKHPD (128-bit Legacy SSE version)

DEST[63:0] ← SRC1[127:64]
DEST[127:64] ← SRC2[127:64]
DEST[VLMAX-1:128] (Unmodified)

VUNPCKHPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[127:64] DEST[127:64] \leftarrow SRC2[127:64] DESTIVLMAX-1:1281 \leftarrow 0

VUNPCKHPD (VEX.256 encoded version)

DEST[63:0] \leftarrow SRC1[127:64]

INSTRUCTION SET REFERENCE, N-Z

DEST[127:64] ← SRC2[127:64]
DEST[191:128]←SRC1[255:192]
DEST[255:192]←SRC2[255:192]

Intel C/C++ Compiler Intrinsic Equivalent

UNPCKHPD __m128d _mm_unpackhi_pd(__m128d a, __m128d b)

UNPCKHPD __m256d _mm256_unpackhi_pd(__m256d a, __m256d b)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

UNPCKHPS—Unpack and Interleave High Packed Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 15 /r UNPCKHPS xmm1, xmm2/m128	A	V/V	SSE	Unpacks and Interleaves single-precision floating-point values from high quadwords of xmm1 and xmm2/mem into xmm1.
VEX.NDS.128.0F.WIG 15 /r VUNPCKHPS xmm1,xmm2, xmm3/m128	В	V/V	AVX	Unpacks and Interleaves single-precision floating-point values from high quadwords of xmm2 and xmm3/m128.
VEX.NDS.256.0F.WIG 15 /r VUNPCKHPS ymm1,ymm2,ymm3/m256	В	V/V	AVX	Unpacks and Interleaves single-precision floating-point values from high quadwords of ymm2 and ymm3/m256.

Instruction Operand Encoding

		-		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an interleaved unpack of the high-order single-precision floating-point values from the source operand (second operand) and the destination operand (first operand). See Figure 4-18. The source operand can be an XMM register or a 128-bit memory location; the destination operand is an XMM register.




Figure 4-18. UNPCKHPS Instruction High Unpack and Interleave Operation

When unpacking from a memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to 16-byte boundary and normal segment checking will still be enforced.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: T second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

Operation

UNPCKHPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SRC1[95:64]

 $\mathsf{DEST}[63:32] \leftarrow \mathsf{SRC2}[95:64]$

 $\mathsf{DEST}[95:64] \leftarrow \mathsf{SRC1}[127:96]$

DEST[127:96] \leftarrow SRC2[127:96]

DEST[VLMAX-1:128] (Unmodified)

VUNPCKHPS (VEX.128 encoded version)

 $\mathsf{DEST}[31:0] \leftarrow \mathsf{SRC1}[95:64]$

 $\mathsf{DEST}[63:32] \leftarrow \mathsf{SRC2}[95:64]$

DEST[95:64] ← SRC1[127:96]

DEST[127:96] \leftarrow SRC2[127:96]

DEST[VLMAX-1:128] \leftarrow 0

VUNPCKHPS (VEX.256 encoded version)

DEST[31:0] \leftarrow SRC1[95:64]

DEST[63:32] \leftarrow SRC2[95:64]

DEST[95:64] \leftarrow SRC1[127:96]

DEST[127:96] \leftarrow SRC2[127:96]

DEST[159:128] \leftarrow SRC1[223:192]

DEST[191:160] \leftarrow SRC2[223:192]

DEST[223:192] \leftarrow SRC1[255:224]

DEST[255:224] \leftarrow SRC2[255:224]

Intel C/C++ Compiler Intrinsic Equivalent

UNPCKHPS __m128 _mm_unpackhi_ps(__m128 a, __m128 b)

UNPCKHPS __m256 _mm256_unpackhi_ps (__m256 a, __m256 b);

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

UNPCKLPD—Unpack and Interleave Low Packed Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 14 /r UNPCKLPD xmm1, xmm2/m128	Α	V/V	SSE2	Unpacks and Interleaves double-precision floating-point values from low quadwords of xmm1 and xmm2/m128.
VEX.NDS.128.66.0F.WIG 14 /r VUNPCKLPD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Unpacks and Interleaves double precision floating-point values low high quadwords of xmm2 and xmm3/m128.
VEX.NDS.256.66.0F.WIG 14 /r VUNPCKLPD ymm1,ymm2, ymm3/m256	В	V/V	AVX	Unpacks and Interleaves double precision floating-point values low high quadwords of ymm2 and ymm3/m256.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an interleaved unpack of the low double-precision floating-point values from the source operand (second operand) and the destination operand (first operand). See Figure 4-19. The source operand can be an XMM register or a 128-bit memory location; the destination operand is an XMM register.




Figure 4-19. UNPCKLPD Instruction Low Unpack and Interleave Operation

When unpacking from a memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to 16-byte boundary and normal segment checking will still be enforced.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: T second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

Operation

UNPCKLPD (128-bit Legacy SSE version)

DEST[63:0] \leftarrow SRC1[63:0] DEST[127:64] \leftarrow SRC2[63:0] DEST[VLMAX-1:128] (Unmodified)

VUNPCKLPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] DEST[127:64] \leftarrow SRC2[63:0] DEST[VLMAX-1:128] \leftarrow 0

VUNPCKLPD (VEX.256 encoded version)

DEST[63:0] \leftarrow SRC1[63:0]

INSTRUCTION SET REFERENCE, N-Z

DEST[127:64] \leftarrow SRC2[63:0] DEST[191:128] \leftarrow SRC1[191:128] DEST[255:192] \leftarrow SRC2[191:128]

Intel C/C++ Compiler Intrinsic Equivalent

UNPCKHPD__m128d _mm_unpacklo_pd(__m128d a, __m128d b)

UNPCKLPD __m256d _mm256_unpacklo_pd(__m256d a, __m256d b)

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

UNPCKLPS—Unpack and Interleave Low Packed Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 14 /r UNPCKLPS xmm1, xmm2/m128	Α	V/V	SSE	Unpacks and Interleaves single-precision floating-point values from low quadwords of xmm1 and xmm2/mem into xmm1.
VEX.NDS.128.0F.WIG 14 /r VUNPCKLPS xmm1,xmm2, xmm3/m128	В	V/V	AVX	Unpacks and Interleaves single-precision floating-point values from low quadwords of xmm2 and xmm3/m128.
VEX.NDS.256.0F.WIG 14 /r VUNPCKLPS ymm1,ymm2,ymm3/m256	В	V/V	AVX	Unpacks and Interleaves single-precision floating-point values from low quadwords of ymm2 and ymm3/m256.

Instruction Operand Encoding

		-		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an interleaved unpack of the low-order single-precision floating-point values from the source operand (second operand) and the destination operand (first operand). See Figure 4-20. The source operand can be an XMM register or a 128-bit memory location; the destination operand is an XMM register.




Figure 4-20. UNPCKLPS Instruction Low Unpack and Interleave Operation

When unpacking from a memory operand, an implementation may fetch only the appropriate 64 bits; however, alignment to 16-byte boundary and normal segment checking will still be enforced.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: T second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (255:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (255:128) of the corresponding YMM register destination are zeroed.

Operation

UNPCKLPS (128-bit Legacy SSE version)

 $\mathsf{DEST[31:0]} \leftarrow \mathsf{SRC1[31:0]}$

DEST[63:32] ← SRC2[31:0]

 $DEST[95:64] \leftarrow SRC1[63:32]$

DEST[127:96] \leftarrow SRC2[63:32]

DEST[VLMAX-1:128] (Unmodified)

VUNPCKLPS (VEX.128 encoded version)

 $\mathsf{DEST[31:0]} \leftarrow \mathsf{SRC1[31:0]}$

DEST[63:32] ← SRC2[31:0]

DEST[95:64] \leftarrow SRC1[63:32]

DEST[127:96] \leftarrow SRC2[63:32]

DEST[VLMAX-1:128] \leftarrow 0

UNPCKLPS (VEX.256 encoded version)

DEST[31:0] \leftarrow SRC1[31:0]

DEST[63:32] \leftarrow SRC2[31:0]

DEST[95:64] \leftarrow SRC1[63:32]

DEST[127:96] \leftarrow SRC2[63:32]

DEST[159:128] \leftarrow SRC1[159:128]

DEST[191:160] \leftarrow SRC2[159:128]

DEST[223:192] \leftarrow SRC1[191:160]

DEST[255:224] \leftarrow SRC2[191:160]

Intel C/C++ Compiler Intrinsic Equivalent

UNPCKLPS __m128 _mm_unpacklo_ps(__m128 a, __m128 b)

UNPCKLPS __m256 _mm256_unpacklo_ps (__m256 a, __m256 b);

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

VBROADCAST—Load with Broadcast

Opcode/ Instruction	Op/ En	64/32-bit Mode	CPUID Feature Flag	Description
VEX.128.66.0F38.W0 18 /r VBROADCASTSS xmm1, m32	Α	I/V	AVX	Broadcast single-precision floating-point element in mem to four locations in xmm1.
VEX.256.66.0F38.W0 18 /r VBROADCASTSS ymm1, m32	Α	V/V	AVX	Broadcast single-precision floating-point element in mem to eight locations in ymm1.
VEX.256.66.0F38.W0 19 /r VBROADCASTSD ymm1, m64	Α	V/V	AVX	Broadcast double-precision floating-point element in mem to four locations in ymm1.
VEX.256.66.0F38.W0 1A /r VBROADCASTF128 ymm1, m128	Α	V/V	AVX	Broadcast 128 bits of floating-point data in mem to low and high 128-bits in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Load floating point values from the source operand (second operand) and broadcast to all elements of the destination operand (first operand).

The destination operand is a YMM register. The source operand is either a 32-bit, 64-bit, or 128-bit memory location. Register source encodings are reserved and will #UD.

VBROADCASTSD and VBROADCASTF128 are only supported as 256-bit wide versions. VBROADCASTSS is supported in both 128-bit and 256-bit wide versions.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD.

If VBROADCASTSD or VBROADCASTF128 is encoded with VEX.L= 0, an attempt to execute the instruction encoded with VEX.L= 0 will cause an #UD exception.




Figure 4-21. VBROADCASTSS Operation (VEX.256 encoded version)




Figure 4-22. VBROADCASTSS Operation (128-bit version)




Figure 4-23. VBROADCASTSD Operation




Figure 4-24. VBROADCASTF128 Operation

Operation

VBROADCASTSS (128 bit version)

temp \leftarrow SRC[31:0] DEST[31:0] \leftarrow temp DEST[63:32] \leftarrow temp DEST[95:64] \leftarrow temp DEST[127:96] \leftarrow temp DEST[VLMAX-1:128] \leftarrow 0

VBROADCASTSS (VEX.256 encoded version)

temp \leftarrow SRC[31:0] DEST[31:0] \leftarrow temp DEST[63:32] \leftarrow temp DEST[95:64] \leftarrow temp DEST[127:96] \leftarrow temp DEST[159:128] \leftarrow temp DEST[191:160] \leftarrow temp DEST[223:192] \leftarrow temp DEST[255:224] \leftarrow temp

VBROADCASTSD (VEX.256 encoded version)

temp \leftarrow SRC[63:0] DEST[63:0] \leftarrow temp DEST[127:64] \leftarrow temp DEST[191:128] \leftarrow temp DEST[255:192] \leftarrow temp

VBROADCASTF128

temp \leftarrow SRC[127:0] DEST[127:0] \leftarrow temp DEST[VLMAX-1:128] \leftarrow temp

Intel C/C++ Compiler Intrinsic Equivalent

VBROADCASTSS __m128 _mm_broadcast_ss(float *a);

VBROADCASTSS __m256 _mm256_broadcast_ss(float *a);

VBROADCASTSD __m256d _mm256_broadcast_sd(double *a);

VBROADCASTF128 __m256 _mm256_broadcast_ps(__m128 * a);

VBROADCASTF128 __m256d _mm256_broadcast_pd(__m128d * a);

Flags Affected

None.

Other Exceptions

See Exceptions Type 6; additionally

#UD If VEX.L = 0 for VBROADCASTSD

If VEX.I = 0 for VBROADCASTE128

If VEX.W = 1.

VERR/VERW—Verify a Segment for Reading or Writing

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 00 /4	VERR r/m16	Α	Valid	Valid	Set ZF=1 if segment specified with <i>r/m16</i> can be read.
0F 00 /5	VERW r/m16	В	Valid	Valid	Set ZF=1 if segment specified with <i>r/m16</i> can be written.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r)	NA	NA	NA
В	NA	NA	NA	NA

Description

Verifies whether the code or data segment specified with the source operand is readable (VERR) or writable (VERW) from the current privilege level (CPL). The source operand is a 16-bit register or a memory location that contains the segment selector for the segment to be verified. If the segment is accessible and readable (VERR) or writable (VERW), the ZF flag is set; otherwise, the ZF flag is cleared. Code segments are never verified as writable. This check cannot be performed on system segments.

To set the ZF flag, the following conditions must be met:

- The segment selector is not NULL.
- The selector must denote a descriptor within the bounds of the descriptor table (GDT or LDT).
- The selector must denote the descriptor of a code or data segment (not that of a system segment or gate).
- For the VERR instruction, the segment must be readable.
- For the VERW instruction, the segment must be a writable data segment.
- If the segment is not a conforming code segment, the segment's DPL must be greater than or equal to (have less or the same privilege as) both the CPL and the segment selector's RPL.

The validation performed is the same as is performed when a segment selector is loaded into the DS, ES, FS, or GS register, and the indicated access (read or write) is performed. The segment selector's value cannot result in a protection exception, enabling the software to anticipate possible segment access problems.

This instruction's operation is the same in non-64-bit modes and 64-bit mode. The operand size is fixed at 16 bits.

Operation

```
\begin{split} & \text{IF SRC(Offset)} > (\text{GDTR(Limit)} \text{ or (LDTR(Limit))} \\ & \text{THEN ZF} \leftarrow 0; \text{ FI}; \\ & \text{Read segment descriptor;} \\ & \text{IF SegmentDescriptor(DescriptorType)} = 0 \text{ (* System segment *)} \\ & \text{ or (SegmentDescriptor(Type)} \neq \text{conforming code segment)} \\ & \text{and (CPL} > \text{DPL)} \text{ or (RPL} > \text{DPL)} \\ & \text{THEN} \\ & \text{ZF} \leftarrow 0; \\ & \text{ELSE} \\ & \text{IF ((Instruction} = \text{VERR)} \text{ and (Segment readable))} \\ & \text{ or ((Instruction} = \text{VERW)}) \text{ and (Segment writable))} \\ & \text{THEN} \\ & \text{ZF} \leftarrow 1; \\ & \text{FI;} \\ & \text{FI;} \end{split}
```

Flags Affected

The ZF flag is set to 1 if the segment is accessible and readable (VERR) or writable (VERW); otherwise, it is set to 0.

Protected Mode Exceptions

The only exceptions generated for these instructions are those related to illegal addressing of the source operand.

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register is used to access memory and it

contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD The VERR and VERW instructions are not recognized in real-

address mode.

If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#UD The VERR and VERW instructions are not recognized in virtual-

8086 mode.

If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used.

VEXTRACTF128 — Extract Packed Floating-Point Values

Opcode/ Instruction	Op/ En	64/32-bit Mode	CPUID Feature Flag	Description
VEX.256.66.0F3A.W0 19 /r ib VEXTRACTF128 xmm1/m128, ymm2, imm8	А	V/V	AVX	Extract 128 bits of packed floating-point values from ymm2 and store results in xmm1/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	ModRM:reg (r)	NA	NA

Description

Extracts 128-bits of packed floating-point values from the source operand (second operand) at an 128-bit offset from imm8[0] into the destination operand (first operand). The destination may be either an XMM register or an 128-bit memory location.

VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD.

The high 7 bits of the immediate are ignored.

If VEXTRACTF128 is encoded with VEX.L= 0, an attempt to execute the instruction encoded with VEX.L= 0 will cause an #UD exception.

Operation

VEXTRACTF128 (memory destination form)

CASE (imm8[0]) OF

0: DEST[127:0] ← SRC1[127:0]

1: DEST[127:0] ← SRC1[255:128]

ESAC.

VEXTRACTF128 (register destination form)

CASE (imm8[0]) OF 0: DEST[127:0] \leftarrow SRC1[127:0] 1: DEST[127:0] \leftarrow SRC1[255:128] ESAC. DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

VEXTRACTF128 __m128 _mm256_extractf128_ps (__m256 a, int offset);

INSTRUCTION SET REFERENCE, N-Z

VEXTRACTF128 __m128d _mm256_extractf128_pd (__m256d a, int offset);

VEXTRACTF128 __m128i_mm256_extractf128_si256(__m256i a, int offset);

SIMD Floating-Point Exceptions

None

Other Exceptions

See Exceptions Type 6; additionally

#UD If VEX.L= 0

If VEX.W=1.

VINSERTF128 — Insert Packed Floating-Point Values

Opcode/ Instruction	Op/ En	64/32-bit Mode	CPUID Feature Flag	Description
VEX.NDS.256.66.0F3A.W0 18 /r ib VINSERTF128 ymm1, ymm2, xmm3/m128, imm8	A	V/V	AVX	Insert a single precision floating-point value selected by imm8 from xmm2/m32 into xmm1 at the specified destination element specified by imm8 and zero out destination elements in xmm1 as indicated in imm8.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs an insertion of 128-bits of packed floating-point values from the second source operand (third operand) into an the destination operand (first operand) at an 128-bit offset from imm8[0]. The remaining portions of the destination are written by the corresponding fields of the first source operand (second operand). The second source operand can be either an XMM register or a 128-bit memory location.

The high 7 bits of the immediate are ignored.

Operation

TEMP[255:0] \leftarrow SRC1[255:0] CASE (imm8[0]) OF 0: TEMP[127:0] \leftarrow SRC2[127:0] 1: TEMP[255:128] \leftarrow SRC2[127:0] ESAC DEST \leftarrow TEMP

Intel C/C++ Compiler Intrinsic Equivalent

INSERTF128 __m256 _mm256_insertf128_ps (__m256 a, __m128 b, int offset);

INSERTF128 __m256d _mm256_insertf128_pd (__m256d a, __m128d b, int offset);

INSERTF128 __m256i _mm256_insertf128_si256 (__m256i a, __m128i b, int offset);

SIMD Floating-Point Exceptions

None

Other Exceptions

See Exceptions Type 6; additionally #UD If VEX.W = 1.

VPERMILPD — Permute Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128.66.0F38.W0 0D /r VPERMILPD xmm1, xmm2, xmm3/m128	A	V/V	AVX	Permute double-precision floating-point values in xmm2 using controls from xmm3/mem and store result in xmm1.
VEX.NDS.256.66.0F38.W0 0D /r VPERMILPD ymm1, ymm2, ymm3/m256	A	V/V	AVX	Permute double-precision floating-point values in ymm2 using controls from ymm3/mem and store result in ymm1.
VEX.128.66.0F3A.W0 05 /r ib VPERMILPD xmm1, xmm2/m128, imm8	В	V/V	AVX	Permute double-precision floating-point values in xmm2/mem using controls from imm8.
VEX.256.66.0F3A.W0 05 /r ib VPERMILPD ymm1, ymm2/m256, imm8	В	V/V	AVX	Permute double-precision floating-point values in ymm2/mem using controls from imm8.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA
В	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

Permute double-precision floating-point values in the first source operand (second operand) using 8-bit control fields in the low bytes of the second source operand (third operand) and store results in the destination operand (first operand). The first source operand is a YMM register, the second source operand is a YMM register or a 256-bit memory location, and the destination operand is a YMM register.




Figure 4-25. VPERMILPD operation

There is one control byte per destination double-precision element. Each control byte is aligned with the low 8 bits of the corresponding double-precision destination element. Each control byte contains a 1-bit select field (see Figure 4-26) that determines which of the source elements are selected. Source elements are restricted to lie in the same source 128-bit region as the destination.




Figure 4-26. VPERMILPD Shuffle Control

(immediate control version)

Permute double-precision floating-point values in the first source operand (second operand) using two, 1-bit control fields in the low 2 bits of the 8-bit immediate and store results in the destination operand (first operand). The source operand is a YMM register or 256-bit memory location and the destination operand is a YMM register.

Note: For the VEX.128.66.0F3A 05 instruction version, VEX.vvvv is reserved and must be 1111b otherwise instruction will #UD.

Note: For the VEX.256.66.0F3A 05 instruction version, VEX.vvvv is reserved and must be 1111b otherwise instruction will #UD.

Operation

VPERMILPD (256-bit immediate version)

IF (imm8[0] = 0) THEN DEST[63:0] \leftarrow SRC1[63:0]

IF (imm8[0] = 1) THEN DEST[63:0] \leftarrow SRC1[127:64]

IF (imm8[1] = 0) THEN DEST[127:64] \leftarrow SRC1[63:0]

IF (imm8[1] = 1) THEN DEST[127:64] \leftarrow SRC1[127:64]

IF (imm8[2] = 0) THEN DEST[191:128] \leftarrow SRC1[191:128]

IF (imm8[2] = 1) THEN DEST[191:128] \leftarrow SRC1[255:192]

IF (imm8[3] = 0) THEN DEST[255:192] \leftarrow SRC1[191:128]

IF (imm8[3] = 1) THEN DEST[255:192] \leftarrow SRC1[255:192]

VPERMILPD (128-bit immediate version)

IF (imm8[0] = 0) THEN DEST[63:0] \leftarrow SRC1[63:0]

IF (imm8[0] = 1) THEN DEST[63:0] \leftarrow SRC1[127:64]

IF (imm8[1] = 0) THEN DEST[127:64] \leftarrow SRC1[63:0]

IF (imm8[1] = 1) THEN DEST[127:64] \leftarrow SRC1[127:64]

DEST[VLMAX-1:128] \leftarrow 0

VPERMILPD (256-bit variable version)

IF (SRC2[1] = 0) THEN DEST[63:0] \leftarrow SRC1[63:0]

IF (SRC2[1] = 1) THEN DEST[63:0] \leftarrow SRC1[127:64]

IF (SRC2[65] = 0) THEN DEST[127:64] \leftarrow SRC1[63:0]

IF (SRC2[65] = 1) THEN DEST[127:64] \leftarrow SRC1[127:64]

IF (SRC2[129] = 0) THEN DEST[191:128] \leftarrow SRC1[191:128]

IF (SRC2[129] = 1) THEN DEST[191:128]←SRC1[255:192]

IF (SRC2[193] = 0) THEN DEST[255:192] \leftarrow SRC1[191:128]

IF (SRC2[193] = 1) THEN DEST[255:192]←SRC1[255:192]

VPERMILPD (128-bit variable version)

IF (SRC2[1] = 0) THEN DEST[63:0] \leftarrow SRC1[63:0]

IF (SRC2[1] = 1) THEN DEST[63:0] \leftarrow SRC1[127:64]

IF (SRC2[65] = 0) THEN DEST[127:64] \leftarrow SRC1[63:0]

IF (SRC2[65] = 1) THEN DEST[127:64] \leftarrow SRC1[127:64]

DEST[VLMAX-1:128] \leftarrow 0

Intel C/C++ Compiler Intrinsic Equivalent

VPERMILPD __m128d _mm_permute_pd (__m128d a, int control)

VPERMILPD __m256d _mm256_permute_pd (__m256d a, int control)

INSTRUCTION SET REFERENCE, N-Z

VPERMILPD __m128d _mm_permutevar_pd (__m128d a, __m128i control);

VPERMILPD __m256d _mm256_permutevar_pd (__m256d a, __m256i control);

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 6; additionally #UD If VEX.W = 1

VPERMILPS — Permute Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.128.66.0F38.W0 0C /r VPERMILPS xmm1, xmm2, xmm3/m128	A	V/V	AVX	Permute single-precision floating-point values in xmm2 using controls from xmm3/mem and store result in xmm1.
VEX.128.66.0F3A.W0 04 /r ib VPERMILPS xmm1, xmm2/m128, imm8	В	V/V	AVX	Permute single-precision floating-point values in xmm2/mem using controls from imm8 and store result in xmm1.
VEX.NDS.256.66.0F38.W0 0C /r VPERMILPS ymm1, ymm2, ymm3/m256	A	V/V	AVX	Permute single-precision floating-point values in ymm2 using controls from ymm3/mem and store result in ymm1.
VEX.256.66.0F3A.W0 04 /r ib VPERMILPS ymm1, ymm2/m256, imm8	В	V/V	AVX	Permute single-precision floating-point values in ymm2/mem using controls from imm8 and store result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
А	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA
В	ModRM:reg (w)	ModRM:r/m (r)	NA	NA

Description

(variable control version)

Permute single-precision floating-point values in the first source operand (second operand) using 8-bit control fields in the low bytes of corresponding elements the shuffle control (third operand) and store results in the destination operand (first operand). The first source operand is a YMM register, the second source operand is a YMM register or a 256-bit memory location, and the destination operand is a YMM register.




Figure 4-27. VPERMILPS Operation

There is one control byte per destination single-precision element. Each control byte is aligned with the low 8 bits of the corresponding single-precision destination element. Each control byte contains a 2-bit select field (see Figure 4-28) that determines which of the source elements are selected. Source elements are restricted to lie in the same source 128-bit region as the destination.




Figure 4-28. VPERMILPS Shuffle Control

(immediate control version)

Permute single-precision floating-point values in the first source operand (second operand) using four 2-bit control fields in the 8-bit immediate and store results in the destination operand (first operand). The source operand is a YMM register or 256-bit memory location and the destination operand is a YMM register. This is similar to a wider version of PSHUFD, just operating on single-precision floating-point values.

Note: For the VEX.128.66.0F3A 04 instruction version, VEX.vvvv is reserved and must be 1111b otherwise instruction will #UD.

Note: For the VEX.256.66.0F3A 04 instruction version, VEX.vvvv is reserved and must be 1111b otherwise instruction will #UD.

Operation

```
Select4(SRC, control) {
CASE (control[1:0]) OF
        TMP \leftarrow SRC[31:0];
    1:
        TMP \leftarrow SRC[63:32];
    2:
        TMP \leftarrow SRC[95:64];
        TMP ← SRC[127:96];
    3:
ESAC:
RETURN TMP
}
VPERMILPS (256-bit immediate version)
DEST[31:0] \leftarrow Select4(SRC1[127:0], imm8[1:0]);
DEST[63:32] \leftarrow Select4(SRC1[127:0], imm8[3:2]);
DEST[95:64] \leftarrow Select4(SRC1[127:0], imm8[5:4]);
DEST[127:96] \leftarrow Select4(SRC1[127:0], imm8[7:6]);
DEST[159:128] \leftarrow Select4(SRC1[255:128], imm8[1:0]);
DEST[191:160] \leftarrow Select4(SRC1[255:128], imm8[3:2]);
DEST[223:192] \leftarrow Select4(SRC1[255:128], imm8[5:4]);
DEST[255:224] \leftarrow Select4(SRC1[255:128], imm8[7:6]);
VPERMILPS (128-bit immediate version)
DEST[31:0] \leftarrow Select4(SRC1[127:0], imm8[1:0]);
DEST[63:32] \leftarrow Select4(SRC1[127:0], imm8[3:2]);
DEST[95:64] \leftarrow Select4(SRC1[127:0], imm8[5:4]);
DEST[127:96] \leftarrow Select4(SRC1[127:0], imm8[7:6]);
DEST[VLMAX-1:128] \leftarrow 0
VPERMILPS (256-bit variable version)
DEST[31:0] \leftarrow Select4(SRC1[127:0], SRC2[1:0]);
DEST[63:32] \leftarrow Select4(SRC1[127:0], SRC2[33:32]);
DEST[95:64] \leftarrow Select4(SRC1[127:0], SRC2[65:64]);
DEST[127:96] \leftarrow Select4(SRC1[127:0], SRC2[97:96]);
DEST[159:128] \leftarrow Select4(SRC1[255:128], SRC2[129:128]);
DEST[191:160] \leftarrow Select4(SRC1[255:128], SRC2[161:160]);
DEST[223:192] \leftarrow Select4(SRC1[255:128], SRC2[193:192]);
DEST[255:224] \leftarrow Select4(SRC1[255:128], SRC2[225:224]);
```

VPERMILPS (128-bit variable version)

INSTRUCTION SET REFERENCE, N-Z

```
\begin{split} \mathsf{DEST}[31:0] &\leftarrow \mathsf{Select4}(\mathsf{SRC1}[127:0], \mathsf{SRC2}[1:0]); \\ \mathsf{DEST}[63:32] &\leftarrow \mathsf{Select4}(\mathsf{SRC1}[127:0], \mathsf{SRC2}[33:32]); \\ \mathsf{DEST}[95:64] &\leftarrow \mathsf{Select4}(\mathsf{SRC1}[127:0], \mathsf{SRC2}[65:64]); \\ \mathsf{DEST}[127:96] &\leftarrow \mathsf{Select4}(\mathsf{SRC1}[127:0], \mathsf{SRC2}[97:96]); \\ \mathsf{DEST}[\mathsf{VLMAX-1:128}] &\leftarrow \mathsf{O} \end{split}
```

Intel C/C++ Compiler Intrinsic Equivalent

```
VPERM1LPS __m128 _mm_permute_ps (__m128 a, int control);

VPERM1LPS __m256 _mm256_permute_ps (__m256 a, int control);

VPERM1LPS __m128 _mm_permutevar_ps (__m128 a, __m128i control);

VPERM1LPS __m256 _mm256_permutevar_ps (__m256 a, __m256i control);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 6; additionally #UD If VEX.W = 1.

VPERM2F128 — Permute Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.NDS.256.66.0F3A.W0 06 /r ib VPERM2F128 ymm1, ymm2, ymm3/m256, imm8	A	V/V	AVX	Permute 128-bit floating- point fields in ymm2 and ymm3/mem using controls from imm8 and store result in ymm1.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Permute 128 bit floating-point-containing fields from the first source operand (second operand) and second source operand (third operand) using bits in the 8-bit immediate and store results in the destination operand (first operand). The first source operand is a YMM register, the second source operand is a YMM register or a 256-bit memory location, and the destination operand is a YMM register.




Figure 4-29. VPERM2F128 Operation

Imm8[1:0] select the source for the first destination 128-bit field, imm8[5:4] select the source for the second destination field. If imm8[3] is set, the low 128-bit field is zeroed. If imm8[7] is set, the high 128-bit field is zeroed.

VEX.L must be 1, otherwise the instruction will #UD.

Operation

```
VPERM2F128
CASE IMM8[1:0] of
0: DEST[127:0] \leftarrow SRC1[127:0]
1: DEST[127:0] ← SRC1[255:128]
2: DEST[127:0] ← SRC2[127:0]
3: DEST[127:0] ← SRC2[255:128]
ESAC
CASE IMM8[5:4] of
0: DEST[255:128] \leftarrow SRC1[127:0]
1: DEST[255:128] ← SRC1[255:128]
2: DEST[255:128] ← SRC2[127:0]
3: DEST[255:128] ← SRC2[255:128]
ESAC
IF (imm8[3])
DEST[127:0] ← 0
FΙ
IF (imm8[7])
DEST[VLMAX-1:128] \leftarrow 0
FΙ
Intel C/C++ Compiler Intrinsic Equivalent
VPERM2F128 m256 mm256 permute2f128 ps ( m256 a, m256 b, int control)
VPERM2F128 __m256d _mm256_permute2f128_pd (__m256d a, __m256d b, int control)
VPERM2F128 __m256i _mm256_permute2f128_si256 (__m256i a, __m256i b, int control)
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

```
See Exceptions Type 6; additionally #UD If VEX.L = 0
```

If VEX.W = 1.

VTESTPD/VTESTPS—Packed Bit Test

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.128.66.0F38.W0 0E /r VTESTPS xmm1, xmm2/m128	Α	V/V	AVX	Set ZF and CF depending on sign bit AND and ANDN of packed single-precision floating-point sources.
VEX.256.66.0F38.W0 0E /r VTESTPS ymm1, ymm2/m256	Α	V/V	AVX	Set ZF and CF depending on sign bit AND and ANDN of packed single-precision floating-point sources.
VEX.128.66.0F38.W0 0F /r VTESTPD xmm1, xmm2/m128	Α	V/V	AVX	Set ZF and CF depending on sign bit AND and ANDN of packed double-precision floating-point sources.
VEX.256.66.0F38.W0 0F /r VTESTPD ymm1, ymm2/m256	Α	V/V	AVX	Set ZF and CF depending on sign bit AND and ANDN of packed double-precision floating-point sources.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	ModRM:reg (r)	ModRM:r/m (r)	NA	NA	

Description

VTESTPS performs a bitwise comparison of all the sign bits of the packed single-precision elements in the first source operation and corresponding sign bits in the second source operand. If the AND of the source sign bits with the dest sign bits produces all zeros, the ZF is set else the ZF is clear. If the AND of the source sign bits with the inverted dest sign bits produces all zeros the CF is set else the CF is clear. An attempt to execute VTESTPS with VEX.W=1 will cause #UD.

VTESTPD performs a bitwise comparison of all the sign bits of the double-precision elements in the first source operation and corresponding sign bits in the second source operand. If the AND of the source sign bits with the dest sign bits produces all zeros, the ZF is set else the ZF is clear. If the AND the source sign bits with the inverted dest sign bits produces all zeros the CF is set else the CF is clear. An attempt to execute VTESTPS with VEX.W=1 will cause #UD.

The first source register is specified by the ModR/M reg field.

128-bit version: The first source register is an XMM register. The second source register can be an XMM register or a 128-bit memory location. The destination register is not modified.

VEX.256 encoded version: The first source register is a YMM register. The second source register can be a YMM register or a 256-bit memory location. The destination register is not modified.

Note: In VEX-encoded versions, VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD.

Operation

```
VTESTPS (128-bit version)
 TEMP[127:0] \leftarrow SRC[127:0] AND DEST[127:0]
 IF (TEMP[31] = TEMP[63] = TEMP[95] = TEMP[127] = 0)
                  THEN ZF \leftarrow1:
                  ELSE ZF \leftarrow 0:
 TEMP[127:0] \leftarrow SRC[127:0] AND NOT DEST[127:0]
 IF (TEMP[31] = TEMP[63] = TEMP[95] = TEMP[127] = 0)
                  THEN CF \leftarrow 1:
                  ELSE CF \leftarrow 0:
DEST (unmodified)
 AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O:
 VTESTPS (VEX.256 encoded version)
 TEMP[255:0] \leftarrow SRC[255:0] AND DEST[255:0]
 |F(TEMP[31] = TEMP[63] = TEMP[95] = TEMP[127] = TEMP[160] = TEMP[191] = TEMP[224] = TEMP[160] = TEMP[191] = TEMP
 TEMP[255] = 0
                  THEN ZF \leftarrow 1:
                  ELSE ZF \leftarrow 0:
 TEMP[255:0] \leftarrow SRC[255:0] AND NOT DEST[255:0]
 |F(TEMP[31] = TEMP[63] = TEMP[95] = TEMP[127] = TEMP[160] = TEMP[191] = TEMP[224] = TEMP[191] = TEMP
 TEMP[255] = 0
                  THEN CF \leftarrow 1:
                  ELSE CF \leftarrow 0;
 DEST (unmodified)
 AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O;
VTESTPD (128-bit version)
 TEMP[127:0] \leftarrow SRC[127:0] AND DEST[127:0]
 IF (TEMP[63] = TEMP[127] = 0)
                  THEN ZF \leftarrow1:
```

```
ELSE ZF \leftarrow 0;
TEMP[127:0] \leftarrow SRC[127:0] AND NOT DEST[127:0]
IF (TEMP[63] = TEMP[127] = 0)
   THEN CF \leftarrow 1;
   ELSE CF \leftarrow 0;
DEST (unmodified)
AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O;
VTESTPD (VEX.256 encoded version)
TEMP[255:0] ← SRC[255:0] AND DEST[255:0]
IF (TEMP[63] = TEMP[127] = TEMP[191] = TEMP[255] = 0)
   THEN ZF \leftarrow1;
   ELSE ZF \leftarrow 0;
TEMP[255:0] ← SRC[255:0] AND NOT DEST[255:0]
IF (TEMP[63] = TEMP[127] = TEMP[191] = TEMP[255] = 0)
   THEN CF \leftarrow 1;
   ELSE CF \leftarrow 0;
DEST (unmodified)
AF \leftarrow OF \leftarrow PF \leftarrow SF \leftarrow O:
Intel C/C++ Compiler Intrinsic Equivalent
VTESTPS
   int _mm256_testz_ps (__m256 s1, __m256 s2);
   int _mm256_testc_ps (__m256 s1, __m256 s2);
   int mm256 testnzc ps ( m256 s1, m128 s2);
   int _mm_testz_ps (__m128 s1, __m128 s2);
   int _mm_testc_ps (__m128 s1, __m128 s2);
   int mm testnzc ps ( m128 s1, m128 s2);
VTESTPD
   int _mm256_testz_pd (__m256d s1, __m256d s2);
   int mm256 testc pd ( m256d s1, m256d s2);
   int _mm256_testnzc_pd (__m256d s1, __m256d s2);
```

```
int _mm_testz_pd (__m128d s1, __m128d s2);
int _mm_testc_pd (__m128d s1, __m128d s2);
int _mm_testnzc_pd (__m128d s1, __m128d s2);
```

Flags Affected

The OF, AF, PF, SF flags are cleared and the ZF, CF flags are set according to the operation.

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4; additionally

#UD If VEX.vvvv != 1111B.

If VEX.W = 1 for VTESTPS or VTESTPD.

VZEROALL—Zero All YMM Registers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.256.0F.WIG 77 VZEROALL	Α	V/V	AVX	Zero all YMM registers.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

The instruction zeros contents of all XMM or YMM registers.

Note: VEX.vvvv is reserved and must be 1111b, otherwise instructions will #UD. In Compatibility and legacy 32-bit mode only the lower 8 registers are modified.

Operation

VZEROALL (VEX.256 encoded version)

IF (64-bit mode)

YMM0[VLMAX-1:0] \leftarrow 0

YMM1[VLMAX-1:0] \leftarrow 0

 $YMM2[VLMAX-1:0] \leftarrow 0$

YMM3[VLMAX-1:0] \leftarrow 0

YMM4[VLMAX-1:0] \leftarrow 0

YMM5[VLMAX-1:0] \leftarrow 0

YMM6[VLMAX-1:0] \leftarrow 0

 $YMM7[VLMAX-1:0] \leftarrow 0$

YMM8[VLMAX-1:0] \leftarrow 0

YMM9[VLMAX-1:0] \leftarrow 0

YMM10[VLMAX-1:0] \leftarrow 0

YMM11[VLMAX-1:0] \leftarrow 0

YMM12[VLMAX-1:0] \leftarrow 0

YMM13[VLMAX-1:0] \leftarrow 0

YMM14[VLMAX-1:0] \leftarrow 0

YMM15[VLMAX-1:0] \leftarrow 0

ELSE

YMM0[VLMAX-1:0] \leftarrow 0

 $YMM1[VLMAX-1:0] \leftarrow 0$

 $YMM2[VLMAX-1:0] \leftarrow 0$

YMM3[VLMAX-1:0] \leftarrow YMM4[VLMAX-1:0] \leftarrow YMM5[VLMAX-1:0] \leftarrow YMM6[VLMAX-1:0] \leftarrow YMM7[VLMAX-1:0] \leftarrow YMM8-15: Unmodified

Intel C/C++ Compiler Intrinsic Equivalent

VZEROALL _mm256_zeroall()

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 8.

VZEROUPPER—Zero Upper Bits of YMM Registers

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
VEX.128.0F.WIG 77 VZEROUPPER	Α	V/V	AVX	Zero upper 128 bits of all YMM registers.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

The instruction zeros the upper 128 bits of all YMM registers. The lower 128-bits of the registers (the corresponding XMM registers) are unmodified.

This instruction is recommended when transitioning between AVX and legacy SSE code - it will eliminate performance penalties caused by false dependencies.

Note: VEX.vvvv is reserved and must be 1111b otherwise instructions will #UD. In Compatibility and legacy 32-bit mode only the lower 8 registers are modified.

Operation

VZEROUPPER

IF (64-bit mode) YMM0[VLMAX-1:128] \leftarrow 0 YMM1[VLMAX-1:128] ← 0 YMM2[VLMAX-1:128] \leftarrow 0 YMM3[VLMAX-1:128] \leftarrow 0 $YMM4[VLMAX-1:128] \leftarrow 0$ YMM5[VLMAX-1:128] ← 0 YMM6[VLMAX-1:128] \leftarrow 0 YMM7[VLMAX-1:128] \leftarrow 0 YMM8[VLMAX-1:128] \leftarrow 0 YMM9[VLMAX-1:128] ← 0 YMM10[VLMAX-1:128] ← 0 YMM11[VLMAX-1:128] ← 0 YMM12[VLMAX-1:128] ← 0 YMM13[VLMAX-1:128] ← 0 YMM14[VLMAX-1:128] ← 0 YMM15[VLMAX-1:128] ← 0

ELSE

```
YMM0[VLMAX-1:128] ← 0

YMM1[VLMAX-1:128] ← 0

YMM2[VLMAX-1:128] ← 0

YMM3[VLMAX-1:128] ← 0

YMM4[VLMAX-1:128] ← 0

YMM5[VLMAX-1:128] ← 0

YMM6[VLMAX-1:128] ← 0

YMM7[VLMAX-1:128] ← 0

YMM8-15: unmodified
```

Intel C/C++ Compiler Intrinsic Equivalent

VZEROUPPER _mm256_zeroupper()

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 8.

WAIT/FWAIT—Wait

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
9B	WAIT	Α	Valid	Valid	Check pending unmasked floating-point exceptions.
9B	FWAIT	Α	Valid	Valid	Check pending unmasked floating-point exceptions.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Causes the processor to check for and handle pending, unmasked, floating-point exceptions before proceeding. (FWAIT is an alternate mnemonic for WAIT.)

This instruction is useful for synchronizing exceptions in critical sections of code. Coding a WAIT instruction after a floating-point instruction ensures that any unmasked floating-point exceptions the instruction may raise are handled before the processor can modify the instruction's results. See the section titled "Floating-Point Exception Synchronization" in Chapter 8 of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 1*, for more information on using the WAIT/FWAIT instruction.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

Operation

CheckForPendingUnmaskedFloatingPointExceptions;

FPU Flags Affected

The C0, C1, C2, and C3 flags are undefined.

Floating-Point Exceptions

None.

Protected Mode Exceptions

#NM If CR0.MP[bit 1] = 1 and CR0.TS[bit 3] = 1.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

Same exceptions as in protected mode.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

WBINVD—Write Back and Invalidate Cache

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 09	WBINVD	А	Valid	Valid	Write back and flush Internal caches; initiate writing-back and flushing of external caches.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Writes back all modified cache lines in the processor's internal cache to main memory and invalidates (flushes) the internal caches. The instruction then issues a special-function bus cycle that directs external caches to also write back modified data and another bus cycle to indicate that the external caches should be invalidated.

After executing this instruction, the processor does not wait for the external caches to complete their write-back and flushing operations before proceeding with instruction execution. It is the responsibility of hardware to respond to the cache write-back and flush signals. The amount of time or cycles for WBINVD to complete will vary due to size and other factors of different cache hierarchies. As a consequence, the use of the WBINVD instruction can have an impact on logical processor interrupt/event response time.

The WBINVD instruction is a privileged instruction. When the processor is running in protected mode, the CPL of a program or procedure must be 0 to execute this instruction. This instruction is also a serializing instruction (see "Serializing Instructions" in Chapter 10 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A).

In situations where cache coherency with main memory is not a concern, software can use the INVD instruction.

This instruction's operation is the same in non-64-bit modes and 64-bit mode.

IA-32 Architecture Compatibility

The WBINVD instruction is implementation dependent, and its function may be implemented differently on future Intel 64 and IA-32 processors. The instruction is not supported on IA-32 processors earlier than the Intel486 processor.

Operation

WriteBack(InternalCaches);

Flush(InternalCaches); SignalWriteBack(ExternalCaches); SignalFlush(ExternalCaches);

Continue; (* Continue execution *)

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) WBINVD cannot be executed at the virtual-8086 mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

WRMSR—Write to Model Specific Register

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 30	WRMSR	Α	Valid	Valid	Write the value in EDX:EAX to MSR specified by ECX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Writes the contents of registers EDX:EAX into the 64-bit model specific register (MSR) specified in the ECX register. (On processors that support the Intel 64 architecture, the high-order 32 bits of RCX are ignored.) The contents of the EDX register are copied to high-order 32 bits of the selected MSR and the contents of the EAX register are copied to low-order 32 bits of the MSR. (On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX and RDX are ignored.) Undefined or reserved bits in an MSR should be set to values previously read.

This instruction must be executed at privilege level 0 or in real-address mode; otherwise, a general protection exception #GP(0) is generated. Specifying a reserved or unimplemented MSR address in ECX will also cause a general protection exception. The processor will also generate a general protection exception if software attempts to write to bits in a reserved MSR.

When the WRMSR instruction is used to write to an MTRR, the TLBs are invalidated. This includes global entries (see "Translation Lookaside Buffers (TLBs)" in Chapter 3 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A).

MSRs control functions for testability, execution tracing, performance-monitoring and machine check errors. Appendix B, "Model-Specific Registers (MSRs)", in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B, lists all MSRs that can be read with this instruction and their addresses. Note that each processor family has its own set of MSRs.

The WRMSR instruction is a serializing instruction (see "Serializing Instructions" in Chapter 8 of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 3A*). Note that WRMSR to the IA32_TSC_DEADLINE MSR (MSR index 6E0H) and the X2APIC MSRs (MSR indices 802H to 83FH) are not serializing.

The CPUID instruction should be used to determine whether MSRs are supported (CPUID.01H:EDX[5] = 1) before using this instruction.

IA-32 Architecture Compatibility

The MSRs and the ability to read them with the WRMSR instruction were introduced into the IA-32 architecture with the Pentium processor. Execution of this instruction by an IA-32 processor earlier than the Pentium processor results in an invalid opcode exception #UD.

Operation

 $MSR[ECX] \leftarrow EDX:EAX;$

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the value in ECX specifies a reserved or unimplemented MSR

address.

If the value in EDX:EAX sets bits that are reserved in the MSR

specified by ECX.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If the value in ECX specifies a reserved or unimplemented MSR

address.

If the value in EDX: EAX sets bits that are reserved in the MSR

specified by ECX.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) The WRMSR instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

XADD—	Exchange	e and Add
-------	----------	-----------

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F C0 /r	XADD r/m8, r8	Α	Valid	Valid	Exchange <i>r8</i> and <i>r/m8</i> ; load sum into <i>r/m8</i> .
REX + 0F C0 /r	XADD r/m8*, r8*	Α	Valid	N.E.	Exchange <i>r8</i> and <i>r/m8</i> ; load sum into <i>r/m8</i> .
0F C1 /r	XADD r/m16, r16	Α	Valid	Valid	Exchange r16 and r/m16; load sum into r/m16.
0F C1 /r	XADD r/m32, r32	Α	Valid	Valid	Exchange <i>r32</i> and <i>r/m32</i> ; load sum into <i>r/m32</i> .
REX.W + 0F C1 /r	XADD r/m64, r64	Α	Valid	N.E.	Exchange <i>r64</i> and <i>r/m64</i> ; load sum into <i>r/m64</i> .

NOTES:

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
A	ModRM:r/m (r, w)	ModRM:reg (г)	NA	NA

Description

Exchanges the first operand (destination operand) with the second operand (source operand), then loads the sum of the two values into the destination operand. The destination operand can be a register or a memory location; the source operand is a register.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

IA-32 Architecture Compatibility

IA-32 processors earlier than the Intel486 processor do not recognize this instruction. If this instruction is used, you should provide an equivalent code sequence that runs on earlier processors.

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

Operation

```
TEMP \leftarrow SRC + DEST;
SRC \leftarrow DEST;
DEST \leftarrow TEMP;
```

Flags Affected

The CF, PF, AF, SF, ZF, and OF flags are set according to the result of the addition, which is stored in the destination operand.

Protected Mode Exceptions

#GP(0) If the destination is located in a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

seament limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

XCHG—Exchange Register/Memory with Register

			_	_	
Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
90+ <i>rw</i>	XCHG AX, r16	Α	Valid	Valid	Exchange <i>r16</i> with AX.
90+ <i>rw</i>	XCHG <i>r16</i> , AX	В	Valid	Valid	Exchange AX with <i>r16.</i>
90+ <i>rd</i>	XCHG EAX, <i>r32</i>	Α	Valid	Valid	Exchange <i>r32</i> with EAX.
REX.W + 90+ <i>rd</i>	XCHG RAX, r64	Α	Valid	N.E.	Exchange <i>r64</i> with RAX.
90+ <i>rd</i>	XCHG <i>r32</i> , EAX	В	Valid	Valid	Exchange EAX with <i>r32.</i>
REX.W + 90+ <i>rd</i>	XCHG <i>r64</i> , RAX	В	Valid	N.E.	Exchange RAX with r64.
86 /r	XCHG r/m8, r8	С	Valid	Valid	Exchange <i>r8</i> (byte register) with byte from <i>r/m8.</i>
REX + 86 /r	XCHG r/m8*, r8*	С	Valid	N.E.	Exchange <i>r8</i> (byte register) with byte from <i>r/m8</i> .
86 /r	XCHG r8, r/m8	D	Valid	Valid	Exchange byte from <i>r/m8</i> with <i>r8</i> (byte register).
REX + 86 /r	XCHG r8*, r/m8*	D	Valid	N.E.	Exchange byte from <i>r/m8</i> with <i>r8</i> (byte register).
87 /r	XCHG r/m16, r16	С	Valid	Valid	Exchange <i>r16</i> with word from <i>r/m16.</i>
87 /r	XCHG <i>r16, r/m16</i>	D	Valid	Valid	Exchange word from <i>r/m16</i> with <i>r16</i> .
87 /r	XCHG r/m32, r32	С	Valid	Valid	Exchange <i>r32</i> with doubleword from <i>r/m32</i> .
REX.W + 87 /r	XCHG r/m64, r64	С	Valid	N.E.	Exchange <i>r64</i> with quadword from <i>r/m64.</i>
87 /r	XCHG <i>r32, r/m32</i>	D	Valid	Valid	Exchange doubleword from r/m32 with r32.
REX.W + 87 /r	XCHG <i>r64, r/m64</i>	D	Valid	N.E.	Exchange quadword from r/m64 with r64.

NOTES:

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

		mode domain operation and		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	AX/EAX/RAX (r, w)	reg (r, w)	NA	NA
В	reg (r, w)	AX/EAX/RAX (r, w)	NA	NA
С	ModRM:r/m (r, w)	ModRM:reg (r, w)	NA	NA
D	ModRM:reg (r, w)	ModRM:r/m (r, w)	NA	NA

Instruction Operand Encoding

Description

Exchanges the contents of the destination (first) and source (second) operands. The operands can be two general-purpose registers or a register and a memory location. If a memory operand is referenced, the processor's locking protocol is automatically implemented for the duration of the exchange operation, regardless of the presence or absence of the LOCK prefix or of the value of the IOPL. (See the LOCK prefix description in this chapter for more information on the locking protocol.)

This instruction is useful for implementing semaphores or similar data structures for process synchronization. (See "Bus Locking" in Chapter 8 of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 3A*, for more information on bus locking.)

The XCHG instruction can also be used instead of the BSWAP instruction for 16-bit operands.

In 64-bit mode, the instruction's default operation size is 32 bits. Using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

TEMP \leftarrow DEST; DEST \leftarrow SRC; SRC \leftarrow TEMP;

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If either operand is in a non-writable segment.

If a memory operand effective address is outside the CS, DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

XGETBV—Get Value of Extended Control Register

				_	
Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 D0	XGETBV	Α	Valid	Valid	Reads an XCR specified by ECX into EDX:EAX.

Instruction Operand Encoding

		-		
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Reads the contents of the extended control register (XCR) specified in the ECX register into registers EDX:EAX. (On processors that support the Intel 64 architecture, the high-order 32 bits of RCX are ignored.) The EDX register is loaded with the high-order 32 bits of the XCR and the EAX register is loaded with the low-order 32 bits. (On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX and RDX are cleared.) If fewer than 64 bits are implemented in the XCR being read, the values returned to EDX:EAX in unimplemented bit locations are undefined.

Specifying a reserved or unimplemented XCR in ECX causes a general protection exception.

Currently, only XCR0 (the XFEATURE_ENABLED_MASK register) is supported. Thus, all other values of ECX are reserved and will cause a #GP(0).

Operation

 $EDX:EAX \leftarrow XCR[ECX];$

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If an invalid XCR is specified in ECX. #UD If CPUID.01H:ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Real-Address Mode Exceptions

#GP If an invalid XCR is specified in ECX. #UD If CPUID.01H:ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

XLAT/XLATB—Table Look-up Translation

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
D7	XLAT m8	Α	Valid	Valid	Set AL to memory byte DS:[(E)BX + unsigned AL].
D7	XLATB	Α	Valid	Valid	Set AL to memory byte DS:[(E)BX + unsigned AL].
REX.W + D7	XLATB	Α	Valid	N.E.	Set AL to memory byte [RBX + unsigned AL].

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Locates a byte entry in a table in memory, using the contents of the AL register as a table index, then copies the contents of the table entry back into the AL register. The index in the AL register is treated as an unsigned integer. The XLAT and XLATB instructions get the base address of the table in memory from either the DS:EBX or the DS:BX registers (depending on the address-size attribute of the instruction, 32 or 16, respectively). (The DS segment may be overridden with a segment override prefix.)

At the assembly-code level, two forms of this instruction are allowed: the "explicit-operand" form and the "no-operand" form. The explicit-operand form (specified with the XLAT mnemonic) allows the base address of the table to be specified explicitly with a symbol. This explicit-operands form is provided to allow documentation; however, note that the documentation provided by this form can be misleading. That is, the symbol does not have to specify the correct base address. The base address is always specified by the DS:(E)BX registers, which must be loaded correctly before the XLAT instruction is executed.

The no-operands form (XLATB) provides a "short form" of the XLAT instructions. Here also the processor assumes that the DS:(E)BX registers contain the base address of the table.

In 64-bit mode, operation is similar to that in legacy or compatibility mode. AL is used to specify the table index (the operand size is fixed at 8 bits). RBX, however, is used to specify the table's base address. See the summary chart at the beginning of this section for encoding data and limits.

Operation

IF AddressSize = 16

```
THEN  AL \leftarrow (DS:BX + ZeroExtend(AL)); \\ ELSE IF (AddressSize = 32) \\ AL \leftarrow (DS:EBX + ZeroExtend(AL)); FI; \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ FI; \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (AddressSize = 64) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (ADDRess + AL) \\ AL \leftarrow (RBX + ZeroExtend(AL)); \\ ELSE (ADDRess + AL) \\ AL \leftarrow (RBX + AL) \\ AL \leftarrow (RBX + AL)
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#UD If the LOCK prefix is used.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.
#UD If the LOCK prefix is used.

XOR—Logical Exclusive OR

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
34 <i>ib</i>	XOR AL, i <i>mm8</i>	Α	Valid	Valid	AL XOR imm8.
35 <i>iw</i>	XOR AX, imm16	Α	Valid	Valid	AX XOR imm16.
35 id	XOR EAX, imm32	Α	Valid	Valid	EAX XOR imm32.
REX.W + 35 id	XOR RAX, imm32	Α	Valid	N.E.	RAX XOR imm32 (sign-extended).
80 /6 ib	XOR r/m8, imm8	В	Valid	Valid	r/m8 XOR imm8.
REX + 80 /6 ib	XOR r/m8*, imm8	В	Valid	N.E.	r/m8 XOR imm8.
81 /6 iw	XOR r/m16, imm16	В	Valid	Valid	r/m16 XOR imm16.
81 /6 id	XOR r/m32, imm32	В	Valid	Valid	r/m32 XOR imm32.
REX.W + 81 /6 id	XOR r/m64, imm32	В	Valid	N.E.	r/m64 XOR imm32 (sign- extended).
83 /6 ib	XOR r/m16, imm8	В	Valid	Valid	r/m16 XOR imm8 (sign- extended).
83 /6 ib	XOR r/m32, imm8	В	Valid	Valid	r/m32 XOR imm8 (sign- extended).
REX.W + 83 /6 ib	XOR r/m64, imm8	В	Valid	N.E.	r/m64 XOR imm8 (sign- extended).
30 /r	XOR r/m8, r8	C	Valid	Valid	r/m8 XOR r8.
REX + 30 /r	XOR <i>r/m8*, r8*</i>	С	Valid	N.E.	r/m8 XOR r8.
31 /r	XOR r/m16, r16	С	Valid	Valid	r/m16 XOR r16.
31 /r	XOR r/m32, r32	C	Valid	Valid	r/m32 XOR r32.
REX.W + 31 /r	XOR r/m64, r64	C	Valid	N.E.	r/m64 XOR r64.
32 /r	XOR <i>r8, r/m8</i>	D	Valid	Valid	r8 XOR r/m8.
REX + 32 /r	XOR <i>r8*, r/m8*</i>	D	Valid	N.E.	r8 XOR r/m8.
33 /r	XOR <i>r16, r/m16</i>	D	Valid	Valid	r16 XOR r/m16.
33 /r	XOR <i>r32, r/m32</i>	D	Valid	Valid	r32 XOR r/m32.
REX.W + 33 /r	XOR <i>r64, r/m64</i>	D	Valid	N.E.	r64 XOR r/m64.

NOTES:

^{*} In 64-bit mode, r/m8 can not be encoded to access the following byte registers if a REX prefix is used: AH, BH, CH, DH.

		modeden operand ci	icodinig	
Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	AL/AX/EAX/RAX	imm8/16/32	NA	NA
В	ModRM:r/m (r, w)	imm8/16/32	NA	NA
С	ModRM:r/m (r, w)	ModRM:reg (r)	NA	NA
D	ModRM:rea (r, w)	ModRM:r/m (r)	NA	NA

Instruction Operand Encoding

Description

Performs a bitwise exclusive OR (XOR) operation on the destination (first) and source (second) operands and stores the result in the destination operand location. The source operand can be an immediate, a register, or a memory location; the destination operand can be a register or a memory location. (However, two memory operands cannot be used in one instruction.) Each bit of the result is 1 if the corresponding bits of the operands are different; each bit is 0 if the corresponding bits are the same.

This instruction can be used with a LOCK prefix to allow the instruction to be executed atomically.

In 64-bit mode, using a REX prefix in the form of REX.R permits access to additional registers (R8-R15). Using a REX prefix in the form of REX.W promotes operation to 64 bits. See the summary chart at the beginning of this section for encoding data and limits.

Operation

DEST \leftarrow DEST XOR SRC:

Flags Affected

The OF and CF flags are cleared; the SF, ZF, and PF flags are set according to the result. The state of the AF flag is undefined.

Protected Mode Exceptions

#GP(0) If the destination operand points to a non-writable segment.

If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains a NULL segment

selector.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Real-Address Mode Exceptions

#GP If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS If a memory operand effective address is outside the SS

segment limit.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Virtual-8086 Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs.

#AC(0) If alignment checking is enabled and an unaligned memory

reference is made while the current privilege level is 3.

#UD If the LOCK prefix is used but the destination is not a memory

operand.

XORPD—Bitwise Logical XOR for Double-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
66 OF 57 /r XORPD xmm1, xmm2/m128	Α	V/V	SSE2	Bitwise exclusive-OR of xmm2/m128 and xmm1.
VEX.NDS.128.66.0F.WIG 57 /r VXORPD xmm1,xmm2, xmm3/m128	В	V/V	AVX	Return the bitwise logical XOR of packed double-precision floating-point values in xmm2 and xmm3/mem.
VEX.NDS.256.66.0F.WIG 57 /r VXORPD ymm1, ymm2, ymm3/m256	В	V/V	AVX	Return the bitwise logical XOR of packed double-precision floating-point values in ymm2 and ymm3/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical exclusive-OR of the two packed double-precision floating-point values from the source operand (second operand) and the destination operand (first operand), and stores the result in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Operation

XORPD (128-bit Legacy SSE version)

DEST[63:0] \leftarrow DEST[63:0] BITWISE XOR SRC[63:0] DEST[127:64] \leftarrow DEST[127:64] BITWISE XOR SRC[127:64] DEST[VLMAX-1:128] (Unmodified)

VXORPD (VEX.128 encoded version)

DEST[63:0] \leftarrow SRC1[63:0] BITWISE XOR SRC2[63:0] DEST[127:64] \leftarrow SRC1[127:64] BITWISE XOR SRC2[127:64] DEST[VLMAX-1:128] \leftarrow 0

VXORPD (VEX.256 encoded version)

DEST[63:0] ← SRC1[63:0] BITWISE XOR SRC2[63:0]
DEST[127:64] ← SRC1[127:64] BITWISE XOR SRC2[127:64]
DEST[191:128] ← SRC1[191:128] BITWISE XOR SRC2[191:128]
DEST[255:192] ← SRC1[255:192] BITWISE XOR SRC2[255:192]

Intel C/C++ Compiler Intrinsic Equivalent

```
XORPD __m128d _mm_xor_pd(__m128d a, __m128d b)

VXORPD __m256d _mm256_xor_pd (__m256d a, __m256d b);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

XORPS—Bitwise Logical XOR for Single-Precision Floating-Point Values

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF 57 /r XORPS xmm1, xmm2/m128	Α	V/V	SSE	Bitwise exclusive-OR of xmm2/m128 and xmm1.
VEX.NDS.128.0F.WIG 57 /r VXORPS xmm1,xmm2, xmm3/m128	В	V/V	AVX	Return the bitwise logical XOR of packed single-precision floating-point values in xmm2 and xmm3/mem.
VEX.NDS.256.0F.WIG 57 /r VXORPS ymm1, ymm2, ymm3/m256	В	V/V	AVX	Return the bitwise logical XOR of packed single-precision floating-point values in ymm2 and ymm3/mem.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:reg (r, w)	ModRM:r/m (r)	NA	NA
В	ModRM:reg (w)	VEX.νννν (r)	ModRM:r/m (r)	NA

Description

Performs a bitwise logical exclusive-OR of the four packed single-precision floating-point values from the source operand (second operand) and the destination operand (first operand), and stores the result in the destination operand. The source operand can be an XMM register or a 128-bit memory location. The destination operand is an XMM register.

In 64-bit mode, using a REX prefix in the form of REX.R permits this instruction to access additional registers (XMM8-XMM15).

128-bit Legacy SSE version: The second source can be an XMM register or an 128-bit memory location. The destination is not distinct from the first source XMM register and the upper bits (VLMAX-1:128) of the corresponding YMM register destination are unmodified.

VEX.128 encoded version: the first source operand is an XMM register or 128-bit memory location. The destination operand is an XMM register. The upper bits (VLMAX-1:128) of the corresponding YMM register destination are zeroed.

VEX.256 encoded version: The first source operand is a YMM register. The second source operand can be a YMM register or a 256-bit memory location. The destination operand is a YMM register.

Operation

XORPS (128-bit Legacy SSE version)

DEST[31:0] \leftarrow SRC1[31:0] BITWISE XOR SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] BITWISE XOR SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] BITWISE XOR SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] BITWISE XOR SRC2[127:96] DEST[VLMAX-1:128] (Unmodified)

VXORPS (VEX.128 encoded version)

DEST[31:0] \leftarrow SRC1[31:0] BITWISE XOR SRC2[31:0] DEST[63:32] \leftarrow SRC1[63:32] BITWISE XOR SRC2[63:32] DEST[95:64] \leftarrow SRC1[95:64] BITWISE XOR SRC2[95:64] DEST[127:96] \leftarrow SRC1[127:96] BITWISE XOR SRC2[127:96] DEST[VLMAX-1:128] \leftarrow 0

VXORPS (VEX.256 encoded version)

DEST[31:0] ← SRC1[31:0] BITWISE XOR SRC2[31:0]
DEST[63:32] ← SRC1[63:32] BITWISE XOR SRC2[63:32]
DEST[95:64] ← SRC1[95:64] BITWISE XOR SRC2[95:64]
DEST[127:96] ← SRC1[127:96] BITWISE XOR SRC2[127:96]
DEST[159:128] ← SRC1[159:128] BITWISE XOR SRC2[159:128]
DEST[191:160] ← SRC1[191:160] BITWISE XOR SRC2[191:160]
DEST[223:192] ← SRC1[223:192] BITWISE XOR SRC2[223:192]
DEST[255:224] ← SRC1[255:224] BITWISE XOR SRC2[255:224].

Intel C/C++ Compiler Intrinsic Equivalent

```
XORPS __m128 _mm_xor_ps(__m128 a, __m128 b)

VXORPS __m256 _mm256_xor_ps (__m256 a, __m256 b);
```

SIMD Floating-Point Exceptions

None.

Other Exceptions

See Exceptions Type 4.

XRSTOR—Restore Processor Extended States

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF AE /5	XRSTOR mem	Α	Valid	Valid	Restore processor extended states from <i>memory</i> . The states are specified by EDX:EAX
REX.W+ OF AE /5	XRSTOR64 mem	Α	Valid	N.E.	Restore processor extended states from <i>memory</i> . The states are specified by EDX:EAX

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (r)	NA	NA	NA

Description

Performs a full or partial restore of the enabled processor states using the state information stored in the memory address specified by the source operand. The implicit EDX:EAX register pair specifies a 64-bit restore mask.

The format of the XSAVE/XRSTOR area is shown in Table 4-18. The memory layout of the XSAVE/XRSTOR area may have holes between save areas written by the processor as a result of the processor not supporting certain processor extended states or system software not supporting certain processor extended states. There is no relationship between the order of XCR0 bits and the order of the state layout. States corresponding to higher and lower XCR0 bits may be intermingled in the layout.

Tubic 4	Table 4 To. deficial cayout of ASAVE/ARSTOR Save Area						
Save Areas	Offset (Byte)	Size (Bytes)					
FPU/SSE SaveArea ¹	0	512					
Header	512	64					
Reserved (Ext_Save_Area_2)	CPUID.(EAX=0DH, ECX=2):EBX	CPUID.(EAX=0DH, ECX=2):EAX					
Reserved(Ext_Save_A rea_4) ²	CPUID.(EAX=0DH, ECX=4):EBX	CPUID.(EAX=0DH, ECX=4):EAX					
Reserved(Ext_Save_A rea_3)	CPUID.(EAX=0DH, ECX=3):EBX	CPUID.(EAX=0DH, ECX=3):EAX					
Reserved()							

Table 4-18. General Layout of XSAVE/XRSTOR Save Area

NOTES:

- 1. Bytes 464:511 are available for software use. XRSTOR ignores the value contained in bytes 464:511 of an XSAVE SAVE image.
- 2. State corresponding to higher and lower XCRO bits may be intermingled in layout.

XRSTOR operates on each subset of the processor state or a processor extended state in one of three ways (depending on the corresponding bit in XCR0 (XFEATURE_ENABLED_MASK register), the restore mask EDX:EAX, and the save mask XSAVE.HEADER.XSTATE_BV in memory):

- Updates the processor state component using the state information stored in the respective save area (see Table 4-18) of the source operand, if the corresponding bit in XCRO, EDX:EAX, and XSAVE.HEADER.XSTATE_BV are all 1.
- Writes certain registers in the processor state component using processorsupplied values (see Table 4-20) without using state information stored in respective save area of the memory region, if the corresponding bit in XCR0 and EDX:EAX are both 1, but the corresponding bit in XSAVE.HEADER.XSTATE_BV is 0.
- The processor state component is unchanged, if the corresponding bit in XCR0 or EDX:EAX is 0.

The format of the header section (XSAVE.HEADER) of the XSAVE/XRSTOR area is shown in Table 4-19.

	Table 4 13. ASAVE.HEADER Cayout						
15 8	7 0	Byte Offset from Header	Byte Offset from XSAVE/XRSTOR Area				
Rsrvd (Must be 0) XSTATE_BV		0	512				
Reserved	Rsrvd (Must be 0)	16	528				
Reserved	Reserved	32	544				
Reserved	Reserved	48	560				

Table 4-19. XSAVE.HEADER Layout

If a processor state component is not enabled in XCR0 but the corresponding save mask bit in XSAVE.HEADER.XSTATE_BV is 1, an attempt to execute XRSTOR will cause a #GP(0) exception. Software may specify all 1's in the implicit restore mask EDX:EAX, so that all the enabled processors states in XCR0 are restored from state information stored in memory or from processor supplied values. When using all 1's as the restore mask, software is required to determine the total size of the XSAVE/XRSTOR save area (specified as source operand) to fit all enabled processor states by using the value enumerated in CPUID.(EAX=0D, ECX=0):EBX. While it's legal to set any bit in the EDX:EAX mask to 1, it is strongly recommended to set only the bits that are required to save/restore specific states.

An attempt to restore processor states with writing 1s to reserved bits in certain registers (see Table 4-21) will cause a #GP(0) exception.

Because bit 63 of XCR0 is reserved for future bit vector expansion, it will not be used for any future processor state feature, and XRSTOR will ignore bit 63 of EDX:EAX (EDX[31].

	11
Processor State Component	Processor Supplied Register Values
x87 FPU State	FCW \leftarrow 037FH; FTW \leftarrow 0FFFFH; FSW \leftarrow 0H; FPU CS \leftarrow 0H; FPU DS \leftarrow 0H; FPU IP \leftarrow 0H; FPU DP \leftarrow 0; ST0-ST7 \leftarrow 0;
SSE State ¹	If 64-bit Mode: XMM0-XMM15 ← 0H;
	Else XMM0-XMM7 ← 0H

Table 4-20. Processor Supplied Init Values XRSTOR May Use

NOTES:

 MXCSR state is not updated by processor supplied values. MXCSR state can only be updated by XRSTOR from state information stored in XSAVE/XRSTOR area.

Table 4-21. Reserved Bit Checking and XRSTOR

Processor State Component	Reserved Bit Checking
X87 FPU State	None
SSE State	Reserved bits of MXCSR

A source operand not aligned to 64-byte boundary (for 64-bit and 32-bit modes) will result in a general-protection (#GP) exception. In 64-bit mode, the upper 32 bits of RDX and RAX are ignored.

Operation

/* The alignment of the x87 and SSE fields in the XSAVE area is the same as in FXSAVE area*/ $RS_TMP_MASK[62:0] \leftarrow (EDX[30:0] << 32) OR EAX[31:0];$ ST TMP MASK[62:0] \leftarrow SRCMEM.HEADER.XSTATE BV[62:0]; IF (((XCR0[62:0] XOR 7FFFFFFF FFFFFFFH) AND ST TMP MASK[62:0])) THEN #GP(0) **ELSE** FOR i = 0, 62 STEP 1 IF (RS_TMP_MASK[i] and XCRO[i]) THEN IF (ST_TMP_MASK[i]) CASE(i)OF 0: Processor state[x87 FPU] ← SRCMEM. FPUSSESave Area[FPU]; 1: Processor state[SSE] ← SRCMEM. FPUSSESave Area[SSE]; // MXCSR is loaded as part of the SSE state DEFAULT: // i corresponds to a valid sub-leaf index of CPUID leaf ODH Processor state[i] ← SRCMEM. Ext Save Area[i]; ESAC; **ELSE** Processor extended state[i] ← Processor supplied values; (see Table 4-20) CASE(i)OF 1: MXCSR ← SRCMEM. FPUSSESave_Area[SSE]; ESAC: FI: FI: NEXT; FI;

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS seament limit.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

If a bit in XCR0 is 0 and the corresponding bit in HEADER.XSTATE_BV field of the source operand is 1.

If bytes 23:8 of HEADER is not zero.

If attempting to write any reserved bits of the MXCSR register

with 1.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

#AC If this exception is disabled a general protection exception

(#GP) is signaled if the memory operand is not aligned on a 16-byte boundary, as described above. If the alignment check exception (#AC) is enabled (and the CPL is 3), signaling of #AC is not guaranteed and may vary with implementation, as follows. In all implementations where #AC is not signaled, a general protection exception is signaled in its place. In addition, the width of the alignment check may also vary with implementation. For instance, for a given implementation, an alignment check exception might be signaled for a 2-byte misalignment, whereas a general protection exception might be signaled for all other misalignments (4-, 8-, or 16-byte misalignments).

Real-Address Mode Exceptions

#GP If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

If any part of the operand lies outside the effective address

space from 0 to FFFFH.

If a bit in XCR0 is 0 and the corresponding bit in HEADER.XSTATE_BV field of the source operand is 1.

If bytes 23:8 of HEADER is not zero.

If attempting to write any reserved bits of the MXCSR register

with 1.

#NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in Protected Mode

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#GP(0) If the memory address is in a non-canonical form.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

If a bit in XCR0 is 0 and the corresponding bit in

XSAVE.HEADER.XSTATE_BV is 1.

If bytes 23:8 of HEADER is not zero.

If attempting to write any reserved bits of the MXCSR register

with 1.

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If $CR4.OSXSAVE[bit\ 18] = 0$. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

#AC If this exception is disabled a general protection exception

(#GP) is signaled if the memory operand is not aligned on a 16-byte boundary, as described above. If the alignment check exception (#AC) is enabled (and the CPL is 3), signaling of #AC is not guaranteed and may vary with implementation, as follows. In all implementations where #AC is not signaled, a general protection exception is signaled in its place. In addition, the width of the alignment check may also vary with implementation. For instance, for a given implementation, an alignment

INSTRUCTION SET REFERENCE, N-Z

check exception might be signaled for a 2-byte misalignment, whereas a general protection exception might be signaled for all other misalignments (4-, 8-, or 16-byte misalignments).

XSAVE—Save Processor Extended States

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
OF AE /4	XSAVE mem	Α	Valid	Valid	Save processor extended states to <i>memory</i> . The states are specified by EDX:EAX
REX.W+ OF AE /4	XSAVE64 mem	Α	Valid	N.E.	Save processor extended states to <i>memory</i> . The states are specified by EDX:EAX

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4	
Α	ModRM:r/m (w)	NA	NA	NA	

Description

Performs a full or partial save of the enabled processor state components to a memory address specified in the destination operand. A full or partial save of the processor states is specified by an implicit mask operand via the register pair, EDX:EAX. The destination operand is a memory location that must be 64-byte aligned.

The implicit 64-bit mask operand in EDX:EAX specifies the subset of enabled processor state components to save into the XSAVE/XRSTOR save area. The XSAVE/XRSTOR save area comprises of individual save area for each processor state components and a header section, see Table 4-18. Each component save area is written if both the corresponding bits in the save mask operand and in XCR0 (the XFEATURE_ENABLED_MASK register) are 1. A processor state component save area is not updated if either one of the corresponding bits in the mask operand or in XCR0 is 0. If the mask operand (EDX:EAX) contains all 1's, all enabled processor state components in XCR0 are written to the respective component save area.

The bit assignment used for the EDX:EAX register pair matches XCR0 (see chapter 2 of Vol. 3B). For the XSAVE instruction, software can specify "1" in any bit position of EDX:EAX, irrespective of whether the corresponding bit position in XCR0 is valid for the processor. The bit vector in EDX:EAX is "anded" with XCR0 to determine which save area will be written. While it's legal to set any bit in the EDX:EAX mask to 1, it is strongly recommended to set only the bits that are required to save/restore specific states. When specifying 1 in any bit position of EDX:EAX mask, software is required to determine the total size of the XSAVE/XRSTOR save area (specified as destination operand) to fit all enabled processor states by using the value enumerated in CPUID.(EAX=0D, ECX=0):EBX.

The content layout of the XSAVE/XRSTOR save area is architecturally defined to be extendable and enumerated via the sub-leaves of CPUID.0DH leaf. The extendable framework of the XSAVE/XRSTOR layout is depicted by Table 4-18. The layout of the XSAVE/XRSTOR save area is fixed and may contain non-contiguous individual save areas. The XSAVE/XRSTOR save area is not compacted if some features are not saved or are not supported by the processor and/or by system software.

The layout of the register fields of first 512 bytes of the XSAVE/XRSTOR is the same as the FXSAVE/FXRSTOR area (refer to "FXSAVE—Save x87 FPU, MMX Technology, and SSE State" on page 456). But XSAVE/XRSTOR organizes the 512 byte area as x87 FPU states (including FPU operation states, x87/MMX data registers), MXCSR (including MXCSR_MASK), and XMM registers.

Bytes 464:511 are available for software use. The processor does not write to bytes 464:511 when executing XSAVE.

The processor writes 1 or 0 to each HEADER.XSTATE_BV[i] bit field of an enabled processor state component in a manner that is consistent to XRSTOR's interaction with HEADER.XSTATE_BV (see the operation section of XRSTOR instruction). If a processor implementation discern that a processor state component is in its initialized state (according to Table 4-20) it may modify the corresponding bit in the HEADER.XSTATE_BV as '0'.

A destination operand not aligned to 64-byte boundary (in either 64-bit or 32-bit modes) will result in a general-protection (#GP) exception being generated. In 64-bit mode, the upper 32 bits of RDX and RAX are ignored.

Operation

```
\begin{split} \text{TMP\_MASK[62:0]} &\leftarrow (\text{(EDX[30:0]} << 32\ ) \text{ OR EAX[31:0]}) \text{ AND XCR0[62:0]}; \\ \text{FOR } i = 0, 62 \text{ STEP 1} \\ & \text{IF (TMP\_MASK[i]} = 1) \text{ THEN} \\ & \text{THEN} \\ & \text{CASE (i) of} \\ & 0: \text{DEST.FPUSSESAVE\_Area[x87 FPU]} \leftarrow \text{processor state[x87 FPU]}; \\ & 1: \text{DEST.FPUSSESAVE\_Area[SSE]} \leftarrow \text{processor state[SSE]}; \\ & \textit{// SSE state include MXCSR} \\ & \text{DEFAULT: // i corresponds to a valid sub-leaf index of CPUID leaf 0DH} \\ & \text{DEST.Ext\_Save\_Area[i]} \leftarrow \text{processor state[i]}; \\ & \text{ESAC:} \\ & \text{DEST.HEADER.XSTATE\_BV[i]} \leftarrow \text{INIT\_FUNCTION[ii]}; \\ & \text{FI;} \\ \text{NEXT:} \end{split}
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H:ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

#AC If this exception is disabled a general protection exception

(#GP) is signaled if the memory operand is not aligned on a 16-byte boundary, as described above. If the alignment check exception (#AC) is enabled (and the CPL is 3), signaling of #AC is not guaranteed and may vary with implementation, as follows. In all implementations where #AC is not signaled, a general protection exception is signaled in its place. In addition, the width of the alignment check may also vary with implementation. For instance, for a given implementation, an alignment check exception might be signaled for a 2-byte misalignment, whereas a general protection exception might be signaled for all

other misalignments (4-, 8-, or 16-byte misalignments).

Real-Address Mode Exceptions

#GP If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

If any part of the operand lies outside the effective address

space from 0 to FFFFH.

#NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H:ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

#AC If this exception is disabled a general protection exception

(#GP) is signaled if the memory operand is not aligned on a 16-byte boundary, as described above. If the alignment check exception (#AC) is enabled (and the CPL is 3), signaling of #AC is not guaranteed and may vary with implementation, as follows. In all implementations where #AC is not signaled, a general protection exception is signaled in its place. In addition, the width of the alignment check may also vary with implementation. For instance, for a given implementation, an alignment check exception might be signaled for a 2-byte misalignment, whereas a general protection exception might be signaled for all

other misalignments (4-, 8-, or 16-byte misalignments).

XSAVEOPT—Save Processor Extended States Optimized

Opcode/ Instruction	Op/ En	64/32 bit Mode Support	CPUID Feature Flag	Description
OF AE /6 XSAVEOPT mem	Α	V/V	XSAVEOPT	Save processor extended states specified in EDX:EAX to memory, optimizing the state save operation if possible.
REX.W + 0F AE /6 XSAVEOPT64 mem	Α	V/V	XSAVEOPT	Save processor extended states specified in EDX:EAX to memory, optimizing the state save operation if possible.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	ModRM:r/m (w)	NA	NA	NA

Description

XSAVEOPT performs a full or partial save of the enabled processor state components to a memory address specified in the destination operand. A full or partial save of the processor states is specified by an implicit mask operand via the register pair, EDX:EAX. The destination operand is a memory location that must be 64-byte aligned. The hardware may optimize the manner in which data is saved. The performance of this instruction will be equal or better than using the XSAVE instruction.

The implicit 64-bit mask operand in EDX:EAX specifies the subset of enabled processor state components to save into the XSAVE/XRSTOR save area. The XSAVE/XRSTOR save area comprises of individual save area for each processor state components and a header section, see Table 4-18.

The bit assignment used for the EDX:EAX register pair matches XCR0 (the XFEATURE_ENABLED_MASK register). For the XSAVEOPT instruction, software can specify "1" in any bit position of EDX:EAX, irrespective of whether the corresponding bit position in XCR0 is valid for the processor. The bit vector in EDX:EAX is "anded" with XCR0 to determine which save area will be written. While it's legal to set any bit in the EDX:EAX mask to 1, it is strongly recommended to set only the bits that are required to save/restore specific states. When specifying 1 in any bit position of EDX:EAX mask, software is required to determine the total size of the XSAVE/XRSTOR save area (specified as destination operand) to fit all enabled processor states by using the value enumerated in CPUID.(EAX=0D, ECX=0):EBX.

The content layout of the XSAVE/XRSTOR save area is architecturally defined to be extendable and enumerated via the sub-leaves of CPUID.0DH leaf. The extendable

framework of the XSAVE/XRSTOR layout is depicted by Table 4-18. The layout of the XSAVE/XRSTOR save area is fixed and may contain non-contiguous individual save areas. The XSAVE/XRSTOR save area is not compacted if some features are not saved or are not supported by the processor and/or by system software.

The layout of the register fields of first 512 bytes of the XSAVE/XRSTOR is the same as the FXSAVE/FXRSTOR area. But XSAVE/XRSTOR organizes the 512 byte area as x87 FPU states (including FPU operation states, x87/MMX data registers), MXCSR (including MXCSR_MASK), and XMM registers.

The processor writes 1 or 0 to each.HEADER.XSTATE_BV[i] bit field of an enabled processor state component in a manner that is consistent to XRSTOR's interaction with HEADER.XSTATE_BV.

The state updated to the XSAVE/XRSTOR area may be optimized as follows:

 If the state is in its initialized form, the corresponding XSTATE_BV bit may be set to 0, and the corresponding processor state component that is indicated as initialized will not be saved to memory.

A processor state component save area is not updated if either one of the corresponding bits in the mask operand or in XCR0 is 0. The processor state component that is updated to the save area is computed by bit-wise AND of the mask operand (EDX:EAX) with XCR0.

HEADER.XSTATE_BV is updated to reflect the data that is actually written to the save area. A "1" bit in the header indicates the contents of the save area corresponding to that bit are valid. A "0" bit in the header indicates that the state corresponding to that bit is in its initialized form. The memory image corresponding to a "0" bit may or may not contain the correct (initialized) value since only the header bit (and not the save area contents) is updated when the header bit value is 0. XRSTOR will ensure the correct value is placed in the register state regardless of the value of the save area when the header bit is zero.

XSAVEOPT Usage Guidelines

When using the XSAVEOPT facility, software must be aware of the following guidelines:

- The processor uses a tracking mechanism to determine which state components will be written to memory by the XSAVEOPT instruction. The mechanism includes three sub-conditions that are recorded internally each time XRSTOR is executed and evaluated on the invocation of the next XSAVEOPT. If a change is detected in any one of these sub-conditions, XSAVEOPT will behave exactly as XSAVE. The three sub-conditions are:
 - current CPL of the logical processor
 - indication whether or not the logical processor is in VMX non-root operation
 - linear address of the XSAVE/XRSTOR area

- 2. Upon allocation of a new XSAVE/XRSTOR area and before an XSAVE or XSAVEOPT instruction is used, the save area header (HEADER.XSTATE) must be initialized to zeroes for proper operation.
- XSAVEOPT is designed primarily for use in context switch operations. The values stored by the XSAVEOPT instruction depend on the values previously stored in a given XSAVE area.
- 4. Manual modifications to the XSAVE area between an XRSTOR instruction and the matching XSAVEOPT may result in data corruption.
- 5. For optimization to be performed properly, the XRSTOR XSAVEOPT pair must use the same segment when referencing the XSAVE area and the base of that segment must be unchanged between the two operations.
- 6. Software should avoid executing XSAVEOPT into a buffer from which it hadn't previously executed a XRSTOR. For newly allocated buffers, software can execute XRSTOR with the linear address of the buffer and a restore mask of EDX:EAX = 0. Executing XRSTOR(0:0) doesn't restore any state, but ensures expected operation of the XSAVEOPT instruction.
- 7. The XSAVE area can be moved or even paged, but the contents at the linear address of the save area at an XSAVEOPT must be the same as that when the previous XRSTOR was performed.

A destination operand not aligned to 64-byte boundary (in either 64-bit or 32-bit modes) will result in a general-protection (#GP) exception being generated. In 64-bit mode, the upper 32 bits of RDX and RAX are ignored.

Operation

```
TMP_MASK[62:0] (EDX[30:0] << 32 ) OR EAX[31:0] ) AND XCR0[62:0];
FOR i = 0, 62 STEP 1
   IF (TMP\_MASK[i] = 1)
   THEN
       If not HW_CAN_OPTIMIZE_SAVE
       THEN
           CASE(i) of
                0: DEST.FPUSSESAVE_Area[x87 FPU] processor state[x87 FPU];
                1: DEST.FPUSSESAVE_Area[SSE] processor state[SSE];
                    // SSE state include MXCSR
                2: DEST.EXT_SAVE_Area2[YMM] processor state[YMM];
                DEFAULT: // i corresponds to a valid sub-leaf index of CPUID leaf ODH
                    DEST.Ext Save Area[i] processor state[i]:
           ESAC:
       FI:
       DEST.HEADER.XSTATE_BV[i] INIT_FUNCTION[i];
   FI:
NFXT:
```

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If a memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

#SS(0) If a memory operand effective address is outside the SS

segment limit.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CPUID.(EAX=0DH, ECX=01H):EAX.XSAVEOPT[bit 0] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Real-Address Mode Exceptions

#GP If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

If any part of the operand lies outside the effective address

space from 0 to FFFFH.

#NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CPUID.(EAX=0DH, ECX=01H):EAX.XSAVEOPT[bit 0] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Virtual-8086 Mode Exceptions

Same exceptions as in protected mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

#SS(0) If a memory address referencing the SS segment is in a non-

canonical form.

#GP(0) If the memory address is in a non-canonical form.

If a memory operand is not aligned on a 64-byte boundary,

regardless of segment.

#PF(fault-code) If a page fault occurs. #NM If CR0.TS[bit 3] = 1.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CPUID.(EAX=0DH, ECX=01H):EAX.XSAVEOPT[bit 0] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

XSETBV—Set Extended Control Register

Opcode	Instruction	Op/ En	64-Bit Mode	Compat/ Leg Mode	Description
0F 01 D1	XSETBV	Α	Valid	Valid	Write the value in EDX:EAX to the XCR specified by ECX.

Instruction Operand Encoding

Op/En	Operand 1	Operand 2	Operand 3	Operand 4
Α	NA	NA	NA	NA

Description

Writes the contents of registers EDX:EAX into the 64-bit extended control register (XCR) specified in the ECX register. (On processors that support the Intel 64 architecture, the high-order 32 bits of RCX are ignored.) The contents of the EDX register are copied to high-order 32 bits of the selected XCR and the contents of the EAX register are copied to low-order 32 bits of the XCR. (On processors that support the Intel 64 architecture, the high-order 32 bits of each of RAX and RDX are ignored.) Undefined or reserved bits in an XCR should be set to values previously read.

This instruction must be executed at privilege level 0 or in real-address mode; otherwise, a general protection exception #GP(0) is generated. Specifying a reserved or unimplemented XCR in ECX will also cause a general protection exception. The processor will also generate a general protection exception if software attempts to write to reserved bits in an XCR.

Currently, only XCR0 (the XFEATURE_ENABLED_MASK register) is supported. Thus, all other values of ECX are reserved and will cause a #GP(0). Note that bit 0 of XCR0 (corresponding to x87 state) must be set to 1; the instruction will cause a #GP(0) if an attempt is made to clear this bit. Additionally, bit 1 of XCR0 (corresponding to AVX state) and bit 2 of XCR0 (corresponding to SSE state) must be set to 1 when using AVX registers; the instruction will cause a #GP(0) if an attempt is made to set XCR0[2:1] = 10.

Operation

 $XCR[ECX] \leftarrow EDX:EAX;$

Flags Affected

None.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If an invalid XCR is specified in ECX.

If the value in EDX: EAX sets bits that are reserved in the XCR

specified by ECX.

If an attempt is made to clear bit 0 of XCR0. If an attempt is made to set XCR0[2:1] = 10.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Real-Address Mode Exceptions

#GP If an invalid XCR is specified in ECX.

If the value in EDX: EAX sets bits that are reserved in the XCR

specified by ECX.

If an attempt is made to clear bit 0 of XCR0. If an attempt is made to set XCR0[2:1] = 10.

#UD If CPUID.01H: ECX.XSAVE[bit 26] = 0.

If CR4.OSXSAVE[bit 18] = 0. If the LOCK prefix is used.

If 66H, F3H or F2H prefix is used.

Virtual-8086 Mode Exceptions

#GP(0) The XSETBV instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

Same exceptions as in protected mode.

64-Bit Mode Exceptions

Same exceptions as in protected mode.

INSTRUCTION SET REFERENCE, N-Z

CHAPTER 5 VMX INSTRUCTION REFERENCE

5.1 OVERVIEW

This chapter describes the virtual-machine extensions (VMX) for the Intel 64 and IA-32 architectures. VMX is intended to support virtualization of processor hardware and a system software layer acting as a host to multiple guest software environments. The virtual-machine extensions (VMX) includes five instructions that manage the virtual-machine control structure (VMCS) and five instruction that manage VMX operation. Additional details of VMX are described in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*.

The behavior of the VMCS-maintenance instructions is summarized below:

- VMPTRLD This instruction takes a single 64-bit source operand that is in memory. It makes the referenced VMCS active and current, loading the current-VMCS pointer with this operand and establishes the current VMCS based on the contents of VMCS-data area in the referenced VMCS region. Because this makes the referenced VMCS active, a logical processor may start maintaining on the processor some of the VMCS data for the VMCS.
- **VMPTRST** This instruction takes a single 64-bit destination operand that is in memory. The current-VMCS pointer is stored into the destination operand.
- VMCLEAR This instruction takes a single 64-bit operand that is in memory.
 The instruction sets the launch state of the VMCS referenced by the operand to "clear", renders that VMCS inactive, and ensures that data for the VMCS have been written to the VMCS-data area in the referenced VMCS region. If the operand is the same as the current-VMCS pointer, that pointer is made invalid.
- **VMREAD** This instruction reads a component from the VMCS (the encoding of that field is given in a register operand) and stores it into a destination operand that may be a register or in memory.
- VMWRITE This instruction writes a component to the VMCS (the encoding of that field is given in a register operand) from a source operand that may be a register or in memory.

The behavior of the VMX management instructions is summarized below:

- VMCALL This instruction allows a guest in VMX non-root operation to call the VMM for service. A VM exit occurs, transferring control to the VMM.
- VMLAUNCH This instruction launches a virtual machine managed by the VMCS. A VM entry occurs, transferring control to the VM.
- VMRESUME This instruction resumes a virtual machine managed by the VMCS. A VM entry occurs, transferring control to the VM.
- VMXOFF This instruction causes the processor to leave VMX operation.

 VMXON — This instruction takes a single 64-bit source operand that is in memory. It causes a logical processor to enter VMX root operation and to use the memory referenced by the operand to support VMX operation.

Only VMCALL can be executed in compatibility mode (causing a VM exit). The other VMX instructions generate invalid-opcode exceptions if executed in compatibility mode.

The behavior of the VMX-specific TLB-management instructions is summarized below:

- **INVEPT** This instruction invalidates entries in the TLBs and paging-structure caches that were derived from **Extended Page Tables** (EPT).
- INVVPID This instruction invalidates entries in the TLBs and paging-structure caches based on a Virtual-Processor Identifier (VPID).

5.2 CONVENTIONS

The operation sections for the VMX instructions in Section 5.3 use the pseudo-function VMexit, which indicates that the logical processor performs a VM exit.

The operation sections also use the pseudo-functions VMsucceed, VMfail, VMfailInvalid, and VMfailValid. These pseudo-functions signal instruction success or failure by setting or clearing bits in RFLAGS and, in some cases, by writing the VM-instruction error field. The following pseudocode fragments detail these functions:

```
VMsucceed:
      CF \leftarrow 0:
      PF \leftarrow 0;
      AF \leftarrow 0:
      ZF \leftarrow 0:
      SF \leftarrow 0:
      0F \leftarrow 0:
VMfail(ErrorNumber):
      IF VMCS pointer is valid
             THEN VMfailValid(ErrorNumber);
             ELSE VMfailInvalid:
      FI:
VMfailInvalid:
      CF \leftarrow 1:
      PF \leftarrow 0:
      AF \leftarrow 0:
      ZF \leftarrow 0:
      SF \leftarrow 0:
```

```
0F \leftarrow 0;
```

VMfailValid(ErrorNumber):// executed only if there is a current VMCS

 $CF \leftarrow 0$;

 $PF \leftarrow 0$:

 $AF \leftarrow 0$;

 $\mathsf{ZF} \leftarrow \mathsf{1};$

 $SF \leftarrow 0$; $OF \leftarrow 0$:

Set the VM-instruction error field to ErrorNumber:

The different VM-instruction error numbers are enumerated in Section 5.4, "VM Instruction Error Numbers".

5.3 VMX INSTRUCTIONS

This section provides detailed descriptions of the VMX instructions.

INVFPT—	Invalidate 1	Franslations	Derived	from FF	TC
114 V C 1 1 —	IIIValluate	1 1 41 1314 HVI 13	Delived		

Opcode	Instruction	Description
66 OF 38 80	INVEPT r64, m128	Invalidates EPT-derived entries in the TLBs and paging-structure caches (in 64-bit mode)
66 OF 38 80	INVEPT r32, m128	Invalidates EPT-derived entries in the TLBs and paging-structure caches (outside 64-bit mode)

Description

Invalidates mappings in the translation lookaside buffers (TLBs) and paging-structure caches that were derived from **extended page tables** (EPT). (See Chapter 25, "Support for Address Translation" in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*.) Invalidation is based on the **INVEPT type** specified in the register operand and the **INVEPT descriptor** specified in the memory operand.

Outside IA-32e mode, the register operand is always 32 bits, regardless of the value of CS.D. In 64-bit mode, the register operand has 64 bits; however, if bits 63:32 of the register operand are not zero, INVEPT fails due to an attempt to use an unsupported INVEPT type (see below).

The INVEPT types supported by a logical processors are reported in the IA32_VMX_EPT_VPID_CAP MSR (see Appendix "VMX Capability Reporting Facility" in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*). There are two INVEPT types currently defined:

- Single-context invalidation. If the INVEPT type is 1, the logical processor invalidates all mappings associated with bits 51:12 of the EPT pointer (EPTP) specified in the INVEPT descriptor. It may invalidate other mappings as well.
- Global invalidation: If the INVEPT type is 2, the logical processor invalidates mappings associated with all EPTPs.

If an unsupported INVEPT type is specified, the instruction fails.

INVEPT invalidates all the specified mappings for the indicated EPTP(s) regardless of the VPID and PCID values with which those mappings may be associated.

The INVEPT descriptor comprises 128 bits and contains a 64-bit EPTP value in bits 63:0 (see Figure 5-1).




Figure 5-1. INVEPT Descriptor

Operation

```
IF (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or (IA32_EFER.LMA = 1 and CS.L = 0)
   THEN #UD:
ELSIF in VMX non-root operation
   THEN VM exit;
ELSIF CPL > 0
   THEN #GP(0);
   ELSE
        INVEPT TYPE \leftarrow value of register operand;
        IF IA32_VMX_EPT_VPID_CAP MSR indicates that processor does not support INVEPT_TYPE
            THEN VMfail(Invalid operand to INVEPT/INVVPID);
                     // INVEPT TYPE must be 1 or 2
            ELSE
                 INVEPT DESC ← value of memory operand;
                 EPTP ← INVEPT DESC[63:0];
                 CASE INVEPT TYPE OF
                     1.
                                        // single-context invalidation
                          IF VM entry with the "enable EPT" VM execution control set to 1
                          would fail due to the EPTP value
                               THEN VMfail(Invalid operand to INVEPT/INVVPID);
                              ELSE
                                   Invalidate mappings associated with EPTP[51:12];
                                   VMsucceed;
                          FI:
                          BREAK:
                     2.
                                        // global invalidation
                          Invalidate mappings associated with all EPTPs;
                          VMsucceed:
                          BREAK:
                 ESAC:
        FI:
FI;
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the source operand is located in an execute-only code

segment.

VMX INSTRUCTION REFERENCE

#PF(fault-code) If a page fault occurs in accessing the memory operand.

#SS(0) If the memory operand effective address is outside the SS

segment limit.

If the SS register contains an unusable segment.

#UD If not in VMX operation.

If the logical processor does not support EPT (IA32_VMX_PROCBASED_CTLS2[33]=0).

If the logical processor supports EPT

(IA32_VMX_PROCBASED_CTLS2[33]=1) but does not support the INVEPT instruction (IA32_VMX_EPT_VPID_CAP[20]=0).

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the INVEPT instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The INVEPT instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The INVEPT instruction is not recognized in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory operand is in the CS, DS, ES, FS, or GS segments

and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory operand.

#SS(0) If the memory operand is in the SS segment and the memory

address is in a non-canonical form.

#UD If not in VMX operation.

If the logical processor does not support EPT (IA32_VMX_PROCBASED_CTLS2[33]=0).

If the logical processor supports EPT

(IA32_VMX_PROCBASED_CTLS2[33]=1) but does not support the INVEPT instruction (IA32_VMX_EPT_VPID_CAP[20]=0).

	N	J١	Λ	/F)	n.	In	N	ıa	li	Ч	a	t	ρ	٦	'n	a	n	9	la	ti	in	п	2	P	la	9	ρ	ď	n	n	1	/1		D
- 1	ш		, ,	, .		ш.		ıv	Æ ■		ш		L	┖	_		а		-		ш	ıv	, ,			,,		┖	u	u	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		•	_	u

Opcode	Instruction	Description
66 0F 38 81	INVVPID r64, m128	Invalidates entries in the TLBs and paging-structure caches based on VPID (in 64-bit mode)
66 0F 38 81	INVVPID r32, m128	Invalidates entries in the TLBs and paging-structure caches based on VPID (outside 64-bit mode)

Description

Invalidates mappings in the translation lookaside buffers (TLBs) and paging-structure caches based on **virtual-processor identifier** (VPID). (See Chapter 25, "Support for Address Translation" in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B.*) Invalidation is based on the **INVVPID type** specified in the register operand and the **INVVPID descriptor** specified in the memory operand.

Outside IA-32e mode, the register operand is always 32 bits, regardless of the value of CS.D. In 64-bit mode, the register operand has 64 bits; however, if bits 63:32 of the register operand are not zero, INVVPID fails due to an attempt to use an unsupported INVVPID type (see below).

The INVVPID types supported by a logical processors are reported in the IA32_VMX_EPT_VPID_CAP MSR (see Appendix "VMX Capability Reporting Facility" in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*). There are four INVVPID types currently defined:

- Individual-address invalidation: If the INVVPID type is 0, the logical processor invalidates mappings for a single linear address and tagged with the VPID specified in the INVVPID descriptor. In some cases, it may invalidate mappings for other linear addresses (or with other VPIDs) as well.
- Single-context invalidation: If the INVVPID type is 1, the logical processor invalidates all mappings tagged with the VPID specified in the INVVPID descriptor. In some cases, it may invalidate mappings for other VPIDs as well.
- All-contexts invalidation: If the INVVPID type is 2, the logical processor invalidates all mappings tagged with all VPIDs except VPID 0000H. In some cases, it may invalidate translations with VPID 0000H as well.
- Single-context invalidation, retaining global translations: If the INVVPID type is 3, the logical processor invalidates all mappings tagged with the VPID specified in the INVVPID descriptor except global translations. In some cases, it may invalidate global translations (and mappings with other VPIDs) as well. See the "Caching Translation Information" section in Chapter 4 of the IA-32 Intel Architecture Software Developer's Manual, Volumes 3A for information about global translations.

If an unsupported INVVPID type is specified, the instruction fails.

INVVPID invalidates all the specified mappings for the indicated VPID(s) regardless of the EPTP and PCID values with which those mappings may be associated.

The INVVPID descriptor comprises 128 bits and consists of a VPID and a linear address as shown in Figure 5-2.




Figure 5-2. INVVPID Descriptor

Operation

```
IF (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or (IA32_EFER.LMA = 1 and CS.L = 0)
   THEN #UD:
ELSIF in VMX non-root operation
   THEN VM exit:
ELSIF CPL > 0
   THEN #GP(0);
   ELSE
        INVVPID_TYPE \leftarrow value of register operand;
        IF IA32 VMX EPT VPID CAP MSR indicates that processor does not support
        INVVPID TYPE
            THEN VMfail(Invalid operand to INVEPT/INVVPID);
            ELSE
                          // INVVPID TYPE must be in the range 0-3
                 INVVPID_DESC ← value of memory operand;
                 IF INVVPID DESC[63:16] ≠ 0
                     THEN VMfail(Invalid operand to INVEPT/INVVPID);
                     ELSE
                          CASE INVVPID TYPE OF
                              0:
                                                 // individual-address invalidation
                                   VPID \leftarrow INVVPID DESC[15:0];
                                   IF VPID = 0
                                        THEN VMfail(Invalid operand to INVEPT/INVVPID);
                                        ELSE
                                            GL ADDR ← INVVPID DESC[127:64];
                                            IF (GL ADDR is not in a canonical form)
                                                 THEN
                                                     VMfail(Invalid operand to INVEPT/INVVPID);
                                                 ELSE
```

Invalidate mappings for GL ADDR tagged

```
with VPID:
                                                         VMsucceed:
                                               FI:
                                     FI:
                                     BREAK:
                                1:
                                                   // single-context invalidation
                                     VPID \leftarrow INVVPID\_DESC[15:0];
                                     IF VPID = 0
                                          THEN VMfail(Invalid operand to INVEPT/INVVPID);
                                          FLSE
                                               Invalidate all mappings tagged with VPID;
                                               VMsucceed:
                                     FI:
                                     BREAK:
                                2:
                                                   // all-context invalidation
                                     Invalidate all mappings tagged with all non-zero VPIDs;
                                     VMsucceed:
                                     BRFAK:
                                3:
                                                   // single-context invalidation retaining globals
                                     VPID \leftarrow INVVPID\_DESC[15:0];
                                     IF VPID = 0
                                          THEN VMfail(Invalid operand to INVEPT/INVVPID);
                                          ELSE
                                               Invalidate all mappings tagged with VPID except
global translations;
                                               VMsucceed:
                                     FI:
                                     BREAK:
                            ESAC:
                  FI:
        FI:
FI;
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the source operand is located in an execute-only code

segment.

#PF(fault-code) If a page fault occurs in accessing the memory operand.

#SS(0) If the memory operand effective address is outside the SS

segment limit.

If the SS register contains an unusable segment.

#UD If not in VMX operation.

If the logical processor does not support VPIDs (IA32_VMX_PROCBASED_CTLS2[37]=0).

If the logical processor supports VPIDs

(IA32_VMX_PROCBASED_CTLS2[37]=1) but does not support the INVVPID instruction (IA32_VMX_EPT_VPID_CAP[32]=0).

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the INVVPID instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The INVVPID instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The INVVPID instruction is not recognized in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory operand is in the CS, DS, ES, FS, or GS segments

and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory operand.

#SS(0) If the memory destination operand is in the SS segment and the

memory address is in a non-canonical form.

#UD If not in VMX operation.

If the logical processor does not support VPIDs (IA32_VMX_PROCBASED_CTLS2[37]=0).

If the logical processor supports VPIDs

(IA32_VMX_PROCBASED_CTLS2[37]=1) but does not support the INVVPID instruction (IA32_VMX_EPT_VPID_CAP[32]=0).

VMCALL—Call to VM Monitor

Opcode	Instruction	Description
0F 01 C1	VMCALL	Call to VM monitor by causing VM exit.

Description

This instruction allows guest software can make a call for service into an underlying VM monitor. The details of the programming interface for such calls are VMM-specific; this instruction does nothing more than cause a VM exit, registering the appropriate exit reason.

Use of this instruction in VMX root operation invokes an SMM monitor (see Section 26.15.2 in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*). This invocation will activate the dual-monitor treatment of system-management interrupts (SMIs) and system-management mode (SMM) if it is not already active (see Section 26.15.6 in *IA-32 Intel Architecture Software Developer's Manual, Volume 3B*).

Operation

IF not in VMX operation

THEN #UD:

ELSIF in VMX non-root operation

THEN VM exit;

ELSIF (RFLAGS.VM = 1) or (IA32 EFER.LMA = 1 and CS.L = 0)

THEN #UD;

ELSIF CPL > 0

THEN #GP(0);

ELSIF in SMM or the logical processor does not support the dual-monitor treatment of SMIs and SMM or the valid bit in the IA32 SMM MONITOR CTL MSR is clear

THEN VMfail (VMCALL executed in VMX root operation);

ELSIF dual-monitor treatment of SMIs and SMM is active

THEN perform an SMM VM exit (see Section 26.15.2

of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B);

ELSIF current-VMCS pointer is not valid

THEN VMfailInvalid:

ELSIF launch state of current VMCS is not clear

THEN VMfailValid(VMCALL with non-clear VMCS);

ELSIF VM-exit control fields are not valid (see Section 26.15.6.1 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B)

THEN VMfailValid (VMCALL with invalid VM-exit control fields);

ELSE

enter SMM:

read revision identifier in MSEG:

```
IF revision identifier does not match that supported by processor
        THEN
            leave SMM:
            VMfailValid(VMCALL with incorrect MSEG revision identifier);
        ELSE
            read SMM-monitor features field in MSEG (see Section 26.15.6.2,
            in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B);
            IF features field is invalid
                 THEN
                      leave SMM:
                      VMfailValid(VMCALL with invalid SMM-monitor features);
                 ELSE activate dual-monitor treatment of SMIs and SMM (see Section 26.15.6
                 in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume
                 3B);
            FI:
        FI:
FI:
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0 and the logical processor is

in VMX root operation.

#UD If executed outside VMX operation.

Real-Address Mode Exceptions

#UD If executed outside VMX operation.

Virtual-8086 Mode Exceptions

#UD If executed outside VMX non-root operation.

Compatibility Mode Exceptions

#UD If executed outside VMX non-root operation.

64-Bit Mode Exceptions

#UD If executed outside VMX non-root operation.

VMCLEAR—Clear Virtual-Machine Control Structure

Opcode	Instruction	Description
66 0F C7 /6	VMCLEAR m64	Copy VMCS data to VMCS region in memory.

Description

This instruction applies to the VMCS whose VMCS region resides at the physical address contained in the instruction operand. The instruction ensures that VMCS data for that VMCS (some of these data may be currently maintained on the processor) are copied to the VMCS region in memory. It also initializes parts of the VMCS region (for example, it sets the launch state of that VMCS to clear). See Chapter 21, "Virtual-Machine Control Structures," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B.

The operand of this instruction is always 64 bits and is always in memory. If the operand is the current-VMCS pointer, then that pointer is made invalid (set to FFFFFFFF_FFFFFFH).

Note that the VMCLEAR instruction might not explicitly write any VMCS data to memory; the data may be already resident in memory before the VMCLEAR is executed.

Operation

```
IF (register operand) or (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or
(IA32 EFER.LMA = 1 and CS.L = 0)
   THEN #UD:
ELSIF in VMX non-root operation
   THEN VM exit;
ELSIF CPL > 0
   THEN #GP(0):
   ELSE
        addr ← contents of 64-bit in-memory operand;
        IF addr is not 4KB-aligned OR
        addr sets any bits beyond the physical-address width<sup>1</sup>
             THEN VMfail(VMCLEAR with invalid physical address);
        ELSIF addr = VMXON pointer
             THEN VMfail(VMCLEAR with VMXON pointer);
             ELSE
                 ensure that data for VMCS referenced by the operand is in memory;
                 initialize implementation-specific data in VMCS region;
```

If IA32_VMX_BASIC[48] is read as 1, VMfail occurs if addr sets any bits in the range 63:32; see Appendix G.1.

launch state of VMCS referenced by the operand \leftarrow "clear"

IF operand addr = current-VMCS pointer

THEN current-VMCS pointer ← FFFFFFFFFFFH;

FI;

VMsucceed:

FI;

FI:

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory operand effective address is outside the CS, DS,

ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the operand is located in an execute-only code segment.

#PF(fault-code) If a page fault occurs in accessing the memory operand.

#SS(0) If the memory operand effective address is outside the SS

segment limit.

If the SS register contains an unusable segment.

#UD If operand is a register.

If not in VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMCLEAR instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMCLEAR instruction is not recognized in virtual-8086

mode.

Compatibility Mode Exceptions

#UD The VMCLEAR instruction is not recognized in compatibility

mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the source operand is in the CS, DS, ES, FS, or GS segments

and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory operand.
#SS(0) If the source operand is in the SS segment and the memory

address is in a non-canonical form.

#UD If operand is a register.

If not in VMX operation.

VMLAUNCH/VMRESUME—Launch/Resume Virtual Machine

Opcode	Instruction	Description
0F 01 C2	VMLAUNCH	Launch virtual machine managed by current VMCS.
0F 01 C3	VMRESUME	Resume virtual machine managed by current VMCS.

Description

Effects a VM entry managed by the current VMCS.

- VMLAUNCH fails if the launch state of current VMCS is not "clear". If the instruction is successful, it sets the launch state to "launched."
- VMRESUME fails if the launch state of the current VMCS is not "launched."

If VM entry is attempted, the logical processor performs a series of consistency checks as detailed in Chapter 23, "VM Entries," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. Failure to pass checks on the VMX controls or on the host-state area passes control to the instruction following the VMLAUNCH or VMRESUME instruction. If these pass but checks on the guest-state area fail, the logical processor loads state from the host-state area of the VMCS, passing control to the instruction referenced by the RIP field in the host-state area.

VM entry is not allowed when events are blocked by MOV SS or POP SS. Neither VMLAUNCH nor VMRESUME should be used immediately after either MOV to SS or POP to SS.

Operation

ELSIF (VMRESUME and launch state of current VMCS is not "launched")

THEN VMfailValid(VMRESUME with non-launched VMCS);

ELSE

Check settings of VMX controls and host-state area; IF invalid settings

```
THEN VMfailValid(VM entry with invalid VMX-control field(s)) or
                      VMfailValid(VM entry with invalid host-state field(s)) or
                      VMfailValid(VM entry with invalid executive-VMCS pointer)) or
                      VMfailValid(VM entry with non-launched executive VMCS) or
                      VMfailValid(VM entry with executive-VMCS pointer not VMXON pointer) or
                      VMfailValid(VM entry with invalid VM-execution control fields in executive
                      VMCS)
                      as appropriate;
             ELSE
                 Attempt to load quest state and PDPTRs as appropriate;
                 clear address-range monitoring;
                 IF failure in checking guest state or PDPTRs
                      THEN VM entry fails (see Section 22.7, in the
                      Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B);
                           Attempt to load MSRs from VM-entry MSR-load area;
                           IF failure
                               THEN VM entry fails (see Section 22.7, in the Intel® 64 and IA-32
Architectures Software Developer's Manual, Volume 3B);
                               ELSE
                                    IF VMLAUNCH
                                         THEN launch state of VMCS \leftarrow "launched";
                                    FI:
                                    IF in SMM and "entry to SMM" VM-entry control is 0
                                         THEN
                                              IF "deactivate dual-monitor treatment" VM-entry
                                              control is 0
                                                  THEN SMM-transfer VMCS pointer ←
                                                  current-VMCS pointer;
                                              FI;
                                              IF executive-VMCS pointer is VMX pointer
                                                  THEN current-VMCS pointer \leftarrow
                                                  VMCS-link pointer;
                                                  ELSE current-VMCS pointer ←
                                                  executive-VMCS pointer;
                                              FI:
                                              leave SMM:
                                    FI:
                                    VM entry succeeds;
                           FI:
                 FI:
        FI:
FI:
```

Further details of the operation of the VM-entry appear in Chapter 22 of *IA-32 Intel Architecture Software Developer's Manual, Volume 3B.*

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.
#UD If executed outside VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMLAUNCH and VMRESUME instructions are

not recognized outside VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMLAUNCH and VMRESUME instructions are not recognized

in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The VMLAUNCH and VMRESUME instructions are not recognized

in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.
#UD If executed outside VMX operation.

VMPTRLD—Load Pointer to Virtual-Machine Control Structure

Opcode	Instruction	Description
0F C7 /6	VMPTRLD m64	Loads the current VMCS pointer from memory.

Description

Marks the current-VMCS pointer valid and loads it with the physical address in the instruction operand. The instruction fails if its operand is not properly aligned, sets unsupported physical-address bits, or is equal to the VMXON pointer. In addition, the instruction fails if the 32 bits in memory referenced by the operand do not match the VMCS revision identifier supported by this processor. ¹

The operand of this instruction is always 64 bits and is always in memory.

Operation

```
IF (register operand) or (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or
(IA32 EFER.LMA = 1 and CS.L = 0)
   THEN #UD:
ELSIF in VMX non-root operation
   THEN VMexit:
ELSIF CPL > 0
   THEN #GP(0);
   ELSE
        addr ← contents of 64-bit in-memory source operand;
        IF addr is not 4KB-aligned OR
        addr sets any bits beyond the physical-address width<sup>2</sup>
             THEN VMfail(VMPTRLD with invalid physical address);
        ELSIF addr = VMXON pointer
             THEN VMfail(VMPTRLD with VMXON pointer);
             ELSE
                 rev ← 32 bits located at physical address addr;
                 IF rev ≠ VMCS revision identifier supported by processor
                      THEN VMfail(VMPTRLD with incorrect VMCS revision identifier);
                      ELSE
                           current-VMCS pointer \leftarrow addr;
                           VMsucceed:
```

Software should consult the VMX capability MSR VMX_BASIC to discover the VMCS revision identifier supported by this processor (see Appendix G, "VMX Capability Reporting Facility," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B).

If IA32_VMX_BASIC[48] is read as 1, VMfail occurs if addr sets any bits in the range 63:32; see Appendix G.1.

FI:

FI:

FI;

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory source operand effective address is outside the

CS, DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the source operand is located in an execute-only code

segment.

#PF(fault-code) If a page fault occurs in accessing the memory source operand.

#SS(0) If the memory source operand effective address is outside the

SS segment limit.

If the SS register contains an unusable segment.

#UD If operand is a register.

If not in VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMPTRLD instruction is not recognized

outside VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMPTRLD instruction is not recognized in virtual-8086

mode.

Compatibility Mode Exceptions

#UD The VMPTRLD instruction is not recognized in compatibility

mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the source operand is in the CS, DS, ES, FS, or GS segments

and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory source operand.

If the source operand is in the SS segment and the memory address is in a non-canonical form. #SS(0)

#UD If operand is a register.

If not in VMX operation.

VMPTRST—Store Pointer to Virtual-Machine Control Structure

Opcode	Instruction	Description
0F C7 /7	VMPTRST m64	Stores the current VMCS pointer into memory.

Description

Stores the current-VMCS pointer into a specified memory address. The operand of this instruction is always 64 bits and is always in memory.

Operation

```
IF (register operand) or (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or (IA32_EFER.LMA = 1 and CS.L = 0)
        THEN #UD;
ELSIF in VMX non-root operation
        THEN VMexit;
ELSIF CPL > 0
        THEN #GP(0);
ELSE
        64-bit in-memory destination operand ← current-VMCS pointer;
        VMsucceed;
FI:
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

Protected Mode Ext	ceptions .
#GP(0)	If the current privilege level is not 0.
	If the memory destination operand effective address is outside the CS, DS, ES, FS, or GS segment limit.
	If the DS, ES, FS, or GS register contains an unusable segment.
	If the destination operand is located in a read-only data segment or any code segment.
#PF(fault-code)	If a page fault occurs in accessing the memory destination operand.
#SS(0)	If the memory destination operand effective address is outside the SS segment limit.
	If the SS register contains an unusable segment.
#UD	If operand is a register.
	If not in VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMPTRST instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMPTRST instruction is not recognized in virtual-8086

mode.

Compatibility Mode Exceptions

#UD The VMPTRST instruction is not recognized in compatibility

mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the destination operand is in the CS, DS, ES, FS, or GS

segments and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory destination

operand.

#SS(0) If the destination operand is in the SS segment and the memory

address is in a non-canonical form.

#UD If operand is a register.

If not in VMX operation.

VMREAD—Read Field from Virtual-Machine Control Structure

Opcode	Instruction	Description
0F 78	VMREAD r/m64, r64	Reads a specified VMCS field (in 64-bit mode).
0F 78	VMREAD r/m32, r32	Reads a specified VMCS field (outside 64-bit mode).

Description

Reads a specified field from the VMCS and stores it into a specified destination operand (register or memory).

The specific VMCS field is identified by the VMCS-field encoding contained in the register source operand. Outside IA-32e mode, the source operand has 32 bits, regardless of the value of CS.D. In 64-bit mode, the source operand has 64 bits; however, if bits 63:32 of the source operand are not zero, VMREAD will fail due to an attempt to access an unsupported VMCS component (see operation section).

The effective size of the destination operand, which may be a register or in memory, is always 32 bits outside IA-32e mode (the setting of CS.D is ignored with respect to operand size) and 64 bits in 64-bit mode. If the VMCS field specified by the source operand is shorter than this effective operand size, the high bits of the destination operand are cleared to 0. If the VMCS field is longer, then the high bits of the field are not read.

Note that any faults resulting from accessing a memory destination operand can occur only after determining, in the operation section below, that the VMCS pointer is valid and that the specified VMCS field is supported.

Operation

```
IF (not in VMX operation) or (RFLAGS.VM = 1) or (IA32_EFER.LMA = 1 and CS.L = 0)
    THEN #UD;

ELSIF in VMX non-root operation
    THEN VMexit;

ELSIF CPL > 0
    THEN #GP(0);

ELSIF current-VMCS pointer is not valid
    THEN VMfaillnvalid;

ELSIF register source operand does not correspond to any VMCS field
    THEN VMfailValid(VMREAD/VMWRITE from/to unsupported VMCS component);
    ELSE
        DEST ← contents of VMCS field indexed by register source operand;
        VMsucceed;
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If the current privilege level is not 0.

If a memory destination operand effective address is outside the

CS, DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the destination operand is located in a read-only data

segment or any code segment.

#PF(fault-code) If a page fault occurs in accessing a memory destination

operand.

#SS(0) If a memory destination operand effective address is outside the

SS segment limit.

If the SS register contains an unusable segment.

#UD If not in VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMREAD instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMREAD instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The VMREAD instruction is not recognized in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If the current privilege level is not 0.

If the memory destination operand is in the CS, DS, ES, FS, or GS segments and the memory address is in a non-canonical

form.

#PF(fault-code) If a page fault occurs in accessing a memory destination

operand.

#SS(0) If the memory destination operand is in the SS segment and the

memory address is in a non-canonical form.

#UD If not in VMX operation.

VMRESUME—Resume Virtual Machine

See VMLAUNCH/VMRESUME—Launch/Resume Virtual Machine.

VMWRITE—Write Field to Virtual-Machine Control Structure

Opcode	Instruction	Description
0F 79	VMWRITE r64, r/m64	Writes a specified VMCS field (in 64-bit mode)
0F 79	VMWRITE r32, r/m32	Writes a specified VMCS field (outside 64-bit mode)

Description

Writes to a specified field in the VMCS specified by a secondary source operand (register only) using the contents of a primary source operand (register or memory).

The VMCS field is identified by the VMCS-field encoding contained in the register secondary source operand. Outside IA-32e mode, the secondary source operand is always 32 bits, regardless of the value of CS.D. In 64-bit mode, the secondary source operand has 64 bits; however, if bits 63:32 of the secondary source operand are not zero, VMWRITE will fail due to an attempt to access an unsupported VMCS component (see operation section).

The effective size of the primary source operand, which may be a register or in memory, is always 32 bits outside IA-32e mode (the setting of CS.D is ignored with respect to operand size) and 64 bits in 64-bit mode. If the VMCS field specified by the secondary source operand is shorter than this effective operand size, the high bits of the primary source operand are ignored. If the VMCS field is longer, then the high bits of the field are cleared to 0.

Note that any faults resulting from accessing a memory source operand occur after determining, in the operation section below, that the VMCS pointer is valid but before determining if the destination VMCS field is supported.

Operation

IF (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or (IA32_EFER.LMA = 1 and CS.L = 0) THEN #UD:

ELSIF in VMX non-root operation

THEN VMexit:

ELSIF CPL > 0

THEN #GP(0);

ELSIF current-VMCS pointer is not valid

THEN VMfailInvalid:

ELSIF register destination operand does not correspond to any VMCS field

THEN VMfailValid(VMREAD/VMWRITE from/to unsupported VMCS component);

ELSIF VMCS field indexed by register destination operand is read-only)

THEN VMfailValid(VMWRITE to read-only VMCS component);

ELSE

VMCS field indexed by register destination operand \leftarrow SRC; VMsucceed:

FI:

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0)If the current privilege level is not 0.

If a memory source operand effective address is outside the CS,

DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the source operand is located in an execute-only code

segment.

#PF(fault-code) If a page fault occurs in accessing a memory source operand. #SS(0) If a memory source operand effective address is outside the SS

segment limit.

If the SS register contains an unusable segment.

#UD If not in VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMWRITE instruction is not recognized

outside VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMWRITE instruction is not recognized in virtual-8086

mode.

Compatibility Mode Exceptions

#UD The VMWRITE instruction is not recognized in compatibility

mode.

64-Bit Mode Exceptions

#GP(0)If the current privilege level is not 0.

> If the memory source operand is in the CS, DS, ES, FS, or GS segments and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing a memory source operand. #SS(0)

If the memory source operand is in the SS segment and the

memory address is in a non-canonical form.

#UD If not in VMX operation.

VMXOFF—Leave VMX Operation

Opcode	Instruction	Description
0F 01 C4	VMXOFF	Leaves VMX operation.

Description

Takes the logical processor out of VMX operation, unblocks INIT signals, conditionally re-enables A20M, and clears any address-range monitoring.¹

Operation

```
IF (not in VMX operation) or (CR0.PE = 0) or (RFLAGS.VM = 1) or (IA32 EFER.LMA = 1 and CS.L = 0)
   THEN #UD:
ELSIF in VMX non-root operation
   THEN VMexit:
ELSIF CPL > 0
   THEN #GP(0):
ELSIF dual-monitor treatment of SMIs and SMM is active
   THEN VMfail(VMXOFF under dual-monitor treatment of SMIs and SMM);
   ELSE
        leave VMX operation;
        unblock INIT;
        IF IA32 SMM MONITOR CTL[2] = 0^2
            THEN unblock SMIs;
        IF outside SMX operation<sup>3</sup>
            THEN unblock and enable A20M:
        FI:
        clear address-range monitoring;
        VMsucceed:
F۱۰
```

^{1.} See the information on MONITOR/MWAIT in Chapter 8, "Multiple-Processor Management," of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

Setting IA32_SMM_MONITOR_CTL[bit 2] to 1 prevents VMXOFF from unblocking SMIs regardless
of the value of the register's value bit (bit 0). Not all processors allow this bit to be set to 1. Software should consult the VMX capability MSR IA32_VMX_MISC (see Appendix G.6) to determine
whether this is allowed.

A logical processor is outside SMX operation if GETSEC[SENTER] has not been executed or if GETSEC[SEXIT] was executed after the last execution of GETSEC[SENTER]. See Chapter 6, "Safer Mode Extensions Reference."

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If executed in VMX root operation with CPL > 0.

#UD If executed outside VMX operation.

Real-Address Mode Exceptions

#UD A logical processor cannot be in real-address mode while in VMX

operation and the VMXOFF instruction is not recognized outside

VMX operation.

Virtual-8086 Mode Exceptions

#UD The VMXOFF instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The VMXOFF instruction is not recognized in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If executed in VMX root operation with CPL > 0.

#UD If executed outside VMX operation.

VMXON—Enter VMX Operation

Opcode	Instruction	Description
F3 0F C7 /6	VMXON m64	Enter VMX root operation.

Description

Puts the logical processor in VMX operation with no current VMCS, blocks INIT signals, disables A20M, and clears any address-range monitoring established by the MONITOR instruction. ¹

The operand of this instruction is a 4KB-aligned physical address (the VMXON pointer) that references the VMXON region, which the logical processor may use to support VMX operation. This operand is always 64 bits and is always in memory.

Operation

```
IF (register operand) or (CR0.PE = 0) or (CR4.VMXE = 0) or (RFLAGS.VM = 1) or (IA32 EFER.LMA = 1
and CS.L = 0)
   THEN #UD:
ELSIF not in VMX operation
   THEN
        IF (CPL > 0) or (in A20M mode) or
        (the values of CRO and CR4 are not supported in VMX operation<sup>2</sup>) or
        (bit 0 (lock bit) of IA32 FEATURE CONTROL MSR is clear) or
        (in SMX operation<sup>3</sup> and bit 1 of IA32 FEATURE CONTROL MSR is clear) or
        (outside SMX operation and bit 2 of IA32 FEATURE CONTROL MSR is clear)
             THEN #GP(0);
             ELSE
                 addr ← contents of 64-bit in-memory source operand;
                 IF addr is not 4KB-aligned or
                 addr sets any bits beyond the physical-address width<sup>4</sup>
                      THEN VMfailInvalid;
```

^{1.} See the information on MONITOR/MWAIT in Chapter 8, "Multiple-Processor Management," of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3A.

^{2.} See Section 19.8 of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B.

^{3.} A logical processor is in SMX operation if GETSEC[SEXIT] has not been executed since the last execution of GETSEC[SENTER]. A logical processor is outside SMX operation if GETSEC[SENTER] has not been executed or if GETSEC[SEXIT] was executed after the last execution of GET-SEC[SENTER]. See Chapter 6, "Safer Mode Extensions Reference."

^{4.} If IA32_VMX_BASIC[48] is read as 1, VMfailInvalid occurs if addr sets any bits in the range 63:32; see Appendix G.1.

```
ELSE
                           rev \leftarrow 32 bits located at physical address addr;
                           IF rev ≠ VMCS revision identifier supported by processor
                               THEN VMfailInvalid:
                               ELSE
                                    current-VMCS pointer ← FFFFFFF FFFFFFH;
                                    enter VMX operation;
                                    block INIT signals;
                                    block and disable A20M;
                                    clear address-range monitoring;
                                    VMsucceed:
                          FI:
                 FI:
        FI:
ELSIF in VMX non-root operation
   THEN VMexit:
FLSIF CPL > 0
   THEN #GP(0):
   ELSE VMfail("VMXON executed in VMX root operation");
FI:
```

Flags Affected

See the operation section and Section 5.2.

Protected Mode Exceptions

#GP(0) If executed outside VMX operation with CPL>0 or with invalid

CR0 or CR4 fixed bits.

If executed in A20M mode.

If the memory source operand effective address is outside the

CS, DS, ES, FS, or GS segment limit.

If the DS, ES, FS, or GS register contains an unusable segment.

If the source operand is located in an execute-only code

segment.

#PF(fault-code) If a page fault occurs in accessing the memory source operand.

#SS(0) If the memory source operand effective address is outside the

SS segment limit.

If the SS register contains an unusable segment.

#UD If operand is a register.

If executed with CR4.VMXE = 0.

Real-Address Mode Exceptions

#UD The VMXON instruction is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD The VMXON instruction is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

#UD The VMXON instruction is not recognized in compatibility mode.

64-Bit Mode Exceptions

#GP(0) If executed outside VMX operation with CPL > 0 or with invalid

CR0 or CR4 fixed bits.

If executed in A20M mode.

If the source operand is in the CS, DS, ES, FS, or GS segments

and the memory address is in a non-canonical form.

#PF(fault-code) If a page fault occurs in accessing the memory source operand.

#SS(0) If the source operand is in the SS segment and the memory

address is in a non-canonical form.

#UD If operand is a register.

If executed with CR4.VMXE = 0.

5.4 VM INSTRUCTION ERROR NUMBERS

For certain error conditions, the VM-instruction error field is loaded with an error number to indicate the source of the error. Table 5-1 lists VM-instruction error numbers.

Table 5-1. VM-Instruction Error Numbers

Error Number	Description		
1	VMCALL executed in VMX root operation		
2	VMCLEAR with invalid physical address		
3	VMCLEAR with VMXON pointer		
4	VMLAUNCH with non-clear VMCS		
5	VMRESUME with non-launched VMCS		
6	VMRESUME after VMXOFF (VMXOFF and VMXON between VMLAUNCH and VMRESUME) ¹		
7	VM entry with invalid control field(s) ^{2,3}		
8	VM entry with invalid host-state field(s) ²		
9	VMPTRLD with invalid physical address		
10	VMPTRLD with VMXON pointer		
11	VMPTRLD with incorrect VMCS revision identifier		
12	VMREAD/VMWRITE from/to unsupported VMCS component		
13	VMWRITE to read-only VMCS component		
15	VMXON executed in VMX root operation		
16	VM entry with invalid executive-VMCS pointer ²		
17	VM entry with non-launched executive VMCS ²		
18	VM entry with executive-VMCS pointer not VMXON pointer (when attempting to deactivate the dual-monitor treatment of SMIs and SMM) ²		
19	VMCALL with non-clear VMCS (when attempting to activate the dual-monitor treatment of SMIs and SMM)		
20	VMCALL with invalid VM-exit control fields		
22	VMCALL with incorrect MSEG revision identifier (when attempting to activate the dual-monitor treatment of SMIs and SMM)		
23	VMXOFF under dual-monitor treatment of SMIs and SMM		
24	VMCALL with invalid SMM-monitor features (when attempting to activate the dual-monitor treatment of SMIs and SMM)		

Table 5-1. VM-Instruction Error Numbers (Contd.)

Error Number	Description
25	VM entry with invalid VM-execution control fields in executive VMCS (when attempting to return from SMM) 2,3
26	VM entry with events blocked by MOV SS.
28	Invalid operand to INVEPT/INVVPID.

NOTES:

- 1. Earlier versions of this manual described this error as "VMRESUME with a corrupted VMCS".
- 2. VM-entry checks on control fields and host-state fields may be performed in any order. Thus, an indication by error number of one cause does not imply that there are not also other errors. Different processors may give different error numbers for the same VMCS.
- 3. Error number 7 is not used for VM entries that return from SMM that fail due to invalid VM-execution control fields in the executive VMCS. Error number 25 is used for these cases.

VMX INSTRUCTION REFERENCE

CHAPTER 6 SAFER MODE EXTENSIONS REFERENCE

6.1 OVERVIEW

This chapter describes the Safer Mode Extensions (SMX) for the Intel 64 and IA-32 architectures. Safer Mode Extensions (SMX) provide a programming interface for system software to establish a measured environment within the platform to support trust decisions by end users. The measured environment includes:

- Measured launch of a system executive, referred to as a Measured Launched Environment (MLE)¹. The system executive may be based on a Virtual Machine Monitor (VMM), a measured VMM is referred to as MVMM².
- Mechanisms to ensure the above measurement is protected and stored in a secure location in the platform.
- Protection mechanisms that allow the VMM to control attempts to modify the VMM

The measurement and protection mechanisms used by a measured environment are supported by the capabilities of an Intel® Trusted Execution Technology (Intel® TXT) platform:

- The SMX are the processor's programming interface in an Intel TXT platform;
- The chipset in an Intel TXT platform provides enforcement of the protection mechanisms;
- Trusted Platform Module (TPM) 1.2 in the platform provides platform configuration registers (PCRs) to store software measurement values.

6.2 SMX FUNCTIONALITY

SMX functionality is provided in an Intel 64 processor through the GETSEC instruction via leaf functions. The GETSEC instruction supports multiple leaf functions. Leaf functions are selected by the value in EAX at the time GETSEC is executed. Each GETSEC leaf function is documented separately in the reference pages with a unique mnemonic (even though these mnemonics share the same opcode, 0F 37).

^{1.} See Intel® Trusted Execution Technology Measured Launched Environment Programming Guide.

^{2.} An MVMM is sometimes referred to as a measured launched environment (MLE). See Intel® Trusted Execution Technology Measured Launched Environment Programming Guide

6.2.1 Detecting and Enabling SMX

Software can detect support for SMX operation using the CPUID instruction. If software executes CPUID with 1 in EAX, a value of 1 in bit 6 of ECX indicates support for SMX operation (GETSEC is available), see CPUID instruction for the layout of feature flags of reported by CPUID.01H:ECX.

System software enables SMX operation by setting CR4.SMXE[Bit 14] = 1 before attempting to execute GETSEC. Otherwise, execution of GETSEC results in the processor signaling an invalid opcode exception (#UD).

If the CPUID SMX feature flag is clear (CPUID.01H.ECX[Bit 6] = 0), attempting to set CR4.SMXE[Bit 14] results in a general protection exception.

The IA32_FEATURE_CONTROL MSR (at address 03AH) provides feature control bits that configure operation of VMX and SMX. These bits are documented in Table 6-1.

Bit Position	Description
0	Lock bit (0 = unlocked, 1 = locked). When set to '1' further writes to this MSR are blocked.
1	Enable VMX in SMX operation
2	Enable VMX outside SMX operation
7:3	Reserved
14:8	SENTER Local Function Enables: When set, each bit in the field represents an enable control for a corresponding SENTER function.
15	SENTER Global Enable: Must be set to '1' to enable operation of GETSEC[SENTER]
63:16	Reserved

Table 6-1. Layout of IA32_FEATURE_CONTROL

- Bit 0 is a lock bit. If the lock bit is clear, an attempt to execute VMXON will cause a general-protection exception. Attempting to execute GETSEC[SENTER] when the lock bit is clear will also cause a general-protection exception. If the lock bit is set, WRMSR to the IA32_FEATURE_CONTROL MSR will cause a general-protection exception. Once the lock bit is set, the MSR cannot be modified until a power-on reset. System BIOS can use this bit to provide a setup option for BIOS to disable support for VMX, SMX or both VMX and SMX.
- Bit 1 enables VMX in SMX operation (between executing the SENTER and SEXIT leaves of GETSEC). If this bit is clear, an attempt to execute VMXON in SMX will cause a general-protection exception if executed in SMX operation. Attempts to set this bit on logical processors that do not support both VMX operation (Chapter 5, "VMX Instruction Reference") and SMX operation cause general-protection exceptions.

- Bit 2 enables VMX outside SMX operation. If this bit is clear, an attempt to
 execute VMXON will cause a general-protection exception if executed outside
 SMX operation. Attempts to set this bit on logical processors that do not support
 VMX operation cause general-protection exceptions.
- Bits 8 through 14 specify enabled functionality of the SENTER leaf function. Each bit in the field represents an enable control for a corresponding SENTER function. Only enabled SENTER leaf functionality can be used when executing SENTER.
- Bits 15 specify global enable of all SENTER functionalities.

6.2.2 SMX Instruction Summary

System software must first query for available GETSEC leaf functions by executing GETSEC[CAPABILITIES]. The CAPABILITIES leaf function returns a bit map of available GETSEC leaves. An attempt to execute an unsupported leaf index results in an undefined opcode (#UD) exception.

6.2.2.1 GETSEC[CAPABILITIES]

The SMX functionality provides an architectural interface for newer processor generations to extend SMX capabilities. Specifically, the GETSEC instruction provides a capability leaf function for system software to discover the available GETSEC leaf functions that are supported in a processor. Table 6-2 lists the currently available GETSEC leaf functions.

Index (EAX)	Leaf function	Description
0	CAPABILITIES	Returns the available leaf functions of the GETSEC instruction
1	Undefined	Reserved
2	ENTERACCS	Enter
3	EXITAC	Exit
4	SENTER	Launch an MLE
5	SEXIT	Exit the MLE
6	PARAMETERS	Return SMX related parameter information
7	SMCTRL	SMX mode control
8	WAKEUP	Wake up sleeping processors in safer mode
9 - (4G-1)	Undefined	Reserved

Table 6-2. GETSEC Leaf Functions

6.2.2.2 GETSEC[ENTERACCS]

The GETSEC[ENTERACCS] leaf enables authenticated code execution mode. The ENTERACCS leaf function performs an authenticated code module load using the chipset public key as the signature verification. ENTERACCS requires the existence of an Intel® Trusted Execution Technology capable chipset since it unlocks the chipset private configuration register space after successful authentication of the loaded module. The physical base address and size of the authenticated code module are specified as input register values in EBX and ECX, respectively.

While in the authenticated code execution mode, certain processor state properties change. For this reason, the time in which the processor operates in authenticated code execution mode should be limited to minimize impact on external system events.

Upon entry into , the previous paging context is disabled (since the authenticated code module image is specified with physical addresses and can no longer rely upon external memory-based page-table structures).

Prior to executing the GETSEC[ENTERACCS] leaf, system software must ensure the logical processor issuing GETSEC[ENTERACCS] is the boot-strap processor (BSP), as indicated by IA32_APIC_BASE.BSP = 1. System software must ensure other logical processors are in a suitable idle state and not marked as BSP.

The GETSEC[ENTERACCS] leaf may be used by different agents to load different authenticated code modules to perform functions related to different aspects of a measured environment, for example system software and Intel® TXT enabled BIOS may use more than one authenticated code modules.

6.2.2.3 GETSEC[EXITAC]

GETSEC[EXITAC] takes the processor out of . When this instruction leaf is executed, the contents of the authenticated code execution area are scrubbed and control is transferred to the non-authenticated context defined by a near pointer passed with the GETSEC[EXITAC] instruction.

The authenticated code execution area is no longer accessible after completion of GETSEC[EXITAC]. RBX (or EBX) holds the address of the near absolute indirect target to be taken.

6.2.2.4 GETSEC[SENTER]

The GETSEC[SENTER] leaf function is used by the initiating logical processor (ILP) to launch an MLE. GETSEC[SENTER] can be considered a superset of the ENTERACCS leaf, because it enters as part of the measured environment launch.

Measured environment startup consists of the following steps:

 the ILP rendezvous the responding logical processors (RLPs) in the platform into a controlled state (At the completion of this handshake, all the RLPs except for the ILP initiating the measured environment launch are placed in a newly defined SENTER sleep state).

- Load and authenticate the authenticated code module required by the measured environment, and enter authenticated code execution mode.
- Verify and lock certain system configuration parameters.
- Measure the dynamic root of trust and store into the PCRs in TPM.
- Transfer control to the MLE with interrupts disabled.

Prior to executing the GETSEC[SENTER] leaf, system software must ensure the platform's TPM is ready for access and the ILP is the boot-strap processor (BSP), as indicated by IA32_APIC_BASE.BSP. System software must ensure other logical processors (RLPs) are in a suitable idle state and not marked as BSP.

System software launching a measurement environment is responsible for providing a proper authenticate code module address when executing GETSEC[SENTER]. The AC module responsible for the launch of a measured environment and loaded by GETSEC[SENTER] is referred to as SINIT. See *Intel® Trusted Execution Technology Measured Launched Environment Programming Guide* for additional information on system software requirements prior to executing GETSEC[SENTER].

6.2.2.5 GETSEC[SEXIT]

System software exits the measured environment by executing the instruction GETSEC[SEXIT] on the ILP. This instruction rendezvous the responding logical processors in the platform for exiting from the measured environment. External events (if left masked) are unmasked and Intel® TXT-capable chipset's private configuration space is re-locked.

6.2.2.6 GETSEC[PARAMETERS]

The GETSEC[PARAMETERS] leaf function is used to report attributes, options and limitations of SMX operation. Software uses this leaf to identify operating limits or additional options.

The information reported by GETSEC[PARAMETERS] may require executing the leaf multiple times using EBX as an index. If the GETSEC[PARAMETERS] instruction leaf or if a specific parameter field is not available, then SMX operation should be interpreted to use the default limits of respective GETSEC leaves or parameter fields defined in the GETSEC[PARAMETERS] leaf.

6.2.2.7 GETSEC[SMCTRL]

The GETSEC[SMCTRL] leaf function is used for providing additional control over specific conditions associated with the SMX architecture. An input register is supported for selecting the control operation to be performed. See the specific leaf description for details on the type of control provided.

6.2.2.8 GETSEC[WAKEUP]

Responding logical processors (RLPs) are placed in the SENTER sleep state after the initiating logical processor executes GETSEC[SENTER]. The ILP can wake up RLPs to join the measured environment by using GETSEC[WAKEUP]. When the RLPs in SENTER sleep state wake up, these logical processors begin execution at the entry point defined in a data structure held in system memory (pointed to by an chipset register LT.MLE.JOIN) in TXT configuration space.

6.2.3 Measured Environment and SMX

This section gives a simplified view of a representative life cycle of a measured environment that is launched by a system executive using SMX leaf functions. *Intel*® *Trusted Execution Technology Measured Launched Environment Programming Guide* provides more detailed examples of using SMX and chipset resources (including chipset registers, Trusted Platform Module) to launch an MVMM.

The life cycle starts with the system executive (an OS, an OS loader, and so forth) loading the MLE and SINIT AC module into available system memory. The system executive must validate and parpare the platform for the measured launch. When the platform is properly configured, the system executive executes GETSEC[SENTER] on the initiating logical processor (ILP) to rendezvous the responding logical processors into an SENTER sleep state, the ILP then enters into using the SINIT AC module. In a multi-threaded or multi-processing environment, the system executive must ensure that other logical processors are already in an idle loop, or asleep (such as after executing HLT) before executing GETSEC[SENTER].

After the GETSEC[SENTER] rendezvous handshake is performed between all logical processors in the platform, the ILP loads the chipset authenticated code module (SINIT) and performs an authentication check. If the check passes, the processor hashes the SINIT AC module and stores the result into TPM PCR 17. It then switches execution context to the SINIT AC module. The SINIT AC module will perform a number of platfom operations, including: verifying the system configuration, protecting the system memory used by the MLE from I/O devices capable of DMA, producing a hash of the MLE, storing the hash value in TPM PCR 18, and various other operations. When SINIT completes execution, it executes the GETSEC[EXITAC] instruction and transfers control the MLE at the designated entry point.

Upon receiving control from the SINIT AC module, the MLE must establish its protection and isolation controls before enabling DMA and interrupts and transferring control to other software modules. It must also wakeup the RLPs from their SENTER sleep state using the GETSEC[WAKEUP] instruction and bring them into its protection and isolation environment.

While executing in a measured environment, the MVMM can access the Trusted Platform Module (TPM) in locality 2. The MVMM has complete access to all TPM commands and may use the TPM to report current measurement values or use the measurement values to protect information such that only when the platform config-

uration registers (PCRs) contain the same value is the information released from the TPM. This protection mechanism is known as sealing.

A measured environment shutdown is ultimately completed by executing GETSEC[SEXIT]. Prior to this step system software is responsible for scrubbing sensitive information left in the processor caches, system memory.

6.3 GETSEC LEAF FUNCTIONS

This section provides detailed descriptions of each leaf function of the GETSEC instruction. GETSEC is available only if CPUID.01H:ECX[Bit 6] = 1. This indicates the availability of SMX and the GETSEC instruction. Before GETSEC can be executed, SMX must be enabled by setting CR4.SMXE[Bit 14] = 1.

A GETSEC leaf can only be used if it is shown to be available as reported by the GETSEC[CAPABILITIES] function. Attempts to access a GETSEC leaf index not supported by the processor, or if CR4.SMXE is 0, results in the signaling of an undefined opcode exception.

All GETSEC leaf functions are available in protected mode, including the compatibility sub-mode of IA-32e mode and the 64-bit sub-mode of IA-32e mode. Unless otherwise noted, the behavior of all GETSEC functions and interactions related to the measured environment are independent of IA-32e mode. This also applies to the interpretation of register widths¹ passed as input parameters to GETSEC functions and to register results returned as output parameters.

The GETSEC functions ENTERACCS, SENTER, SEXIT, and WAKEUP require a Intel® TXT capable-chipset to be present in the platform. The GETSEC[CAPABILITIES] returned bit vector in position 0 indicates an Intel® TXT-capable chipset has been sampled present² by the processor.

The processor's operating mode also affects the execution of the following GETSEC leaf functions: SMCTRL, ENTERACCS, EXITAC, SENTER, SEXIT, and WAKEUP. These functions are only allowed in protected mode at CPL = 0. They are not allowed while in SMM in order to prevent potential intra-mode conflicts. Further execution qualifications exist to prevent potential architectural conflicts (for example: nesting of the measured environment or authenticated code execution mode). See the definitions of the GETSEC leaf functions for specific requirements.

This chapter uses the 64-bit notation RAX, RIP, RSP, RFLAGS, etc. for processor registers because processors that support SMX also support Intel 64 Architecture. The MVMM can be launched in IA-32e mode or outside IA-32e mode. The 64-bit notation of processor registers also refer to its 32-bit forms if SMX is used in 32-bit environment. In some places, notation such as EAX is used to refer specifically to lower 32 bits of the indicated register

Sampled present means that the processor sent a message to the chipset and the chipset
responded that it (a) knows about the message and (b) is capable of executing SENTER. This
means that the chipset CAN support Intel® TXT, and is configured and WILLING to support it.

SAFER MODE EXTENSIONS REFERENCE

For the purpose of performance monitor counting, the execution of GETSEC functions is counted as a single instruction with respect to retired instructions. The response by a responding logical processor (RLP) to messages associated with GETSEC[SENTER] or GTSEC[SEXIT] is transparent to the retired instruction count on the ILP.

GETSEC[CAPABILITIES] - Report the SMX Capabilities	GETSEC[CAPABILITIES]	- Report the	SMX Capabilities
--	-----------------------------	--------------	-------------------------

Opcode	Instruction	Description
0F 37	GETSEC[CAPA	Report the SMX capabilities.
(EAX = 0)	BILITIES]	The capabilities index is input in EBX with the result returned in EAX.

Description

The GETSEC[CAPABILITIES] function returns a bit vector of supported GETSEC leaf functions. The CAPABILITIES leaf of GETSEC is selected with EAX set to 0 at entry. EBX is used as the selector for returning the bit vector field in EAX. GETSEC[CAPABILITIES] may be executed at all privilege levels, but the CR4.SMXE bit must be set or an undefined opcode exception (#UD) is returned.

With EBX = 0 upon execution of GETSEC[CAPABILITIES], EAX returns the a bit vector representing status on the presence of a Intel® TXT-capable chipset and the first 30 available GETSEC leaf functions. The format of the returned bit vector is provided in Table 6-3.

If bit 0 is set to 1, then an Intel® TXT-capable chipset has been sampled present by the processor. If bits in the range of 1-30 are set, then the corresponding GETSEC leaf function is available. If the bit value at a given bit index is 0, then the GETSEC leaf function corresponding to that index is unsupported and attempted execution results in a #UD.

Bit 31 of EAX indicates if further leaf indexes are supported. If the Extended Leafs bit 31 is set, then additional leaf functions are accessed by repeating GETSEC[CAPABILITIES] with EBX incremented by one. When the most significant bit of EAX is not set, then additional GETSEC leaf functions are not supported; indexing EBX to a higher value results in EAX returning zero.

Table 6-3. Getsec Capability Result Encoding (EBX = 0)

Field	Bit position	Description
Chipset Present	0	Intel® TXT-capable chipset is present
Undefined	1	Reserved
ENTERACCS	2	GETSEC[ENTERACCS] is available
EXITAC	3	GETSEC[EXITAC] is available
SENTER	4	GETSEC[SENTER] is available
SEXIT	5	GETSEC[SEXIT] is available

Table 6-3. Getsec Capability Result Encoding (EBX = 0) (Contd.)

Field	Bit position	Description
PARAMETERS	6	GETSEC[PARAMETERS] is available
SMCTRL	7	GETSEC[SMCTRL] is available
WAKEUP	8	GETSEC[WAKEUP] is available
Undefined	30:9	Reserved
Extended Leafs	31	Reserved for extended information reporting of GETSEC capabilities

Operation

```
IF (CR4.SMXE=0)
   THEN #UD;
ELSIF (in VMX non-root operation)
   THEN VM Exit (reason="GETSEC instruction");
IF (EBX=0) THEN
        BitVector\leftarrow 0;
        IF (TXT chipset present)
             BitVector[Chipset present]\leftarrow 1;
        IF (ENTERACCS Available)
             THEN BitVector[ENTERACCS] \leftarrow 1;
        IF (EXITAC Available)
             THEN BitVector[EXITAC]\leftarrow 1;
        IF (SENTER Available)
             THEN BitVector[SENTER]\leftarrow 1;
        IF (SEXIT Available)
             THEN BitVector[SEXIT]\leftarrow 1;
        IF (PARAMETERS Available)
              THEN BitVector[PARAMETERS]\leftarrow 1;
        IF (SMCTRL Available)
             THEN BitVector[SMCTRL]\leftarrow 1;
        IF (WAKEUP Available)
             THEN BitVector[WAKEUP]\leftarrow 1;
        EAX← BitVector:
FLSE
   EAX \leftarrow 0;
END::
```

Flags Affected

None

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD IF CR4.SMXE = 0.

Real-Address Mode Exceptions

#UD IF CR4.SMXE = 0.

Virtual-8086 Mode Exceptions

#UD IF CR4.SMXE = 0.

Compatibility Mode Exceptions

#UD IF CR4.SMXE = 0.

64-Bit Mode Exceptions

#UD IF CR4.SMXE = 0.

VM-exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[ENTERACCS] - Execute Authenticated Chipset Code

Opcode	Instruction	Description
0F 37	GETSEC[ENTERACCS]	Enter authenticated code execution mode.
(EAX = 2)		EBX holds the authenticated code module physical base address. ECX holds the authenticated code module size (bytes).

Description

The GETSEC[ENTERACCS] function loads, authenticates and executes an authenticated code module using an Intel® TXT platform chipset's public key. The ENTERACCS leaf of GETSEC is selected with EAX set to 2 at entry.

There are certain restrictions enforced by the processor for the execution of the GETSEC[ENTERACCS] instruction:

- Execution is not allowed unless the processor is in protected mode or IA-32e mode with CPL = 0 and EFLAGS.VM = 0.
- Processor cache must be available and not disabled, that is, CR0.CD and CR0.NW bits must be 0.
- For processor packages containing more than one logical processor, CR0.CD is checked to ensure consistency between enabled logical processors.
- For enforcing consistency of operation with numeric exception reporting using Interrupt 16, CR0.NE must be set.
- An Intel TXT-capable chipset must be present as communicated to the processor by sampling of the power-on configuration capability field after reset.
- The processor can not already be in authenticated code execution mode as launched by a previous GETSEC[ENTERACCS] or GETSEC[SENTER] instruction without a subsequent exiting using GETSEC[EXITAC]).
- To avoid potential operability conflicts between modes, the processor is not allowed to execute this instruction if it currently is in SMM or VMX operation.
- To insure consistent handling of SIPI messages, the processor executing the GETSEC[ENTERACCS] instruction must also be designated the BSP (boot-strap processor) as defined by A32_APIC_BASE.BSP (Bit 8).

Failure to conform to the above conditions results in the processor signaling a general protection exception.

Prior to execution of the ENTERACCS leaf, other logical processors, i.e. RLPs, in the platform must be:

- idle in a wait-for-SIPI state (as initiated by an INIT assertion or through reset for non-BSP designated processors), or
- in the SENTER sleep state as initiated by a GETSEC[SENTER] from the initiating logical processor (ILP).

If other logical processor(s) in the same package are not idle in one of these states, execution of ENTERACCS signals a general protection exception. The same requirement and action applies if the other logical processor(s) of the same package do not have CR0.CD = 0.

A successful execution of ENTERACCS results in the ILP entering an authenticated code execution mode. Prior to reaching this point, the processor performs several checks. These include:

- Establish and check the location and size of the specified authenticated code module to be executed by the processor.
- Inhibit the ILP's response to the external events: INIT, A20M, NMI and SMI.
- Broadcast a message to enable protection of memory and I/O from other processor agents.
- Load the designated code module into an authenticated code execution area.
- Isolate the contents of the authenticated code execution area from further state modification by external agents.
- Authenticate the authenticated code module.
- Initialize the initiating logical processor state based on information contained in the authenticated code module header.
- Unlock the Intel® TXT-capable chipset private configuration space and TPM locality 3 space.
- Begin execution in the authenticated code module at the defined entry point.

The GETSEC[ENTERACCS] function requires two additional input parameters in the general purpose registers EBX and ECX. EBX holds the authenticated code (AC) module physical base address (the AC module must reside below 4 GBytes in physical address space) and ECX holds the AC module size (in bytes). The physical base address and size are used to retrieve the code module from system memory and load it into the internal authenticated code execution area. The base physical address is checked to verify it is on a modulo-4096 byte boundary. The size is verified to be a multiple of 64, that it does not exceed the internal authenticated code execution area capacity (as reported by GETSEC[CAPABILITIES]), and that the top address of the AC module does not exceed 32 bits. An error condition results in an abort of the authenticated code execution launch and the signaling of a general protection exception.

As an integrity check for proper processor hardware operation, execution of GETSEC[ENTERACCS] will also check the contents of all the machine check status registers (as reported by the MSRs IA32_MCi_STATUS) for any valid uncorrectable error condition. In addition, the global machine check status register IA32_MCG_STATUS MCIP bit must be cleared and the IERR processor package pin (or its equivalent) must not be asserted, indicating that no machine check exception processing is currently in progress. These checks are performed prior to initiating the load of the authenticated code module. Any outstanding valid uncorrectable machine check error condition present in these status registers at this point will result in the processor signaling a general protection violation.

The ILP masks the response to the assertion of the external signals INIT#, A20M, NMI#, and SMI#. This masking remains active until optionally unmasked by GETSEC[EXITAC] (this defined unmasking behavior assumes GETSEC[ENTERACCS] was not executed by a prior GETSEC[SENTER]). The purpose of this masking control is to prevent exposure to existing external event handlers that may not be under the control of the authenticated code module..

The ILP sets an internal flag to indicate it has entered authenticated code execution mode. The state of the A20M pin is likewise masked and forced internally to a deasserted state so that any external assertion is not recognized during authenticated code execution mode.

To prevent other (logical) processors from interfering with the ILP operating in authenticated code execution mode, memory (excluding implicit write-back transactions) access and I/O originating from other processor agents are blocked. This protection starts when the ILP enters into authenticated code execution mode. Only memory and I/O transactions initiated from the ILP are allowed to proceed. Exiting authenticated code execution mode is done by executing GETSEC[EXITAC]. The protection of memory and I/O activities remains in effect until the ILP executes GETSEC[EXITAC].

Prior to launching the authenticated execution module using GETSEC[ENTERACCS] or GETSEC[SENTER], the processor's MTRRs (Memory Type Range Registers) must first be initialized to map out the authenticated RAM addresses as WB (writeback). Failure to do so may affect the ability for the processor to maintain isolation of the loaded authenticated code module. If the processor detected this requirement is not met, it will signal an Intel® TXT reset condition with an error code during the loading of the authenticated code module.

While physical addresses within the load module must be mapped as WB, the memory type for locations outside of the module boundaries must be mapped to one of the supported memory types as returned by GETSEC[PARAMETERS] (or UC as default).

To conform to the minimum granularity of MTRR MSRs for specifying the memory type, authenticated code RAM (ACRAM) is allocated to the processor in 4096 byte granular blocks. If an AC module size as specified in ECX is not a multiple of 4096 then the processor will allocate up to the next 4096 byte boundary for mapping as ACRAM with indeterminate data. This pad area will not be visible to the authenticated code module as external memory nor can it depend on the value of the data used to fill the pad area.

At the successful completion of GETSEC[ENTERACCS], the architectural state of the processor is partially initialized from contents held in the header of the authenticated code module. The processor GDTR, CS, and DS selectors are initialized from fields within the authenticated code module. Since the authenticated code module must be relocatable, all address references must be relative to the authenticated code module base address in EBX. The processor GDTR base value is initialized to the AC module header field GDTBasePtr + module base address held in EBX and the GDTR limit is set to the value in the GDTLimit field. The CS selector is initialized to the AC module header SegSel field, while the DS selector is initialized to CS + 8. The segment

descriptor fields are implicitly initialized to BASE=0, LIMIT=FFFFFh, G=1, D=1, P=1, S=1, read/write access for DS, and execute/read access for CS. The processor begins the authenticated code module execution with the EIP set to the AC module header EntryPoint field + module base address (EBX). The AC module based fields used for initializing the processor state are checked for consistency and any failure results in a shutdown condition.

A summary of the register state initialization after successful completion of GETSEC[ENTERACCS] is given for the processor in Table 6-4. The paging is disabled upon entry into authenticated code execution mode. The authenticated code module is loaded and initially executed using physical addresses. It is up to the system software after execution of GETSEC[ENTERACCS] to establish a new (or restore its previous) paging environment with an appropriate mapping to meet new protection requirements. EBP is initialized to the authenticated code module base physical address for initial execution in the authenticated environment. As a result, the authenticated code can reference EBP for relative address based references, given that the authenticated code module must be position independent.

Table 6-4. Register State Initialization after GETSEC[ENTERACCS]

Register State	Initialization Status	Comment
CR0	PG←0, AM←0, WP←0: Others unchanged	Paging, Alignment Check, Write- protection are disabled
CR4	MCE←0: Others unchanged	Machine Check Exceptions Disabled
EFLAGS	00000002H	
IA32_EFER	ОН	IA-32e mode disabled
EIP	AC.base + EntryPoint	AC.base is in EBX as input to GETSEC[ENTERACCS]
[E R]BX	Pre-ENTERACCS state: Next [E R]IP prior to GETSEC[ENTERACCS]	Carry forward 64-bit processor state across GETSEC[ENTERACCS]
ECX	Pre-ENTERACCS state: [31:16]=GDTR.limit; [15:0]=CS.sel	Carry forward processor state across GETSEC[ENTERACCS]
[E R]DX	Pre-ENTERACCS state: GDTR base	Carry forward 64-bit processor state across GETSEC[ENTERACCS]
EBP	AC.base	
CS	Sel=[SegSel], base=0, limit=FFFFFh, G=1, D=1, AR=9BH	
DS	Sel=[SegSel] +8, base=0, limit=FFFFFh, G=1, D=1, AR=93H	

Register State	Initialization Status	Comment
GDTR	Base= AC.base (EBX) + [GDTBasePtr], Limit=[GDTLimit]	
DR7	00000400Н	
IA32_DEBUGCTL	ОН	
IA32_MISC_ENA BLE	see Table 6-5 for example	The number of initialized fields may change due.to processor implementation

Table 6-4. Register State Initialization after GETSEC[ENTERACCS] (Contd.)

The segmentation related processor state that has not been initialized by GETSEC[ENTERACCS] requires appropriate initialization before use. Since a new GDT context has been established, the previous state of the segment selector values held in ES, SS, FS, GS, TR, and LDTR might not be valid.

The MSR IA32_EFER is also unconditionally cleared as part of the processor state initialized by ENTERACCS. Since paging is disabled upon entering authenticated code execution mode, a new paging environment will have to be reestablished in order to establish IA-32e mode while operating in authenticated code execution mode.

Debug exception and trap related signaling is also disabled as part of GETSEC[ENTERACCS]. This is achieved by resetting DR7, TF in EFLAGs, and the MSR IA32_DEBUGCTL. These debug functions are free to be re-enabled once supporting exception handler(s), descriptor tables, and debug registers have been properly initialized following entry into authenticated code execution mode. Also, any pending single-step trap condition will have been cleared upon entry into this mode.

The IA32_MISC_ENABLE MSR is initialized upon entry into authenticated execution mode. Certain bits of this MSR are preserved because preserving these bits may be important to maintain previously established platform settings (See the footnote for Table 6-5.). The remaining bits are cleared for the purpose of establishing a more consistent environment for the execution of authenticated code modules. One of the impacts of initializing this MSR is any previous condition established by the MONITOR instruction will be cleared.

To support the possible return to the processor architectural state prior to execution of GETSEC[ENTERACCS], certain critical processor state is captured and stored in the general- purpose registers at instruction completion. [E|R]BX holds effective address ([E|R]IP) of the instruction that would execute next after GETSEC[ENTERACCS], ECX[15:0] holds the CS selector value, ECX[31:16] holds the GDTR limit field, and [E|R]DX holds the GDTR base field. The subsequent authenticated code can preserve the contents of these registers so that this state can be manually restored if needed, prior to exiting authenticated code execution mode with GETSEC[EXITAC]. For the processor state after exiting authenticated code execution mode, see the description of GETSEC[SEXIT].

Table 6-5. IA32_MISC_ENALBES MSR Initialization by ENTERACCS and SENTER

Field	Bit position	Description
Fast strings enable	0	Clear to 0
FOPCODE compatibility mode enable	2	Clear to 0
Thermal monitor enable	3	Set to 1 if other thermal monitor capability is not enabled. ²
Split-lock disable	4	Clear to 0
Bus lock on cache line splits disable	8	Clear to 0
Hardware prefetch disable	9	Clear to 0
GV1/2 legacy enable	15	Clear to 0
MONITOR/MWAIT s/m enable	18	Clear to 0
Adjacent sector prefetch disable	19	Clear to 0

NOTES:

- The number of IA32_MISC_ENABLE fields that are initialized may vary due to processor implementations.
- 2. ENTERACCS (and SENTER) initialize the state of processor thermal throttling such that at least a minimum level is enabled. If thermal throttling is already enabled when executing one of these GETSEC leaves, then no change in the thermal throttling control settings will occur. If thermal throttling is disabled, then it will be enabled via setting of the thermal throttle control bit 3 as a result of executing these GETSEC leaves.

The IDTR will also require reloading with a new IDT context after entering authenticated code execution mode, before any exceptions or the external interrupts INTR and NMI can be handled. Since external interrupts are re-enabled at the completion of authenticated code execution mode (as terminated with EXITAC), it is recommended that a new IDT context be established before this point. Until such a new IDT context is established, the programmer must take care in not executing an INT n instruction or any other operation that would result in an exception or trap signaling.

Prior to completion of the GETSEC[ENTERACCS] instruction and after successful authentication of the AC module, the private configuration space of the Intel TXT chipset is unlocked. The authenticated code module alone can gain access to this normally restricted chipset state for the purpose of securing the platform.

Once the authenticated code module is launched at the completion of GETSEC[ENTERACCS], it is free to enable interrupts by setting EFLAGS.IF and enable NMI by execution of IRET. This presumes that it has re-established interrupt handling support through initialization of the IDT, GDT, and corresponding interrupt handling code.

Operation in a Uni-Processor Platform

```
(* The state of the internal flag ACMODEFLAG persists across instruction boundary *)
IF (CR4.SMXE=0)
   THEN #UD;
ELSIF (in VMX non-root operation)
   THEN VM Exit (reason="GETSEC instruction");
ELSIF (GETSEC leaf unsupported)
   THEN #UD:
ELSIF ((in VMX operation) or
   (CR0.PE=0) or (CR0.CD=1) or (CR0.NW=1) or (CR0.NE=0) or
   (CPL>0) or (EFLAGS.VM=1) or
   (IA32_APIC_BASE.BSP=0) or
   (TXT chipset not present) or
   (ACMODEFLAG=1) or (IN SMM=1))
        THEN #GP(0);
IF (GETSEC[PARAMETERS].Parameter_Type = 5, MCA_Handling (bit 6) = 0)
   FOR I = 0 to IA32 MCG CAP.COUNT-1 DO
        IF (IA32_MC[I]_STATUS = uncorrectable error)
            THEN #GP(0);
   OD:
FI:
IF (IA32 MCG STATUS.MCIP=1) or (IERR pin is asserted)
   THEN #GP(0);
ACBASE← EBX;
ACSIZE← ECX:
IF (((ACBASE MOD 4096) != 0) or ((ACSIZE MOD 64 )!= 0 ) or (ACSIZE < minimum module size) OR
(ACSIZE > authenticated RAM capacity)) or ((ACBASE+ACSIZE) > (2^32 -1)))
   THEN #GP(0);
IF (secondary thread(s) CRO.CD = 1) or ((secondary thread(s) NOT(wait-for-SIPI)) and
   (secondary thread(s) not in SENTER sleep state)
   THEN #GP(0);
Mask SMI, INIT, A20M, and NMI external pin events;
IA32_MISC_ENABLE← (IA32_MISC_ENABLE & MASK_CONST*)
(* The hexadecimal value of MASK CONST may vary due to processor implementations *)
A20M← 0;
IA32 DEBUGCTL← 0;
Invalidate processor TLB(s);
Drain Outgoing Transactions;
```

```
ACMODEFLAG \leftarrow 1;
SignalTXTMessage(ProcessorHold);
Load the internal ACRAM based on the AC module size;
(* Ensure that all ACRAM loads hit Write Back memory space *)
IF (ACRAM memory type != WB)
   THEN TXT-SHUTDOWN(#BadACMMTvpe);
IF (AC module header version is not supported) OR (ACRAM[ModuleType] <> 2)
   THEN TXT-SHUTDOWN(#UnsupportedACM);
(* Authenticate the AC Module and shutdown with an error if it fails *)
KEY \leftarrow GETKEY(ACRAM, ACBASE);
KEYHASH← HASH(KEY);
CSKEYHASH← READ(TXT.PUBLIC.KEY);
IF (KEYHASH <> CSKEYHASH)
   THEN TXT-SHUTDOWN(#AuthenticateFail);
SIGNATURE← DECRYPT(ACRAM, ACBASE, KEY);
(* The value of SIGNATURE LEN CONST is implementation-specific*)
FOR I=0 to SIGNATURE LEN CONST - 1 DO
   ACRAM[SCRATCH.I]← SIGNATURE[I];
COMPUTEDSIGNATURE← HASH(ACRAM, ACBASE, ACSIZE);
FOR I=0 to SIGNATURE LEN CONST - 1 DO
   ACRAM[SCRATCH.SIGNATURE LEN CONST+I]← COMPUTEDSIGNATURE[I];
IF (SIGNATURE<>COMPUTEDSIGNATURE)
   THEN TXT-SHUTDOWN(#AuthenticateFail);
ACMCONTROL← ACRAM[CodeControl];
IF ((ACMCONTROL.0 = 0) and (ACMCONTROL.1 = 1) and (snoop hit to modified line detected on
ACRAM load))
   THEN TXT-SHUTDOWN(#UnexpectedHITM):
IF (ACMCONTROL reserved bits are set)
   THEN TXT-SHUTDOWN(#BadACMFormat):
IF ((ACRAM[GDTBasePtr] < (ACRAM[HeaderLen] * 4 + Scratch_size)) OR</pre>
   ((ACRAM[GDTBasePtr] + ACRAM[GDTLimit]) >= ACSIZE))
   THEN TXT-SHUTDOWN(#BadACMFormat):
IF ((ACMCONTROL.0 = 1) and (ACMCONTROL.1 = 1) and (snoop hit to modified line detected on
ACRAM load))
   THEN ACEntryPoint← ACBASE+ACRAM[ErrorEntryPoint];
ELSE
   ACEntryPoint← ACBASE+ACRAM[EntryPoint];
IF ((ACEntryPoint >= ACSIZE) OR (ACEntryPoint < (ACRAM[HeaderLen] * 4 + Scratch size)))THEN
TXT-SHUTDOWN(#BadACMFormat);
IF (ACRAM[GDTLimit] & FFFF0000h)
   THEN TXT-SHUTDOWN(#BadACMFormat);
IF ((ACRAM[SegSel] > (ACRAM[GDTLimit] - 15)) OR (ACRAM[SeqSel] < 8))
   THEN TXT-SHUTDOWN(#BadACMFormat);
IF ((ACRAM[SeqSel].TI=1) OR (ACRAM[SeqSel].RPL!=0))
```

```
THEN TXT-SHUTDOWN(#BadACMFormat);
CR0.[PG.AM.WP] \leftarrow 0;
CR4.MCE← 0:
EFLAGS← 00000002h;
IA32_EFER← 0h;
[E|R]BX← [E|R]IP of the instruction after GETSEC[ENTERACCS];
ECX← Pre-GETSEC[ENTERACCS] GDT.limit:CS.sel;
[E|R]DX← Pre-GETSEC[ENTERACCS] GDT.base;
EBP← ACBASE;
GDTR.BASE← ACBASE+ACRAM[GDTBasePtr];
GDTR.LIMIT← ACRAM[GDTLimit];
CS.SEL← ACRAM[SeqSel];
CS.BASE \leftarrow 0;
CS.LIMIT← FFFFFh;
CS.G \leftarrow 1;
CS.D← 1;
CS.AR← 9Bh;
DS.SEL← ACRAM[SegSel]+8;
DS.BASE← 0;
DS.LIMIT← FFFFFh;
DS.G\leftarrow 1;
DS.D← 1;
DS.AR← 93h;
DR7← 00000400h;
IA32 DEBUGCTL← 0;
SignalTXTMsg(OpenPrivate);
SignalTXTMsg(OpenLocality3);
EIP← ACEntryPoint;
END;
```

Flags Affected

All flags are cleared.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[ENTERACCS] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) If CR0.CD = 1 or CR0.NW = 1 or CR0.NE = 0 or CR0.PE = 0 or

CPL > 0 or EFLAGS.VM = 1.

If a Intel® TXT-capable chipset is not present.

If in VMX root operation.

If the initiating processor is not designated as the bootstrap

processor via the MSR bit IA32_APIC_BASE.BSP.

If the processor is already in authenticated code execution

mode.

If the processor is in SMM.

If a valid uncorrectable machine check error is logged in

IA32_MC[I]_STATUS.

If the authenticated code base is not on a 4096 byte boundary.

If the authenticated code size > processor internal authenti-

cated code area capacity.

If the authenticated code size is not modulo 64.

If other enabled logical processor(s) of the same package

CR0.CD = 1.

If other enabled logical processor(s) of the same package are

not in the wait-for-SIPI or SENTER sleep state.

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[ENTERACCS] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[ENTERACCS] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[ENTERACCS] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[ENTERACCS] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

#GP IF AC code module does not reside in physical address below

2^32 -1.

64-Bit Mode Exceptions

All protected mode exceptions apply.

#GP IF AC code module does not reside in physical address below

2^32 -1.

VM-exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[EXITAC]—Exit Authenticated Code Execution Mode

Opcode	Instruction	Description
0F 37	GETSEC[EXITA	Exit authenticated code execution mode.
(EAX=3)	C]	RBX holds the Near Absolute Indirect jump target and EDX hold the exit parameter flags

Description

The GETSEC[EXITAC] leaf function exits the ILP out of authenticated code execution mode established by GETSEC[ENTERACCS] or GETSEC[SENTER]. The EXITAC leaf of GETSEC is selected with EAX set to 3 at entry. EBX (or RBX, if in 64-bit mode) holds the near jump target offset for where the processor execution resumes upon exiting authenticated code execution mode. EDX contains additional parameter control information. Currently only an input value of 0 in EDX is supported. All other EDX settings are considered reserved and result in a general protection violation.

GETSEC[EXITAC] can only be executed if the processor is in protected mode with CPL = 0 and EFLAGS.VM = 0. The processor must also be in authenticated code execution mode. To avoid potential operability conflicts between modes, the processor is not allowed to execute this instruction if it is in SMM or in VMX operation. A violation of these conditions results in a general protection violation.

Upon completion of the GETSEC[EXITAC] operation, the processor unmasks responses to external event signals INIT#, NMI#, and SMI#. This unmasking is performed conditionally, based on whether the authenticated code execution mode was entered via execution of GETSEC[SENTER] or GETSEC[ENTERACCS]. If the processor is in authenticated code execution mode due to the execution of GETSEC[SENTER], then these external event signals will remain masked. In this case, A20M is kept disabled in the measured environment until the measured environment executes GETSEC[SEXIT]. INIT# is unconditionally unmasked by EXITAC. Note that any events that are pending, but have been blocked while in authenticated code execution mode, will be recognized at the completion of the GETSEC[EXITAC] instruction if the pin event is unmasked.

The intent of providing the ability to optionally leave the pin events SMI#, and NMI# masked is to support the completion of a measured environment bring-up that makes use of VMX. In this envisioned security usage scenario, these events will remain masked until an appropriate virtual machine has been established in order to field servicing of these events in a safer manner. Details on when and how events are masked and unmasked in VMX operation are described in Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. It should be cautioned that if no VMX environment is to be activated following GETSEC[EXITAC], that these events will remain masked until the measured environment is exited with GETSEC[SEXIT]. If this is not desired then the GETSEC function SMCTRL(0) can be used for unmasking SMI# in this context. NMI# can be correspondingly unmasked by execution of IRET.

A successful exit of the authenticated code execution mode requires the ILP to perform additional steps as outlined below:

- Invalidate the contents of the internal authenticated code execution area.
- Invalidate processor TLBs.
- Clear the internal processor AC Mode indicator flag.
- Re-lock the TPM locality 3 space.
- Unlock the Intel® TXT-capable chipset memory and I/O protections to allow memory and I/O activity by other processor agents.
- Perform a near absolute indirect jump to the designated instruction location.

The content of the authenticated code execution area is invalidated by hardware in order to protect it from further use or visibility. This internal processor storage area can no longer be used or relied upon after GETSEC[EXITAC]. Data structures need to be re-established outside of the authenticated code execution area if they are to be referenced after EXITAC. Since addressed memory content formerly mapped to the authenticated code execution area may no longer be coherent with external system memory after EXITAC, processor TLBs in support of linear to physical address translation are also invalidated.

Upon completion of GETSEC[EXITAC] a near absolute indirect transfer is performed with EIP loaded with the contents of EBX (based on the current operating mode size). In 64-bit mode, all 64 bits of RBX are loaded into RIP if REX.W precedes GETSEC[EXITAC]. Otherwise RBX is treated as 32 bits even while in 64-bit mode. Conventional CS limit checking is performed as part of this control transfer. Any exception conditions generated as part of this control transfer will be directed to the existing IDT; thus it is recommended that an IDTR should also be established prior to execution of the EXITAC function if there is a need for fault handling. In addition, any segmentation related (and paging) data structures to be used after EXITAC should be re-established or validated by the authenticated code prior to EXITAC.

In addition, any segmentation related (and paging) data structures to be used after EXITAC need to be re-established and mapped outside of the authenticated RAM designated area by the authenticated code prior to EXITAC. Any data structure held within the authenticated RAM allocated area will no longer be accessible after completion by EXITAC.

Operation

```
(* The state of the internal flag ACMODEFLAG and SENTERFLAG persist across instruction boundary *)

IF (CR4.SMXE=0)

THEN #UD;

ELSIF ( in VMX non-root operation)

THEN VM Exit (reason="GETSEC instruction");

ELSIF (GETSEC leaf unsupported)

THEN #UD;

ELSIF ((in VMX operation) or ( (in 64-bit mode) and ( RBX is non-canonical) )
```

```
(CRO.PE=0) or (CPL>0) or (EFLAGS.VM=1) or
   (ACMODEFLAG=0) or (IN SMM=1)) or (EDX != 0))
   THEN #GP(0);
IF (OperandSize = 32)
   THEN tempEIP← EBX;
ELSIF (OperandSize = 64)
   THEN tempEIP\leftarrow RBX;
ELSE
   tempEIP← EBX AND 0000FFFFH;
IF (tempEIP > code segment limit)
   THEN #GP(0);
Invalidate ACRAM contents:
Invalidate processor TLB(s);
Drain outgoing messages;
SignalTXTMsq(CloseLocality3);
SignalTXTMsg(LockSMRAM);
SignalTXTMsg(ProcessorRelease);
Unmask INIT;
IF (SENTERFLAG=0)
   THEN Unmask SMI, INIT, NMI, and A20M pin event;
ELSEIF (IA32 SMM MONITOR CTL[0] = 0)
   THEN Unmask SMI pin event;
ACMODEFLAG \leftarrow 0;
EIP← tempEIP;
END;
```

Flags Affected

None.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored

REX.W Sets 64-bit mode Operand size attribute

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[EXITAC] is not reported as supported by

GETSEC[CAPABILITIES].

SAFER MODE EXTENSIONS REFERENCE

#GP(0) If CR0.PE = 0 or CPL>0 or EFLAGS.VM =1.

If in VMX root operation.

If the processor is not currently in authenticated code execution

mode.

If the processor is in SMM.

If any reserved bit position is set in the EDX parameter register.

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[EXITAC] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[EXITAC] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[EXITAC] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[EXITAC] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

64-Bit Mode Exceptions

All protected mode exceptions apply.

#GP(0) If the target address in RBX is not in a canonical form.

VM-Exit Condition

Reason (GETSEC) IF in VMX non-root operation.

Opcode	Instruction	Description
0F 37	GETSEC[SENTER]	Launch a measured environment
(EAX=4)		EBX holds the SINIT authenticated code module physical base address.
		ECX holds the SINIT authenticated code module size (bytes).
		EDX controls the level of functionality supported by the measured environment launch.

Description

The GETSEC[SENTER] instruction initiates the launch of a measured environment and places the initiating logical processor (ILP) into the authenticated code execution mode. The SENTER leaf of GETSEC is selected with EAX set to 4 at execution. The physical base address of the AC module to be loaded and authenticated is specified in EBX. The size of the module in bytes is specified in ECX. EDX controls the level of functionality supported by the measured environment launch. To enable the full functionality of the protected environment launch, EDX must be initialized to zero.

The authenticated code base address and size parameters (in bytes) are passed to the GETSEC[SENTER] instruction using EBX and ECX respectively. The ILP evaluates the contents of these registers according to the rules for the AC module address in GETSEC[ENTERACCS]. AC module execution follows the same rules, as set by GETSEC[ENTERACCS].

The launching software must ensure that the TPM.ACCESS_0.activeLocality bit is clear before executing the GETSEC[SENTER] instruction.

There are restrictions enforced by the processor for execution of the GETSEC[SENTER] instruction:

- Execution is not allowed unless the processor is in protected mode or IA-32e mode with CPL = 0 and EFLAGS.VM = 0.
- Processor cache must be available and not disabled using the CR0.CD and NW bits.
- For enforcing consistency of operation with numeric exception reporting using Interrupt 16, CR0.NE must be set.
- An Intel TXT-capable chipset must be present as communicated to the processor by sampling of the power-on configuration capability field after reset.
- The processor can not be in authenticated code execution mode or already in a measured environment (as launched by a previous GETSEC[ENTERACCS] or GETSEC[SENTER] instruction).
- To avoid potential operability conflicts between modes, the processor is not allowed to execute this instruction if it currently is in SMM or VMX operation.

SAFER MODE EXTENSIONS REFERENCE

- To insure consistent handling of SIPI messages, the processor executing the GETSEC[SENTER] instruction must also be designated the BSP (boot-strap processor) as defined by A32_APIC_BASE.BSP (Bit 8).
- EDX must be initialized to a setting supportable by the processor. Unless enumeration by the GETSEC[PARAMETERS] leaf reports otherwise, only a value of zero is supported.

Failure to abide by the above conditions results in the processor signaling a general protection violation.

This instruction leaf starts the launch of a measured environment by initiating a rendezvous sequence for all logical processors in the platform. The rendezvous sequence involves the initiating logical processor sending a message (by executing GETSEC[SENTER]) and other responding logical processors (RLPs) acknowledging the message, thus synchronizing the RLP(s) with the ILP.

In response to a message signaling the completion of rendezvous, RLPs clear the bootstrap processor indicator flag (IA32_APIC_BASE.BSP) and enter an SENTER sleep state. In this sleep state, RLPs enter an idle processor condition while waiting to be activated after a measured environment has been established by the system executive. RLPs in the SENTER sleep state can only be activated by the GETSEC leaf function WAKEUP in a measured environment.

A successful launch of the measured environment results in the initiating logical processor entering the authenticated code execution mode. Prior to reaching this point, the ILP performs the following steps internally:

- Inhibit processor response to the external events: INIT, A20M, NMI, and SMI.
- Establish and check the location and size of the authenticated code module to be executed by the ILP.
- Check for the existence of an Intel® TXT-capable chipset.
- Verify the current power management configuration is acceptable.
- Broadcast a message to enable protection of memory and I/O from activities from other processor agents.
- Load the designated AC module into authenticated code execution area.
- Isolate the content of authenticated code execution area from further state modification by external agents.
- Authenticate the AC module.
- Updated the Trusted Platform Module (TPM) with the authenticated code module's hash.
- Initialize processor state based on the authenticated code module header information.
- Unlock the Intel® TXT-capable chipset private configuration register space and TPM locality 3 space.
- Begin execution in the authenticated code module at the defined entry point.

As an integrity check for proper processor hardware operation, execution of GETSEC[SENTER] will also check the contents of all the machine check status registers (as reported by the MSRs IA32_MCi_STATUS) for any valid uncorrectable error condition. In addition, the global machine check status register IA32_MCG_STATUS MCIP bit must be cleared and the IERR processor package pin (or its equivalent) must be not asserted, indicating that no machine check exception processing is currently in-progress. These checks are performed twice: once by the ILP prior to the broadcast of the rendezvous message to RLPs, and later in response to RLPs acknowledging the rendezvous message. Any outstanding valid uncorrectable machine check error condition present in the machine check status registers at the first check point will result in the ILP signaling a general protection violation. If an outstanding valid uncorrectable machine check error condition is present at the second check point, then this will result in the corresponding logical processor signaling the more severe TXT-shutdown condition with an error code of 12.

Before loading and authentication of the target code module is performed, the processor also checks that the current voltage and bus ratio encodings correspond to known good values supportable by the processor. The MSR IA32_PERF_STATUS values are compared against either the processor supported maximum operating target setting, system reset setting, or the thermal monitor operating target. If the current settings do not meet any of these criteria then the SENTER function will attempt to change the voltage and bus ratio select controls in a processor-specific manner. This adjustment may be to the thermal monitor, minimum (if different), or maximum operating target depending on the processor.

This implies that some thermal operating target parameters configured by BIOS may be overridden by SENTER. The measured environment software may need to take responsibility for restoring such settings that are deemed to be safe, but not necessarily recognized by SENTER. If an adjustment is not possible when an out of range setting is discovered, then the processor will abort the measured launch. This may be the case for chipset controlled settings of these values or if the controllability is not enabled on the processor. In this case it is the responsibility of the external software to program the chipset voltage ID and/or bus ratio select settings to known good values recognized by the processor, prior to executing SENTER.

NOTE

For a mobile processor, an adjustment can be made according to the thermal monitor operating target. For a quad-core processor the SENTER adjustment mechanism may result in a more conservative but non-uniform voltage setting, depending on the pre-SENTER settings per core.

The ILP and RLPs mask the response to the assertion of the external signals INIT#, A20M, NMI#, and SMI#. The purpose of this masking control is to prevent exposure to existing external event handlers until a protected handler has been put in place to directly handle these events. Masked external pin events may be unmasked conditionally or unconditionally via the GETSEC[EXITAC], GETSEC[SEXIT], GETSEC[SMCTRL] or for specific VMX related operations such as a VM entry or the

VMXOFF instruction (see respective GETSEC leaves and *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 3B* for more details). The state of the A20M pin is masked and forced internally to a de-asserted state so that external assertion is not recognized. A20M masking as set by GETSEC[SENTER] is undone only after taking down the measured environment with the GETSEC[SEXIT] instruction or processor reset. INTR is masked by simply clearing the EFLAGS.IF bit. It is the responsibility of system software to control the processor response to INTR through appropriate management of EFLAGS.

To prevent other (logical) processors from interfering with the ILP operating in authenticated code execution mode, memory (excluding implicit write-back transactions) and I/O activities originating from other processor agents are blocked. This protection starts when the ILP enters into authenticated code execution mode. Only memory and I/O transactions initiated from the ILP are allowed to proceed. Exiting authenticated code execution mode is done by executing GETSEC[EXITAC]. The protection of memory and I/O activities remains in effect until the ILP executes GETSEC[EXITAC].

Once the authenticated code module has been loaded into the authenticated code execution area, it is protected against further modification from external bus snoops. There is also a requirement that the memory type for the authenticated code module address range be WB (via initialization of the MTRRs prior to execution of this instruction). If this condition is not satisfied, it is a violation of security and the processor will force a TXT system reset (after writing an error code to the chipset LT.ERROR-CODE register). This action is referred to as a Intel® TXT reset condition. It is performed when it is considered unreliable to signal an error through the conventional exception reporting mechanism.

To conform to the minimum granularity of MTRR MSRs for specifying the memory type, authenticated code RAM (ACRAM) is allocated to the processor in 4096 byte granular blocks. If an AC module size as specified in ECX is not a multiple of 4096 then the processor will allocate up to the next 4096 byte boundary for mapping as ACRAM with indeterminate data. This pad area will not be visible to the authenticated code module as external memory nor can it depend on the value of the data used to fill the pad area.

Once successful authentication has been completed by the ILP, the computed hash is stored in the TPM at PCR17 after this register is implicitly reset. PCR17 is a dedicated register for holding the computed hash of the authenticated code module loaded and subsequently executed by the GETSEC[SENTER]. As part of this process, the dynamic PCRs 18-22 are reset so they can be utilized by subsequently software for registration of code and data modules. After successful execution of SENTER, PCR17 contains the measurement of AC code and the SENTER launching parameters.

After authentication is completed successfully, the private configuration space of the Intel® TXT-capable chipset is unlocked so that the authenticated code module and measured environment software can gain access to this normally restricted chipset state. The Intel® TXT-capable chipset private configuration space can be locked later by software writing to the chipset LT.CMD.CLOSE-PRIVATE register or unconditionally using the GETSEC[SEXIT] instruction.

The SENTER leaf function also initializes some processor architecture state for the ILP from contents held in the header of the authenticated code module. Since the authenticated code module is relocatable, all address references are relative to the base address passed in via EBX. The ILP GDTR base value is initialized to EBX + [GDTBasePtr] and GDTR limit set to [GDTLimit]. The CS selector is initialized to the value held in the AC module header field SegSel, while the DS, SS, and ES selectors are initialized to CS+8. The segment descriptor fields are initialized implicitly with BASE=0, LIMIT=FFFFFh, G=1, D=1, P=1, S=1, read/write/accessed for DS, SS, and ES, while execute/read/accessed for CS. Execution in the authenticated code module for the ILP begins with the EIP set to EBX + [EntryPoint]. AC module defined fields used for initializing processor state are consistency checked with a failure resulting in an TXT-shutdown condition.

Table 6-6 provides a summary of processor state initialization for the ILP and RLP(s) after successful completion of GETSEC[SENTER]. For both ILP and RLP(s), paging is disabled upon entry to the measured environment. It is up to the ILP to establish a trusted paging environment, with appropriate mappings, to meet protection requirements established during the launch of the measured environment. RLP state initialization is not completed until a subsequent wake-up has been signaled by execution of the GETSEC[WAKEUP] function by the ILP.

Table 6-6. Register State Initialization after GETSEC[SENTER] and GETSEC[WAKEUP]

Register State	ILP after GETSEC[SENTER]	RLP after GETSEC[WAKEUP]
CR0	PG←0, AM←0, WP←0; Others unchanged	$\begin{array}{c} PG {\leftarrow} 0, CD {\leftarrow} 0, NW {\leftarrow} 0, AM {\leftarrow} 0, WP {\leftarrow} 0; \\ PE {\leftarrow} 1, NE {\leftarrow} 1 \end{array}$
CR4	00004000H	00004000H
EFLAGS	00000002H	0000002H
IA32_EFER	ОН	0
EIP	[EntryPoint from MLE header ¹]	[LT.MLE.JOIN + 12]
EBX	Unchanged [SINIT.BASE]	Unchanged
EDX	SENTER control flags	Unchanged
EBP	SINIT.BASE	Unchanged
CS	Sel=[SINIT SegSel], base=0, limit=FFFFFh, G=1, D=1, AR=9BH	Sel = [LT.MLE.JOIN + 8], base = 0, limit = FFFFFH, G = 1, D = 1, AR = 9BH
DS, ES, SS	Sel=[SINIT SegSel] +8, base=0, limit=FFFFFh, G=1, D=1, AR=93H	Sel = [LT.MLE.JOIN + 8] +8, base = 0, limit = FFFFFH, G = 1, D = 1, AR = 93H

Table 6-6. Register State Initialization after GETSEC[SENTER] and GETSEC[WAKEUP]

GDTR	Base= SINIT.base (EBX) + [SINIT.GDTBasePtr], Limit=[SINIT.GDTLimit]	Base = [LT.MLE.JOIN + 4], Limit = [LT.MLE.JOIN]
DR7	00000400H	00000400H
IA32_DEBUGC TL	ОН	ОН
Performance counters and counter control registers	ОН	ОН
IA32_MISC_EN ABLE	See Table 6-5	See Table 6-5
IA32_SMM_MO NITOR_CTL	Bit 2←0	Bit 2←0

NOTES:

1. See Intel® Trusted Execution Technology Measured Launched Environment Programming Guide for MLE header format.

Segmentation related processor state that has not been initialized by GETSEC[SENTER] requires appropriate initialization before use. Since a new GDT context has been established, the previous state of the segment selector values held in FS, GS, TR, and LDTR may no longer be valid. The IDTR will also require reloading with a new IDT context after launching the measured environment before exceptions or the external interrupts INTR and NMI can be handled. In the meantime, the programmer must take care in not executing an INT n instruction or any other condition that would result in an exception or trap signaling.

Debug exception and trap related signaling is also disabled as part of execution of GETSEC[SENTER]. This is achieved by clearing DR7, TF in EFLAGs, and the MSR IA32_DEBUGCTL as defined in Table 6-6. These can be re-enabled once supporting exception handler(s), descriptor tables, and debug registers have been properly reinitialized following SENTER. Also, any pending single-step trap condition will be cleared at the completion of SENTER for both the ILP and RLP(s).

Performance related counters and counter control registers are cleared as part of execution of SENTER on both the ILP and RLP. This implies any active performance counters at the time of SENTER execution will be disabled. To reactive the processor performance counters, this state must be re-initialized and re-enabled.

Since MCE along with all other state bits (with the exception of SMXE) are cleared in CR4 upon execution of SENTER processing, any enabled machine check error condition that occurs will result in the processor performing the TXT-shutdown action. This also applies to an RLP while in the SENTER sleep state. For each logical processor

CR4.MCE must be reestablished with a valid machine check exception handler to otherwise avoid an TXT-shutdown under such conditions.

The MSR IA32_EFER is also unconditionally cleared as part of the processor state initialized by SENTER for both the ILP and RLP. Since paging is disabled upon entering authenticated code execution mode, a new paging environment will have to be reestablished if it is desired to enable IA-32e mode while operating in authenticated code execution mode.

The miscellaneous feature control MSR, IA32_MISC_ENABLE, is initialized as part of the measured environment launch. Certain bits of this MSR are preserved because preserving these bits may be important to maintain previously established platform settings. See the footnote for Table 6-5 The remaining bits are cleared for the purpose of establishing a more consistent environment for the execution of authenticated code modules. Among the impact of initializing this MSR, any previous condition established by the MONITOR instruction will be cleared.

Effect of MSR IA32_FEATURE_CONTROL MSR

Bits 15:8 of the IA32_FEATURE_CONTROL MSR affect the execution of GETSEC[SENTER]. These bits consist of two fields:

- Bit 15: a global enable control for execution of SENTER.
- Bits 14:8: a parameter control field providing the ability to qualify SENTER execution based on the level of functionality specified with corresponding EDX parameter bits 6:0.

The layout of these fields in the IA32_FEATURE_CONTROL MSR is shown in Table 6-1.

Prior to the execution of GETSEC[SENTER], the lock bit of IA32_FEATURE_CONTROL MSR must be bit set to affirm the settings to be used. Once the lock bit is set, only a power-up reset condition will clear this MSR. The IA32_FEATURE_CONTROL MSR must be configured in accordance to the intended usage at platform initialization. Note that this MSR is only available on SMX or VMX enabled processors. Otherwise, IA32_FEATURE_CONTROL is treated as reserved.

The Intel® Trusted Execution Technology Measured Launched Environment Programming Guide provides additional details and requirements for programming measured environment software to launch in an Intel TXT platform.

Operation in a Uni-Processor Platform

(* The state of the internal flag ACMODEFLAG and SENTERFLAG persist across instruction boundary *)

GETSEC[SENTER] (ILP only):

IF (CR4.SMXE=0)

THEN #UD:

ELSE IF (in VMX non-root operation)

THEN VM Exit (reason="GETSEC instruction");

ELSE IF (GETSEC leaf unsupported)

THEN #UD:

```
ELSE IF ((in VMX root operation) or
   (CR0.PE=0) or (CR0.CD=1) or (CR0.NW=1) or (CR0.NE=0) or
   (CPL>0) or (EFLAGS.VM=1) or
   (IA32_APIC_BASE.BSP=0) or (TXT chipset not present) or
   (SENTERFLAG=1) or (ACMODEFLAG=1) or (IN_SMM=1) or
   (TPM interface is not present) or
   (EDX != (SENTER EDX support mask & EDX)) or
   (IA32 CR FEATURE CONTROL[0]=0) or (IA32 CR FEATURE CONTROL[15]=0) or
   ((IA32_CR_FEATURE_CONTROL[14:8] & EDX[6:0]) != EDX[6:0]))
       THEN #GP(0);
IF (GETSEC[PARAMETERS].Parameter Type = 5, MCA Handling (bit 6) = 0)
   FOR I = 0 to IA32 MCG CAP.COUNT-1 DO
       IF IA32_MC[I]_STATUS = uncorrectable error
            THEN #GP(0);
       FI;
   OD;
FI:
IF (IA32_MCG_STATUS.MCIP=1) or (IERR pin is asserted)
   THEN #GP(0);
ACBASE← EBX;
ACSIZE← ECX:
IF (((ACBASE MOD 4096) != 0) or ((ACSIZE MOD 64) != 0 ) or (ACSIZE < minimum
   module size) or (ACSIZE > AC RAM capacity) or ((ACBASE+ACSIZE) > (2^32 -1)))
       THEN #GP(0);
Mask SMI, INIT, A20M, and NMI external pin events;
SignalTXTMsq(SENTER);
DO
WHILE (no SignalSENTER message);
TXT_SENTER__MSG_EVENT (ILP & RLP):
Mask and clear SignalSENTER event;
Unmask SignalSEXIT event;
IF (in VMX operation)
   THEN TXT-SHUTDOWN(#IllegalEvent);
FOR I = 0 to IA32 MCG CAP.COUNT-1 DO
   IF IA32_MC[I]_STATUS = uncorrectable error
       THEN TXT-SHUTDOWN(#UnrecovMCError);
   FI;
OD:
IF (IA32_MCG_STATUS.MCIP=1) or (IERR pin is asserted)
   THEN TXT-SHUTDOWN(#UnrecovMCError);
IF (Voltage or bus ratio status are NOT at a known good state)
   THEN IF (Voltage select and bus ratio are internally adjustable)
```

```
THEN
           Make product-specific adjustment on operating parameters;
       ELSE
           TXT-SHUTDOWN(#IllegalVIDBRatio);
FI:
IA32 MISC ENABLE← (IA32 MISC ENABLE & MASK CONST*)
(* The hexadecimal value of MASK CONST may vary due to processor implementations *)
A20M← 0:
IA32 DEBUGCTL← 0;
Invalidate processor TLB(s);
Drain outgoing transactions;
Clear performance monitor counters and control;
SENTERFLAG← 1;
SignalTXTMsq(SENTERAck);
IF (logical processor is not ILP)
   THEN GOTO RLP SENTER ROUTINE;
(* ILP waits for all logical processors to ACK *)
DO
   DONE← TXT.READ(LT.STS);
WHILE (not DONE);
SignalTXTMsg(SENTERContinue);
SignalTXTMsg(ProcessorHold);
FOR I=ACBASE to ACBASE+ACSIZE-1 DO
   ACRAM[I-ACBASE].ADDR \leftarrow I;
   ACRAM[I-ACBASE].DATA← LOAD(I);
OD:
IF (ACRAM memory type != WB)
   THEN TXT-SHUTDOWN(#BadACMMType);
IF (AC module header version is not supported) OR (ACRAM[ModuleType] <> 2)
   THEN TXT-SHUTDOWN(#UnsupportedACM);
KEY← GETKEY(ACRAM, ACBASE);
KEYHASH← HASH(KEY);
CSKEYHASH← LT.READ(LT.PUBLIC.KEY);
IF (KEYHASH <> CSKEYHASH)
   THEN TXT-SHUTDOWN(#AuthenticateFail);
SIGNATURE← DECRYPT(ACRAM, ACBASE, KEY);
(* The value of SIGNATURE LEN CONST is implementation-specific*)
FOR I=0 to SIGNATURE LEN CONST - 1 DO
   ACRAM[SCRATCH.I]← SIGNATURE[I];
COMPUTEDSIGNATURE← HASH(ACRAM, ACBASE, ACSIZE);
FOR I=0 to SIGNATURE LEN CONST - 1 DO
   ACRAM[SCRATCH.SIGNATURE LEN CONST+I]← COMPUTEDSIGNATURE[I];
```

```
IF (SIGNATURE != COMPUTEDSIGNATURE)
   THEN TXT-SHUTDOWN(#AuthenticateFail);
ACMCONTROL← ACRAM[CodeControl];
IF ((ACMCONTROL.0 = 0) and (ACMCONTROL.1 = 1) and (snoop hit to modified line detected on
ACRAM load))
   THEN TXT-SHUTDOWN(#UnexpectedHITM);
IF (ACMCONTROL reserved bits are set)
   THEN TXT-SHUTDOWN(#BadACMFormat);
IF ((ACRAM[GDTBasePtr] < (ACRAM[HeaderLen] * 4 + Scratch_size)) OR
   ((ACRAM[GDTBasePtr] + ACRAM[GDTLimit]) >= ACSIZE))
   THEN TXT-SHUTDOWN(#BadACMFormat);
IF ((ACMCONTROL.0 = 1) and (ACMCONTROL.1 = 1) and (snoop hit to modified
   line detected on ACRAM load))
   THEN ACEntryPoint← ACBASE+ACRAM[ErrorEntryPoint];
ELSE
   ACEntryPoint← ACBASE+ACRAM[EntryPoint];
IF ((ACEntryPoint >= ACSIZE) or (ACEntryPoint < (ACRAM[HeaderLen] * 4 + Scratch_size)))
   THEN TXT-SHUTDOWN(#BadACMFormat):
IF ((ACRAM[SeqSel] > (ACRAM[GDTLimit] - 15)) or (ACRAM[SeqSel] < 8))
   THEN TXT-SHUTDOWN(#BadACMFormat);
IF ((ACRAM[SeqSel].TI=1) or (ACRAM[SeqSel].RPL!=0))
   THEN TXT-SHUTDOWN(#BadACMFormat);
ACRAM[SCRATCH.SIGNATURE_LEN_CONST]← EDX;
WRITE(TPM.HASH.START)← 0:
FOR I=0 to SIGNATURE_LEN_CONST + 3 DO
   WRITE(TPM.HASH.DATA) \leftarrow ACRAM[SCRATCH.I];
WRITE(TPM.HASH.END)\leftarrow 0:
ACMODEFLAG← 1:
CR0.[PG.AM.WP] \leftarrow 0;
CR4← 00004000h:
EFLAGS← 00000002h:
IA32 EFER← 0:
EBP← ACBASE:
GDTR.BASE← ACBASE+ACRAM[GDTBasePtr];
GDTR.LIMIT \leftarrow ACRAM[GDTLimit];
CS.SEL \leftarrow ACRAM[SeaSel]:
CS.BASE \leftarrow 0:
CS.LIMIT← FFFFFh:
CS.G← 1:
CS.D← 1:
CS.AR← 9Bh:
DS.SEL← ACRAM[SeqSel]+8;
DS.BASE\leftarrow 0:
DS.LIMIT← FFFFFh;
```

 $DS.G \leftarrow 1$; $DS.D \leftarrow 1$; $DS.AR \leftarrow 93h$; $SS \leftarrow DS$; $ES \leftarrow DS$:

DR7← 00000400h; IA32_DEBUGCTL← 0;

SignalTXTMsg(UnlockSMRAM); SignalTXTMsg(OpenPrivate); SignalTXTMsg(OpenLocality3);

EIP← ACEntryPoint;

END;

RLP_SENTER_ROUTINE: (RLP only)

Mask SMI, INIT, A20M, and NMI external pin events Unmask SignalWAKEUP event; Wait for SignalSENTERContinue message; IA32_APIC_BASE.BSP← 0; GOTO SENTER sleep state;

END;

Flags Affected

All flags are cleared.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SENTER] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) If CR0.CD = 1 or CR0.NW = 1 or CR0.NE = 0 or CR0.PE = 0 or

CPL > 0 or EFLAGS.VM = 1. If in VMX root operation.

If the initiating processor is not designated as the bootstrap

processor via the MSR bit IA32 APIC BASE.BSP.

If an Intel® TXT-capable chipset is not present.

If an Intel® TXT-capable chipset interface to TPM is not detected as present.

If a protected partition is already active or the processor is already in authenticated code mode.

If the processor is in SMM.

If a valid uncorrectable machine check error is logged in

IA32 MC[I] STATUS.

If the authenticated code base is not on a 4096 byte boundary.

If the authenticated code size > processor's authenticated code

execution area storage capacity.

If the authenticated code size is not modulo 64.

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SENTER] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SENTER] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SENTER] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SENTER] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

#GP IF AC code module does not reside in physical address below

2^32 -1.

64-Bit Mode Exceptions

All protected mode exceptions apply.

#GP IF AC code module does not reside in physical address below

2^32 -1.

VM-Exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[SEXIT]—Exit Measured Environment

Opcode	Instruction	Description
0F 37	GETSEC[SEXIT]	Exit measured environment
(EAX=5)		

Description

The GETSEC[SEXIT] instruction initiates an exit of a measured environment established by GETSEC[SENTER]. The SEXIT leaf of GETSEC is selected with EAX set to 5 at execution. This instruction leaf sends a message to all logical processors in the platform to signal the measured environment exit.

There are restrictions enforced by the processor for the execution of the GETSEC[SEXIT] instruction:

- Execution is not allowed unless the processor is in protected mode (CR0.PE = 1) with CPL = 0 and EFLAGS.VM = 0.
- The processor must be in a measured environment as launched by a previous GETSEC[SENTER] instruction, but not still in authenticated code execution mode.
- To avoid potential inter-operability conflicts between modes, the processor is not allowed to execute this instruction if it currently is in SMM or in VMX operation.
- To insure consistent handling of SIPI messages, the processor executing the GETSEC[SEXIT] instruction must also be designated the BSP (bootstrap processor) as defined by the register bit IA32_APIC_BASE.BSP (bit 8).

Failure to abide by the above conditions results in the processor signaling a general protection violation.

This instruction initiates a sequence to rendezvous the RLPs with the ILP. It then clears the internal processor flag indicating the processor is operating in a measured environment.

In response to a message signaling the completion of rendezvous, all RLPs restart execution with the instruction that was to be executed at the time GETSEC[SEXIT] was recognized. This applies to all processor conditions, with the following exceptions:

- If an RLP executed HLT and was in this halt state at the time of the message initiated by GETSEC[SEXIT], then execution resumes in the halt state.
- If an RLP was executing MWAIT, then a message initiated by GETSEC[SEXIT] causes an exit of the MWAIT state, falling through to the next instruction.
- If an RLP was executing an intermediate iteration of a string instruction, then the
 processor resumes execution of the string instruction at the point which the
 message initiated by GETSEC[SEXIT] was recognized.
- If an RLP is still in the SENTER sleep state (never awakened with GETSEC[WAKEUP]), it will be sent to the wait-for-SIPI state after first clearing

the bootstrap processor indicator flag (IA32_APIC_BASE.BSP) and any pending SIPI state. In this case, such RLPs are initialized to an architectural state consistent with having taken a soft reset using the INIT# pin.

Prior to completion of the GETSEC[SEXIT] operation, both the ILP and any active RLPs unmask the response of the external event signals INIT#, A20M, NMI#, and SMI#. This unmasking is performed unconditionally to recognize pin events which are masked after a GETSEC[SENTER]. The state of A20M is unmasked, as the A20M pin is not recognized while the measured environment is active.

On a successful exit of the measured environment, the ILP re-locks the Intel® TXT-capable chipset private configuration space. GETSEC[SEXIT] does not affect the content of any PCR.

At completion of GETSEC[SEXIT] by the ILP, execution proceeds to the next instruction. Since EFLAGS and the debug register state are not modified by this instruction, a pending trap condition is free to be signaled if previously enabled.

Operation in a Uni-Processor Platform

(* The state of the internal flag ACMODEFLAG and SENTERFLAG persist across instruction boundary *)

```
GETSEC[SEXIT] (ILP only):
IF (CR4.SMXE=0)
   THEN #UD;
ELSE IF (in VMX non-root operation)
   THEN VM Exit (reason="GETSEC instruction");
ELSE IF (GETSEC leaf unsupported)
   THEN #UD;
ELSE IF ((in VMX root operation) or
   (CRO.PE=0) or (CPL>0) or (EFLAGS.VM=1) or
   (IA32 APIC BASE.BSP=0) or
   (TXT chipset not present) or
   (SENTERFLAG=0) or (ACMODEFLAG=1) or (IN SMM=1))
       THEN #GP(0);
SignalTXTMsg(SEXIT);
DO
WHILE (no SignalSEXIT message);
```

TXT_SEXIT_MSG_EVENT (ILP & RLP):

Mask and clear SignalSEXIT event; Clear MONITOR FSM; Unmask SignalSENTER event; IF (in VMX operation) THEN TXT-SHUTDOWN(#IllegalEvent); SignalTXTMsg(SEXITAck); IF (logical processor is not ILP)

```
THEN GOTO RLP SEXIT ROUTINE;
(* ILP waits for all logical processors to ACK *)
DO
   DONE← READ(LT.STS);
WHILE (NOT DONE);
SignalTXTMsq(SEXITContinue);
SignalTXTMsq(ClosePrivate);
SENTERFLAG\leftarrow 0;
Unmask SMI, INIT, A20M, and NMI external pin events;
END:
RLP SEXIT ROUTINE (RLPs only):
Wait for SignalSEXITContinue message;
Unmask SMI, INIT, A20M, and NMI external pin events;
IF (prior execution state = HLT)
   THEN reenter HLT state;
IF (prior execution state = SENTER sleep)
   THFN
        IA32 APIC BASE.BSP← 0;
       Clear pending SIPI state;
       Call INIT PROCESSOR STATE;
       Unmask SIPI event;
       GOTO WAIT-FOR-SIPI:
FI;
END;
```

Flags Affected

ILP: None.

RLPs: all flags are modified for an RLP. returning to wait-for-SIPI state, none otherwise

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXF = 0.

If GETSEC[SEXIT] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) If CR0.PE = 0 or CPL > 0 or EFLAGS.VM = 1.

If in VMX root operation.

If the initiating processor is not designated as the via the MSR

bit IA32 APIC BASE.BSP.

If an Intel® TXT-capable chipset is not present.

If a protected partition is not already active or the processor is

already in authenticated code mode.

If the processor is in SMM.

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SEXIT] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SEXIT] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SEXIT] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SEXIT] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

64-Bit Mode Exceptions

All protected mode exceptions apply.

VM-Exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[PARAMETERS]—Report the SMX Parameters

Opcode	Instruction	Description
0F 37	GETSEC[PARAMETERS]	Report the SMX Parameters
(EAX=6)		The parameters index is input in EBX with the result returned in EAX, EBX, and ECX.

Description

The GETSEC[PARAMETERS] instruction returns specific parameter information for SMX features supported by the processor. Parameter information is returned in EAX, EBX, and ECX, with the input parameter selected using EBX.

Software retrieves parameter information by searching with an input index for EBX starting at 0, and then reading the returned results in EAX, EBX, and ECX. EAX[4:0] is designated to return a parameter type field indicating if a parameter is available and what type it is. If EAX[4:0] is returned with 0, this designates a null parameter and indicates no more parameters are available.

Table 6-7 defines the parameter types supported in current and future implementations.

Table 6-7. SMX Reporting Parameters Format

Parameter Type EAX[4:0]	Parameter Description	EAX[31:5]	EBX[31:0]	ECX[31:0]
0	NULL	Reserved (0 returned)	Reserved (unmodified)	Reserved (unmodified)
1	Supported AC module versions	Reserved (0 returned)	version comparison mask	version numbers supported
2	Max size of authenticated code execution area	Multiply by 32 for size in bytes	Reserved (unmodified)	Reserved (unmodified)
3	External memory types supported during AC mode	Memory type bit mask	Reserved (unmodified)	Reserved (unmodified)

Table 6-7. SMX Reporting Parameters Format (Contd.)

Parameter Type EAX[4:0]	Parameter Description	EAX[31:5]	EBX[31:0]	ECX[31:0]
4	Selective SENTER functionality control	EAX[14:8] correspond to available SENTER function disable controls	Reserved (unmodified)	Reserved (unmodified)
5	TXT extensions support	TXT Feature Extensions Flags (see Table 6-8)	Reserved	Reserved
6-31	Undefined	Reserved (unmodified)	Reserved (unmodified)	Reserved (unmodified)

Table 6-8. TXT Feature Extensions Flags

Bit	Definition	Description
5	Processor based S-CRTM support	Returns 1 if this processor implements a processor- rooted S-CRTM capability and 0 if not (S-CRTM is rooted in BIOS). This flag cannot be used to infer whether the chipset supports TXT or whether the processor support SMX.
6	Machine Check Handling	Returns 1 if it machine check status registers can be preserved through ENTERACCS and SENTER. If this bit is 1, the caller of ENTERACCS and SENTER is not required to clear machine check error status bits before invoking these GETSEC leaves.
		If this bit returns 0, the caller of ENTERACCS and SENTER must clear all machine check error status bits before invoking these GETSEC leaves.
31:7	Reserved	Reserved for future use. Will return 0.

Supported AC module versions (as defined by the AC module HeaderVersion field) can be determined for a particular SMX capable processor by the type 1 parameter. Using EBX to index through the available parameters reported by GETSEC[PARAMETERS] for each unique parameter set returned for type 1, software can determine the complete list of AC module version(s) supported.

For each parameter set, EBX returns the comparison mask and ECX returns the available HeaderVersion field values supported, after AND'ing the target HeaderVersion with the comparison mask. Software can then determine if a particular AC module version is supported by following the pseudo-code search routine given below:

If only AC modules with a HeaderVersion of 0 are supported by the processor, then only one parameter set of type 1 will be returned, as follows: EAX = 00000001H,

```
EBX = FFFFFFFH and ECX = 00000000H.
```

The maximum capacity for an authenticated code execution area supported by the processor is reported with the parameter type of 2. The maximum supported size in bytes is determined by multiplying the returned size in EAX[31:5] by 32. Thus, for a maximum supported authenticated RAM size of 32KBytes, EAX returns with 00008002H.

Supportable memory types for memory mapped outside of the authenticated code execution area are reported with the parameter type of 3. While is active, as initiated by the GETSEC functions SENTER and ENTERACCS and terminated by EXITAC, there are restrictions on what memory types are allowed for the rest of system memory. It is the responsibility of the system software to initialize the memory type range register (MTRR) MSRs and/or the page attribute table (PAT) to only map memory types consistent with the reporting of this parameter. The reporting of supportable memory types of external memory is indicated using a bit map returned in EAX[31:8]. These bit positions correspond to the memory type encodings defined for the MTRR MSR and PAT programming. See Table 6-9.

The parameter type of 4 is used for enumerating the availability of selective GETSEC[SENTER] function disable controls. If a 1 is reported in bits 14:8 of the returned parameter EAX, then this indicates a disable control capability exists with SENTER for a particular function. The enumerated field in bits 14:8 corresponds to use of the EDX input parameter bits 6:0 for SENTER. If an enumerated field bit is set to 1, then the corresponding EDX input parameter bit of EDX may be set to 1 to disable that designated function. If the enumerated field bit is 0 or this parameter is not reported, then no disable capability exists with the corresponding EDX input parameter for SENTER, and EDX bit(s) must be cleared to 0 to enable execution of

SENTER. If no selective disable capability for SENTER exists as enumerated, then the corresponding bits in the IA32_FEATURE_CONTROL MSR bits 14:8 must also be programmed to 1 if the SENTER global enable bit 15 of the MSR is set. This is required to enable future extensibility of SENTER selective disable capability with respect to potentially separate software initialization of the MSR.

Table 6-9. External Memory Types Using Parameter 3

EAX Bit Position	Parameter Description
8	Uncacheable (UC)
9	Write Combining (WC)
11:10	Reserved
12	Write-through (WT)
13	Write-protected (WP)
14	Write-back (WB)
31:15	Reserved

If the GETSEC[PARAMETERS] leaf or specific parameter is not present for a given SMX capable processor, then default parameter values should be assumed. These are defined in Table 6-10.

Table 6-10. Default Parameter Values

Parameter Type EAX[4:0]	Default Setting	Parameter Description
1	0.0 only	Supported AC module versions
2	32 KBytes	Authenticated code execution area size
3	UC only	External memory types supported during AC execution mode
4	None	Available SENTER selective disable controls

Operation

(* example of a processor supporting only a 0.0 Header Version, 32K ACRAM size, memory types UC and WC *)

IF (CR4.SMXE=0)

THEN #UD:

ELSE IF (in VMX non-root operation)

```
THEN VM Exit (reason="GETSEC instruction");
ELSE IF (GETSEC leaf unsupported)
   THEN #UD:
   (* example of a processor supporting a 0.0 HeaderVersion *)
IF (EBX=0) THEN
   EAX← 00000001h;
   EBX← FFFFFFFh:
   ECX← 00000000h;
ELSE IF (EBX=1)
   (* example of a processor supporting a 32K ACRAM size *)
   THEN EAX\leftarrow 00008002h;
ESE IF (EBX= 2)
   (* example of a processor supporting external memory types of UC and WC *)
   THEN EAX← 00000303h:
ESE IF (EBX= other value(s) less than unsupported index value)
   (* EAX value varies. Consult Table 6-7 and Table 6-8*)
ELSE (* unsupported index*)
   EAX" 00000000h:
END;
```

Flags Affected

None.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[PARAMETERS] is not reported as supported by

GETSEC[CAPABILITIES].

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[PARAMETERS] is not reported as supported by

GETSEC[CAPABILITIES].

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[PARAMETERS] is not reported as supported by

GETSEC[CAPABILITIES].

Compatibility Mode Exceptions

All protected mode exceptions apply.

64-Bit Mode Exceptions

All protected mode exceptions apply.

VM-Exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[SMCTRL]—SMX Mode Control

Opcode	Instruction	Description
OF 37 (EAX = 7)	GETSEC[SMCTRL]	Perform specified SMX mode control as selected with the input EBX.

Description

The GETSEC[SMCTRL] instruction is available for performing certain SMX specific mode control operations. The operation to be performed is selected through the input register EBX. Currently only an input value in EBX of 0 is supported. All other EBX settings will result in the signaling of a general protection violation.

If EBX is set to 0, then the SMCTRL leaf is used to re-enable SMI events. SMI is masked by the ILP executing the GETSEC[SENTER] instruction (SMI is also masked in the responding logical processors in response to SENTER rendezvous messages.). The determination of when this instruction is allowed and the events that are unmasked is dependent on the processor context (See Table 6-11). For brevity, the usage of SMCTRL where EBX=0 will be referred to as GETSEC[SMCTRL(0)].

As part of support for launching a measured environment, the SMI, NMI and INIT events are masked after GETSEC[SENTER], and remain masked after exiting authenticated execution mode. Unmasking these events should be accompanied by securely enabling these event handlers. These security concerns can be addressed in VMX operation by a MVMM.

The VM monitor can choose two approaches:

- In a dual monitor approach, the executive software will set up an SMM monitor in parallel to the executive VMM (i.e. the MVMM), see Chapter 26, "System Management" of Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 3B. The SMM monitor is dedicated to handling SMI events without compromising the security of the MVMM. This usage model of handling SMI while a measured environment is active does not require the use of GETSEC[SMCTRL(0)] as event re-enabling after the VMX environment launch is handled implicitly and through separate VMX based controls.
- If a dedicated SMM monitor will not be established and SMIs are to be handled within the measured environment, then GETSEC[SMCTRL(0)] can be used by the executive software to re-enable SMI that has been masked as a result of SENTER.

Table 6-11 defines the processor context in which GETSEC[SMCTRL(0)] can be used and which events will be unmasked. Note that the events that are unmasked are dependent upon the currently operating processor context.

Table 6-11. Supported Actions for GETSEC[SMCTRL(0)]

ILP Mode of Operation	SMCTRL execution action
In VMX non-root operation	VM exit
SENTERFLAG = 0	#GP(0), illegal context
In authenticated code execution mode (ACMODEFLAG = 1)	#GP(0), illegal context
SENTERFLAG = 1, not in VMX operation, not in SMM	Unmask SMI
SENTERFLAG = 1, in VMX root operation, not in SMM	Unmask SMI if SMM monitor is not configured, otherwise #GP(0)
SENTERFLAG = 1, In VMX root operation, in SMM	#GP(0), illegal context

Operation

```
(* The state of the internal flag ACMODEFLAG and SENTERFLAG persist across instruction
boundary *)
IF (CR4.SMXE=0)
   THEN #UD;
ELSE IF (in VMX non-root operation)
   THEN VM Exit (reason="GETSEC instruction");
ELSE IF (GETSEC leaf unsupported)
   THEN #UD:
ELSE IF ((CRO.PE=0) or (CPL>0) OR (EFLAGS.VM=1))
   THEN #GP(0):
ELSE IF((EBX=0) and (SENTERFLAG=1) and (ACMODEFLAG=0) and (IN_SMM=0) and
        (((in VMX root operation) and (SMM monitor not configured)) or (not in VMX operation)))
   THEN unmask SMI;
ELSE
   #GP(0);
FND
```

Flags Affected

None.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SMCTRL] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) If CR0.PE = 0 or CPL > 0 or EFLAGS.VM = 1.

If in VMX root operation.

If a protected partition is not already active or the processor is

currently in authenticated code mode.

If the processor is in SMM.

If the SMM monitor is not configured

Real-Address Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SMCTRL] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SMCTRL] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[SMCTRL] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[SMCTRL] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

64-Bit Mode Exceptions

All protected mode exceptions apply.

VM-exit Condition

Reason (GETSEC) IF in VMX non-root operation.

GETSEC[WAKEUP]—Wake up sleeping processors in measured environment

Opcode	Instruction	Description
OF 37 (EAX=8)	GETSEC[WAKE UP]	Wake up the responding logical processors from the SENTER sleep state.

Description

The GETSEC[WAKEUP] leaf function broadcasts a wake-up message to all logical processors currently in the SENTER sleep state. This GETSEC leaf must be executed only by the ILP, in order to wake-up the RLPs. Responding logical processors (RLPs) enter the SENTER sleep state after completion of the SENTER rendezvous sequence.

The GETSEC[WAKEUP] instruction may only be executed:

- In a measured environment as initiated by execution of GETSEC[SENTER].
- Outside of authenticated code execution mode.
- Execution is not allowed unless the processor is in protected mode with CPL = 0 and EFLAGS.VM = 0.
- In addition, the logical processor must be designated as the boot-strap processor as configured by setting IA32 APIC BASE.BSP = 1.

If these conditions are not met, attempts to execute GETSEC[WAKEUP] result in a general protection violation.

An RLP exits the SENTER sleep state and start execution in response to a WAKEUP signal initiated by ILP's execution of GETSEC[WAKEUP]. The RLP retrieves a pointer to a data structure that contains information to enable execution from a defined entry point. This data structure is located using a physical address held in the Intel® TXT-capable chipset configuration register LT.MLE.JOIN. The register is publicly writable in the chipset by all processors and is not restricted by the Intel® TXT-capable chipset configuration register lock status. The format of this data structure is defined in Table 6-12.

OffsetField0GDT limit4GDT base pointer8Segment selector initializer12EIP

Table 6-12. RLP MVMM JOIN Data Structure

The MLE JOIN data structure contains the information necessary to initialize RLP processor state and permit the processor to join the measured environment. The GDTR, LIP, and CS, DS, SS, and ES selector values are initialized using this data structure. The CS selector index is derived directly from the segment selector initializer field; DS, SS, and ES selectors are initialized to CS+8. The segment descriptor fields are initialized implicitly with BASE = 0, LIMIT = FFFFFH, G = 1, D = 1, P = 1, S = 1; read/write/access for DS, SS, and ES; and execute/read/access for CS. It is the responsibility of external software to establish a GDT pointed to by the MLE JOIN data structure that contains descriptor entries consistent with the implicit settings initialized by the processor (see Table 6-6). Certain states from the content of Table 6-12 are checked for consistency by the processor prior to execution. A failure of any consistency check results in the RLP aborting entry into the protected environment and signaling an Intel® TXT shutdown condition. The specific checks performed are documented later in this section. After successful completion of processor consistency checks and subsequent initialization, RLP execution in the measured environment begins from the entry point at offset 12 (as indicated in Table 6-12).

```
Operation
(* The state of the internal flag ACMODEFLAG and SENTERFLAG persist across instruction
boundary *)
IF (CR4.SMXE=0)
   THEN #UD:
ELSE IF (in VMX non-root operation)
   THEN VM Exit (reason="GETSEC instruction");
ELSE IF (GETSEC leaf unsupported)
   THEN #UD:
ELSE IF ((CRO.PE=0) or (CPL>0) or (EFLAGS.VM=1) or (SENTERFLAG=0) or (ACMODEFLAG=1) or
(IN SMM=0) or (in VMX operation) or (IA32 APIC BASE.BSP=0) or (TXT chipset not present))
   THEN #GP(0);
FI SF
   SignalTXTMsq(WAKEUP);
END;
RLP_SIPI_WAKEUP_FROM_SENTER_ROUTINE: (RLP only)
IF (IA32 SMM MONITOR CTL[0] != ILP.IA32 SMM MONITOR CTL[0])
```

```
WHILE (no SignalWAKEUP event);
   THEN TXT-SHUTDOWN(#IllegalEvent)
IF (IA32 SMM MONITOR CTL[0] = 0)
   THEN Unmask SMI pin event;
ELSE
   Mask SMI pin event;
Mask A20M, and NMI external pin events (unmask INIT);
Mask SignalWAKEUP event;
```

```
Invalidate processor TLB(s);
Drain outgoing transactions;
TempGDTRLIMIT← LOAD(LT.MLE.JOIN);
TempGDTRBASE\leftarrow LOAD(LT.MLE.JOIN+4);
TempSegSel\leftarrow LOAD(LT.MLE.JOIN+8);
TempEIP← LOAD(LT.MLE.|OIN+12);
IF (TempGDTLimit & FFFF0000h)
   THEN TXT-SHUTDOWN(#BadJOINFormat);
IF ((TempSegSel > TempGDTRLIMIT-15) or (TempSegSel < 8))
   THEN TXT-SHUTDOWN(#BadJOINFormat);
IF ((TempSeqSel.TI=1) or (TempSeqSel.RPL!=0))
   THEN TXT-SHUTDOWN(#BadJOINFormat);
CR0.[PG,CD,NW,AM,WP] \leftarrow 0;
CR0.[NE,PE] \leftarrow 1;
CR4← 00004000h;
EFLAGS← 00000002h;
IA32 EFER← 0;
GDTR.BASE← TempGDTRBASE;
GDTR.LIMIT← TempGDTRLIMIT;
CS.SEL← TempSeqSel;
CS.BASE← 0:
CS.LIMIT← FFFFFh;
CS.G \leftarrow 1;
CS.D← 1;
CS.AR← 9Bh;
DS.SEL← TempSeqSel+8;
DS.BASE← 0;
DS.LIMIT← FFFFFh;
DS.G\leftarrow 1;
DS.D← 1:
DS.AR← 93h;
SS \leftarrow DS;
ES← DS;
DR7← 00000400h;
IA32 DEBUGCTL← 0;
EIP← TempEIP;
END;
Flags Affected
```

None.

Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD
Segment overrides Ignored
Address size Ignored
REX Ignored

Protected Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[WAKEUP] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) If CR0.PE = 0 or CPL > 0 or EFLAGS.VM = 1.

If in VMX operation.

If a protected partition is not already active or the processor is

currently in authenticated code mode.

If the processor is in SMM.

#UD If CR4.SMXE = 0.

If GETSEC[WAKEUP] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[WAKEUP] is not recognized in real-address mode.

Virtual-8086 Mode Exceptions

#UD If CR4.SMXE = 0.

If GETSEC[WAKEUP] is not reported as supported by

GETSEC[CAPABILITIES].

#GP(0) GETSEC[WAKEUP] is not recognized in virtual-8086 mode.

Compatibility Mode Exceptions

All protected mode exceptions apply.

64-Bit Mode Exceptions

All protected mode exceptions apply.

VM-exit Condition

Reason (GETSEC) IF in VMX non-root operation.

SAFER MODE EXTENSIONS REFERENCE

Use the opcode tables in this chapter to interpret IA-32 and Intel 64 architecture object code. Instructions are divided into encoding groups:

- 1-byte, 2-byte and 3-byte opcode encodings are used to encode integer, system, MMX technology, SSE/SSE2/SSE3/SSE3/SSE4, and VMX instructions. Maps for these instructions are given in Table A-2 through Table A-6.
- Escape opcodes (in the format: ESC character, opcode, ModR/M byte) are used for floating-point instructions. The maps for these instructions are provided in Table A-7 through Table A-22.

NOTE

All blanks in opcode maps are reserved and must not be used. Do not depend on the operation of undefined or blank opcodes.

A.1 USING OPCODE TABLES

Tables in this appendix list opcodes of instructions (including required instruction prefixes, opcode extensions in associated ModR/M byte). Blank cells in the tables indicate opcodes that are reserved or undefined.

The opcode map tables are organized by hex values of the upper and lower 4 bits of an opcode byte. For 1-byte encodings (Table A-2), use the four high-order bits of an opcode to index a row of the opcode table; use the four low-order bits to index a column of the table. For 2-byte opcodes beginning with 0FH (Table A-3), skip any instruction prefixes, the 0FH byte (0FH may be preceded by 66H, F2H, or F3H) and use the upper and lower 4-bit values of the next opcode byte to index table rows and columns. Similarly, for 3-byte opcodes beginning with 0F38H or 0F3AH (Table A-4), skip any instruction prefixes, 0F38H or 0F3AH and use the upper and lower 4-bit values of the third opcode byte to index table rows and columns. See Section A.2.4, "Opcode Look-up Examples for One, Two, and Three-Byte Opcodes."

When a ModR/M byte provides opcode extensions, this information qualifies opcode execution. For information on how an opcode extension in the ModR/M byte modifies the opcode map in Table A-2 and Table A-3, see Section A.4.

The escape (ESC) opcode tables for floating point instructions identify the eight high order bits of opcodes at the top of each page. See Section A.5. If the accompanying ModR/M byte is in the range of 00H-BFH, bits 3-5 (the top row of the third table on each page) along with the reg bits of ModR/M determine the opcode. ModR/M bytes

outside the range of 00H-BFH are mapped by the bottom two tables on each page of the section.

A.2 KEY TO ABBREVIATIONS

Operands are identified by a two-character code of the form Zz. The first character, an uppercase letter, specifies the addressing method; the second character, a lower-case letter, specifies the type of operand.

A.2.1 Codes for Addressing Method

The following abbreviations are used to document addressing methods:

- A Direct address: the instruction has no ModR/M byte; the address of the operand is encoded in the instruction. No base register, index register, or scaling factor can be applied (for example, far JMP (EA)).
- C The reg field of the ModR/M byte selects a control register (for example, MOV (0F20, 0F22)).
- D The reg field of the ModR/M byte selects a debug register (for example, MOV (0F21,0F23)).
- E A ModR/M byte follows the opcode and specifies the operand. The operand is either a general-purpose register or a memory address. If it is a memory address, the address is computed from a segment register and any of the following values: a base register, an index register, a scaling factor, a displacement.
- F EFLAGS/RFLAGS Register.
- G The reg field of the ModR/M byte selects a general register (for example, AX (000)).
- H The VEX.vvvv field of the VEX prefix selects a 128-bit XMM register or a 256-bit YMM register, determined by operand type. For legacy SSE encodings this operand does not exist, changing the instruction to destructive form.
- I Immediate data: the operand value is encoded in subsequent bytes of the instruction.
- J The instruction contains a relative offset to be added to the instruction pointer register (for example, JMP (0E9), LOOP).
- K Mask registers: rK is reg field, mK is r/m field, vK is vvvv field.
- L The upper 4 bits of the 8-bit immediate selects a 128-bit XMM register or a 256-bit YMM register, determined by operand type.

- M The ModR/M byte may refer only to memory (for example, BOUND, LES, LDS, LSS, LFS, LGS, CMPXCHG8B).
- N The R/M field of the ModR/M byte selects a packed-quadword, MMX technology register.
- O The instruction has no ModR/M byte. The offset of the operand is coded as a word or double word (depending on address size attribute) in the instruction. No base register, index register, or scaling factor can be applied (for example, MOV (A0–A3)).
- P The reg field of the ModR/M byte selects a packed quadword MMX technology register.
- Q A ModR/M byte follows the opcode and specifies the operand. The operand is either an MMX technology register or a memory address. If it is a memory address, the address is computed from a segment register and any of the following values: a base register, an index register, a scaling factor, and a displacement.
- R The R/M field of the ModR/M byte may refer only to a general register (for example, MOV (0F20-0F23)).
- S The reg field of the ModR/M byte selects a segment register (for example, MOV (8C,8E)).
- U The R/M field of the ModR/M byte selects a 128-bit XMM register or a 256-bit YMM register, determined by operand type.
- V The reg field of the ModR/M byte selects a 128-bit XMM register or a 256-bit YMM register, determined by operand type.
- W A ModR/M byte follows the opcode and specifies the operand. The operand is either a 128-bit XMM register, a 256-bit YMM register (determined by operand type), or a memory address. If it is a memory address, the address is computed from a segment register and any of the following values: a base register, an index register, a scaling factor, and a displacement.
- X Memory addressed by the DS:rSI register pair (for example, MOVS, CMPS, OUTS, or LODS).
- Y Memory addressed by the ES:rDI register pair (for example, MOVS, CMPS, INS, STOS, or SCAS).

A.2.2 Codes for Operand Type

The following abbreviations are used to document operand types:

- a Two one-word operands in memory or two double-word operands in memory, depending on operand-size attribute (used only by the BOUND instruction).
- b Byte, regardless of operand-size attribute.
- c Byte or word, depending on operand-size attribute.
- d Doubleword, regardless of operand-size attribute.

- dg Double-quadword, regardless of operand-size attribute.
- p 32-bit, 48-bit, or 80-bit pointer, depending on operand-size attribute.
- pd 128-bit or 256-bit packed double-precision floating-point data.
- pi Quadword MMX technology register (for example: mm0).
- ps 128-bit or 256-bit packed single-precision floating-point data.
- q Quadword, regardless of operand-size attribute.
- qq Quad-Quadword (256-bits), regardless of operand-size attribute.
- s 6-byte or 10-byte pseudo-descriptor.
- sd Scalar element of a 128-bit double-precision floating data.
- ss Scalar element of a 128-bit single-precision floating data.
- si Doubleword integer register (for example: eax).
- Word, doubleword or quadword (in 64-bit mode), depending on operand-size attribute.
- w Word, regardless of operand-size attribute.
- x dq or qq based on the operand-size attribute.
- y Doubleword or quadword (in 64-bit mode), depending on operand-size attribute.
- z Word for 16-bit operand-size or doubleword for 32 or 64-bit operand-size.

A.2.3 Register Codes

When an opcode requires a specific register as an operand, the register is identified by name (for example, AX, CL, or ESI). The name indicates whether the register is 64, 32, 16, or 8 bits wide.

A register identifier of the form eXX or rXX is used when register width depends on the operand-size attribute. eXX is used when 16 or 32-bit sizes are possible; rXX is used when 16, 32, or 64-bit sizes are possible. For example: eAX indicates that the AX register is used when the operand-size attribute is 16 and the EAX register is used when the operand-size attribute is 32. rAX can indicate AX, EAX or RAX.

When the REX.B bit is used to modify the register specified in the reg field of the opcode, this fact is indicated by adding ''x" to the register name to indicate the additional possibility. For example, rCX/r9 is used to indicate that the register could either be rCX or r9. Note that the size of r9 in this case is determined by the operand size attribute (just as for rCX).

A.2.4 Opcode Look-up Examples for One, Two, and Three-Byte Opcodes

This section provides examples that demonstrate how opcode maps are used.

A.2.4.1 One-Byte Opcode Instructions

The opcode map for 1-byte opcodes is shown in Table A-2. The opcode map for 1-byte opcodes is arranged by row (the least-significant 4 bits of the hexadecimal value) and column (the most-significant 4 bits of the hexadecimal value). Each entry in the table lists one of the following types of opcodes:

- Instruction mnemonics and operand types using the notations listed in Section A.2
- Opcodes used as an instruction prefix

For each entry in the opcode map that corresponds to an instruction, the rules for interpreting the byte following the primary opcode fall into one of the following cases:

- A ModR/M byte is required and is interpreted according to the abbreviations listed in Section A.1 and Chapter 2, "Instruction Format," of the *Intel*® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A. Operand types are listed according to notations listed in Section A.2.
- A ModR/M byte is required and includes an opcode extension in the reg field in the ModR/M byte. Use Table A-6 when interpreting the ModR/M byte.
- Use of the ModR/M byte is reserved or undefined. This applies to entries that represent an instruction prefix or entries for instructions without operands that use ModR/M (for example: 60H, PUSHA; 06H, PUSH ES).

Example A-1. Look-up Example for 1-Byte Opcodes

Opcode 030500000000H for an ADD instruction is interpreted using the 1-byte opcode map (Table A-2) as follows:

- The first digit (0) of the opcode indicates the table row and the second digit (3) indicates the table column. This locates an opcode for ADD with two operands.
- The first operand (type Gv) indicates a general register that is a word or doubleword depending on the operand-size attribute. The second operand (type Ev) indicates a ModR/M byte follows that specifies whether the operand is a word or doubleword general-purpose register or a memory address.
- The ModR/M byte for this instruction is 05H, indicating that a 32-bit displacement follows (00000000H). The reg/opcode portion of the ModR/M byte (bits 3-5) is 000, indicating the EAX register.

The instruction for this opcode is ADD EAX, mem_op, and the offset of mem_op is 00000000H.

Some 1- and 2-byte opcodes point to group numbers (shaded entries in the opcode map table). Group numbers indicate that the instruction uses the reg/opcode bits in the ModR/M byte as an opcode extension (refer to Section A.4).

A.2.4.2 Two-Byte Opcode Instructions

The two-byte opcode map shown in Table A-3 includes primary opcodes that are either two bytes or three bytes in length. Primary opcodes that are 2 bytes in length begin with an escape opcode 0FH. The upper and lower four bits of the second opcode byte are used to index a particular row and column in Table A-3.

Two-byte opcodes that are 3 bytes in length begin with a mandatory prefix (66H, F2H, or F3H) and the escape opcode (0FH). The upper and lower four bits of the third byte are used to index a particular row and column in Table A-3 (except when the second opcode byte is the 3-byte escape opcodes 38H or 3AH; in this situation refer to Section A.2.4.3).

For each entry in the opcode map, the rules for interpreting the byte following the primary opcode fall into one of the following cases:

- A ModR/M byte is required and is interpreted according to the abbreviations listed in Section A.1 and Chapter 2, "Instruction Format," of the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 2A*. The operand types are listed according to notations listed in Section A.2.
- A ModR/M byte is required and includes an opcode extension in the reg field in the ModR/M byte. Use Table A-6 when interpreting the ModR/M byte.
- Use of the ModR/M byte is reserved or undefined. This applies to entries that represent an instruction without operands that are encoded using ModR/M (for example: 0F77H, EMMS).

Example A-2. Look-up Example for 2-Byte Opcodes

Look-up opcode 0FA4050000000003H for a SHLD instruction using Table A-3.

- The opcode is located in row A, column 4. The location indicates a SHLD instruction with operands Ev, Gv, and Ib. Interpret the operands as follows:
 - Ev: The ModR/M byte follows the opcode to specify a word or doubleword operand.
 - Gv: The reg field of the ModR/M byte selects a general-purpose register.
 - Ib: Immediate data is encoded in the subsequent byte of the instruction.
- The third byte is the ModR/M byte (05H). The mod and opcode/reg fields of ModR/M indicate that a 32-bit displacement is used to locate the first operand in memory and eAX as the second operand.
- The next part of the opcode is the 32-bit displacement for the destination memory operand (0000000H). The last byte stores immediate byte that provides the count of the shift (03H).

 By this breakdown, it has been shown that this opcode represents the instruction: SHLD DS:00000000H, EAX, 3.

A.2.4.3 Three-Byte Opcode Instructions

The three-byte opcode maps shown in Table A-4 and Table A-5 includes primary opcodes that are either 3 or 4 bytes in length. Primary opcodes that are 3 bytes in length begin with two escape bytes 0F38H or 0F3A. The upper and lower four bits of the third opcode byte are used to index a particular row and column in Table A-4 or Table A-5.

Three-byte opcodes that are 4 bytes in length begin with a mandatory prefix (66H, F2H, or F3H) and two escape bytes (0F38H or 0F3AH). The upper and lower four bits of the fourth byte are used to index a particular row and column in Table A-4 or Table A-5.

For each entry in the opcode map, the rules for interpreting the byte following the primary opcode fall into the following case:

 A ModR/M byte is required and is interpreted according to the abbreviations listed in A.1 and Chapter 2, "Instruction Format," of the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A. The operand types are listed according to notations listed in Section A.2.

Example A-3. Look-up Example for 3-Byte Opcodes

Look-up opcode 660F3A0FC108H for a PALIGNR instruction using Table A-5.

- 66H is a prefix and 0F3AH indicate to use Table A-5. The opcode is located in row 0, column F indicating a PALIGNR instruction with operands Vdq, Wdq, and Ib. Interpret the operands as follows:
 - Vdq: The reg field of the ModR/M byte selects a 128-bit XMM register.
 - Wdq: The R/M field of the ModR/M byte selects either a 128-bit XMM register or memory location.
 - Ib: Immediate data is encoded in the subsequent byte of the instruction.
- The next byte is the ModR/M byte (C1H). The reg field indicates that the first operand is XMM0. The mod shows that the R/M field specifies a register and the R/M indicates that the second operand is XMM1.
- The last byte is the immediate byte (08H).
- By this breakdown, it has been shown that this opcode represents the instruction: PALIGNR XMM0, XMM1, 8.

A.2.4.4 VEX Prefix Instructions

Instructions that include a VEX prefix are organized relative to the 2-byte and 3-byte opcode maps, based on the VEX.mmmmm field encoding of implied 0F, 0F38H, 0F3AH, respectively. Each entry in the opcode map of a VEX-encoded instruction is based on the value of the opcode byte, similar to non-VEX-encoded instructions.

A VEX prefix includes several bit fields that encode implied 66H, F2H, F3H prefix functionality (VEX.pp), operand order (VEX.W), and operand size/opcode information (VEX.L). See section ### for details.

Opcode tables A2-A5 include instructions which do not include a VEX prefix. Opcode tables A6-A8 contain instructions which must include a VEX prefix. In the VEX opcode tables, where the VEX.pp, VEX.W, and VEX.L information differentiates instructions it is indicated by the general notation (vPPwL). Non-VEX-encoded instructions that require mandatory 66H, F2H, F3H prefix functionality before the opcode have used the form (PP), PP = 66, F2, F3, or white space. The parts of the VEX vPPwL notation should be interpreted as follows:

- v Indicates a VEX prefix encoding is required (vpsrlw in table A9). "v" is not shown but a VEX prefix is required for instructions in separate VEX tables (A6, A7 and A8).
- PP The value of none, 66, F2, or F3, indicates the VEX.pp field must be encoded accordingly. For non-VEX instructions this is with the legacy prefix. For VEX instructions this encoding is with the embedded "PP" field.
- w If the instruction uses VEX.W to determine operand order, the presence of the lower case 'w' indicates that the VEX.W=1 and the absence indicates VEX.W=0.
- L When VEX.L is used as an opcode extension rather than indicating operand size (VZEROALL, VZEROUPPER), presence of 'L' indicates VEX.L=1 and absence indicates VEX.L=0.

Operand size of VEX prefix instructions can be determined by the operand type code. 128-bit vectors are indicated by 'dq', 256-bit vectors are indicated by 'qq', and instructions with operands supporting either 128 or 256-bit, determined by VEX.L, are indicated by 'x'.

The entry "VMOVUPD Vx,Wx" indicates both VEX.L=0 and VEX.L=1 are supported, because VEX.L=0 and the operand notation Vx, indicate the destination operand can be 256-bit YMM register or 128-bit XMM register.

A.2.5 Superscripts Utilized in Opcode Tables

Table A-1 contains notes on particular encodings. These notes are indicated in the following opcode maps by superscripts. Gray cells indicate instruction groupings.

Superscript Symbol	Meaning of Symbol
1A	Bits 5, 4, and 3 of ModR/M byte used as an opcode extension (refer to Section A.4, "Opcode Extensions For One-Byte And Two-byte Opcodes").
1B	Use the OFOB opcode (UD2 instruction) or the OFB9H opcode when deliberately trying to generate an invalid opcode exception (#UD)

Table A-1. Superscripts Utilized in Opcode Tables

Table A-1. Superscripts Utilized in Opcode Tables

Superscript Symbol	Meaning of Symbol
1C	Some instructions added in the Pentium III processor may use the same two- byte opcode. If the instruction has variations, or the opcode represents different instructions, the ModR/M byte will be used to differentiate the instruction. For the value of the ModR/M byte needed to decode the instruction, see Table A-6.
	These instructions include SFENCE, STMXCSR, LDMXCSR, FXRSTOR, and FXSAVE, as well as PREFETCH and its variations.
i64	The instruction is invalid or not encodable in 64-bit mode. 40 through 4F (single-byte INC and DEC) are REX prefix combinations when in 64-bit mode (use FE/FF Grp 4 and 5 for INC and DEC).
o64	Instruction is only available when in 64-bit mode.
d64	When in 64-bit mode, instruction defaults to 64-bit operand size and cannot encode 32-bit operand size.
f64	The operand size is forced to a 64-bit operand size when in 64-bit mode (prefixes that change operand size are ignored for this instruction in 64-bit mode).
V	VEX form only exists. There is no legacy SSE form of the instruction.
v1	VEX128 $\&$ SSE forms only exist (no VEX256), when can't be inferred from the data size.

A.3 ONE, TWO, AND THREE-BYTE OPCODE MAPS

See Table A-2 through Table A-5 below. The tables are multiple page presentations. Rows and columns with sequential relationships are placed on facing pages to make look-up tasks easier. Note that table footnotes are not presented on each page. Table footnotes for each table are presented on the last page of the table.

This page intentionally left blank

Table A-2. One-byte Opcode Map: (00H — F7H) *

	0	1	2	3	4	5	6	7	
0	Eb, Gb	Ev, Gv	AD Gb, Eb	D Gv, Ev	AL, Ib	rAX, Iz	PUSH ES ⁱ⁶⁴	POP ES ⁱ⁶⁴	
1	Eb, Gb	Ev, Gv	AD Gb, Eb	C Gv, Ev	AL, Ib	rAX, Iz	PUSH SS ¹⁶⁴	POP SS ⁱ⁶⁴	
2	Eb, Gb	Ev, Gv	AN Gb, Eb	D Gv, Ev	AL, Ib	rAX, Iz	SEG=ES (Prefix)	DAA ^{I64}	
3	Eb, Gb	Ev, Gv	Gb, Eb	Gv, Ev	AL, Ib	rAX, Iz	SEG=SS (Prefix)	AAA ⁱ⁶⁴	
4			INC	³⁴ general regis	ster / REX ⁰⁶⁴ Pr	refixes			
	eAX REX	eCX REX.B	eDX REX.X	eBX REX.XB	eSP REX.R	eBP REX.RB	eSI REX.RX	eDI REX.RXB	
5				PUSH ^{d64} ge	eneral register				
	rAX/r8	rCX/r9	rDX/r10	rBX/r11	rSP/r12	rBP/r13	rSI/r14	rDI/r15	
6	PUSHA ⁱ⁶⁴ / PUSHAD ⁱ⁶⁴	Popa ⁱ⁶⁴ / Popad ⁱ⁶⁴	BOUND ⁱ⁶⁴ Gv, Ma	ARPL ⁱ⁶⁴ Ew, Gw MOVSXD ⁰⁶⁴ Gv, Ev	SEG=FS (Prefix)	SEG=GS (Prefix)	Operand Size (Prefix)	Address Size (Prefix)	
7	Jcc ^{f64} , Jb - Short-displacement jump on condition								
	0	NO	B/NAE/C	NB/AE/NC	Z/E	NZ/NE	BE/NA	NBE/A	
8		Immedia	te Grp 1 ^{1A}		TE	ST	X	CHG	
	Eb, lb	Ev, Iz	Eb, Ib ⁱ⁶⁴	Ev, Ib	Eb, Gb	Ev, Gv	Eb, Gb	Ev, Gv	
9	NOP		XCH	G word, double	e-word or quad-v	word register wi	th rAX		
	PAUSE(F3) XCHG r8, rAX	rCX/r9	rDX/r10	rBX/r11	rSP/r12	rBP/r13	rSI/r14	rDI/r15	
A	AL, Ob	rAX, Ov	OV Ob, AL	Ov, rAX	MOVS/B Xb, Yb	MOVS/W/D/Q Xv, Yv	CMPS/B Xb, Yb	CMPS/W/D Xv, Yv	
В			MC	V immediate b	yte into byte reg	gister			
	AL/R8L, Ib	CL/R9L, Ib	DL/R10L, lb	BL/R11L, lb	AH/R12L, Ib	CH/R13L, lb	DH/R14L, lb	BH/R15L, lb	
С	Shift G Eb, lb	Ev, Ib	RETN ^{f64} lw	RETN ^{f64}	LES ⁱ⁶⁴ Gz, MpVEX+2byte	LDS ⁱ⁶⁴ Gz, Mp VEX+1byte	Grp 11 Eb, lb	^{1A} - MOV Ev, Iz	
D	Eb, 1	Shift (Ev, 1	Grp 2 ^{1A} Eb, CL	Ev, CL	AAM ⁱ⁶⁴ Ib	AAD ⁱ⁶⁴ Ib		XLAT/ XLATB	
E	LOOPNE ^{f64} / LOOPNZ ^{f64} Jb	LOOPE ^{f64} / LOOPZ ^{f64} Jb	LOOP ^{f64} Jb	JrCXZ ^{f64} / Jb	AL, lb	eAX, lb	Ib, AL	DUT lb, eAX	
F	LOCK (Prefix)		REPNE (Prefix)	REP/REPE (Prefix)	HLT	CMC	Unary Eb	Grp 3 ^{1A} Ev	

Table A-2. One-byte Opcode Map: (08H — FFH) *

	8	9	Α	В	С	D	Е	F
0	Eb, Gb	Ev, Gv	C Gb, Eb	Gv, Ev	AL, Ib	rAX, Iz	PUSH CS ⁱ⁶⁴	2-byte escape (Table A-3)
1	Eb, Gb	Ev, Gv	SI Gb, Eb	Gv, Ev	AL, Ib	rAX, Iz	PUSH DS ¹⁶⁴	POP DS ¹⁶⁴
2	Eb, Gb	Ev, Gv	SI Gb, Eb	JB Gv, Ev	AL, Ib	rAX, Iz	SEG=CS (Prefix)	DAS ¹⁶⁴
3	Eb, Gb	Ev, Gv	Cf Gb, Eb	MP Gv, Ev	AL, Ib	rAX, Iz	SEG=DS (Prefix)	AAS ¹⁶⁴
4			DEC	⁶⁴ general regis	ter / REX ⁰⁶⁴ Pr	efixes		
	eAX REX.W	eCX REX.WB	eDX REX.WX	eBX REX.WXB	eSP REX.WR	eBP REX.WRB	eSI REX.WRX	eDI REX.WRXB
5				POP ^{d64} into g	eneral register			
	rAX/r8	rCX/r9	rDX/r10	rBX/r11	rSP/r12	rBP/r13	rSI/r14	rDI/r15
6	PUSH ^{d64} Iz	IMUL Gv, Ev, Iz	PUSH ^{d64} lb	IMUL Gv, Ev, Ib	INS/ INSB Yb, DX	INS/ INSW/ INSD Yz, DX	OUTS/ OUTSB DX, Xb	OUTS/ OUTSW/ OUTSD DX, Xz
7		•	Jcc ^{f64} , Jl	b- Short displac	ement jump on	condition		
	S	NS	P/PE	NP/PO	L/NGE	NL/GE	LE/NG	NLE/G
8		M	OV		MOV	LEA	MOV	Grp 1A ^{1A} POP ^{d64} Ev
	Eb, Gb	Ev, Gv	Gb, Eb	Gv, Ev	Ev, Sw	Gv, M	Sw, Ew	POPTOEV
9	CBW/ CWDE/ CDQE	CWD/ CDQ/ CQO	CALLF ⁱ⁶⁴ Ap	FWAIT/ WAIT	PUSHF/D/Q d64/ Fv	POPF/D/Q d64/ Fv	SAHF	LAHF
А	TE AL, Ib	ST rAX, lz	STOS/B Yb, AL	STOS/W/D/Q Yv, rAX	LODS/B AL, Xb	LODS/W/D/Q rAX, Xv	SCAS/B AL, Yb	SCAS/W/D/Q rAX, Xv
В		MC	OV immediate v	vord or double in	nto word, double	e, or quad regis	ter	
	rAX/r8, Iv	rCX/r9, Iv	rDX/r10, lv	rBX/r11, lv	rSP/r12, Iv	rBP/r13, Iv	rSI/r14, Iv	rDI/r15 , lv
С	ENTER	LEAVE ^{d64}	RETF	RETF	INT 3	INT	INTO ⁱ⁶⁴	IRET/D/Q
	lw, lb		lw			lb		
D			ESC (I	Escape to copro	cessor instructi	on set)		
E	CALL ^{f64} JMP				II	N	OUT	
	Jz	near ^{f64} Jz	far ⁱ⁶⁴ Ap	short ^{f64} Jb	AL, DX	eAX, DX	DX, AL	DX, eAX
F	CLC	STC	CLI	STI	CLD	STD	INC/DEC Grp 4 ^{1A}	INC/DEC Grp 5 ^{1A}

NOTES:

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

Table A-3. Two-byte Opcode Map: 00H — 77H (First Byte is 0FH) *

	pfx	0	1	2	3	4	5	6	7
0		Grp 6 ^{1A}	Grp 7 ^{1A}	LAR Gv, Ew	LSL Gv, Ew		SYSCALL ⁰⁶⁴	CLTS	SYSRET ⁰⁶⁴
		vmovups Vps, Wps	vmovups Wps, Vps	vmovlps Vq, Hq, Mq vmovhlps Vq, Hq, Uq	vmovlps Mq, Vq	vunpcklps Vps, Wq Vx, Hx, Wx	vunpckhps Vps, Wq Vx, Hx, Wx	vmovhps ^{v1} Vdq, Hq, Mq vmovlhps Vdq, Hq, Uq	vmovhps ^{v1} Mq, Vq
1	66	vmovupd Vpd, Wpd	vmovupd Wpd,Vpd	vmovlpd Vq, Hq, Mq	vmovlpd Mq, Vq	vunpcklpd Vpd,WqVx,Hx,Wx	vunpckhpd Vpd,WqVx,Hx,Wx	vmovhpd ^{v1} Vdq, Hq, Mq	vmovhpd ^{v1} Mq, Vq
	F3	vmovss Vss, Wss Mss, Hss, Vss	vmovss Wss, Vss Mss, Hss, Vss	vmovsldup Vq, Wq Vx, Wx				vmovshdup Vq, Wq Vx, Wx	
	F2	vmovsd Vsd, Wsd Vsd, Hsd, Msd	vmovsd Vsd, Wsd Vsd, Hsd, Msd	vmovddup Vq, Wq Vx, Wx					
		MOV Rd, Cd	MOV Rd, Dd	MOV Cd, Rd	MOV Dd, Rd				
2	2								
3	3	WRMSR	RDTSC	RDMSR	RDPMC	SYSENTER	SYSEXIT		GETSEC
4	4			С	MOVcc, (Gv, Ev	/) - Conditional Me	ove	•	
4	4	0	NO	B/C/NAE	AE/NB/NC	E/Z	NE/NZ	BE/NA	A/NBE
		vmovmskps Gy, Ups	vsqrtps Vps, Wps	vrsqrtps Vps, Wps	vrcpps Vps, Wps	vandps Vps, Hps, Wps	vandnps Vps, Hps, Wps	vorps Vps, Hps, Wps	vxorps Vps, Hps, Wps
5	66	vmovmskpd Gy,Upd	vsqrtpd Vpd,Wpd			vandpd Wpd, Hpd, Vpd	vandnpd Wpd, Hpd, Vpd	vorpd Wpd, Hpd, Vpd	vxorpd Wpd, Hpd, Vpd
	F3		vsqrtss Vss, Hss, Wss	vrsqrtss Vss, Hss, Wss	vrcpss Vss, Hss, Wss				
	F2		vsqrtsd Vsd, Hsd, Wsd						
		punpcklbw Pq, Qd	punpcklwd Pq, Qd	punpckldq Pq, Qd	packsswb Pq, Qq	pcmpgtb Pq, Qq	pcmpgtw Pq, Qq	pcmpgtd Pq, Qq	packuswb Pq, Qq
6	66	vpunpcklbw Vdq, Hdq, Wdq	vpunpcklwd Vdq, Hdq, Wdq	vpunpckldq Vdq, Hdq, Wdq	vpacksswb Vdq, Hdq,Wdq	vpcmpgtb Vdq, Hdq, Wdq	vpcmpgtw Vdq, Hdq, Wdq	vpcmpgtd Vdq, Hdq, Wdq	vpackuswb Vdq, Hdq, Wdq
	F3								
		pshufw Pq, Qq, Ib	(Grp 12 ^{1A})	(Grp 13 ^{1A})	(Grp 14 ^{1A})	pcmpeqb Pq, Qq	pcmpeqw Pq, Qq	pcmpeqd Pq, Qq	emmsvzeroupp er ^v vzeroall(L) ^v
7	66	vpshufd Vdq,Wdq,Ib				vpcmpeqb Vdq, Hdq, Wdq	vpcmpeqw Vdq, Hdq, Wdq	vpcmpeqd Vdq, Hdq, Wdq	
	F3	vpshufhw Vdq,Wdq,Ib							
	F2	vpshuflw Vdq,Wdq,Ib							

Table A-3. Two-byte Opcode Map: 08H - 7FH (First Byte is 0FH) *

	pfx	8	9	Α	В	С	D	Е	F
0		INVD	WBINVD		2-byte Illegal Opcodes UD2 ^{1B}		NOP Ev		
1		Prefetch ^{1C} (Grp 16 ^{1A})							NOP Ev
		vmovaps Vps, Wps	vmovaps Wps, Vps	cvtpi2ps Vps, Qpi	vmovntps Mps, Vps	cvttps2pi Ppi, Wps	cvtps2pi Ppi, Wps	vucomiss Vss, Wss	vcomiss Vss, Wss
	66	vmovapd Vpd, Wpd	vmovapd Wpd,Vpd	cvtpi2pd Vpd, Qpi	vmovntpd Mpd, Vpd	cvttpd2pi Ppi, Wpd	cvtpd2pi Qpi, Wpd	vucomisd Vsd, Wsd	vcomisd Vsd, Wsd
2	F3			vcvtsi2ss Vss, Hss, Ey		vcvttss2si Gy, Wss	vcvtss2si Gy, Wss		,
	F2			vcvtsi2sd Vsd, Hsd, Ey		vcvttsd2si Gy, Wsd	vcvtsd2si Gy, Wsd		
3	3	3-byte escape (Table A-4)		3-byte escape (Table A-5)					
4	4	S	NS	CI P/PE	MOVcc(Gv, Ev) · NP/PO	Conditional Mo	ve NL/GE	LE/NG	NLE/G
		vaddps Vps, Hps, Wps	vmulps Vps, Hps, Wps	vcvtps2pd Vpd, Wps	vcvtdq2ps Vps, Wdq	vsubps Vps, Hps, Wps	vminps Vps, Hps, Wps	vdivps Vps, Hps, Wps	vmaxps Vps, Hps, Wps
5	66	vaddpd Vpd, Hpd, Wpd	vmulpd Vpd, Hpd, Wpd	vcvtpd2ps Vps, Wpd	vcvtps2dq Vdq, Wps	vsubpd Vpd, Hpd, Wpd	vminpd Vpd, Hpd, Wpd	vdivpd Vpd, Hpd, Wpd	vmaxpd Vpd, Hpd, Wpd
3	F3	vaddss Vss, Hss, Wss	vmulss Vss, Hss, Wss	vcvtss2sd Vsd, Hx, Wss	vcvttps2dq Vdq, Wps	vsubss Vss, Hss, Wss	vminss Vss, Hss, Wss	vdivss Vss, Hss, Wss	vmaxss Vss, Hss, Wss
	F2	vaddsd Vsd, Hsd, Wsd	vmulsd Vsd, Hsd, Wsd	vcvtsd2ss Vss, Hx, Wsd		vsubsd Vsd, Hsd, Wsd	vminsd Vsd, Hsd, Wsd	vdivsd Vsd, Hsd, Wsd	vmaxsd Vsd, Hsd, Wsd
		punpckhbw Pq, Qd	punpckhwd Pq, Qd	punpckhdq Pq, Qd	packssdw Pq, Qd			movd/q Pd, Ey	movq Pq, Qq
6	66	vpunpckhbw Vdq, Hdq, Wdq	vpunpckhwd Vdq, Hdq, Wdq	vpunpckhdq Vdq, Hdq, Wdq	vpackssdw Vdq, Hdq, Wdq	vpunpcklqdq Vdq, Hdq, Wdq	vpunpckhqdq Vdq, Hdq, Wdq	vmovd/q Vy, Ey	vmovdqa Vdq, Wdq Vx, Wx
	F3								vmovdqu Vdq, Wdq Vx, Wx
7		VMREAD Ey, Gy	VMWRITE Gy, Ey					movd/q Ey, Pd	movq Qq, Pq
	66					vhaddpd Vpd, Hpd, Wpd	vhsubpd Vpd, Hpd, Wpd	vmovd/q ^v Ey, Vy	vmovdqa ^v Wdq,Vdq Wx,Vx
	F3							vmovq ^v Vq, Wq	vmovdqu ^v Wdq,Vdq Wx,Vx
	F2					vhaddps Vps, Hps, Wps	vhsubps Vps, Hps, Wps		

Table A-3. Two-byte Opcode Map: 80H - F7H (First Byte is 0FH) *

	pfx	0	1	2	3	4	5	6	7
8			•	Jcc ^{f64} , J	z - Long-displace	ement jump on co	ndition	•	•
0		0	NO	B/CNAE	AE/NB/NC	E/Z	NE/NZ	BE/NA	A/NBE
9				5	SETcc, Eb - Byte	Set on condition			
J		0	NO	B/C/NAE	AE/NB/NC	E/Z	NE/NZ	BE/NA	A/NBE
Α		PUSH ^{d64} FS	POP ^{d64} FS	CPUID	BT Ev, Gv	SHLD Ev, Gv, Ib	SHLD Ev, Gv, CL		
		CMPX	CHG	LSS	BTR	LFS	LGS	MO	VZX
В		Eb, Gb	Ev, Gv	Gv, Mp	Ev, Gv	Gv, Mp	Gv, Mp	Gv, Eb	Gv, Ew
		XADD Eb, Gb	XADD Ev, Gv	vcmpps Vps,Hps,Wps,Ib	movnti My, Gy	pinsrw Pq,Ry/Mw,Ib	pextrw Gd, Nq, Ib	vshufps Vps,Hps,Wps,Ib	Grp 9 ^{1A}
С	66			vcmppd Vpd,Hpd,Wpd,Ib		vpinsrw Vdq,Hdq,Ry/Mw,Ib	vpextrw Gd, Udq, Ib	vshufpd Vpd,Hpd,Wpd,Ib	
	F3			vcmpss Vss,Hss,Wss,Ib					
	F2			vcmpsd Vsd,Hsd,Wsd,Ib					
			psrlw Pq, Qq	psrld Pq, Qq	psrlq Pq, Qq	paddq Pq, Qq	pmullw Pq, Qq		pmovmskb Gd, Nq
D	66	vaddsubpd Vpd, Hpd, Wpd	vpsrlw Vdq, Hdq, Wdq	vpsrld Vdq, Hdq, Wdq	vpsrlq Vdq, Hdq, Wdq	vpaddq Vdq, Hdq, Wdq	vpmullw Vdq, Hdq, Wdq	vmovq Wq, Vq	vpmovmskb Gd, Udq
	F3							movq2dq Vdq, Nq	
	F2	vaddsubps Vps, Hps, Wps						movdq2q Pq, Uq	
		pavgb Pq, Qq	psraw Pq, Qq	psrad Pq, Qq	pavgw Pq, Qq	pmulhuw Pq, Qq	pmulhw Pq, Qq		movntq Mq, Pq
	66	vpavgb Vdq, Hdq, Wdq	vpsraw Vdq, Hdq, Wdq	vpsrad Vdq, Hdq, Wdq	vpavgw Vdq, Hdq, Wdq	vpmulhuw Vdq, Hdq, Wdq	vpmulhw Vdq, Hdq, Wdq	vcvttpd2dq Vdq, Wpd Vx, Wpd	vmovntdq Mdq, Vdq Mx, Vx
Е	F3							vcvtdq2pd Vdq, Wpd Vx, Wpd	
	F2							vcvtpd2dq Vdq, Wpd Vx, Wpd	
			psllw Pq, Qq	pslld Pq, Qq	psllq Pq, Qq	pmuludq Pq, Qq	pmaddwd Pq, Qq	psadbw Pq, Qq	maskmovq Pq, Nq
F	66		vpsllw Vdq, Hdq, Wdq	vpslld Vdq, Hdq, Wdq	vpsllq Vdq, Hdq, Wdq	vpmuludq Vdq, Hdq, Wdq	vpmaddwd Vdq, Hdq, Wdq	vpsadbw Vdq, Hdq, Wdq	vmaskmovdqu Vdq, Udq
	F2	vlddqu Vdq, Mdq Vx, Mx							

Table A-3. Two-byte Opcode Map: 88H — FFH (First Byte is 0FH) *

	pfx	8	9	А	В	С	D	Е	F
8				Jcc ^{f64} , .	Jz - Long-displac	ement jump on	condition		
O		S	NS	P/PE	NP/PO	L/NGE	NL/GE	LE/NG	NLE/G
9			1	1		Set on conditio	1	•	•
		S	NS	P/PE	NP/PO	L/NGE	NL/GE	LE/NG	NLE/G
Α		PUSH ^{d64} GS	POP ^{d64} GS	RSM	BTS Ev, Gv	SHRD Ev, Gv, Ib	SHRD Ev, Gv, CL	(Grp 15 ^{1A}) ^{1C}	IMUL Gv, Ev
В		JMPE (reserved for emulator on IPF)	Grp 10 ^{1A} Invalid Opcode ^{1B}	Grp 8 ^{1A} Ev, Ib	BTC Ev, Gv	BSF Gv, Ev	BSR Gv, Ev	MO Gv, Eb	VSX Gv, Ew
	F3	POPCNT Gv, Ev							
					BSV	WAP			
С		RAX/EAX/ R8/R8D	RCX/ECX/ R9/R9D	RDX/EDX/ R10/R10D	RBX/EBX/ R11/R11D	RSP/ESP/ R12/R12D	RBP/EBP/ R13/R13D	RSI/ESI/ R14/R14D	RDI/EDI/ R15/R15D
		psubusb	psubusw	pminub	pand	paddusb	paddusw	pmaxub	pandn
		Pq, Qq	Pq, Qq	Pq, Qq	Pq, Qq	Pq, Qq	Pq, Qq	Pq, Qq	Pq, Qq
D	66	vpsubusb Vdq, Hdq, Wdq	vpsubusw Vdq, Hdq, Wdq	vpminub Vdq, Hdq, Wdq	vpand Vdq, Hdq, Wdq	vpaddusb Vdq, Hdq, Wdq	vpaddusw Vdq, Hdq, Wdq	vpmaxub Vdq, Hdq, Wdq	vpandn Vdq, Hdq, Wdq
	F3								
	F2								
		psubsb Pq, Qq	psubsw Pq, Qq	pminsw Pq, Qq	por Pq, Qq	paddsb Pq, Qq	paddsw Pq, Qq	pmaxsw Pq, Qq	pxor Pq, Qq
_	66	vpsubsb ^v Vdq, Hdq, Wdq	vpsubsw ^v Vdq, Hdq, Wdq	vpminsw ^v Vdq, Hdq, Wdq	vpor ^v Vdq, Hdq, Wdq	vpaddsb ^v Vdq, Hdq, Wdq	vpaddsw ^v Vdq, Hdq, Wdq	vpmaxsw ^v Vdq, Hdq, Wdq	vpxor ^v Vdq, Hdq, Wdq
Е	F3								
	F2								
		psubb Pq, Qq	psubw Pq, Qq	psubd Pq, Qq	psubq Pq, Qq	paddb Pq, Qq	paddw Pq, Qq	paddd Pq, Qq	
F	66	vpsubb Vdq, Hdq, Wdq	vpsubw Vdq, Hdq, Wdq	vpsubd Vdq, Hdq, Wdq	vpsubq Vdq, Hdq, Wdq	vpaddb Vdq, Hdq, Wdq	vpaddw Vdq, Hdq, Wdq	vpaddd Vdq, Hdq, Wdq	
	F2								
NOT									

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

Table A-4. Three-byte Opcode Map: 00H - F7H (First Two Bytes are 0F 38H) *

	pfx	0	1	2	3	4	5	6	7
		pshufb Pq, Qq	phaddw Pq, Qq	phaddd Pq, Qq	phaddsw Pq, Qq	pmaddubsw Pq, Qq	phsubw Pq, Qq	phsubd Pq, Qq	phsubsw Pq, Qq
0	66	vpshufb Vdq, Hdq, Wdq	vphaddw Vdq, Hdq, Wdq	vphaddd Vdq, Hdq, Wdq	vphaddsw Vdq, Hdq, Wdq	vpmaddubsw Vdq, Hdq, Wdq	vphsubw Vdq, Hdq, Wdq	vphsubd Vdq, Hdq, Wdq	vphsubsw Vdq, Hdq, Wdq
1	66	pblendvb Vdq, Wdq				blendvps Vdq, Wdq Vx, Wx	blendvpd Vdq, Wdq Vx, Wx		vptest Vdq, Wdq Vx, Wx
2	66	vpmovsxbw Vdq, Udq/Mq	vpmovsxbd Vdq, Udq/Md	vpmovsxbq Vdq, Udq/Mw	vpmovsxwd Vdq, Udq/Mq	vpmovsxwq Vdq, Udq/Md	vpmovsxdq Vdq, Udq/Mq		
3	66	vpmovzxbw Vdq, Udq/Mq	vpmovzxbd Vdq, Udq/Md	vpmovzxbq Vdq, Udq/Mw	vpmovzxwd Vdq, Udq/Mq	vpmovzxwq Vdq, Udq/Md	vpmovzxdq Vdq, Udq/Mq		vpcmpgtq Vdq, Hdq, Wdq
4	66	vpmulld Vdq, Hdq, Wdq	vphminposuw Vdq, Wdq						
5									
6									
7									
8	66	INVEPT Gy, Mdq	INVVPID Gy, Mdq						
9									
Α									
В						Ī			
С									
D									
Е									
		MOVBE Gy, My	MOVBE My, Gy						
	66	MOVBE Gw, Mw	MOVBE Mw, Gw						
F	F3								
	F2	CRC32 Gd, Eb	CRC32 Gd, Ey						_
	66 & F2	CRC32 Gd, Eb	CRC32 Gd, Ew						

Table A-4. Three-byte Opcode Map: 08H — FFH (First Two Bytes are 0F 38H) *

	pfx	8	9	Α	В	С	D	Е	F
		psignb Pq, Qq	psignw Pq, Qq	psignd Pq, Qq	pmulhrsw Pq, Qq				
0	66	vpsignb Vdq, Hdq, Wdq	vpsignw Vdq, Hdq, Wdq		vpmulhrswVdq, Hdq, Wdq	vpermilps ^v Vx,Hx,Wx	vpermilpd ^v Vx,Hx,Wx	vtestps ^v Vx, Wx	vtestpd ^v Vx, Wx
						pabsb Pq, Qq	pabsw Pq, Qq	pabsd Pq, Qq	
1	66	vbroadcastss ^v Vx, Md	vbroadcastsd ^v Vqq, Mq	vbroadcastf128 ^V Vqq, Mdq		vpabsb Vdq, Hdq, Wdq	vpabsw Vdq, Hdq, Wdq	vpabsd Vdq, Hdq, Wdq	
2	66	vpmuldq Vdq, Hdq, Wdq	vpcmpeqq Vdq, Hdq, Wdq	vmovntdqa Vdq, Hdq, Mdq	vpackusdw Vdq, Hdq, Wdq	vmaskmovps ^v Vx,Hx,Mx	vmaskmovpd ^v Vx,Hx,Mx	vmaskmovps ^v Mx,Vx,Hx	vmaskmovpd ^v Mx,Vx,Hx
3	66	vpminsb Vdq, Hdq, Wdq	vpminsd Vdq, Hdq, Wdq	vpminuw Vdq, Hdq, Wdq	vpminud Vdq, Hdq, Wdq	vpmaxsb Vdq, Hdq, Wdq	vpmaxsd Vdq, Hdq, Wdq	vpmaxuw Vdq, Hdq, Wdq	vpmaxud Vdq, Hdq, Wdq
4									
5									
6									
7									
8									
9									
Α									
B C									
D	66				VAESIMC Vdq, Wdq	VAESENC Vdg,Hdg,Wdg	VAESENCLAST Vdq,Hdq,Wdq	VAESDEC Vdq,Hdq,Wdq	VAESDECLAST Vdq,Hdq,Wdq
Е					vuq, vvuq	vaq,riaq,vvaq	v 3q,1 10q, v 40q	v aq,i iaq,vvaq	vaq,riaq,vvaq
F	66								
[']	F3								
	F2								

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

Table A-5. Three-byte Opcode Map: 00H - F7H (First two bytes are 0F 3AH) *

	pfx	0	1	2	3	4	5	6	7
0	66					vpermilps ^v Vx, Wx, Ib	vpermilpd ^v Vx, Wx, Ib	vperm2f128 ^V Vqq,Hqq,Wqq,Ib	
1	66					vpextrb Rd/Mb, Vdq, Ib	vpextrw Rd/Mw, Vdq, Ib	vpextrd/q Ey, Vdq, Ib	vextractps Ed, Vdq, Ib
2	66	vpinsrb Vdq,Hdq,Ry/Mb ,Ib	vinsertps Vdq,Hdq,Udq/M d,Ib	vpinsrd/q Vdq,Hdq,Ey,Ib					
3									
4	66	vdpps Vdq,Wdq,Ib Vx,Hx,Wx,Ib	vdppd Vdq,Wdq,Ib Vx,Hx,Wx,Ib	vmpsadbw Vdq,Hdq,Wdq,Ib		vpclmulqdq Vdq,Hdq,Wdq,lb			
5									
6	66	vpcmpestrm Vdq, Wdq, Ib	vpcmpestri Vdq, Wdq, Ib	vpcmpistrm Vdq, Wdq, Ib	vpcmpistri Vdq, Wdq, Ib				
7									
8									
9									
Α									
В									
С									
D									
Е									
F									

Table A-5. Three-byte Opcode Map: 08H — FFH (First Two Bytes are 0F 3AH) *

	pfx	8	9	Α	В	С	D	E	F
									palignr Pq, Qq, Ib
0	66	vroundps Vdq,Wdq,Ib Vx,Wx,Ib	vroundpd Vdq,Wdq,Ib Vx,Wx,Ib	vroundss Vss,Hss,Wss,Ib	vroundsd Vss,Hss,Wss,Ib	vblendps Vdq,Wdq,Ib Vx,Hx,Wx,Ib	vblendpd Vdq,Wdq,lb Vx,Hx,Wx,lb	vpblendw Vdq,Hdq,Wdq,Ib	vpalignr Vdq,Hdq,Wdq,lb
1	66	vinsertf128 ^v Vqq,Hqq,Wqq,Ib	vextractf128 ^v Wdq,Vqq,lb						
2									
3									
4	66			vblendvps ^v Vx,Hx ,Wx,Lx,Ib	vblendvpd ^v Vx,Hx ,Wx,Lx,lb	vpblendvb ^V Vdq, Hdq,Wdq, Ldq,Ib			
5									
6									
7									
8									
9									
Α									
В									
C D	66								VAESKEYGEN Vdq, Wdq, Ib
Е									
F									

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.4 OPCODE EXTENSIONS FOR ONE-BYTE AND TWO-BYTE OPCODES

Some 1-byte and 2-byte opcodes use bits 3-5 of the ModR/M byte (the nnn field in Figure A-1) as an extension of the opcode.




Figure A-1. ModR/M Byte nnn Field (Bits 5, 4, and 3)

Opcodes that have opcode extensions are indicated in Table A-6 and organized by group number. Group numbers (from 1 to 16, second column) provide a table entry point. The encoding for the r/m field for each instruction can be established using the third column of the table.

A.4.1 Opcode Look-up Examples Using Opcode Extensions

An Example is provided below.

Example A-3. Interpreting an ADD Instruction

An ADD instruction with a 1-byte opcode of 80H is a Group 1 instruction:

- Table A-6 indicates that the opcode extension field encoded in the ModR/M byte for this instruction is 000B.
- The r/m field can be encoded to access a register (11B) or a memory address using a specified addressing mode (for example: mem = 00B, 01B, 10B).

Example A-2. Looking Up 0F01C3H

Look up opcode 0F01C3 for a VMRESUME instruction by using Table A-2, Table A-3 and Table A-6:

- OF tells us that this instruction is in the 2-byte opcode map.
- 01 (row 0, column 1 in Table A-3) reveals that this opcode is in Group 7 of Table A-6.
- C3 is the ModR/M byte. The first two bits of C3 are 11B. This tells us to look at the second of the Group 7 rows in Table A-6.
- The Op/Reg bits [5,4,3] are 000B. This tells us to look in the 000 column for Group 7.
- Finally, the R/M bits [2,1,0] are 011B. This identifies the opcode as the VMRESUME instruction.

A.4.2 Opcode Extension Tables

See Table A-6 below.

Table A-6. Opcode Extensions for One- and Two-byte Opcodes by Group Number *

				Encodi	ng of Bits	5,4,3 of	the ModR	M Byte (b	oits 2,1	,0 in par	enthesis)
Opcode	Group	Mod 7,6	pfx	000	001	010	011	100	101	110	111
80-83	1	mem, 11B		ADD	OR	ADC	SBB	AND	SUB	XOR	CMP
8F	1A	mem, 11B		POP							
C0,C1 reg, imm D0, D1 reg, 1 D2, D3 reg, CL	2	mem, 11B		ROL	ROR	RCL	RCR	SHL/SAL	SHR		SAR
F6, F7	3	mem, 11B		TEST lb/lz		NOT	NEG	MUL AL/rAX	IMUL AL/rAX	DIV AL/rAX	IDIV AL/rAX
FE	4	mem, 11B		INC Eb	DEC Eb						•
FF	5	mem, 11B		INC Ev	DEC Ev	CALLN ^{f64} Ev	CALLF Ep	JMPN ^{f64} Ev	JMPF Ep	PUSH ^{d64} Ev	
0F 00	6	mem, 11B		SLDT Rv/Mw	STR Rv/Mw	LLDT Ew	LTR Ew	VERR Ew	VERW Ew		
		mem		SGDT Ms	SIDT Ms	LGDT Ms	LIDT Ms	SMSW Mw/Rv		LMSW Ew	INVLPG Mb
0F 01	7	11B		VMCALL (001) VMLAUNCH (010) VMRESUME (011) VMXOFF (100)	MONITOR (000) MWAIT (001)	XGETBV (000) XSETBV (001)					SWAPGS 064(000) RDTSCP (001)
0F BA	8	mem, 11B						ВТ	BTS	BTR	BTC
		mem			CMPXCH8B Mq CMPXCHG16B Mdq						qVMPTRST Mq
0F C7	9		66 F3							VMCLEAR Mq VMXON	VMPTRST Mg
			13							Mq	VIVII TROTIVIQ
		11B									
0F B9	10	mem 11B									
C6		mem, 11B		MOV Eb, lb							
C7	11	mem 11B		MOV Ev, Iz							

Table A-6. Opcode Extensions for One- and Two-byte Opcodes by Group Number *

				Encodir	ng of Bits	5,4,3 of	the ModR/	M Byte (b	its 2,1	,0 in pare	nthesis)
Opcode	Group	Mod 7,6	pfx	000	001	010	011	100	101	110	111
		mem									
0F 71	12	11B				psrlw Nq, lb		psraw Nq, Ib		psllw Nq, Ib	
		ПВ	66			vpsrlw Hdq,Udq,Ib		vpsraw Hdq,Udq,Ib		vpsllw Hdq,Udq,lb	
		mem									
0F 72	13	11B				psrld Nq, lb		psrad Nq, Ib		pslld Nq, Ib	
		115	66			vpsrld Hdq,Udq,Ib		vpsrad Hdq,Udq,Ib		vpslld Hdq,Udq,lb	
		mem									
0F 73	14	11B				psrlq Nq, lb				psllq Nq, Ib	
		ПВ	66			vpsrlq Hdq,Udq,Ib	vpsrldq Hdq,Udq,Ib			vpsllq Hdq,Udq,lb	vpslldq Hdq,Udq,Ib
0F AE	15	mem		fxsave	fxrstor	Idmxcsr	stmxcsr	XSAVE	XRSTOR	XSAVEOPT	clflush
		11B							Ifence	mfence	sfence
0F 18	16	mem		prefetch NTA	prefetch T0	prefetch T1	prefetch T2				
		11B									

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5 ESCAPE OPCODE INSTRUCTIONS

Opcode maps for coprocessor escape instruction opcodes (x87 floating-point instruction opcodes) are in Table A-7 through Table A-22. These maps are grouped by the first byte of the opcode, from D8-DF. Each of these opcodes has a ModR/M byte. If the ModR/M byte is within the range of 00H-BFH, bits 3-5 of the ModR/M byte are used as an opcode extension, similar to the technique used for 1-and 2-byte opcodes (see A.4). If the ModR/M byte is outside the range of 00H through BFH, the entire ModR/M byte is used as an opcode extension.

A.5.1 Opcode Look-up Examples for Escape Instruction Opcodes

Examples are provided below.

Example A-5. Opcode with ModR/M Byte in the 00H through BFH Range

DD0504000000H can be interpreted as follows:

- The instruction encoded with this opcode can be located in Section . Since the ModR/M byte (05H) is within the 00H through BFH range, bits 3 through 5 (000) of this byte indicate the opcode for an FLD double-real instruction (see Table A-9).
- The double-real value to be loaded is at 00000004H (the 32-bit displacement that follows and belongs to this opcode).

Example A-3. Opcode with ModR/M Byte outside the 00H through BFH Range

D8C1H can be interpreted as follows:

- This example illustrates an opcode with a ModR/M byte outside the range of 00H through BFH. The instruction can be located in Section A.4.
- In Table A-8, the ModR/M byte C1H indicates row C, column 1 (the FADD instruction using ST(0), ST(1) as operands).

A.5.2 Escape Opcode Instruction Tables

Tables are listed below.

A.5.2.1 Escape Opcodes with D8 as First Byte

Table A-7 and A-8 contain maps for the escape instruction opcodes that begin with D8H. Table A-7 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-7. D8 Opcode Map When ModR/M Byte is Within 00H to BFH *

	nnn Field of ModR/M Byte (refer to Figure A.4)											
000B	001B	010B	011B	100B	101B	110B	111B					
FADD single- real	FMUL single- real	FCOM single- real	FCOMP single- real	FSUB single- real	FSUBR single- real	FDIV single-real	FDIVR single- real					

NOTES:

Table A-8 shows the map if the ModR/M byte is outside the range of 00H-BFH. Here, the first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-8. D8 Opcode Map When ModR/M Byte is Outside 00H to BFH *

	0	1	2	3	4	5	6	7				
С	FADD											
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
D				FC	OM							
	ST(0),ST(0)	ST(0),ST(1)	ST(0),T(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
Е				FS	UB							
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
F	FDIV											
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				

	8	9	А	В	С	D	Е	F				
С	FMUL											
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
D				FCC	MP							
	ST(0),ST(0)	ST(0),ST(1)	ST(0),T(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
Е				FSU	JBR							
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
F	FDIVR											
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations

A.5.2.2 Escape Opcodes with D9 as First Byte

Table A-9 and A-10 contain maps for escape instruction opcodes that begin with D9H. Table A-9 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-9. D9 Opcode Map When ModR/M Byte is Within 00H to BFH *

	nnn Field of ModR/M Byte												
000B	001B	010B	011B	100B	101B	110B	111B						
FLD single-real		FST single-real	FSTP single-real	FLDENV 14/28 bytes	FLDCW 2 bytes	FSTENV 14/28 bytes	FSTCW 2 bytes						

NOTES:

Table A-10 shows the map if the ModR/M byte is outside the range of 00H-BFH. Here, the first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-10. D9 Opcode Map When ModR/M Byte is Outside 00H to BFH *

_											
	0	1	2	3	4	5	6	7			
С		FLD									
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
D	FNOP										
Е	FCHS	FABS			FTST	FXAM					
F	F2XM1	FYL2X	FPTAN	FPATAN	FXTRACT	FPREM1	FDECSTP	FINCSTP			

	8	9	Α	В	С	D	E	F				
С		FXCH										
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
D												
Е	FLD1	FLDL2T	FLDL2E	FLDPI	FLDLG2	FLDLN2	FLDZ					
F	FPREM	FYL2XP1	FSQRT	FSINCOS	FRNDINT	FSCALE	FSIN	FCOS				

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.3 Escape Opcodes with DA as First Byte

Table A-11 and A-12 contain maps for escape instruction opcodes that begin with DAH. Table A-11 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-11. DA Opcode Map When ModR/M Byte is Within 00H to BFH *

nnn Field of ModR/M Byte									
000B	001B	010B	011B	100B	101B	110B	111B		
FIADD dword-integer	FIMUL dword-integer	FICOM dword-integer	FICOMP dword-integer	FISUB dword-integer	FISUBR dword-integer	FIDIV dword-integer	FIDIVR dword-integer		

NOTES:

Table A-11 shows the map if the ModR/M byte is outside the range of 00H-BFH. Here, the first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-12. DA Opcode Map When ModR/M Byte is Outside 00H to BFH *

	0	1	2	3	4	5	6	7			
С	FCMOVB										
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
D				FCMC	OVBE						
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
Е											
F											

	8	9	Α	В	С	D	E	F				
С		FCMOVE										
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
D		FCMOVU										
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)				
Е		FUCOMPP										
F												

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.4 Escape Opcodes with DB as First Byte

Table A-13 and A-14 contain maps for escape instruction opcodes that begin with DBH. Table A-13 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-13. DB Opcode Map When ModR/M Byte is Within 00H to BFH *

nnn Field of ModR/M Byte										
000B	001B	010B	011B	100B	101B	110B	111B			
FILD dword-integer	FISTTP dword- integer	FIST dword-integer	FISTP dword-integer		FLD extended-real		FSTP extended-real			

NOTES:

Table A-14 shows the map if the ModR/M byte is outside the range of 00H-BFH. Here, the first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-14. DB Opcode Map When ModR/M Byte is Outside 00H to BFH *

	Table A-14. Db Opcode Hap Wileli Hodri H byte is Odtside Ooi 10 bi ii										
	0	1	2	3	4	5	6	7			
С				FCM	OVNB						
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
D				FCMC	VNBE						
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
Е			FCLEX	FINIT							
F		FCOMI									
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
								•			
	8	9	Α	В	С	D	E	F			
С				FCM	OVNE						
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
D				FCMC	DVNU						
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
Е			•	FUC	OMI	•					
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)			
1											

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.5 Escape Opcodes with DC as First Byte

Table A-15 and A-16 contain maps for escape instruction opcodes that begin with DCH. Table A-15 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-15. DC Opcode Map When ModR/M Byte is Within 00H to BFH *

nnn Field of ModR/M Byte (refer to Figure A-1)										
000B 001B 010B 011B 100B 101B 110B 111B										
FADD double- real	FMUL double- real	FCOM double-real	FCOMP double-real	FSUB double- real	FSUBR double-real	FDIV double- real	FDIVR double-real			

NOTES:

Table A-16 shows the map if the ModR/M byte is outside the range of 00H-BFH. In this case the first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-16. DC Opcode Map When ModR/M Byte is Outside 00H to BFH *

	Table A-16. DC Opcode Map when ModR/M Byte is Outside OUH to BFH *											
	0	1	2	3	4	5	6	7				
С				FA	DD							
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)				
D												
Е	FSUBR											
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)				
F				FD	IVR							
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)				
				•	•							
	8	9	Α	В	С	D	E	F				
0												

	8	9	Α	В	С	D	E	F					
С		FMUL											
	ST(0),ST(0)	ST(0),ST(0)											
D													
Е				FS	UB								
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)					
F		FDIV											
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)					

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.6 Escape Opcodes with DD as First Byte

Table A-17 and A-18 contain maps for escape instruction opcodes that begin with DDH. Table A-17 shows the map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-17. DD Opcode Map When ModR/M Byte is Within 00H to BFH *

	nnn Field of ModR/M Byte										
000B	001B	010B	011B	100B	101B	110B	111B				
FLD double- real	FISTTP integer64	FST double- real	FSTP double- real	FRSTOR 98/108bytes		FSAVE 98/108bytes	FSTSW 2 bytes				

NOTES:

Table A-18 shows the map if the ModR/M byte is outside the range of 00H-BFH. The first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-18. DD Opcode Map When ModR/M Byte is Outside 00H to BFH *

	0	1	2	3	4	5	6	7			
С				FFF	REE						
	ST(0)	ST(1)	ST(2)	ST(3)	ST(4)	ST(5)	ST(6)	ST(7)			
D		FST									
	ST(0)	ST(1)	ST(2)	ST(3)	ST(4)	ST(5)	ST(6)	ST(7)			
Е		FUCOM									
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)			
F											
	8	9	Α	В	С	D	Е	F			
С											
D				FS	TP						
	ST(0)	ST(1)	ST(2)	ST(3)	ST(4)	ST(5)	ST(6)	ST(7)			
Е				FUC	OMP						
	ST(0)	ST(1)	ST(2)	ST(3)	ST(4)	ST(5)	ST(6)	ST(7)			
F											

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.7 Escape Opcodes with DE as First Byte

Table A-19 and A-20 contain opcode maps for escape instruction opcodes that begin with DEH. Table A-19 shows the opcode map if the ModR/M byte is in the range of 00H-BFH. In this case, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-19. DE Opcode Map When ModR/M Byte is Within 00H to BFH *

nnn Field of ModR/M Byte							
000B	001B	010B	011B	100B	101B	110B	111B
FIADD word-integer	FIMUL word-integer	FICOM word-integer	FICOMP word- integer	FISUB word-integer	FISUBR word- integer	FIDIV word-integer	FIDIVR word-integer

NOTES:

Table A-20 shows the opcode map if the ModR/M byte is outside the range of 00H-BFH. The first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-20. DE Opcode Map When ModR/M Byte is Outside 00H to BFH *

	I dbic A	Lo. DC op	code i lap	WIICHTIO	Jivii byte	is outside	ים טוו נט טו	
	0	1	2	3	4	5	6	7
С		FADDP						
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)
D								
Е				FSU	BRP			
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)
F	FDIVRP							
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)
	<u> </u>						<u> </u>	

	8	9	Α	В	С	D	E	F
С				FMI	JLP			
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)
D		FCOMPP						
Е				FSU	JBP			
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0)	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)
F	FDIVP							
	ST(0),ST(0)	ST(1),ST(0)	ST(2),ST(0).	ST(3),ST(0)	ST(4),ST(0)	ST(5),ST(0)	ST(6),ST(0)	ST(7),ST(0)

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

^{*} All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

A.5.2.8 Escape Opcodes with DF As First Byte

Table A-21 and A-22 contain the opcode maps for escape instruction opcodes that begin with DFH. Table A-21 shows the opcode map if the ModR/M byte is in the range of 00H-BFH. Here, the value of bits 3-5 (the nnn field in Figure A-1) selects the instruction.

Table A-21. DF Opcode Map When ModR/M Byte is Within 00H to BFH *

	nnn Field of ModR/M Byte							
000B	001B	010B	011B	100B	101B	110B	111B	
FILD word-integer	FISTTP word-integer	FIST word-integer	FISTP word-integer	FBLD packed- BCD	FILD qword-integer	FBSTP packed- BCD	FISTP qword-integer	

NOTES:

* All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

Table A-22 shows the opcode map if the ModR/M byte is outside the range of 00H-BFH. The first digit of the ModR/M byte selects the table row and the second digit selects the column.

Table A-22. DF Opcode Map When ModR/M Byte is Outside 00H to BFH *

	1001071	o. o.	and the p				- 0011 10 5		
	0	1	2	3	4	5	6	7	
С									
D									
Е	FSTSW AX								
F		FCOMIP							
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)	
		· · · · · · · · · · · · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·		· ·	

	8	9	Α	В	С	D	Е	F
С								
D								
Е				FUC	OMIP			
	ST(0),ST(0)	ST(0),ST(1)	ST(0),ST(2)	ST(0),ST(3)	ST(0),ST(4)	ST(0),ST(5)	ST(0),ST(6)	ST(0),ST(7)
F								

NOTES:

* All blanks in all opcode maps are reserved and must not be used. Do not depend on the operation of undefined or reserved locations.

APPENDIX B INSTRUCTION FORMATS AND ENCODINGS

This appendix provides machine instruction formats and encodings of IA-32 instructions. The first section describes the IA-32 architecture's machine instruction format. The remaining sections show the formats and encoding of general-purpose, MMX, P6 family, SSE/SSE2/SSE3, x87 FPU instructions, and VMX instructions. Those instruction formats also apply to Intel 64 architecture. Instruction formats used in 64-bit mode are provided as supersets of the above.

B.1 MACHINE INSTRUCTION FORMAT

All Intel Architecture instructions are encoded using subsets of the general machine instruction format shown in Figure B-1. Each instruction consists of:

- an opcode
- a register and/or address mode specifier consisting of the ModR/M byte and sometimes the scale-index-base (SIB) byte (if required)
- a displacement and an immediate data field (if required)




Figure B-1. General Machine Instruction Format

The following sections discuss this format.

B.1.1 Legacy Prefixes

The legacy prefixes noted in Figure B-1 include 66H, 67H, F2H and F3H. They are optional, except when F2H, F3H and 66H are used in new instruction extensions. Legacy prefixes must be placed before REX prefixes.

Refer to Chapter 2, "Instruction Format," in the *Intel*® 64 and *IA-32 Architectures* Software Developer's Manual, Volume 2A, for more information on legacy prefixes.

B.1.2 REX Prefixes

REX prefixes are a set of 16 opcodes that span one row of the opcode map and occupy entries 40H to 4FH. These opcodes represent valid instructions (INC or DEC) in IA-32 operating modes and in compatibility mode. In 64-bit mode, the same opcodes represent the instruction prefix REX and are not treated as individual instructions.

Refer to Chapter 2, "Instruction Format," in the Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A, for more information on REX prefixes.

B.1.3 Opcode Fields

The primary opcode for an instruction is encoded in one to three bytes of the instruction. Within the primary opcode, smaller encoding fields may be defined. These fields vary according to the class of operation being performed.

Almost all instructions that refer to a register and/or memory operand have a register and/or address mode byte following the opcode. This byte, the ModR/M byte, consists of the mod field (2 bits), the reg field (3 bits; this field is sometimes an opcode extension), and the R/M field (3 bits). Certain encodings of the ModR/M byte indicate that a second address mode byte, the SIB byte, must be used.

If the addressing mode specifies a displacement, the displacement value is placed immediately following the ModR/M byte or SIB byte. Possible sizes are 8, 16, or 32 bits. If the instruction specifies an immediate value, the immediate value follows any displacement bytes. The immediate, if specified, is always the last field of the instruction.

Refer to Chapter 2, "Instruction Format," in the *Intel*® *64 and IA-32 Architectures Software Developer's Manual, Volume 2A*, for more information on opcodes.

B.1.4 Special Fields

Table B-1 lists bit fields that appear in certain instructions, sometimes within the opcode bytes. All of these fields (except the d bit) occur in the general-purpose instruction formats in Table B-13.

Table B-1. Special Fields Within Instruction Encodings

Field Name	Description	Number of Bits
reg	General-register specifier (see Table B-4 or B-5)	3
W	Specifies if data is byte or full-sized, where full-sized is 16 or 32 bits (see Table B-6)	1
S	Specifies sign extension of an immediate field (see Table B-7)	1
sreg2	Segment register specifier for CS, SS, DS, ES (see Table B-8)	2
sreg3	Segment register specifier for CS, SS, DS, ES, FS, GS (see Table B-8)	3
eee	Specifies a special-purpose (control or debug) register (see Table B-9)	3
tttn	For conditional instructions, specifies a condition asserted or negated (see Table B-12)	4
d	Specifies direction of data operation (see Table B-11)	1

B.1.4.1 Reg Field (reg) for Non-64-Bit Modes

The reg field in the ModR/M byte specifies a general-purpose register operand. The group of registers specified is modified by the presence and state of the w bit in an encoding (refer to Section B.1.4.3). Table B-2 shows the encoding of the reg field when the w bit is not present in an encoding; Table B-3 shows the encoding of the reg field when the w bit is present.

Table B-2. Encoding of reg Field When w Field is Not Present in Instruction

reg Field	Register Selected during 16-Bit Data Operations	Register Selected during 32-Bit Data Operations
000	AX	EAX
001	CX	ECX
010	DX	EDX
011	BX	EBX
100	SP	ESP
101	BP	EBP
110	SI	ESI
111	DI	EDI

Table B-3. Encoding of reg Field When w Field is Present in Instruction

Table B 3: Chedding of reg field W						
	Register Specified by reg Field During 16-Bit Data Operations					
	Function	Function of w Field				
reg	When w = 0	When w = 1				
000	AL	AX				
001	CL	CX				
010	DL	DX				
011	BL	BX				
100	АН	SP				
101	CH	BP				
110	DH	SI				
111	BH	DI				

	Register Specified by reg Field During 32-Bit Data Operations					
	Function o	Function of w Field				
reg	When w = 0	When w = 1				
000	AL	EAX				
001	CL	ECX				
010	DL	EDX				
011	BL	EBX				
100	AH	ESP				
101	CH	EBP				
110	DH	ESI				
111	ВН	EDI				

B.1.4.2 Reg Field (reg) for 64-Bit Mode

Just like in non-64-bit modes, the reg field in the ModR/M byte specifies a general-purpose register operand. The group of registers specified is modified by the presence of and state of the w bit in an encoding (refer to Section B.1.4.3). Table B-4 shows the encoding of the reg field when the w bit is not present in an encoding; Table B-5 shows the encoding of the reg field when the w bit is present.

Table B-4. Encoding of reg Field When w Field is Not Present in Instruction

reg Field	Register Selected during 16-Bit Data Operations	Register Selected during 32-Bit Data Operations	Register Selected during 64-Bit Data Operations
000	AX	EAX	RAX
001	CX	ECX	RCX
010	DX	EDX	RDX
011	BX	EBX	RBX
100	SP	ESP	RSP
101	BP	EBP	RBP
110	SI	ESI	RSI
111	DI	EDI	RDI

Table B-5. Encoding of reg Field When w Field is Present in Instruction

icolo o oi chicoching of reginale to					
Register Specified by reg Field During 16-Bit Data Operations					
Function	Function of w Field				
When w = 0	When w = 1				
AL	AX				
CL	CX				
DL	DX				
BL	BX				
AH ¹	SP				
CH ¹	BP				
DH^1	SI				
BH ¹	DI				
	Function When w = 0 AL CL DL BL AH ¹ CH ¹ DH ¹				

Register Specified by reg Field During 32-Bit Data Operations		
	Function of w Field	
reg	When w = 0	When w = 1
000	AL	EAX
001	CL	ECX
010	DL	EDX
011	BL	EBX
100	AH*	ESP
101	CH*	EBP
110	DH*	ESI
111	BH*	EDI

B.1.4.3 Encoding of Operand Size (w) Bit

The current operand-size attribute determines whether the processor is performing 16-bit, 32-bit or 64-bit operations. Within the constraints of the current operand-size attribute, the operand-size bit (w) can be used to indicate operations on 8-bit operands or the full operand size specified with the operand-size attribute. Table B-6 shows the encoding of the w bit depending on the current operand-size attribute.

Table B-6. Encoding of Operand Size (w) Bit

w Bit	Operand Size When Operand-Size Attribute is 16 Bits	Operand Size When Operand-Size Attribute is 32 Bits
0	8 Bits	8 Bits
1	16 Bits	32 Bits

B.1.4.4 Sign-Extend (s) Bit

The sign-extend (s) bit occurs in instructions with immediate data fields that are being extended from 8 bits to 16 or 32 bits. See Table B-7.

^{1.} AH, CH, DH, BH can not be encoded when REX prefix is used. Such an expression defaults to the low byte.

Table B-7. Encoding of Sign-Extend (s) Bit

s	Effect on 8-Bit Immediate Data	Effect on 16- or 32-Bit Immediate Data
0	None	None
1	Sign-extend to fill 16-bit or 32-bit destination	None

B.1.4.5 Segment Register (sreg) Field

When an instruction operates on a segment register, the reg field in the ModR/M byte is called the sreg field and is used to specify the segment register. Table B-8 shows the encoding of the sreg field. This field is sometimes a 2-bit field (sreg2) and other times a 3-bit field (sreg3).

Table B-8. Encoding of the Segment Register (sreg) Field

2-Bit sreg2 Field	Segment Register Selected
00	ES
01	CS
10	SS
11	DS

3-Bit sreg3 Field	Segment Register Selected
000	ES
001	CS
010	SS
011	DS
100	FS
101	GS
110	Reserved ¹
111	Reserved

NOTES:

B.1.4.6 Special-Purpose Register (eee) Field

When control or debug registers are referenced in an instruction they are encoded in the eee field, located in bits 5 though 3 of the ModR/M byte (an alternate encoding of the sreg field). See Table B-9.

^{1.} Do not use reserved encodings.

DR7

Control Register eee **Debug Register** 000 CR₀ DR0 Reserved¹ 001 DR1 010 CR2 DR2 011 CR3 DR3 100 CR4 Reserved 101 Reserved Reserved 110 Reserved DR₆

Reserved

Table B-9. Encoding of Special-Purpose Register (eee) Field

NOTES:

111

B.1.4.7 Condition Test (tttn) Field

For conditional instructions (such as conditional jumps and set on condition), the condition test field (tttn) is encoded for the condition being tested. The ttt part of the field gives the condition to test and the n part indicates whether to use the condition (n = 0) or its negation (n = 1).

- For 1-byte primary opcodes, the tttn field is located in bits 3, 2, 1, and 0 of the opcode byte.
- For 2-byte primary opcodes, the tttn field is located in bits 3, 2, 1, and 0 of the second opcode byte.

Table B-10 shows the encoding of the tttn field.

^{1.} Do not use reserved encodings.

tttn	Mnemonic	Condition
0000	0	Overflow
0001	NO	No overflow
0010	B, NAE	Below, Not above or equal
0011	NB, AE	Not below, Above or equal
0100	E, Z	Equal, Zero
0101	NE, NZ	Not equal, Not zero
0110	BE, NA	Below or equal, Not above
0111	NBE, A	Not below or equal, Above
1000	S	Sign
1001	NS	Not sign
1010	P, PE	Parity, Parity Even
1011	NP, PO	Not parity, Parity Odd
1100	L, NGE	Less than, Not greater than or equal to
1101	NL, GE	Not less than, Greater than or equal to
1110	LE, NG	Less than or equal to, Not greater than
1111	NLE, G	Not less than or equal to, Greater than

Table B-10. Encoding of Conditional Test (tttn) Field

B.1.4.8 Direction (d) Bit

In many two-operand instructions, a direction bit (d) indicates which operand is considered the source and which is the destination. See Table B-11.

- When used for integer instructions, the d bit is located at bit 1 of a 1-byte primary opcode. Note that this bit does not appear as the symbol "d" in Table B-13; the actual encoding of the bit as 1 or 0 is given.
- When used for floating-point instructions (in Table B-16), the d bit is shown as bit 2 of the first byte of the primary opcode.

d	Source	Destination
0	reg Field	ModR/M or SIB Byte
1	ModR/M or SIB Byte	reg Field

Table B-11. Encoding of Operation Direction (d) Bit

B.1.5 Other Notes

Table B-12 contains notes on particular encodings. These notes are indicated in the tables shown in the following sections by superscripts.

Table B-12. Notes on Instruction Encoding

Symbol	Note
А	A value of 11B in bits 7 and 6 of the ModR/M byte is reserved.
В	A value of 01B (or 10B) in bits 7 and 6 of the ModR/M byte is reserved.

B.2 GENERAL-PURPOSE INSTRUCTION FORMATS AND ENCODINGS FOR NON-64-BIT MODES

Table B-13 shows machine instruction formats and encodings for general purpose instructions in non-64-bit modes.

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes

Instruction and Format	Encoding
AAA - ASCII Adjust after Addition	0011 0111
AAD - ASCII Adjust AX before Division	1101 0101 : 0000 1010
AAM - ASCII Adjust AX after Multiply	1101 0100 : 0000 1010
AAS - ASCII Adjust AL after Subtraction	0011 1111
ADC - ADD with Carry	
register1 to register2	0001 000w:11 reg1 reg2
register2 to register1	0001 001w:11 reg1 reg2
memory to register	0001 001w: mod reg r/m
register to memory	0001 000w : mod reg r/m
immediate to register	1000 00sw : 11 010 reg : immediate data
immediate to AL, AX, or EAX	0001 010w : immediate data
immediate to memory	1000 00sw : mod 010 r/m : immediate data
ADD - Add	
register1 to register2	0000 000w:11 reg1 reg2
register2 to register1	0000 001w:11 reg1 reg2
memory to register	0000 001w: mod reg r/m
register to memory	0000 000w : mod reg r/m

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
immediate to register	1000 00sw : 11 000 reg : immediate data
immediate to AL, AX, or EAX	0000 010w : immediate data
immediate to memory	1000 00sw : mod 000 r/m : immediate data
AND - Logical AND	
register1 to register2	0010 000w: 11 reg1 reg2
register2 to register1	0010 001w:11 reg1 reg2
memory to register	0010 001w : mod reg r/m
register to memory	0010 000w : mod reg r/m
immediate to register	1000 00sw : 11 100 reg : immediate data
immediate to AL, AX, or EAX	0010 010w : immediate data
immediate to memory	1000 00sw : mod 100 r/m : immediate data
ARPL - Adjust RPL Field of Selector	
from register	0110 0011 : 11 reg1 reg2
from memory	0110 0011 : mod reg r/m
BOUND - Check Array Against Bounds	0110 0010 : mod ^A reg r/m
BSF - Bit Scan Forward	
register1, register2	0000 1111 : 1011 1100 : 11 reg1 reg2
memory, register	0000 1111 : 1011 1100 : mod reg r/m
BSR - Bit Scan Reverse	
register1, register2	0000 1111 : 1011 1101 : 11 reg1 reg2
memory, register	0000 1111 : 1011 1101 : mod reg r/m
BSWAP - Byte Swap	0000 1111 : 1100 1 reg
BT - Bit Test	
register, immediate	0000 1111 : 1011 1010 : 11 100 reg: imm8 data
memory, immediate	0000 1111 : 1011 1010 : mod 100 r/m : imm8 data
register1, register2	0000 1111 : 1010 0011 : 11 reg2 reg1
memory, reg	0000 1111 : 1010 0011 : mod reg r/m
BTC - Bit Test and Complement	

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
register, immediate	0000 1111 : 1011 1010 : 11 111 reg: imm8 data
memory, immediate	0000 1111 : 1011 1010 : mod 111 r/m : imm8 data
register1, register2	0000 1111 : 1011 1011 : 11 reg2 reg1
memory, reg	0000 1111 : 1011 1011 : mod reg r/m
BTR - Bit Test and Reset	
register, immediate	0000 1111 : 1011 1010 : 11 110 reg: imm8 data
memory, immediate	0000 1111 : 1011 1010 : mod 110 r/m : imm8 data
register1, register2	0000 1111 : 1011 0011 : 11 reg2 reg1
memory, reg	0000 1111 : 1011 0011 : mod reg r/m
BTS - Bit Test and Set	
register, immediate	0000 1111 : 1011 1010 : 11 101 reg: imm8 data
memory, immediate	0000 1111 : 1011 1010 : mod 101 r/m : imm8 data
register1, register2	0000 1111 : 1010 1011 : 11 reg2 reg1
memory, reg	0000 1111 : 1010 1011 : mod reg r/m
CALL - Call Procedure (in same segment)	
direct	1110 1000 : full displacement
register indirect	1111 1111 : 11 010 reg
memory indirect	1111 1111 : mod 010 r/m
CALL - Call Procedure (in other segment)	
direct	1001 1010 : unsigned full offset, selector
indirect	1111 1111 : mod 011 r/m
CBW - Convert Byte to Word	1001 1000
CDQ - Convert Doubleword to Qword	1001 1001
CLC - Clear Carry Flag	1111 1000
CLD - Clear Direction Flag	1111 1100

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
CLI - Clear Interrupt Flag	1111 1010
CLTS - Clear Task-Switched Flag in CRO	0000 1111 : 0000 0110
CMC - Complement Carry Flag	1111 0101
CMP - Compare Two Operands	
register1 with register2	0011 100w:11 reg1 reg2
register2 with register1	0011 101w:11 reg1 reg2
memory with register	0011 100w : mod reg r/m
register with memory	0011 101w: mod reg r/m
immediate with register	1000 00sw : 11 111 reg : immediate data
immediate with AL, AX, or EAX	0011 110w : immediate data
immediate with memory	1000 00sw : mod 111 r/m : immediate data
CMPS/CMPSB/CMPSW/CMPSD - Compare String Operands	1010 011w
CMPXCHG - Compare and Exchange	
register1, register2	0000 1111 : 1011 000w : 11 reg2 reg1
memory, register	0000 1111 : 1011 000w : mod reg r/m
CPUID - CPU Identification	0000 1111 : 1010 0010
CWD - Convert Word to Doubleword	1001 1001
CWDE - Convert Word to Doubleword	1001 1000
DAA - Decimal Adjust AL after Addition	0010 0111
DAS - Decimal Adjust AL after Subtraction	0010 1111
DEC – Decrement by 1	
register	1111 111w:11 001 reg
register (alternate encoding)	0100 1 reg
memory	1111 111w: mod 001 r/m
DIV - Unsigned Divide	
AL, AX, or EAX by register	1111 011w:11 110 reg
AL, AX, or EAX by memory	1111 011w: mod 110 r/m
HLT - Halt	1111 0100

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
IDIV - Signed Divide	
AL, AX, or EAX by register	1111 011w:11 111 reg
AL, AX, or EAX by memory	1111 011w: mod 111 r/m
IMUL - Signed Multiply	
AL, AX, or EAX with register	1111 011w:11 101 reg
AL, AX, or EAX with memory	1111 011w: mod 101 reg
register1 with register2	0000 1111 : 1010 1111 : 11 : reg1 reg2
register with memory	0000 1111 : 1010 1111 : mod reg r/m
register1 with immediate to register2	0110 10s1 : 11 reg1 reg2 : immediate data
memory with immediate to register	0110 10s1 : mod reg r/m : immediate data
IN - Input From Port	
fixed port	1110 010w : port number
variable port	1110 110w
INC - Increment by 1	
reg	1111 111w:11 000 reg
reg (alternate encoding)	0100 0 reg
memory	1111 111w: mod 000 r/m
INS - Input from DX Port	0110 110w
INT n - Interrupt Type n	1100 1101 : type
INT - Single-Step Interrupt 3	1100 1100
INTO - Interrupt 4 on Overflow	1100 1110
INVD - Invalidate Cache	0000 1111 : 0000 1000
INVLPG - Invalidate TLB Entry	0000 1111 : 0000 0001 : mod 111 r/m
IRET/IRETD - Interrupt Return	1100 1111
Jcc - Jump if Condition is Met	
8-bit displacement	0111 tttn:8-bit displacement
full displacement	0000 1111 : 1000 tttn : full displacement
JCXZ/JECXZ - Jump on CX/ECX Zero Address-size prefix differentiates JCXZ and JECXZ	1110 0011 : 8-bit displacement

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
JMP - Unconditional Jump (to same segment)	
short	1110 1011 : 8-bit displacement
direct	1110 1001 : full displacement
register indirect	1111 1111 : 11 100 reg
memory indirect	1111 1111 : mod 100 r/m
JMP - Unconditional Jump (to other segment)	
direct intersegment	1110 1010: unsigned full offset, selector
indirect intersegment	1111 1111 : mod 101 r/m
LAHF - Load Flags into AHRegister	1001 1111
LAR - Load Access Rights Byte	
from register	0000 1111 : 0000 0010 : 11 reg1 reg2
from memory	0000 1111 : 0000 0010 : mod reg r/m
LDS - Load Pointer to DS	1100 0101 : mod ^{A,B} reg r/m
LEA - Load Effective Address	1000 1101 : mod ^A reg г/m
LEAVE - High Level Procedure Exit	1100 1001
LES - Load Pointer to ES	1100 0100 : mod ^{A,B} reg r/m
LFS - Load Pointer to FS	0000 1111 : 1011 0100 : mod ^A reg r/m
LGDT - Load Global Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 010 г/m
LGS - Load Pointer to GS	0000 1111 : 1011 0101 : mod ^A reg r/m
LIDT – Load Interrupt Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 011 r/m
LLDT - Load Local Descriptor Table Register	
LDTR from register	0000 1111 : 0000 0000 : 11 010 reg
LDTR from memory	0000 1111 : 0000 0000 : mod 010 г/m
LMSW - Load Machine Status Word	
from register	0000 1111 : 0000 0001 : 11 110 reg
from memory	0000 1111 : 0000 0001 : mod 110 r/m
LOCK - Assert LOCK# Signal Prefix	1111 0000
LODS/LODSB/LODSW/LODSD - Load String Operand	1010 110w

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
LOOP - Loop Count	1110 0010 : 8-bit displacement
LOOPZ/LOOPE - Loop Count while Zero/Equal	1110 0001 : 8-bit displacement
LOOPNZ/LOOPNE - Loop Count while not Zero/Equal	1110 0000 : 8-bit displacement
LSL - Load Segment Limit	
from register	0000 1111 : 0000 0011 : 11 reg1 reg2
from memory	0000 1111 : 0000 0011 : mod reg г/m
LSS - Load Pointer to SS	0000 1111 : 1011 0010 : mod ^A reg r/m
LTR - Load Task Register	
from register	0000 1111 : 0000 0000 : 11 011 reg
from memory	0000 1111 : 0000 0000 : mod 011 r/m
MOV - Move Data	
register1 to register2	1000 100w : 11 reg1 reg2
register2 to register1	1000 101w:11 reg1 reg2
memory to reg	1000 101w : mod reg r/m
reg to memory	1000 100w : mod reg r/m
immediate to register	1100 011w : 11 000 reg : immediate data
immediate to register (alternate encoding)	1011 w reg : immediate data
immediate to memory	1100 011w : mod 000 r/m : immediate data
memory to AL, AX, or EAX	1010 000w : full displacement
AL, AX, or EAX to memory	1010 001w: full displacement
MOV - Move to/from Control Registers	
CRO from register	0000 1111 : 0010 0010 : 11 000 reg
CR2 from register	0000 1111 : 0010 0010 : 11 010reg
CR3 from register	0000 1111 : 0010 0010 : 11 011 reg
CR4 from register	0000 1111 : 0010 0010 : 11 100 reg
register from CRO-CR4	0000 1111 : 0010 0000 : 11 eee reg
MOV - Move to/from Debug Registers	
DRO-DR3 from register	0000 1111 : 0010 0011 : 11 eee reg
DR4-DR5 from register	0000 1111 : 0010 0011 : 11 eee reg

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
DR6-DR7 from register	0000 1111 : 0010 0011 : 11 eee reg
register from DR6-DR7	0000 1111 : 0010 0001 : 11 eee reg
register from DR4-DR5	0000 1111 : 0010 0001 : 11 eee reg
register from DRO-DR3	0000 1111 : 0010 0001 : 11 eee reg
MOV - Move to/from Segment Registers	
register to segment register	1000 1110 : 11 sreg3 reg
register to SS	1000 1110 : 11 sreg3 reg
memory to segment reg	1000 1110 : mod sreg3 r/m
memory to SS	1000 1110 : mod sreg3 r/m
segment register to register	1000 1100 : 11 sreg3 reg
segment register to memory	1000 1100 : mod sreg3 r/m
MOVBE - Move data after swapping bytes	
memory to register	0000 1111 : 0011 1000:1111 0000 : mod reg r/m
register to memory	0000 1111 : 0011 1000:1111 0001 : mod reg r/m
MOVS/MOVSB/MOVSW/MOVSD - Move Data from String to String	1010 010w
MOVSX - Move with Sign-Extend	
memory to reg	0000 1111 : 1011 111w : mod reg r/m
MOVZX - Move with Zero-Extend	
register2 to register1	0000 1111 : 1011 011w : 11 reg1 reg2
memory to register	0000 1111 : 1011 011w : mod reg r/m
MUL - Unsigned Multiply	
AL, AX, or EAX with register	1111 011w:11 100 reg
AL, AX, or EAX with memory	1111 011w: mod 100 r/m
NEG – Two's Complement Negation	
register	1111 011w:11 011 reg
memory	1111 011w: mod 011 r/m
NOP - No Operation	1001 0000
NOP - Multi-byte No Operation ¹	

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
register	0000 1111 0001 1111 : 11 000 reg
memory	0000 1111 0001 1111 : mod 000 r/m
NOT - One's Complement Negation	
register	1111 011w:11 010 reg
memory	1111 011w: mod 010 r/m
OR - Logical Inclusive OR	
register1 to register2	0000 100w : 11 reg1 reg2
register2 to register1	0000 101w:11 reg1 reg2
memory to register	0000 101w : mod reg r/m
register to memory	0000 100w : mod reg r/m
immediate to register	1000 00sw : 11 001 reg : immediate data
immediate to AL, AX, or EAX	0000 110w : immediate data
immediate to memory	1000 00sw : mod 001 r/m : immediate data
OUT - Output to Port	
fixed port	1110 011w : port number
variable port	1110 111w
OUTS - Output to DX Port	0110 111w
POP - Pop a Word from the Stack	
register	1000 1111 : 11 000 reg
register (alternate encoding)	0101 1 reg
memory	1000 1111 : mod 000 r/m
POP - Pop a Segment Register from the Stack (Note: CS cannot be sreg2 in this usage.)	
segment register DS, ES	000 sreg2 111
segment register SS	000 sreg2 111
segment register FS, GS	0000 1111: 10 sreg3 001
POPA/POPAD - Pop All General Registers	0110 0001
POPF/POPFD - Pop Stack into FLAGS or EFLAGS Register	1001 1101
PUSH - Push Operand onto the Stack	

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
register	1111 1111 : 11 110 reg
register (alternate encoding)	0101 0 reg
memory	1111 1111 : mod 110 r/m
immediate	0110 10s0 : immediate data
PUSH - Push Segment Register onto the Stack	
segment register CS,DS,ES,SS	000 sreg2 110
segment register FS,GS	0000 1111: 10 sreg3 000
PUSHA/PUSHAD - Push All General Registers	0110 0000
PUSHF/PUSHFD – Push Flags Register onto the Stack	1001 1100
RCL - Rotate thru Carry Left	
register by 1	1101 000w : 11 010 reg
memory by 1	1101 000w : mod 010 r/m
register by CL	1101 001w:11 010 reg
memory by CL	1101 001w: mod 010 r/m
register by immediate count	1100 000w : 11 010 reg : imm8 data
memory by immediate count	1100 000w : mod 010 r/m : imm8 data
RCR - Rotate thru Carry Right	
register by 1	1101 000w : 11 011 reg
memory by 1	1101 000w : mod 011 r/m
register by CL	1101 001w:11 011 reg
memory by CL	1101 001w: mod 011 r/m
register by immediate count	1100 000w : 11 011 reg : imm8 data
memory by immediate count	1100 000w : mod 011 r/m : imm8 data
RDMSR - Read from Model-Specific Register	0000 1111 : 0011 0010
RDPMC - Read Performance Monitoring Counters	0000 1111 : 0011 0011
RDTSC - Read Time-Stamp Counter	0000 1111 : 0011 0001

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
RDTSCP - Read Time-Stamp Counter and Processor ID	0000 1111 : 0000 0001: 1111 1001
REP INS - Input String	1111 0011 : 0110 110w
REP LODS - Load String	1111 0011 : 1010 110w
REP MOVS - Move String	1111 0011 : 1010 010w
REP OUTS - Output String	1111 0011 : 0110 111w
REP STOS - Store String	1111 0011 : 1010 101w
REPE CMPS - Compare String	1111 0011 : 1010 011w
REPE SCAS - Scan String	1111 0011 : 1010 111w
REPNE CMPS - Compare String	1111 0010 : 1010 011w
REPNE SCAS – Scan String	1111 0010 : 1010 111w
RET - Return from Procedure (to same segment)	
no argument	1100 0011
adding immediate to SP	1100 0010 : 16-bit displacement
RET - Return from Procedure (to other segment)	
intersegment	1100 1011
adding immediate to SP	1100 1010 : 16-bit displacement
ROL - Rotate Left	
register by 1	1101 000w:11 000 reg
memory by 1	1101 000w: mod 000 r/m
register by CL	1101 001w:11 000 reg
memory by CL	1101 001w: mod 000 r/m
register by immediate count	1100 000w : 11 000 reg : imm8 data
memory by immediate count	1100 000w : mod 000 r/m : imm8 data
ROR - Rotate Right	
register by 1	1101 000w:11 001 reg
memory by 1	1101 000w: mod 001 r/m
register by CL	1101 001w:11 001 reg
memory by CL	1101 001w: mod 001 r/m

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
register by immediate count	1100 000w : 11 001 reg : imm8 data
memory by immediate count	1100 000w : mod 001 r/m : imm8 data
RSM - Resume from System Management Mode	0000 1111 : 1010 1010
SAHF - Store AH into Flags	1001 1110
SAL - Shift Arithmetic Left	same instruction as SHL
SAR – Shift Arithmetic Right	
register by 1	1101 000w : 11 111 reg
memory by 1	1101 000w : mod 111 r/m
register by CL	1101 001w:11 111 reg
memory by CL	1101 001w: mod 111 r/m
register by immediate count	1100 000w : 11 111 reg : imm8 data
memory by immediate count	1100 000w : mod 111 r/m : imm8 data
SBB - Integer Subtraction with Borrow	
register1 to register2	0001 100w : 11 reg1 reg2
register2 to register1	0001 101w:11 reg1 reg2
memory to register	0001 101w : mod reg r/m
register to memory	0001 100w : mod reg r/m
immediate to register	1000 00sw : 11 011 reg : immediate data
immediate to AL, AX, or EAX	0001 110w : immediate data
immediate to memory	1000 00sw : mod 011 r/m : immediate data
SCAS/SCASB/SCASW/SCASD - Scan String	1010 111w
SETcc - Byte Set on Condition	
register	0000 1111 : 1001 tttn : 11 000 reg
memory	0000 1111 : 1001 tttn : mod 000 r/m
SGDT - Store Global Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 000 r/m
SHL - Shift Left	
register by 1	1101 000w: 11 100 reg
memory by 1	1101 000w : mod 100 r/m

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
register by CL	1101 001w:11 100 reg
memory by CL	1101 001w: mod 100 r/m
register by immediate count	1100 000w : 11 100 reg : imm8 data
memory by immediate count	1100 000w : mod 100 r/m : imm8 data
SHLD - Double Precision Shift Left	
register by immediate count	0000 1111 : 1010 0100 : 11 reg2 reg1 : imm8
memory by immediate count	0000 1111 : 1010 0100 : mod reg r/m : imm8
register by CL	0000 1111 : 1010 0101 : 11 reg2 reg1
memory by CL	0000 1111 : 1010 0101 : mod reg r/m
SHR - Shift Right	
register by 1	1101 000w:11 101 reg
memory by 1	1101 000w: mod 101 r/m
register by CL	1101 001w:11 101 reg
memory by CL	1101 001w: mod 101 r/m
register by immediate count	1100 000w : 11 101 reg : imm8 data
memory by immediate count	1100 000w : mod 101 r/m : imm8 data
SHRD - Double Precision Shift Right	
register by immediate count	0000 1111 : 1010 1100 : 11 reg2 reg1 : imm8
memory by immediate count	0000 1111 : 1010 1100 : mod reg r/m : imm8
register by CL	0000 1111 : 1010 1101 : 11 reg2 reg1
memory by CL	0000 1111 : 1010 1101 : mod reg r/m
SIDT – Store Interrupt Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 001 r/m
SLDT - Store Local Descriptor Table Register	
to register	0000 1111 : 0000 0000 : 11 000 reg
to memory	0000 1111 : 0000 0000 : mod 000 r/m
SMSW - Store Machine Status Word	
to register	0000 1111 : 0000 0001 : 11 100 reg
to memory	0000 1111 : 0000 0001 : mod 100 r/m
STC – Set Carry Flag	1111 1001

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
STD - Set Direction Flag	1111 1101
STI - Set Interrupt Flag	1111 1011
STOS/STOSB/STOSW/STOSD - Store String Data	1010 101w
STR - Store Task Register	
to register	0000 1111 : 0000 0000 : 11 001 reg
to memory	0000 1111 : 0000 0000 : mod 001 r/m
SUB - Integer Subtraction	
register1 to register2	0010 100w : 11 reg1 reg2
register2 to register1	0010 101w:11 reg1 reg2
memory to register	0010 101w : mod reg r/m
register to memory	0010 100w : mod reg r/m
immediate to register	1000 00sw : 11 101 reg : immediate data
immediate to AL, AX, or EAX	0010 110w : immediate data
immediate to memory	1000 00sw : mod 101 r/m : immediate data
TEST - Logical Compare	
register1 and register2	1000 010w:11 reg1 reg2
memory and register	1000 010w : mod reg r/m
immediate and register	1111 011w:11 000 reg:immediate data
immediate and AL, AX, or EAX	1010 100w : immediate data
immediate and memory	1111 011w : mod 000 r/m : immediate data
UD2 - Undefined instruction	0000 FFFF : 0000 1011
VERR - Verify a Segment for Reading	
register	0000 1111 : 0000 0000 : 11 100 reg
memory	0000 1111 : 0000 0000 : mod 100 r/m
VERW - Verify a Segment for Writing	
register	0000 1111 : 0000 0000 : 11 101 reg
memory	0000 1111 : 0000 0000 : mod 101 r/m
WAIT - Wait	1001 1011

Table B-13. General Purpose Instruction Formats and Encodings for Non-64-Bit Modes (Contd.)

Instruction and Format	Encoding
WBINVD - Writeback and Invalidate Data Cache	0000 1111 : 0000 1001
WRMSR - Write to Model-Specific Register	0000 1111 : 0011 0000
XADD - Exchange and Add	
register1, register2	0000 1111 : 1100 000w : 11 reg2 reg1
memory, reg	0000 1111 : 1100 000w : mod reg r/m
XCHG - Exchange Register/Memory with Register	
register1 with register2	1000 011w:11 reg1 reg2
AX or EAX with reg	1001 0 reg
memory with reg	1000 011w : mod reg r/m
XLAT/XLATB - Table Look-up Translation	1101 0111
XOR - Logical Exclusive OR	
register1 to register2	0011 000w:11 reg1 reg2
register2 to register1	0011 001w:11 reg1 reg2
memory to register	0011 001w : mod reg r/m
register to memory	0011 000w : mod reg r/m
immediate to register	1000 00sw : 11 110 reg : immediate data
immediate to AL, AX, or EAX	0011 010w : immediate data
immediate to memory	1000 00sw : mod 110 r/m : immediate data
Prefix Bytes	
address size	0110 0111
LOCK	1111 0000
operand size	0110 0110
CS segment override	0010 1110
DS segment override	0011 1110
ES segment override	0010 0110
FS segment override	0110 0100
GS segment override	0110 0101
SS segment override	0011 0110

NOTES:

 The multi-byte NOP instruction does not alter the content of the register and will not issue a memory operation.

B.2.1 General Purpose Instruction Formats and Encodings for 64-Bit Mode

Table B-15 shows machine instruction formats and encodings for general purpose instructions in 64-bit mode.

Table B-14. Special Symbols

Symbol	Application
S	If the value of REX.W. is 1, it overrides the presence of 66H.
W	The value of bit W. in REX is has no effect.

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode

Instruction and Format	Encoding
ADC - ADD with Carry	
register1 to register2	0100 0R0B: 0001 000w: 11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B : 0001 0001 : 11 qwordreg1 qwordreg2
register2 to register1	0100 0R0B: 0001 001w: 11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B : 0001 0011 : 11 qwordreg1 qwordreg2
memory to register	0100 0RXB: 0001 001w: mod reg r/m
memory to qwordregister	0100 1RXB: 0001 0011: mod qwordreg r/m
register to memory	0100 0RXB: 0001 000w: mod reg r/m
qwordregister to memory	0100 1RXB: 0001 0001: mod qwordreg r/m
immediate to register	0100 000B : 1000 00sw : 11 010 reg : immediate
immediate to qwordregister	0100 100B : 1000 0001 : 11 010 qwordreg : imm32
immediate to qwordregister	0100 1R0B : 1000 0011 : 11 010 qwordreg : imm8
immediate to AL, AX, or EAX	0001 010w : immediate data

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
immediate to RAX	0100 1000 : 0000 0101 : imm32
immediate to memory	0100 00XB : 1000 00sw : mod 010 r/m : immediate
immediate32 to memory64	0100 10XB: 1000 0001: mod 010 r/m: imm32
immediate8 to memory64	0100 10XB : 1000 0031 : mod 010 r/m : imm8
ADD - Add	
register1 to register2	0100 0R0B: 0000 000w: 11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B 0000 0000 : 11 qwordreg1 qwordreg2
register2 to register1	0100 0R0B: 0000 001w: 11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B 0000 0010 : 11 qwordreg1 qwordreg2
memory to register	0100 0RXB : 0000 001w : mod reg r/m
memory64 to qwordregister	0100 1RXB : 0000 0000 : mod qwordreg r/m
register to memory	0100 0RXB : 0000 000w : mod reg r/m
qwordregister to memory64	0100 1RXB: 0000 0011: mod qwordreg r/m
immediate to register	0100 0000B : 1000 00sw : 11 000 reg : immediate data
immediate32 to qwordregister	0100 100B : 1000 0001 : 11 010 qwordreg : imm
immediate to AL, AX, or EAX	0000 010w : immediate8
immediate to RAX	0100 1000 : 0000 0101 : imm32
immediate to memory	0100 00XB : 1000 00sw : mod 000 r/m : immediate
immediate32 to memory64	0100 10XB : 1000 0001 : mod 010 r/m : imm32
immediate8 to memory64	0100 10XB: 1000 0011: mod 010 r/m: imm8
AND - Logical AND	
register1 to register2	0100 0R0B 0010 000w:11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B 0010 0001 : 11 qwordreg1 qwordreg2
register2 to register1	0100 0R0B 0010 001w:11 reg1 reg2

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
register1 to register2	0100 1R0B 0010 0011 : 11 qwordreg1 qwordreg2
memory to register	0100 0RXB 0010 001w: mod reg r/m
memory64 to qwordregister	0100 1RXB : 0010 0011 : mod qwordreg r/m
register to memory	0100 0RXB : 0010 000w : mod reg r/m
qwordregister to memory64	0100 1RXB : 0010 0001 : mod qwordreg r/m
immediate to register	0100 000B : 1000 00sw : 11 100 reg : immediate
immediate32 to qwordregister	0100 100B 1000 0001 : 11 100 qwordreg : imm32
immediate to AL, AX, or EAX	0010 010w : immediate
immediate32 to RAX	0100 1000 0010 1001 : imm32
immediate to memory	0100 00XB : 1000 00sw : mod 100 r/m : immediate
immediate32 to memory64	0100 10XB: 1000 0001: mod 100 r/m: immediate32
immediate8 to memory64	0100 10XB: 1000 0011: mod 100 r/m: imm8
BSF - Bit Scan Forward	
register1, register2	0100 0R0B 0000 1111 : 1011 1100 : 11 reg1 reg2
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1011 1100 : 11 qwordreg1 qwordreg2
memory, register	0100 0RXB 0000 1111 : 1011 1100 : mod reg r/m
memory64, qwordregister	0100 1RXB 0000 1111 : 1011 1100 : mod qwordreg r/m
BSR - Bit Scan Reverse	
register1, register2	0100 0R0B 0000 1111 : 1011 1101 : 11 reg1 reg2
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1011 1101 : 11 qwordreg1 qwordreg2
memory, register	0100 0RXB 0000 1111 : 1011 1101 : mod reg r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory64, qwordregister	0100 1RXB 0000 1111 : 1011 1101 : mod qwordreg r/m
BSWAP - Byte Swap	0000 1111 : 1100 1 reg
BSWAP - Byte Swap	0100 100B 0000 1111 : 1100 1 qwordreg
BT - Bit Test	
register, immediate	0100 000B 0000 1111 : 1011 1010 : 11 100 reg: imm8
qwordregister, immediate8	0100 100B 1111 : 1011 1010 : 11 100 qwordreg: imm8 data
memory, immediate	0100 00XB 0000 1111 : 1011 1010 : mod 100 r/m : imm8
memory64, immediate8	0100 10XB 0000 1111 : 1011 1010 : mod 100 r/m : imm8 data
register1, register2	0100 0R0B 0000 1111 : 1010 0011 : 11 reg2 reg1
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1010 0011 : 11 qwordreg2 qwordreg1
memory, reg	0100 0RXB 0000 1111 : 1010 0011 : mod reg r/m
memory, qwordreg	0100 1RXB 0000 1111 : 1010 0011 : mod qwordreg r/m
BTC - Bit Test and Complement	
register, immediate	0100 000B 0000 1111 : 1011 1010 : 11 111 reg: imm8
qwordregister, immediate8	0100 100B 0000 1111 : 1011 1010 : 11 111 qwordreg: imm8
memory, immediate	0100 00XB 0000 1111 : 1011 1010 : mod 111 r/m : imm8
memory64, immediate8	0100 10XB 0000 1111 : 1011 1010 : mod 111 r/m : imm8
register1, register2	0100 0R0B 0000 1111 : 1011 1011 : 11 reg2 reg1

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1011 1011 : 11 qwordreg2 qwordreg1
memory, register	0100 0RXB 0000 1111 : 1011 1011 : mod reg r/m
memory, qwordreg	0100 1RXB 0000 1111 : 1011 1011 : mod qwordreg r/m
BTR - Bit Test and Reset	
register, immediate	0100 000B 0000 1111 : 1011 1010 : 11 110 reg: imm8
qwordregister, immediate8	0100 100B 0000 1111 : 1011 1010 : 11 110 qwordreg: imm8
memory, immediate	0100 00XB 0000 1111 : 1011 1010 : mod 110 r/m : imm8
memory64, immediate8	0100 10XB 0000 1111 : 1011 1010 : mod 110 r/m : imm8
register1, register2	0100 0R0B 0000 1111 : 1011 0011 : 11 reg2 reg1
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1011 0011 : 11 qwordreg2 qwordreg1
memory, register	0100 0RXB 0000 1111 : 1011 0011 : mod reg r/m
memory64, qwordreg	0100 1RXB 0000 1111 : 1011 0011 : mod qwordreg r/m
BTS - Bit Test and Set	
register, immediate	0100 000B 0000 1111 : 1011 1010 : 11 101 reg: imm8
qwordregister, immediate8	0100 100B 0000 1111 : 1011 1010 : 11 101 qwordreg: imm8
memory, immediate	0100 00XB 0000 1111 : 1011 1010 : mod 101 r/m : imm8
memory64, immediate8	0100 10XB 0000 1111 : 1011 1010 : mod 101 r/m : imm8

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
register1, register2	0100 0R0B 0000 1111 : 1010 1011 : 11 reg2 reg1
qwordregister1, qwordregister2	0100 1R0B 0000 1111 : 1010 1011 : 11 qwordreg2 qwordreg1
memory, register	0100 0RXB 0000 1111 : 1010 1011 : mod reg r/m
memory64, qwordreg	0100 1RXB 0000 1111 : 1010 1011 : mod qwordreg r/m
CALL - Call Procedure (in same segment)	
direct	1110 1000 : displacement32
register indirect	0100 WR00 ^w 1111 1111 : 11 010 reg
memory indirect	0100 W0XB ^w 1111 1111 : mod 010 r/m
CALL - Call Procedure (in other segment)	
indirect	1111 1111 : mod 011 r/m
indirect	0100 10XB 0100 1000 1111 1111 : mod 011 r/m
CBW - Convert Byte to Word	1001 1000
CDQ - Convert Doubleword to Qword+	1001 1001
CDQE - RAX, Sign-Extend of EAX	0100 1000 1001 1001
CLC – Clear Carry Flag	1111 1000
CLD - Clear Direction Flag	1111 1100
CLI - Clear Interrupt Flag	1111 1010
CLTS - Clear Task-Switched Flag in CRO	0000 1111 : 0000 0110
CMC - Complement Carry Flag	1111 0101
CMP - Compare Two Operands	
register1 with register2	0100 0R0B 0011 100w:11 reg1 reg2
qwordregister1 with qwordregister2	0100 1R0B 0011 1001 : 11 qwordreg1 qwordreg2
register2 with register1	0100 0R0B 0011 101w:11 reg1 reg2
qwordregister2 with qwordregister1	0100 1R0B 0011 101w:11 qwordreg1 qwordreg2
memory with register	0100 0RXB 0011 100w : mod reg r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory64 with qwordregister	0100 1RXB 0011 1001 : mod qwordreg r/m
register with memory	0100 0RXB 0011 101w : mod reg r/m
qwordregister with memory64	0100 1RXB 0011 101w1 : mod qwordreg r/m
immediate with register	0100 000B 1000 00sw : 11 111 reg : imm
immediate32 with qwordregister	0100 100B 1000 0001 : 11 111 qwordreg : imm64
immediate with AL, AX, or EAX	0011 110w : imm
immediate32 with RAX	0100 1000 0011 1101 : imm32
immediate with memory	0100 00XB 1000 00sw : mod 111 r/m : imm
immediate32 with memory64	0100 1RXB 1000 0001 : mod 111 r/m : imm64
immediate8 with memory64	0100 1RXB 1000 0011 : mod 111 r/m : imm8
CMPS/CMPSB/CMPSW/CMPSD/CMPSQ - Compare String Operands	
compare string operands [X at DS:(E)SI with Y at ES:(E)DI]	1010 011w
qword at address RSI with qword at address RDI	0100 1000 1010 0111
CMPXCHG – Compare and Exchange	
register1, register2	0000 1111 : 1011 000w : 11 reg2 reg1
byteregister1, byteregister2	0100 000B 0000 1111 : 1011 0000 : 11 bytereg2 reg1
qwordregister1, qwordregister2	0100 100B 0000 1111 : 1011 0001 : 11 qwordreg2 reg1
memory, register	0000 1111 : 1011 000w : mod reg г/m
memory8, byteregister	0100 00XB 0000 1111 : 1011 0000 : mod bytereg r/m
memory64, qwordregister	0100 10XB 0000 1111 : 1011 0001 : mod qwordreg r/m
CPUID - CPU Identification	0000 1111 : 1010 0010
CQO – Sign-Extend RAX	0100 1000 1001 1001
CWD – Convert Word to Doubleword	1001 1001
CWDE - Convert Word to Doubleword	1001 1000

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
DEC - Decrement by 1	
register	0100 000B 1111 111w: 11 001 reg
qwordregister	0100 100B 1111 1111 : 11 001 qwordreg
memory	0100 00XB 1111 111w: mod 001 r/m
memory64	0100 10XB 1111 1111 : mod 001 r/m
DIV - Unsigned Divide	
AL, AX, or EAX by register	0100 000B 1111 011w:11 110 reg
Divide RDX:RAX by qwordregister	0100 100B 1111 0111 : 11 110 qwordreg
AL, AX, or EAX by memory	0100 00XB 1111 011w: mod 110 r/m
Divide RDX:RAX by memory64	0100 10XB 1111 0111 : mod 110 r/m
ENTER - Make Stack Frame for High Level Procedure	1100 1000 : 16-bit displacement : 8-bit level (L)
HLT - Halt	1111 0100
IDIV - Signed Divide	
AL, AX, or EAX by register	0100 000B 1111 011w:11 111 reg
RDX:RAX by qwordregister	0100 100B 1111 0111 : 11 111 qwordreg
AL, AX, or EAX by memory	0100 00XB 1111 011w: mod 111 r/m
RDX:RAX by memory64	0100 10XB 1111 0111 : mod 111 r/m
IMUL - Signed Multiply	
AL, AX, or EAX with register	0100 000B 1111 011w:11 101 reg
RDX:RAX <- RAX with qwordregister	0100 100B 1111 0111 : 11 101 qwordreg
AL, AX, or EAX with memory	0100 00XB 1111 011w: mod 101 r/m
RDX:RAX <- RAX with memory64	0100 10XB 1111 0111 : mod 101 r/m
register1 with register2	0000 1111 : 1010 1111 : 11 : reg1 reg2
qwordregister1 <- qwordregister1 with qwordregister2	0100 1R0B 0000 1111 : 1010 1111 : 11 : qwordreg1 qwordreg2
register with memory	0100 0RXB 0000 1111 : 1010 1111 : mod reg r/m
qwordregister <- qwordregister withmemory64	0100 1RXB 0000 1111 : 1010 1111 : mod qwordreg r/m
register1 with immediate to register2	0100 0R0B 0110 10s1 : 11 reg1 reg2 : imm

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
qwordregister1 <- qwordregister2 with sign- extended immediate8	0100 1R0B 0110 1011 : 11 qwordreg1 qwordreg2 : imm8
qwordregister1 <- qwordregister2 with immediate32	0100 1R0B 0110 1001 : 11 qwordreg1 qwordreg2 : imm32
memory with immediate to register	0100 ORXB 0110 10s1 : mod reg r/m : imm
qwordregister <- memory64 with sign- extended immediate8	0100 1RXB 0110 1011 : mod qwordreg r/m : imm8
qwordregister <- memory64 with immediate32	0100 1RXB 0110 1001 : mod qwordreg r/m : imm32
IN - Input From Port	
fixed port	1110 010w : port number
variable port	1110 110w
INC - Increment by 1	
гед	0100 000B 1111 111w:11 000 reg
qwordreg	0100 100B 1111 1111 : 11 000 qwordreg
memory	0100 00XB 1111 111w: mod 000 r/m
memory64	0100 10XB 1111 1111 : mod 000 r/m
INS - Input from DX Port	0110 110w
INT n - Interrupt Type n	1100 1101 : type
INT - Single-Step Interrupt 3	1100 1100
INTO - Interrupt 4 on Overflow	1100 1110
INVD - Invalidate Cache	0000 1111 : 0000 1000
INVLPG - Invalidate TLB Entry	0000 1111 : 0000 0001 : mod 111 r/m
IRETO - Interrupt Return	1100 1111
Jcc - Jump if Condition is Met	
8-bit displacement	0111 tttn: 8-bit displacement
displacements (excluding 16-bit relative offsets)	0000 1111 : 1000 tttn : displacement32
JCXZ/JECXZ - Jump on CX/ECX Zero	
Address-size prefix differentiates JCXZ and JECXZ	1110 0011 : 8-bit displacement
JMP - Unconditional Jump (to same segment)	

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
short	1110 1011 : 8-bit displacement
direct	1110 1001 : displacement32
register indirect	0100 W00B ^w : 1111 1111: 11 100 reg
memory indirect	0100 W0XB ^w : 1111 1111: mod 100 r/m
JMP - Unconditional Jump (to other segment)	
indirect intersegment	0100 00XB: 1111 1111: mod 101 r/m
64-bit indirect intersegment	0100 10XB : 1111 1111 : mod 101 r/m
LAR - Load Access Rights Byte	
from register	0100 0R0B : 0000 1111 : 0000 0010 : 11 reg1 reg2
from dwordregister to qwordregister, masked by 00FxFF00H	0100 WR0B: 0000 1111: 0000 0010: 11 qwordreg1 dwordreg2
from memory	0100 0RXB : 0000 1111 : 0000 0010 : mod reg r/m
from memory32 to qwordregister, masked by OOFxFFOOH	0100 WRXB 0000 1111 : 0000 0010 : mod r/m
LEA - Load Effective Address	
in wordregister/dwordregister	0100 0RXB : 1000 1101 : mod ^A reg r/m
in qwordregister	0100 1RXB : 1000 1101 : mod ^A qwordreg r/m
LEAVE - High Level Procedure Exit	1100 1001
LFS - Load Pointer to FS	
FS:r16/r32 with far pointer from memory	0100 0RXB : 0000 1111 : 1011 0100 : mod ^A reg r/m
FS:r64 with far pointer from memory	0100 1RXB : 0000 1111 : 1011 0100 : mod ^A qwordreg r/m
LGDT - Load Global Descriptor Table Register	0100 10XB : 0000 1111 : 0000 0001 : mod ^A 010 r/m
LGS - Load Pointer to GS	
GS:r16/r32 with far pointer from memory	0100 0RXB : 0000 1111 : 1011 0101 : mod ^A reg r/m
GS:r64 with far pointer from memory	0100 1RXB : 0000 1111 : 1011 0101 : mod ^A qwordreg r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
LIDT - Load Interrupt Descriptor Table Register	0100 10XB : 0000 1111 : 0000 0001 : mod ^A 011 r/m
LLDT - Load Local Descriptor Table Register	
LDTR from register	0100 000B : 0000 1111 : 0000 0000 : 11 010 reg
LDTR from memory	0100 00XB :0000 1111 : 0000 0000 : mod 010 r/m
LMSW - Load Machine Status Word	
from register	0100 000B : 0000 1111 : 0000 0001 : 11 110 reg
from memory	0100 00XB :0000 1111 : 0000 0001 : mod 110 r/m
LOCK - Assert LOCK# Signal Prefix	1111 0000
LODS/LODSB/LODSW/LODSD/LODSQ - Load String Operand	
at DS:(E)SI to AL/EAX/EAX	1010 110w
at (R)SI to RAX	0100 1000 1010 1101
LOOP - Loop Count	
if count != 0, 8-bit displacement	1110 0010
if count !=0, RIP + 8-bit displacement sign- extended to 64-bits	0100 1000 1110 0010
LOOPE - Loop Count while Zero/Equal	
if count != 0 & ZF =1, 8-bit displacement	1110 0001
if count !=0 & ZF = 1, RIP + 8-bit displacement sign-extended to 64-bits	0100 1000 1110 0001
LOOPNE/LOOPNZ - Loop Count while not Zero/Equal	
if count != 0 & ZF = 0, 8-bit displacement	1110 0000
if count !=0 & ZF = 0, RIP + 8-bit displacement sign-extended to 64-bits	0100 1000 1110 0000
LSL - Load Segment Limit	
from register	0000 1111 : 0000 0011 : 11 reg1 reg2

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
from qwordregister	0100 1R00 0000 1111 : 0000 0011 : 11 qwordreg1 reg2
from memory16	0000 1111 : 0000 0011 : mod reg r/m
from memory64	0100 1RXB 0000 1111 : 0000 0011 : mod qwordreg r/m
LSS - Load Pointer to SS	
SS:r16/r32 with far pointer from memory	0100 0RXB : 0000 1111 : 1011 0010 : mod ^A reg r/m
SS:r64 with far pointer from memory	0100 1WXB : 0000 1111 : 1011 0010 : mod ^A qwordreg r/m
LTR - Load Task Register	
from register	0100 0R00 : 0000 1111 : 0000 0000 : 11 011 reg
from memory	0100 00XB : 0000 1111 : 0000 0000 : mod 011 r/m
MOV - Move Data	
register1 to register2	0100 0R0B : 1000 100w : 11 reg1 reg2
qwordregister1 to qwordregister2	0100 1R0B 1000 1001 : 11 qwordeg1 qwordreg2
register2 to register1	0100 0R0B: 1000 101w: 11 reg1 reg2
qwordregister2 to qwordregister1	0100 1R0B 1000 1011 : 11 qwordreg1 qwordreg2
memory to reg	0100 ORXB : 1000 101w : mod reg r/m
memory64 to qwordregister	0100 1RXB 1000 1011 : mod qwordreg r/m
reg to memory	0100 ORXB : 1000 100w : mod reg r/m
qwordregister to memory64	0100 1RXB 1000 1001 : mod qwordreg r/m
immediate to register	0100 000B: 1100 011w: 11 000 reg: imm
immediate32 to qwordregister (zero extend)	0100 100B 1100 0111 : 11 000 qwordreg : imm32
immediate to register (alternate encoding)	0100 000B: 1011 w reg: imm
immediate64 to qwordregister (alternate encoding)	0100 100B 1011 1000 reg : imm64
immediate to memory	0100 00XB : 1100 011w : mod 000 r/m : imm

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
immediate32 to memory64 (zero extend)	0100 10XB 1100 0111 : mod 000 r/m : imm32
memory to AL, AX, or EAX	0100 0000 : 1010 000w : displacement
memory64 to RAX	0100 1000 1010 0001 : displacement64
AL, AX, or EAX to memory	0100 0000 : 1010 001w : displacement
RAX to memory64	0100 1000 1010 0011 : displacement64
MOV - Move to/from Control Registers	
CRO-CR4 from register	0100 OROB : 0000 1111 : 0010 0010 : 11 eee reg (eee = CR#)
CRx from qwordregister	0100 1R0B : 0000 1111 : 0010 0010 : 11 eee qwordreg (Reee = CR#)
register from CRO-CR4	0100 0R0B:0000 1111:0010 0000:11 eee reg (eee = CR#)
qwordregister from CRx	0100 1R0B 0000 1111 : 0010 0000 : 11 eee qwordreg (Reee = CR#)
MOV - Move to/from Debug Registers	
DRO-DR7 from register	0000 1111 : 0010 0011 : 11 eee reg (eee = DR#)
DR0-DR7 from quadregister	0100 100B 0000 1111 : 0010 0011 : 11 eee reg (eee = DR#)
register from DRO-DR7	0000 1111 : 0010 0001 : 11 eee reg (eee = DR#)
quadregister from DRO-DR7	0100 100B 0000 1111 : 0010 0001 : 11 eee quadreg (eee = DR#)
MOV - Move to/from Segment Registers	
register to segment register	0100 W00B ^w : 1000 1110:11 sreg reg
register to SS	0100 000B: 1000 1110: 11 sreg reg
memory to segment register	0100 00XB : 1000 1110 : mod sreg r/m
memory64 to segment register (lower 16 bits)	0100 10XB 1000 1110 : mod sreg r/m
memory to SS	0100 00XB : 1000 1110 : mod sreg r/m
segment register to register	0100 000B: 1000 1100: 11 sreg reg
segment register to qwordregister (zero extended)	0100 100B 1000 1100 : 11 sreg qwordreg
segment register to memory	0100 00XB : 1000 1100 : mod sreg r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
segment register to memory64 (zero extended)	0100 10XB 1000 1100 : mod sreg3 r/m
MOVBE - Move data after swapping bytes	
memory to register	0100 0RXB: 0000 1111: 0011 1000:1111 0000: mod reg r/m
memory64 to qwordregister	0100 1RXB: 0000 1111: 0011 1000:1111 0000: mod reg r/m
register to memory	0100 0RXB:0000 1111: 0011 1000:1111 0001: mod reg r/m
qwordregister to memory64	0100 1RXB:0000 1111:0011 1000:1111 0001:mod reg r/m
MOVS/MOVSB/MOVSW/MOVSD/MOVSQ - Move Data from String to String	
Move data from string to string	1010 010w
Move data from string to string (qword)	0100 1000 1010 0101
MOVSX/MOVSXD - Move with Sign-Extend	
register2 to register1	0100 0R0B: 0000 1111: 1011 111w: 11 reg1 reg2
byteregister2 to qwordregister1 (sign- extend)	0100 1R0B 0000 1111 : 1011 1110 : 11 quadreg1 bytereg2
wordregister2 to qwordregister1	0100 1R0B 0000 1111 : 1011 1111 : 11 quadreg1 wordreg2
dwordregister2 to qwordregister1	0100 1R0B 0110 0011 : 11 quadreg1 dwordreg2
memory to register	0100 0RXB : 0000 1111 : 1011 111w : mod reg r/m
memory8 to qwordregister (sign-extend)	0100 1RXB 0000 1111 : 1011 1110 : mod qwordreg r/m
memory16 to qwordregister	0100 1RXB 0000 1111 : 1011 1111 : mod qwordreg r/m
memory32 to qwordregister	0100 1RXB 0110 0011 : mod qwordreg r/m
MOVZX - Move with Zero-Extend	
register2 to register1	0100 0R0B: 0000 1111: 1011 011w: 11 reg1 reg2

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
dwordregister2 to qwordregister1	0100 1R0B 0000 1111 : 1011 0111 : 11 qwordreg1 dwordreg2
memory to register	0100 ORXB : 0000 1111 : 1011 011w : mod reg r/m
memory32 to qwordregister	0100 1RXB 0000 1111 : 1011 0111 : mod qwordreg r/m
MUL - Unsigned Multiply	
AL, AX, or EAX with register	0100 000B: 1111 011w: 11 100 reg
RAX with qwordregister (to RDX:RAX)	0100 100B 1111 0111 : 11 100 qwordreg
AL, AX, or EAX with memory	0100 00XB 1111 011w: mod 100 r/m
RAX with memory64 (to RDX:RAX)	0100 10XB 1111 0111 : mod 100 r/m
NEG - Two's Complement Negation	
register	0100 000B: 1111 011w: 11 011 reg
qwordregister	0100 100B 1111 0111 : 11 011 qwordreg
memory	0100 00XB: 1111 011w: mod 011 r/m
memory64	0100 10XB 1111 0111 : mod 011 r/m
NOP - No Operation	1001 0000
NOT - One's Complement Negation	
register	0100 000B: 1111 011w: 11 010 reg
qwordregister	0100 000B 1111 0111 : 11 010 qwordreg
memory	0100 00XB : 1111 011w : mod 010 r/m
memory64	0100 1RXB 1111 0111 : mod 010 r/m
OR - Logical Inclusive OR	
register1 to register2	0000 100w : 11 reg1 reg2
byteregister1 to byteregister2	0100 0R0B 0000 1000 : 11 bytereg1 bytereg2
qwordregister1 to qwordregister2	0100 1R0B 0000 1001 : 11 qwordreg1 qwordreg2
register2 to register1	0000 101w:11 reg1 reg2
byteregister2 to byteregister1	0100 0R0B 0000 1010 : 11 bytereg1 bytereg2

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
qwordregister2 to qwordregister1	0100 0R0B 0000 1011 : 11 qwordreg1
qwordrogistor2 to qwordrogistor	qwordreg2
memory to register	0000 101w : mod reg r/m
memory8 to byteregister	0100 0RXB 0000 1010 : mod bytereg r/m
memory8 to qwordregister	0100 0RXB 0000 1011 : mod qwordreg r/m
register to memory	0000 100w : mod reg r/m
byteregister to memory8	0100 0RXB 0000 1000 : mod bytereg r/m
qwordregister to memory64	0100 1RXB 0000 1001 : mod qwordreg r/m
immediate to register	1000 00sw:11 001 reg:imm
immediate8 to byteregister	0100 000B 1000 0000 : 11 001 bytereg : imm8
immediate32 to qwordregister	0100 000B 1000 0001 : 11 001 qwordreg : imm32
immediate8 to qwordregister	0100 000B 1000 0011 : 11 001 qwordreg : imm8
immediate to AL, AX, or EAX	0000 110w : imm
immediate64 to RAX	0100 1000 0000 1101 : imm64
immediate to memory	1000 00sw : mod 001 r/m : imm
immediate8 to memory8	0100 00XB 1000 0000 : mod 001 r/m : imm8
immediate32 to memory64	0100 00XB 1000 0001 : mod 001 r/m : imm32
immediate8 to memory64	0100 00XB 1000 0011 : mod 001 r/m : imm8
OUT - Output to Port	
fixed port	1110 011w : port number
variable port	1110 111w
OUTS - Output to DX Port	
output to DX Port	0110 111w
POP - Pop a Value from the Stack	
wordregister	0101 0101 : 0100 000B : 1000 1111 : 11 000 reg16
qwordregister	0100 W00B ^S : 1000 1111 : 11 000 reg64
wordregister (alternate encoding)	0101 0101 : 0100 000B : 0101 1 reg16

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
qwordregister (alternate encoding)	0100 W00B : 0101 1 reg64
memory64	0100 W0XB ^S : 1000 1111 : mod 000 r/m
memory16	0101 0101 : 0100 00XB 1000 1111 : mod 000 r/m
POP - Pop a Segment Register from the Stack (Note: CS cannot be sreg2 in this usage.)	
segment register FS, GS	0000 1111: 10 sreg3 001
POPF/POPFQ - Pop Stack into FLAGS/RFLAGS Register	
pop stack to FLAGS register	0101 0101 : 1001 1101
pop Stack to RFLAGS register	0100 1000 1001 1101
PUSH - Push Operand onto the Stack	
wordregister	0101 0101 : 0100 000B : 1111 1111 : 11 110 reg16
qwordregister	0100 W00B ^S : 1111 1111 : 11 110 reg64
wordregister (alternate encoding)	0101 0101 : 0100 000B : 0101 0 reg16
qwordregister (alternate encoding)	0100 W00B ^S : 0101 0 reg64
memory16	0101 0101 : 0100 000B : 1111 1111 : mod 110 r/m
memory64	0100 W00B ^S : 1111 1111 : mod 110 r/m
immediate8	0110 1010 : imm8
immediate16	0101 0101 : 0110 1000 : imm16
immediate64	0110 1000 : imm64
PUSH - Push Segment Register onto the Stack	
segment register FS,GS	0000 1111: 10 sreg3 000
PUSHF/PUSHFD - Push Flags Register onto the Stack	1001 1100
RCL - Rotate thru Carry Left	
register by 1	0100 000B: 1101 000w: 11 010 reg
qwordregister by 1	0100 100B 1101 0001 : 11 010 qwordreg
memory by 1	0100 00XB : 1101 000w : mod 010 r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory64 by 1	0100 10XB 1101 0001 : mod 010 r/m
register by CL	0100 000B: 1101 001w: 11 010 reg
qwordregister by CL	0100 100B 1101 0011 : 11 010 qwordreg
memory by CL	0100 00XB : 1101 001w : mod 010 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 010 r/m
register by immediate count	0100 000B : 1100 000w : 11 010 reg : imm
qwordregister by immediate count	0100 100B 1100 0001 : 11 010 qwordreg : imm8
memory by immediate count	0100 00XB : 1100 000w : mod 010 r/m : imm
memory64 by immediate count	0100 10XB 1100 0001 : mod 010 r/m : imm8
RCR - Rotate thru Carry Right	
register by 1	0100 000B: 1101 000w: 11 011 reg
qwordregister by 1	0100 100B 1101 0001 : 11 011 qwordreg
memory by 1	0100 00XB : 1101 000w : mod 011 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 011 r/m
register by CL	0100 000B: 1101 001w: 11 011 reg
qwordregister by CL	0100 000B 1101 0010 : 11 011 qwordreg
memory by CL	0100 00XB : 1101 001w : mod 011 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 011 r/m
register by immediate count	0100 000B: 1100 000w: 11 011 reg: imm8
qwordregister by immediate count	0100 100B 1100 0001 : 11 011 qwordreg : imm8
memory by immediate count	0100 00XB: 1100 000w: mod 011 r/m: imm8
memory64 by immediate count	0100 10XB 1100 0001 : mod 011 r/m : imm8
RDMSR - Read from Model-Specific Register	
load ECX-specified register into EDX:EAX	0000 1111 : 0011 0010
RDPMC - Read Performance Monitoring Counters	
load ECX-specified performance counter into EDX:EAX	0000 1111 : 0011 0011
RDTSC - Read Time-Stamp Counter	

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
read time-stamp counter into EDX:EAX	0000 1111 : 0011 0001
RDTSCP – Read Time-Stamp Counter and Processor ID	0000 1111 : 0000 0001: 1111 1001
REP INS - Input String	
REP LODS - Load String	
REP MOVS - Move String	
REP OUTS - Output String	
REP STOS - Store String	
REPE CMPS – Compare String	
REPE SCAS - Scan String	
REPNE CMPS – Compare String	
REPNE SCAS - Scan String	
RET - Return from Procedure (to same segment)	
no argument	1100 0011
adding immediate to SP	1100 0010 : 16-bit displacement
RET - Return from Procedure (to other segment)	
intersegment	1100 1011
adding immediate to SP	1100 1010 : 16-bit displacement
ROL - Rotate Left	
register by 1	0100 000B 1101 000w: 11 000 reg
byteregister by 1	0100 000B 1101 0000 : 11 000 bytereg
qwordregister by 1	0100 100B 1101 0001 : 11 000 qwordreg
memory by 1	0100 00XB 1101 000w: mod 000 r/m
memory8 by 1	0100 00XB 1101 0000 : mod 000 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 000 r/m
register by CL	0100 000B 1101 001w: 11 000 reg
byteregister by CL	0100 000B 1101 0010 : 11 000 bytereg
qwordregister by CL	0100 100B 1101 0011 : 11 000 qwordreg

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory by CL	0100 00XB 1101 001w : mod 000 r/m
memory8 by CL	0100 00XB 1101 0010 : mod 000 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 000 r/m
register by immediate count	1100 000w : 11 000 reg : imm8
byteregister by immediate count	0100 000B 1100 0000 : 11 000 bytereg : imm8
qwordregister by immediate count	0100 100B 1100 0001 : 11 000 bytereg : imm8
memory by immediate count	1100 000w : mod 000 r/m : imm8
memory8 by immediate count	0100 00XB 1100 0000 : mod 000 r/m : imm8
memory64 by immediate count	0100 10XB 1100 0001 : mod 000 r/m : imm8
ROR - Rotate Right	
register by 1	0100 000B 1101 000w:11 001 reg
byteregister by 1	0100 000B 1101 0000:11 001 bytereg
qwordregister by 1	0100 100B 1101 0001 : 11 001 qwordreg
memory by 1	0100 00XB 1101 000w : mod 001 r/m
memory8 by 1	0100 00XB 1101 0000 : mod 001 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 001 r/m
register by CL	0100 000B 1101 001w:11 001 reg
byteregister by CL	0100 000B 1101 0010:11 001 bytereg
qwordregister by CL	0100 100B 1101 0011 : 11 001 qwordreg
memory by CL	0100 00XB 1101 001w: mod 001 r/m
memory8 by CL	0100 00XB 1101 0010 : mod 001 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 001 r/m
register by immediate count	0100 000B 1100 000w : 11 001 reg : imm8
byteregister by immediate count	0100 000B 1100 0000 : 11 001 reg : imm8
qwordregister by immediate count	0100 100B 1100 0001 : 11 001 qwordreg : imm8
memory by immediate count	0100 00XB 1100 000w: mod 001 r/m: imm8
memory8 by immediate count	0100 00XB 1100 0000 : mod 001 r/m : imm8

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory64 by immediate count	0100 10XB 1100 0001 : mod 001 r/m : imm8
RSM - Resume from System Management Mode	0000 1111 : 1010 1010
SAL - Shift Arithmetic Left	same instruction as SHL
SAR - Shift Arithmetic Right	
register by 1	0100 000B 1101 000w: 11 111 reg
byteregister by 1	0100 000B 1101 0000 : 11 111 bytereg
qwordregister by 1	0100 100B 1101 0001 : 11 111 qwordreg
memory by 1	0100 00XB 1101 000w: mod 111 r/m
memory8 by 1	0100 00XB 1101 0000 : mod 111 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 111 r/m
register by CL	0100 000B 1101 001w: 11 111 reg
byteregister by CL	0100 000B 1101 0010 : 11 111 bytereg
qwordregister by CL	0100 100B 1101 0011 : 11 111 qwordreg
memory by CL	0100 00XB 1101 001w: mod 111 r/m
memory8 by CL	0100 00XB 1101 0010 : mod 111 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 111 r/m
register by immediate count	0100 000B 1100 000w : 11 111 reg : imm8
byteregister by immediate count	0100 000B 1100 0000 : 11 111 bytereg : imm8
qwordregister by immediate count	0100 100B 1100 0001 : 11 111 qwordreg : imm8
memory by immediate count	0100 00XB 1100 000w: mod 111 r/m: imm8
memory8 by immediate count	0100 00XB 1100 0000 : mod 111 r/m : imm8
memory64 by immediate count	0100 10XB 1100 0001 : mod 111 r/m : imm8
SBB - Integer Subtraction with Borrow	
register1 to register2	0100 0R0B 0001 100w: 11 reg1 reg2
byteregister1 to byteregister2	0100 0R0B 0001 1000 : 11 bytereg1 bytereg2
quadregister1 to quadregister2	0100 1R0B 0001 1001 : 11 quadreg1 quadreg2

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
register2 to register1	0100 0R0B 0001 101w:11 reg1 reg2
byteregister2 to byteregister1	0100 0R0B 0001 1010 : 11 reg1 bytereg2
byteregister2 to byteregister1	0100 1R0B 0001 1011 : 11 reg1 bytereg2
memory to register	0100 0RXB 0001 101w : mod reg r/m
memory8 to byteregister	0100 0RXB 0001 1010 : mod bytereg r/m
memory64 to byteregister	0100 1RXB 0001 1011 : mod quadreg r/m
register to memory	0100 0RXB 0001 100w : mod reg r/m
byteregister to memory8	0100 0RXB 0001 1000 : mod reg r/m
quadregister to memory64	0100 1RXB 0001 1001 : mod reg r/m
immediate to register	0100 000B 1000 00sw : 11 011 reg : imm
immediate8 to byteregister	0100 000B 1000 0000 : 11 011 bytereg : imm8
immediate32 to qwordregister	0100 100B 1000 0001 : 11 011 qwordreg : imm32
immediate8 to qwordregister	0100 100B 1000 0011 : 11 011 qwordreg : imm8
immediate to AL, AX, or EAX	0100 000B 0001 110w:imm
immediate32 to RAL	0100 1000 0001 1101 : imm32
immediate to memory	0100 00XB 1000 00sw : mod 011 r/m : imm
immediate8 to memory8	0100 00XB 1000 0000 : mod 011 r/m : imm8
immediate32 to memory64	0100 10XB 1000 0001 : mod 011 r/m : imm32
immediate8 to memory64	0100 10XB 1000 0011 : mod 011 r/m : imm8
SCAS/SCASB/SCASW/SCASD - Scan String	
scan string	1010 111w
scan string (compare AL with byte at RDI)	0100 1000 1010 1110
scan string (compare RAX with qword at RDI)	0100 1000 1010 1111
SETcc - Byte Set on Condition	
register	0100 000B 0000 1111 : 1001 tttn : 11 000 reg
register	0100 0000 0000 1111 : 1001 tttn : 11 000 reg

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory	0100 00XB 0000 1111 : 1001 tttn : mod 000 r/m
memory	0100 0000 0000 1111 : 1001 tttn : mod 000 r/m
SGDT - Store Global Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 000 г/m
SHL - Shift Left	
register by 1	0100 000B 1101 000w: 11 100 reg
byteregister by 1	0100 000B 1101 0000 : 11 100 bytereg
qwordregister by 1	0100 100B 1101 0001 : 11 100 qwordreg
memory by 1	0100 00XB 1101 000w: mod 100 r/m
memory8 by 1	0100 00XB 1101 0000 : mod 100 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 100 r/m
register by CL	0100 000B 1101 001w:11 100 reg
byteregister by CL	0100 000B 1101 0010 : 11 100 bytereg
qwordregister by CL	0100 100B 1101 0011 : 11 100 qwordreg
memory by CL	0100 00XB 1101 001w: mod 100 r/m
memory8 by CL	0100 00XB 1101 0010 : mod 100 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 100 r/m
register by immediate count	0100 000B 1100 000w: 11 100 reg: imm8
byteregister by immediate count	0100 000B 1100 0000 : 11 100 bytereg : imm8
quadregister by immediate count	0100 100B 1100 0001 : 11 100 quadreg : imm8
memory by immediate count	0100 00XB 1100 000w: mod 100 r/m: imm8
memory8 by immediate count	0100 00XB 1100 0000 : mod 100 r/m : imm8
memory64 by immediate count	0100 10XB 1100 0001 : mod 100 r/m : imm8
SHLD - Double Precision Shift Left	
register by immediate count	0100 0R0B 0000 1111 : 1010 0100 : 11 reg2 reg1 : imm8
qwordregister by immediate8	0100 1R0B 0000 1111 : 1010 0100 : 11 qworddreg2 qwordreg1 : imm8

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory by immediate count	0100 0RXB 0000 1111 : 1010 0100 : mod reg r/m : imm8
memory64 by immediate8	0100 1RXB 0000 1111 : 1010 0100 : mod qwordreg r/m : imm8
register by CL	0100 0R0B 0000 1111 : 1010 0101 : 11 reg2 reg1
quadregister by CL	0100 1R0B 0000 1111 : 1010 0101 : 11 quadreg2 quadreg1
memory by CL	0100 00XB 0000 1111 : 1010 0101 : mod reg r/m
memory64 by CL	0100 1RXB 0000 1111 : 1010 0101 : mod quadreg r/m
SHR - Shift Right	
register by 1	0100 000B 1101 000w : 11 101 reg
byteregister by 1	0100 000B 1101 0000 : 11 101 bytereg
qwordregister by 1	0100 100B 1101 0001 : 11 101 qwordreg
memory by 1	0100 00XB 1101 000w : mod 101 r/m
memory8 by 1	0100 00XB 1101 0000 : mod 101 r/m
memory64 by 1	0100 10XB 1101 0001 : mod 101 r/m
register by CL	0100 000B 1101 001w:11 101 reg
byteregister by CL	0100 000B 1101 0010:11 101 bytereg
qwordregister by CL	0100 100B 1101 0011 : 11 101 qwordreg
memory by CL	0100 00XB 1101 001w: mod 101 r/m
memory8 by CL	0100 00XB 1101 0010 : mod 101 r/m
memory64 by CL	0100 10XB 1101 0011 : mod 101 r/m
register by immediate count	0100 000B 1100 000w: 11 101 reg: imm8
byteregister by immediate count	0100 000B 1100 0000 : 11 101 reg : imm8
qwordregister by immediate count	0100 100B 1100 0001 : 11 101 reg : imm8
memory by immediate count	0100 00XB 1100 000w: mod 101 r/m: imm8
memory8 by immediate count	0100 00XB 1100 0000 : mod 101 r/m : imm8

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory64 by immediate count	0100 10XB 1100 0001 : mod 101 r/m : imm8
SHRD - Double Precision Shift Right	
register by immediate count	0100 0R0B 0000 1111 : 1010 1100 : 11 reg2 reg1 : imm8
qwordregister by immediate8	0100 1R0B 0000 1111 : 1010 1100 : 11 qwordreg2 qwordreg1 : imm8
memory by immediate count	0100 00XB 0000 1111 : 1010 1100 : mod reg r/m : imm8
memory64 by immediate8	0100 1RXB 0000 1111 : 1010 1100 : mod qwordreg r/m : imm8
register by CL	0100 000B 0000 1111 : 1010 1101 : 11 reg2 reg1
qwordregister by CL	0100 1R0B 0000 1111 : 1010 1101 : 11 qwordreg2 qwordreg1
memory by CL	0000 1111 : 1010 1101 : mod reg r/m
memory64 by CL	0100 1RXB 0000 1111 : 1010 1101 : mod qwordreg r/m
SIDT – Store Interrupt Descriptor Table Register	0000 1111 : 0000 0001 : mod ^A 001 r/m
SLDT - Store Local Descriptor Table Register	
to register	0100 000B 0000 1111 : 0000 0000 : 11 000 reg
to memory	0100 00XB 0000 1111 : 0000 0000 : mod 000 r/m
SMSW - Store Machine Status Word	
to register	0100 000B 0000 1111 : 0000 0001 : 11 100 reg
to memory	0100 00XB 0000 1111 : 0000 0001 : mod 100 r/m
STC - Set Carry Flag	1111 1001
STD - Set Direction Flag	1111 1101
STI - Set Interrupt Flag	1111 1011

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
STOS/STOSB/STOSW/STOSD/STOSQ - Store String Data	
store string data	1010 101w
store string data (RAX at address RDI)	0100 1000 1010 1011
STR - Store Task Register	
to register	0100 000B 0000 1111 : 0000 0000 : 11 001 reg
to memory	0100 00XB 0000 1111 : 0000 0000 : mod 001 r/m
SUB – Integer Subtraction	
register1 from register2	0100 0R0B 0010 100w : 11 reg1 reg2
byteregister1 from byteregister2	0100 0R0B 0010 1000 : 11 bytereg1 bytereg2
qwordregister1 from qwordregister2	0100 1R0B 0010 1000 : 11 qwordreg1 qwordreg2
register2 from register1	0100 0R0B 0010 101w : 11 reg1 reg2
byteregister2 from byteregister1	0100 0R0B 0010 1010 : 11 bytereg1 bytereg2
qwordregister2 from qwordregister1	0100 1R0B 0010 1011 : 11 qwordreg1 qwordreg2
memory from register	0100 00XB 0010 101w : mod reg r/m
memory8 from byteregister	0100 ORXB 0010 1010 : mod bytereg r/m
memory64 from qwordregister	0100 1RXB 0010 1011 : mod qwordreg r/m
register from memory	0100 ORXB 0010 100w : mod reg r/m
byteregister from memory8	0100 ORXB 0010 1000 : mod bytereg r/m
qwordregister from memory8	0100 1RXB 0010 1000 : mod qwordreg r/m
immediate from register	0100 000B 1000 00sw : 11 101 reg : imm
immediate8 from byteregister	0100 000B 1000 0000 : 11 101 bytereg : imm8
immediate32 from qwordregister	0100 100B 1000 0001 : 11 101 qwordreg : imm32

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
immediate8 from qwordregister	0100 100B 1000 0011 : 11 101 qwordreg : imm8
immediate from AL, AX, or EAX	0100 000B 0010 110w : imm
immediate32 from RAX	0100 1000 0010 1101 : imm32
immediate from memory	0100 00XB 1000 00sw : mod 101 r/m : imm
immediate8 from memory8	0100 00XB 1000 0000 : mod 101 r/m : imm8
immediate32 from memory64	0100 10XB 1000 0001 : mod 101 r/m : imm32
immediate8 from memory64	0100 10XB 1000 0011 : mod 101 r/m : imm8
SWAPGS - Swap GS Base Register	
GS base register value for value in MSR C0000102H	0000 1111 0000 0001 [this one incomplete]
SYSCALL - Fast System Call	
fast call to privilege level 0 system procedures	0000 1111 0000 0101
SYSRET - Return From Fast System Call	
return from fast system call	0000 1111 0000 0111
TEST - Logical Compare	
register1 and register2	0100 0R0B 1000 010w : 11 reg1 reg2
byteregister1 and byteregister2	0100 0R0B 1000 0100 : 11 bytereg1 bytereg2
qwordregister1 and qwordregister2	0100 1R0B 1000 0101 : 11 qwordreg1 qwordreg2
memory and register	0100 0R0B 1000 010w : mod reg r/m
memory8 and byteregister	0100 0RXB 1000 0100 : mod bytereg r/m
memory64 and qwordregister	0100 1RXB 1000 0101 : mod qwordreg r/m
immediate and register	0100 000B 1111 011w : 11 000 reg : imm
immediate8 and byteregister	0100 000B 1111 0110 : 11 000 bytereg : imm8
immediate32 and qwordregister	0100 100B 1111 0111 : 11 000 bytereg : imm8
immediate and AL, AX, or EAX	0100 000B 1010 100w : imm

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
immediate32 and RAX	0100 1000 1010 1001 : imm32
	0.00.000.000.000
immediate and memory	0100 00XB 1111 011w : mod 000 r/m : imm
immediate8 and memory8	0100 1000 1111 0110 : mod 000 r/m : imm8
immediate32 and memory64	0100 1000 1111 0111 : mod 000 r/m : imm32
UD2 - Undefined instruction	0000 FFFF : 0000 1011
VERR - Verify a Segment for Reading	
register	0100 000B 0000 1111 : 0000 0000 : 11 100 reg
memory	0100 00XB 0000 1111 : 0000 0000 : mod 100 r/m
VERW - Verify a Segment for Writing	
register	0100 000B 0000 1111 : 0000 0000 : 11 101 reg
memory	0100 00XB 0000 1111 : 0000 0000 : mod 101 r/m
WAIT - Wait	1001 1011
WBINVD - Writeback and Invalidate Data Cache	0000 1111 : 0000 1001
WRMSR - Write to Model-Specific Register	
write EDX:EAX to ECX specified MSR	0000 1111 : 0011 0000
write RDX[31:0]:RAX[31:0] to RCX specified MSR	0100 1000 0000 1111 : 0011 0000
XADD – Exchange and Add	
register1, register2	0100 0R0B 0000 1111 : 1100 000w : 11 reg2 reg1
byteregister1, byteregister2	0100 0R0B 0000 1111 : 1100 0000 : 11 bytereg2 bytereg1
qwordregister1, qwordregister2	0100 0R0B 0000 1111 : 1100 0001 : 11 qwordreg2 qwordreg1
memory, register	0100 ORXB 0000 1111 : 1100 000w : mod reg r/m

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
memory8, bytereg	0100 1RXB 0000 1111 : 1100 0000 : mod bytereg r/m
memory64, qwordreg	0100 1RXB 0000 1111 : 1100 0001 : mod qwordreg r/m
XCHG - Exchange Register/Memory with Register	
register1 with register2	1000 011w:11 reg1 reg2
AX or EAX with register	1001 0 reg
memory with register	1000 011w : mod reg r/m
XLAT/XLATB - Table Look-up Translation	
AL to byte DS:[(E)BX + unsigned AL]	1101 0111
AL to byte DS:[RBX + unsigned AL]	0100 1000 1101 0111
XOR - Logical Exclusive OR	
register1 to register2	0100 ORXB 0011 000w: 11 reg1 reg2
byteregister1 to byteregister2	0100 0R0B 0011 0000 : 11 bytereg1 bytereg2
qwordregister1 to qwordregister2	0100 1R0B 0011 0001 : 11 qwordreg1 qwordreg2
register2 to register1	0100 0R0B 0011 001w:11 reg1 reg2
byteregister2 to byteregister1	0100 0R0B 0011 0010 : 11 bytereg1 bytereg2
qwordregister2 to qwordregister1	0100 1R0B 0011 0011 : 11 qwordreg1 qwordreg2
memory to register	0100 ORXB 0011 001w: mod reg r/m
memory8 to byteregister	0100 ORXB 0011 0010 : mod bytereg r/m
memory64 to qwordregister	0100 1RXB 0011 0011 : mod qwordreg r/m
register to memory	0100 ORXB 0011 000w : mod reg r/m
byteregister to memory8	0100 ORXB 0011 0000 : mod bytereg r/m
qwordregister to memory8	0100 1RXB 0011 0001 : mod qwordreg r/m
immediate to register	0100 000B 1000 00sw : 11 110 reg : imm
immediate8 to byteregister	0100 000B 1000 0000 : 11 110 bytereg : imm8

Table B-15. General Purpose Instruction Formats and Encodings for 64-Bit Mode (Contd.)

Instruction and Format	Encoding
immediate32 to qwordregister	0100 100B 1000 0001 : 11 110 qwordreg : imm32
immediate8 to qwordregister	0100 100B 1000 0011 : 11 110 qwordreg : imm8
immediate to AL, AX, or EAX	0100 000B 0011 010w : imm
immediate to RAX	0100 1000 0011 0101 : immediate data
immediate to memory	0100 00XB 1000 00sw : mod 110 r/m : imm
immediate8 to memory8	0100 00XB 1000 0000 : mod 110 r/m : imm8
immediate32 to memory64	0100 10XB 1000 0001 : mod 110 r/m : imm32
immediate8 to memory64	0100 10XB 1000 0011 : mod 110 r/m : imm8
Prefix Bytes	
address size	0110 0111
LOCK	1111 0000
operand size	0110 0110
CS segment override	0010 1110
DS segment override	0011 1110
ES segment override	0010 0110
FS segment override	0110 0100
GS segment override	0110 0101
SS segment override	0011 0110

B.3 PENTIUM® PROCESSOR FAMILY INSTRUCTION FORMATS AND ENCODINGS

The following table shows formats and encodings introduced by the Pentium processor family.

Table B-16. Pentium Processor Family Instruction Formats and Encodings, Non-64-Bit Modes

Instruction and Format	Encoding
CMPXCHG8B - Compare and Exchange 8 Bytes	

Table B-16. Pentium Processor Family Instruction Formats and Encodings,
Non-64-Bit Modes

EDX:EAX with memory64	0000 1111 : 1100 0111 : mod 001 r/m
1	

Table B-17. Pentium Processor Family Instruction Formats and Encodings, 64-Bit Mode

Instruction and Format	Encoding
CMPXCHG8B/CMPXCHG16B - Compare and Exchange Bytes	
EDX:EAX with memory64	0000 1111 : 1100 0111 : mod 001 r/m
RDX:RAX with memory128	0100 10XB 0000 1111 : 1100 0111 : mod 001 r/m

B.4 64-BIT MODE INSTRUCTION ENCODINGS FOR SIMD INSTRUCTION EXTENSIONS

Non-64-bit mode instruction encodings for MMX Technology, SSE, SSE2, and SSE3 are covered by applying these rules to Table B-19 through Table B-31. Table B-34 lists special encodings (instructions that do not follow the rules below).

- 1. The REX instruction has no effect:
 - On immediates
 - If both operands are MMX registers
 - On MMX registers and XMM registers
 - If an MMX register is encoded in the reg field of the ModR/M byte
- 2. If a memory operand is encoded in the r/m field of the ModR/M byte, REX.X and REX.B may be used for encoding the memory operand.
- 3. If a general-purpose register is encoded in the r/m field of the ModR/M byte, REX.B may be used for register encoding and REX.W may be used to encode the 64-bit operand size.
- 4. If an XMM register operand is encoded in the reg field of the ModR/M byte, REX.R may be used for register encoding. If an XMM register operand is encoded in the r/m field of the ModR/M byte, REX.B may be used for register encoding.

B.5 MMX INSTRUCTION FORMATS AND ENCODINGS

MMX instructions, except the EMMS instruction, use a format similar to the 2-byte Intel Architecture integer format. Details of subfield encodings within these formats are presented below.

B.5.1 Granularity Field (gg)

The granularity field (gg) indicates the size of the packed operands that the instruction is operating on. When this field is used, it is located in bits 1 and 0 of the second opcode byte. Table B-18 shows the encoding of the gg field.

	3 (33)
gg	Granularity of Data
00	Packed Bytes
01	Packed Words
10	Packed Doublewords
11	Quadword

Table B-18. Encoding of Granularity of Data Field (gg)

B.5.2 MMX Technology and General-Purpose Register Fields (mmxreg and reg)

When MMX technology registers (mmxreg) are used as operands, they are encoded in the ModR/M byte in the reg field (bits 5, 4, and 3) and/or the R/M field (bits 2, 1, and 0).

If an MMX instruction operates on a general-purpose register (reg), the register is encoded in the R/M field of the ModR/M byte.

B.5.3 MMX Instruction Formats and Encodings Table

Table B-19 shows the formats and encodings of the integer instructions.

Instruction and Format	Encoding
EMMS - Empty MMX technology state	0000 1111:01110111
MOVD - Move doubleword	
reg to mmxreg	0000 1111:0110 1110: 11 mmxreg reg
reg from mmxreg	0000 1111:0111 1110: 11 mmxreg reg
mem to mmxreg	0000 1111:0110 1110: mod mmxreg r/m

Table B-19. MMX Instruction Formats and Encodings

Table B-19. MMX Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
mem from mmxreg	0000 1111:0111 1110: mod mmxreg r/m
MOVQ - Move quadword	
mmxreg2 to mmxreg1	0000 1111:0110 1111:11 mmxreg1 mmxreg2
mmxreg2 from mmxreg1	0000 1111:0111 1111: 11 mmxreg1 mmxreg2
mem to mmxreg	0000 1111:0110 1111: mod mmxreg r/m
mem from mmxreg	0000 1111:0111 1111: mod mmxreg r/m
PACKSSDW ¹ - Pack dword to word data (signed with saturation)	
mmxreg2 to mmxreg1	0000 1111:0110 1011: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:0110 1011: mod mmxreg r/m
PACKSSWB ¹ - Pack word to byte data (signed with saturation)	
mmxreg2 to mmxreg1	0000 1111:0110 0011: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:0110 0011: mod mmxreg r/m
PACKUSWB ¹ - Pack word to byte data (unsigned with saturation)	
mmxreg2 to mmxreg1	0000 1111:0110 0111: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:0110 0111: mod mmxreg r/m
PADD – Add with wrap-around	
mmxreg2 to mmxreg1	0000 1111: 1111 11gg: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111: 1111 11gg: mod mmxreg r/m
PADDS - Add signed with saturation	
mmxreg2 to mmxreg1	0000 1111: 1110 11gg: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111: 1110 11gg: mod mmxreg r/m
PADDUS - Add unsigned with saturation	
mmxreg2 to mmxreg1	0000 1111: 1101 11gg: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111: 1101 11gg: mod mmxreg r/m
PAND - Bitwise And	
mmxreg2 to mmxreg1	0000 1111:1101 1011:11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1101 1011: mod mmxreg r/m
PANDN - Bitwise AndNot	
mmxreg2 to mmxreg1	0000 1111:1101 1111:11 mmxreg1 mmxreg2

Table B-19. MMX Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
	<u> </u>
memory to mmxreg	0000 1111:1101 1111: mod mmxreg r/m
PCMPEQ - Packed compare for equality	
mmxreg1 with mmxreg2	0000 1111:0111 01gg: 11 mmxreg1 mmxreg2
mmxreg with memory	0000 1111:0111 01gg: mod mmxreg r/m
PCMPGT - Packed compare greater (signed)	
mmxreg1 with mmxreg2	0000 1111:0110 01gg: 11 mmxreg1 mmxreg2
mmxreg with memory	0000 1111:0110 01gg: mod mmxreg r/m
PMADDWD - Packed multiply add	
mmxreg2 to mmxreg1	0000 1111:1111 0101: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1111 0101: mod mmxreg r/m
PMULHUW - Packed multiplication, store high word (unsigned)	
mmxreg2 to mmxreg1	0000 1111: 1110 0100: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111: 1110 0100: mod mmxreg r/m
PMULHW – Packed multiplication, store high word	
mmxreg2 to mmxreg1	0000 1111:1110 0101: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1110 0101: mod mmxreg r/m
PMULLW - Packed multiplication, store low word	
mmxreg2 to mmxreg1	0000 1111:1101 0101: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1101 0101: mod mmxreg r/m
POR - Bitwise Or	
mmxreg2 to mmxreg1	0000 1111:1110 1011: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1110 1011: mod mmxreg r/m
PSLL ² - Packed shift left logical	
mmxreg1 by mmxreg2	0000 1111:1111 00gg: 11 mmxreg1 mmxreg2
mmxreg by memory	0000 1111:1111 00gg: mod mmxreg r/m
mmxreg by immediate	0000 1111:0111 00gg: 11 110 mmxreg: imm8 data
PSRA ² - Packed shift right arithmetic	
	•

Table B-19. MMX Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
mmxreg1 by mmxreg2	0000 1111:1110 00gg: 11 mmxreg1 mmxreg2
mmxreg by memory	0000 1111:1110 00gg: mod mmxreg r/m
mmxreg by immediate	0000 1111:0111 00gg: 11 100 mmxreg: imm8 data
PSRL ² - Packed shift right logical	
mmxreg1 by mmxreg2	0000 1111:1101 00gg: 11 mmxreg1 mmxreg2
mmxreg by memory	0000 1111:1101 00gg: mod mmxreg r/m
mmxreg by immediate	0000 1111:0111 00gg: 11 010 mmxreg: imm8 data
PSUB - Subtract with wrap-around	
mmxreg2 from mmxreg1	0000 1111:1111 10gg: 11 mmxreg1 mmxreg2
memory from mmxreg	0000 1111:1111 10gg: mod mmxreg r/m
PSUBS - Subtract signed with saturation	
mmxreg2 from mmxreg1	0000 1111:1110 10gg: 11 mmxreg1 mmxreg2
memory from mmxreg	0000 1111:1110 10gg: mod mmxreg r/m
PSUBUS - Subtract unsigned with saturation	
mmxreg2 from mmxreg1	0000 1111:1101 10gg: 11 mmxreg1 mmxreg2
memory from mmxreg	0000 1111:1101 10gg: mod mmxreg r/m
PUNPCKH – Unpack high data to next larger type	
mmxreg2 to mmxreg1	0000 1111:0110 10gg: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:0110 10gg: mod mmxreg r/m
PUNPCKL - Unpack low data to next larger type	
mmxreg2 to mmxreg1	0000 1111:0110 00gg: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:0110 00gg: mod mmxreg r/m
PXOR - Bitwise Xor	
mmxreg2 to mmxreg1	0000 1111:1110 1111: 11 mmxreg1 mmxreg2
memory to mmxreg	0000 1111:1110 1111: mod mmxreg r/m

Table B-19. MMX Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
------------------------	----------

NOTES:

- 1. The pack instructions perform saturation from signed packed data of one type to signed or unsigned data of the next smaller type.
- 2. The format of the shift instructions has one additional format to support shifting by immediate shift-counts. The shift operations are not supported equally for all data types.

B.6 PROCESSOR EXTENDED STATE INSTRUCTION FORMATS AND ENCODINGS

Table B-20 shows the formats and encodings for several instructions that relate to processor extended state management.

Table B-20. Formats and Encodings of XSAVE/XRSTOR/XGETBV/XSETBV Instructions

Instruction and Format	Encoding
XGETBV - Get Value of Extended Control Register	0000 1111:0000 0001: 1101 0000
XRSTOR - Restore Processor Extended States ¹	0000 1111:1010 1110: mod ^A 101 r/m
XSAVE - Save Processor Extended States ¹	0000 1111:1010 1110: mod ^A 100 r/m
XSETBV - Set Extended Control Register	0000 1111:0000 0001: 1101 0001

NOTES:

1. For XSAVE and XRSTOR, "mod = 11" is reserved.

B.7 P6 FAMILY INSTRUCTION FORMATS AND ENCODINGS

Table B-20 shows the formats and encodings for several instructions that were introduced into the IA-32 architecture in the P6 family processors.

Table B-21. Formats and Encodings of P6 Family Instructions

Instruction and Format	Encoding
CMOVcc - Conditional Move	
register2 to register1	0000 1111: 0100 tttn : 11 reg1 reg2

Table B-21. Formats and Encodings of P6 Family Instructions (Contd.)

Instruction and Format	Encoding
memory to register	0000 1111 : 0100 tttn : mod reg r/m
FCMOVcc - Conditional Move on EFLAG Register Condition Codes	
move if below (B)	11011 010 : 11 000 ST(i)
move if equal (E)	11011 010 : 11 001 ST(i)
move if below or equal (BE)	11011 010 : 11 010 ST(i)
move if unordered (U)	11011 010 : 11 011 ST(i)
move if not below (NB)	11011 011 : 11 000 ST(i)
move if not equal (NE)	11011 011 : 11 001 ST(i)
move if not below or equal (NBE)	11011 011 : 11 010 ST(i)
move if not unordered (NU)	11011 011 : 11 011 ST(i)
FCOMI - Compare Real and Set EFLAGS	11011 011 : 11 110 ST(i)
FXRSTOR - Restore x87 FPU, MMX, SSE, and SSE2 State ¹	0000 1111:1010 1110: mod ^A 001 г/m
FXSAVE – Save x87 FPU, MMX, SSE, and SSE2 State ¹	0000 1111:1010 1110: mod ^A 000 г/m
SYSENTER - Fast System Call	0000 1111:0011 0100
SYSEXIT - Fast Return from Fast System Call	0000 1111:0011 0101

NOTES:

1. For FXSAVE and FXRSTOR, "mod = 11" is reserved.

B.8 SSE INSTRUCTION FORMATS AND ENCODINGS

The SSE instructions use the ModR/M format and are preceded by the 0FH prefix byte. In general, operations are not duplicated to provide two directions (that is, separate load and store variants).

The following three tables (Tables B-22, B-23, and B-24) show the formats and encodings for the SSE SIMD floating-point, SIMD integer, and cacheability and memory ordering instructions, respectively. Some SSE instructions require a mandatory prefix (66H, F2H, F3H) as part of the two-byte opcode. Mandatory prefixes are included in the tables.

Table B-22. Formats and Encodings of SSE Floating-Point Instructions

Instruction and Format	Encoding
ADDPS—Add Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1000:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1000: mod xmmreg r/m
ADDSS—Add Scalar Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0011:0000 1111:01011000:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:01011000: mod xmmreg r/m
ANDNPS—Bitwise Logical AND NOT of Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0101:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0101: mod xmmreg r/m
ANDPS—Bitwise Logical AND of Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0100: mod xmmreg r/m
CMPPS—Compare Packed Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	0000 1111:1100 0010:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0000 1111:1100 0010: mod xmmreg r/m: imm8
CMPSS—Compare Scalar Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	1111 0011:0000 1111:1100 0010:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	1111 0011:0000 1111:1100 0010: mod xmmreg r/m: imm8
COMISS—Compare Scalar Ordered Single-Precision Floating-Point Values and Set EFLAGS	
xmmreg2 to xmmreg1	0000 1111:0010 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0010 1111: mod xmmreg r/m

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
CVTPI2PS—Convert Packed Doubleword Integers to Packed Single- Precision Floating-Point Values	
mmreg to xmmreg	0000 1111:0010 1010:11 xmmreg1 mmreg1
mem to xmmreg	0000 1111:0010 1010: mod xmmreg r/m
CVTPS2PI—Convert Packed Single- Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg to mmreg	0000 1111:0010 1101:11 mmreg1 xmmreg1
mem to mmreg	0000 1111:0010 1101: mod mmreg r/m
CVTSI2SS—Convert Doubleword Integer to Scalar Single-Precision Floating-Point Value	
r32 to xmmreg1	1111 0011:0000 1111:00101010:11 xmmreg1 r32
mem to xmmreg	1111 0011:0000 1111:00101010: mod xmmreg r/m
CVTSS2SI—Convert Scalar Single- Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	1111 0011:0000 1111:0010 1101:11 r32 xmmreg
mem to r32	1111 0011:0000 1111:0010 1101: mod r32 r/m
CVTTPS2PI—Convert with Truncation Packed Single-Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg to mmreg	0000 1111:0010 1100:11 mmreg1 xmmreg1
mem to mmreg	0000 1111:0010 1100: mod mmreg r/m
CVTTSS2SI—Convert with Truncation Scalar Single-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	1111 0011:0000 1111:0010 1100:11 r32 xmmreg1
mem to r32	1111 0011:0000 1111:0010 1100: mod r32 r/m
DIVPS—Divide Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1110: mod xmmreg r/m
DIVSS—Divide Scalar Single-Precision Floating-Point Values	

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1110: mod xmmreg r/m
LDMXCSR—Load MXCSR Register State	
m32 to MXCSR	0000 1111:1010 1110:mod ^A 010 mem
MAXPS—Return Maximum Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1111: mod xmmreg r/m
MAXSS—Return Maximum Scalar Double-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1111:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1111: mod xmmreg r/m
MINPS—Return Minimum Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1101: mod xmmreg r/m
MINSS—Return Minimum Scalar Double- Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1101:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1101: mod xmmreg r/m
MOVAPS—Move Aligned Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0010 1000:11 xmmreg2 xmmreg1
mem to xmmreg1	0000 1111:0010 1000: mod xmmreg r/m
xmmreg1 to xmmreg2	0000 1111:0010 1001:11 xmmreg1 xmmreg2
xmmreg1 to mem	0000 1111:0010 1001: mod xmmreg r/m

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
MOVHLPS—Move Packed Single- Precision Floating-Point Values High to Low	
xmmreg2 to xmmreg1	0000 1111:0001 0010:11 xmmreg1 xmmreg2
MOVHPS—Move High Packed Single- Precision Floating-Point Values	
mem to xmmreg	0000 1111:0001 0110: mod xmmreg r/m
xmmreg to mem	0000 1111:0001 0111: mod xmmreg r/m
MOVLHPS—Move Packed Single- Precision Floating-Point Values Low to High	
xmmreg2 to xmmreg1	0000 1111:00010110:11 xmmreg1 xmmreg2
MOVLPS—Move Low Packed Single- Precision Floating-Point Values	
mem to xmmreg	0000 1111:0001 0010: mod xmmreg r/m
xmmreg to mem	0000 1111:0001 0011: mod xmmreg r/m
MOVMSKPS—Extract Packed Single- Precision Floating-Point Sign Mask	
xmmreg to r32	0000 1111:0101 0000:11 r32 xmmreg
MOVSS—Move Scalar Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0001 0000:11 xmmreg2 xmmreg1
mem to xmmreg1	1111 0011:0000 1111:0001 0000: mod xmmreg r/m
xmmreg1 to xmmreg2	1111 0011:0000 1111:0001 0001:11 xmmreg1 xmmreg2
xmmreg1 to mem	1111 0011:0000 1111:0001 0001: mod xmmreg r/m
MOVUPS—Move Unaligned Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0001 0000:11 xmmreg2 xmmreg1
mem to xmmreg1	0000 1111:0001 0000: mod xmmreg r/m
xmmreg1 to xmmreg2	0000 1111:0001 0001:11 xmmreg1 xmmreg2
xmmreg1 to mem	0000 1111:0001 0001: mod xmmreg r/m

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
MULPS—Multiply Packed Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1001:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1001: mod xmmreg r/m
MULSS—Multiply Scalar Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1001:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1001: mod xmmreg r/m
ORPS—Bitwise Logical OR of Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0110:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0110: mod xmmreg r/m
RCPPS—Compute Reciprocals of Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0011:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0011: mod xmmreg r/m
RCPSS—Compute Reciprocals of Scalar Single-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:01010011:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:01010011: mod xmmreg r/m
RSQRTPS—Compute Reciprocals of Square Roots of Packed Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0010:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0010: mode xmmreg r/m
RSQRTSS—Compute Reciprocals of Square Roots of Scalar Single-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 0010:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 0010: mod xmmreg r/m

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
SHUFPS—Shuffle Packed Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	0000 1111:1100 0110:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0000 1111:1100 0110: mod xmmreg r/m: imm8
SQRTPS—Compute Square Roots of Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0001:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0001: mod xmmreg r/m
SQRTSS—Compute Square Root of Scalar Single-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 0001:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 0001:mod xmmreg r/m
STMXCSR—Store MXCSR Register State	
MXCSR to mem	0000 1111:1010 1110:mod ^A 011 mem
SUBPS—Subtract Packed Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1100:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1100:mod xmmreg r/m
SUBSS—Subtract Scalar Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1100:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1100:mod xmmreg r/m
UCOMISS—Unordered Compare Scalar Ordered Single-Precision Floating-Point Values and Set EFLAGS	
xmmreg2 to xmmreg1	0000 1111:0010 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0010 1110: mod xmmreg r/m
UNPCKHPS—Unpack and Interleave High Packed Single-Precision Floating- Point Values	

Table B-22. Formats and Encodings of SSE Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
xmmreg2 to xmmreg1	0000 1111:0001 0101:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0001 0101: mod xmmreg r/m
UNPCKLPS—Unpack and Interleave Low Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0001 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0001 0100: mod xmmreg r/m
XORPS—Bitwise Logical XOR of Single- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 0111:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 0111: mod xmmreg r/m

Table B-23. Formats and Encodings of SSE Integer Instructions

Instruction and Format	Encoding
PAVGB/PAVGW—Average Packed Integers	
mmreg2 to mmreg1	0000 1111:1110 0000:11 mmreg1 mmreg2
	0000 1111:1110 0011:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1110 0000: mod mmreg r/m
	0000 1111:1110 0011: mod mmreg r/m
PEXTRW—Extract Word	
mmreg to reg32, imm8	0000 1111:1100 0101:11 r32 mmreg: imm8
PINSRW—Insert Word	
reg32 to mmreg, imm8	0000 1111:1100 0100:11 mmreg r32: imm8
m16 to mmreg, imm8	0000 1111:1100 0100: mod mmreg r/m: imm8
PMAXSW—Maximum of Packed Signed Word Integers	
mmreg2 to mmreg1	0000 1111:1110 1110:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1110 1110: mod mmreg r/m
PMAXUB—Maximum of Packed Unsigned Byte Integers	
mmreg2 to mmreg1	0000 1111:1101 1110:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1101 1110: mod mmreg r/m

Table B-23. Formats and Encodings of SSE Integer Instructions (Contd.)

Instruction and Format	Encoding
PMINSW—Minimum of Packed Signed Word Integers	
mmreg2 to mmreg1	0000 1111:1110 1010:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1110 1010: mod mmreg r/m
PMINUB—Minimum of Packed Unsigned Byte Integers	
mmreg2 to mmreg1	0000 1111:1101 1010:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1101 1010: mod mmreg r/m
PMOVMSKB—Move Byte Mask To Integer	
mmreg to reg32	0000 1111:1101 0111:11 r32 mmreg
PMULHUW—Multiply Packed Unsigned Integers and Store High Result	
mmreg2 to mmreg1	0000 1111:1110 0100:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1110 0100: mod mmreg r/m
PSADBW—Compute Sum of Absolute Differences	
mmreg2 to mmreg1	0000 1111:1111 0110:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1111 0110: mod mmreg r/m
PSHUFW—Shuffle Packed Words	
mmreg2 to mmreg1, imm8	0000 1111:0111 0000:11 mmreg1 mmreg2: imm8
mem to mmreg, imm8	0000 1111:0111 0000: mod mmreg r/m: imm8

Table B-24. Format and Encoding of SSE Cacheability & Memory Ordering Instructions

Instruction and Format	Encoding
MASKMOVQ—Store Selected Bytes of Quadword	
mmreg2 to mmreg1	0000 1111:1111 0111:11 mmreg1 mmreg2
MOVNTPS—Store Packed Single-Precision Floating- Point Values Using Non-Temporal Hint	
xmmreg to mem	0000 1111:0010 1011: mod xmmreg r/m

Table B-24. Format and Encoding of SSE Cacheability & Memory Ordering Instructions (Contd.)

Instruction and Format	Encoding
MOVNTQ—Store Quadword Using Non-Temporal Hint	
mmreg to mem	0000 1111:1110 0111: mod mmreg r/m
PREFETCHTO—Prefetch Temporal to All Cache Levels	0000 1111:0001 1000:mod ^A 001 mem
PREFETCHT1—Prefetch Temporal to First Level Cache	0000 1111:0001 1000:mod ^A 010 mem
PREFETCHT2—Prefetch Temporal to Second Level Cache	0000 1111:0001 1000:mod ^A 011 mem
PREFETCHNTA—Prefetch Non-Temporal to All Cache Levels	0000 1111:0001 1000:mod ^A 000 mem
SFENCE—Store Fence	0000 1111:1010 1110:11 111 000

B.9 SSE2 INSTRUCTION FORMATS AND ENCODINGS

The SSE2 instructions use the ModR/M format and are preceded by the 0FH prefix byte. In general, operations are not duplicated to provide two directions (that is, separate load and store variants).

The following three tables show the formats and encodings for the SSE2 SIMD floating-point, SIMD integer, and cacheability instructions, respectively. Some SSE2 instructions require a mandatory prefix (66H, F2H, F3H) as part of the two-byte opcode. These prefixes are included in the tables.

B.9.1 Granularity Field (gg)

The granularity field (gg) indicates the size of the packed operands that the instruction is operating on. When this field is used, it is located in bits 1 and 0 of the second opcode byte. Table B-25 shows the encoding of this gg field.

Table B-25.	Encoding of	Granularity	ot pata F	leia (gg)

99	Granularity of Data
00	Packed Bytes
01	Packed Words
10	Packed Doublewords
11	Quadword

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions

Instruction and Format	Encoding
ADDPD—Add Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1000:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1000: mod xmmreg r/m
ADDSD—Add Scalar Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1000:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1000: mod xmmreg r/m
ANDNPD—Bitwise Logical AND NOT of Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 0101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 0101: mod xmmreg r/m
ANDPD—Bitwise Logical AND of Packed Double-Precision Floating- Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 0100: mod xmmreg r/m
CMPPD—Compare Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:1100 0010:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:1100 0010: mod xmmreg r/m: imm8
CMPSD—Compare Scalar Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	1111 0010:0000 1111:1100 0010:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	11110 010:0000 1111:1100 0010: mod xmmreg r/m: imm8

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
COMISD—Compare Scalar Ordered Double-Precision Floating-Point Values and Set EFLAGS	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0010 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0010 1111: mod xmmreg r/m
CVTPI2PD—Convert Packed Doubleword Integers to Packed Double-Precision Floating-Point Values	
mmreg to xmmreg	0110 0110:0000 1111:0010 1010:11 xmmreg1 mmreg1
mem to xmmreg	0110 0110:0000 1111:0010 1010: mod xmmreg r/m
CVTPD2PI—Convert Packed Double- Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg to mmreg	0110 0110:0000 1111:0010 1101:11 mmreg1 xmmreg1
mem to mmreg	0110 0110:0000 1111:0010 1101: mod mmreg r/m
CVTSI2SD—Convert Doubleword Integer to Scalar Double-Precision Floating-Point Value	
r32 to xmmreg1	1111 0010:0000 1111:0010 1010:11 xmmreg r32
mem to xmmreg	1111 0010:0000 1111:0010 1010: mod xmmreg r/m
CVTSD2SI—Convert Scalar Double- Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	1111 0010:0000 1111:0010 1101:11 r32 xmmreg
mem to r32	1111 0010:0000 1111:0010 1101: mod r32 r/m
CVTTPD2PI—Convert with Truncation Packed Double-Precision Floating- Point Values to Packed Doubleword Integers	
xmmreg to mmreg	0110 0110:0000 1111:0010 1100:11 mmreg xmmreg
mem to mmreg	0110 0110:0000 1111:0010 1100: mod mmreg r/m

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
CVTTSD2SI—Convert with Truncation Scalar Double-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	1111 0010:0000 1111:0010 1100:11 r32 xmmreg
mem to r32	1111 0010:0000 1111:0010 1100: mod r32 r/m
CVTPD2PS—Covert Packed Double- Precision Floating-Point Values to Packed Single-Precision Floating- Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1010: mod xmmreg r/m
CVTPS2PD—Covert Packed Single- Precision Floating-Point Values to Packed Double-Precision Floating- Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0000 1111:0101 1010: mod xmmreg r/m
CVTSD2SS—Covert Scalar Double- Precision Floating-Point Value to Scalar Single-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1010:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1010: mod xmmreg r/m
CVTSS2SD—Covert Scalar Single- Precision Floating-Point Value to Scalar Double-Precision Floating- Point Value	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1010:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:00001 111:0101 1010: mod xmmreg r/m

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
CVTPD2DQ—Convert Packed Double- Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg2 to xmmreg1	1111 0010:0000 1111:1110 0110:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:1110 0110: mod xmmreg r/m
CVTTPD2DQ—Convert With Truncation Packed Double-Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 0110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1110 0110: mod xmmreg r/m
CVTDQ2PD—Convert Packed Doubleword Integers to Packed Single-Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0011:0000 1111:1110 0110:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:1110 0110: mod xmmreg r/m
CVTPS2DQ—Convert Packed Single- Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1011: mod xmmreg r/m
CVTTPS2DQ—Convert With Truncation Packed Single-Precision Floating-Point Values to Packed Doubleword Integers	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0101 1011:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0101 1011: mod xmmreg r/m
CVTDQ2PS—Convert Packed Doubleword Integers to Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0000 1111:0101 1011:11 xmmreg1 xmmreg2

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	0000 1111:0101 1011: mod xmmreg r/m
DIVPD—Divide Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1110: mod xmmreg r/m
DIVSD—Divide Scalar Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1110: mod xmmreg r/m
MAXPD—Return Maximum Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1111: mod xmmreg r/m
MAXSD—Return Maximum Scalar Double-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1111:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1111: mod xmmreg r/m
MINPD—Return Minimum Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1101: mod xmmreg r/m
MINSD—Return Minimum Scalar Double-Precision Floating-Point Value	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1101:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1101: mod xmmreg r/m

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
MOVAPD—Move Aligned Packed Double-Precision Floating-Point Values	
xmmreg1 to xmmreg2	0110 0110:0000 1111:0010 1001:11 xmmreg2 xmmreg1
xmmreg1 to mem	0110 0110:0000 1111:0010 1001: mod xmmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0010 1000:11 xmmreg1 xmmreg2
mem to xmmreg1	0110 0110:0000 1111:0010 1000: mod xmmreg r/m
MOVHPD—Move High Packed Double- Precision Floating-Point Values	
xmmreg to mem	0110 0110:0000 1111:0001 0111: mod xmmreg r/m
mem to xmmreg	0110 0110:0000 1111:0001 0110: mod xmmreg r/m
MOVLPD—Move Low Packed Double- Precision Floating-Point Values	
xmmreg to mem	0110 0110:0000 1111:0001 0011: mod xmmreg r/m
mem to xmmreg	0110 0110:0000 1111:0001 0010: mod xmmreg r/m
MOVMSKPD—Extract Packed Double- Precision Floating-Point Sign Mask	
xmmreg to r32	0110 0110:0000 1111:0101 0000:11 r32 xmmreg
MOVSD—Move Scalar Double- Precision Floating-Point Values	
xmmreg1 to xmmreg2	1111 0010:0000 1111:0001 0001:11 xmmreg2 xmmreg1
xmmreg1 to mem	1111 0010:0000 1111:0001 0001: mod xmmreg r/m
xmmreg2 to xmmreg1	1111 0010:0000 1111:0001 0000:11 xmmreg1 xmmreg2
mem to xmmreg1	1111 0010:0000 1111:0001 0000: mod xmmreg r/m
MOVUPD—Move Unaligned Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0001 0001:11 xmmreg2 xmmreg1
mem to xmmreg1	0110 0110:0000 1111:0001 0001: mod xmmreg r/m

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
xmmreg1 to xmmreg2	0110 0110:0000 1111:0001 0000:11 xmmreg1 xmmreg2
xmmreg1 to mem	0110 0110:0000 1111:0001 0000: mod xmmreg r/m
MULPD—Multiply Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1001: mod xmmreg r/m
MULSD—Multiply Scalar Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0010:00001111:01011001:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:00001111:01011001: mod xmmreg r/m
ORPD—Bitwise Logical OR of Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 0110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 0110: mod xmmreg r/m
SHUFPD—Shuffle Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:1100 0110:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:1100 0110: mod xmmreg r/m: imm8
SQRTPD—Compute Square Roots of Packed Double-Precision Floating- Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 0001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 0001: mod xmmreg r/m
SQRTSD—Compute Square Root of Scalar Double-Precision Floating- Point Value	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 0001:11 xmmreg1 xmmreg2

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	1111 0010:0000 1111:0101 0001: mod xmmreg r/m
SUBPD—Subtract Packed Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 1100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0101 1100: mod xmmreg r/m
SUBSD—Subtract Scalar Double- Precision Floating-Point Values	
xmmreg2 to xmmreg1	1111 0010:0000 1111:0101 1100:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0010:0000 1111:0101 1100: mod xmmreg r/m
UCOMISD—Unordered Compare Scalar Ordered Double-Precision Floating-Point Values and Set EFLAGS	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0010 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0010 1110: mod xmmreg r/m
UNPCKHPD—Unpack and Interleave High Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0001 0101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0001 0101: mod xmmreg r/m
UNPCKLPD—Unpack and Interleave Low Packed Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0001 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0001 0100: mod xmmreg r/m
XORPD—Bitwise Logical OR of Double-Precision Floating-Point Values	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0101 0111:11 xmmreg1 xmmreg2

Table B-26. Formats and Encodings of SSE2 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	0110 0110:0000 1111:0101 0111: mod xmmreg r/m

Table B-27. Formats and Encodings of SSE2 Integer Instructions

Instruction and Format	Encoding
MOVD—Move Doubleword	
reg to xmmreg	0110 0110:0000 1111:0110 1110: 11 xmmreg reg
reg from xmmreg	0110 0110:0000 1111:0111 1110: 11 xmmreg reg
mem to xmmreg	0110 0110:0000 1111:0110 1110: mod xmmreg r/m
mem from xmmreg	0110 0110:0000 1111:0111 1110: mod xmmreg r/m
MOVDQA—Move Aligned Double Quadword	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 1111:11 xmmreg1 xmmreg2
xmmreg2 from xmmreg1	0110 0110:0000 1111:0111 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0110 1111: mod xmmreg r/m
mem from xmmreg	0110 0110:0000 1111:0111 1111: mod xmmreg r/m
MOVDQU—Move Unaligned Double Quadword	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0110 1111:11 xmmreg1 xmmreg2
xmmreg2 from xmmreg1	1111 0011:0000 1111:0111 1111:11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0110 1111: mod xmmreg r/m
mem from xmmreg	1111 0011:0000 1111:0111 1111: mod xmmreg r/m
MOVQ2DQ—Move Quadword from MMX to XMM Register	
mmreg to xmmreg	1111 0011:0000 1111:1101 0110:11 mmreg1 mmreg2
MOVDQ2Q—Move Quadword from XMM to MMX Register	
xmmreg to mmreg	1111 0010:0000 1111:1101 0110:11 mmreg1 mmreg2
MOVQ—Move Quadword	
xmmreg2 to xmmreg1	1111 0011:0000 1111:0111 1110: 11 xmmreg1 xmmreg2
xmmreg2 from xmmreg1	0110 0110:0000 1111:1101 0110: 11 xmmreg1 xmmreg2
mem to xmmreg	1111 0011:0000 1111:0111 1110: mod xmmreg r/m

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

	I
Instruction and Format	Encoding
mem from xmmreg	0110 0110:0000 1111:1101 0110: mod xmmreg r/m
PACKSSDW ¹ —Pack Dword To Word Data (signed with saturation)	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 1011: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:0110 1011: mod xmmreg r/m
PACKSSWB—Pack Word To Byte Data (signed with saturation)	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 0011: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:0110 0011: mod xmmreg r/m
PACKUSWB—Pack Word To Byte Data (unsigned with saturation)	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 0111:11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:0110 0111: mod xmmreg r/m
PADDQ—Add Packed Quadword Integers	
mmreg2 to mmreg1	0000 1111:1101 0100:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1101 0100: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1101 0100: mod xmmreg r/m
PADD—Add With Wrap-around	
xmmreg2 to xmmreg1	0110 0110:0000 1111: 1111 11gg: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111: 1111 11gg: mod xmmreg r/m
PADDS—Add Signed With Saturation	
xmmreg2 to xmmreg1	0110 0110:0000 1111: 1110 11gg: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111: 1110 11gg: mod xmmreg r/m
PADDUS—Add Unsigned With Saturation	
xmmreg2 to xmmreg1	0110 0110:0000 1111: 1101 11gg: 11 xmmreg1 xmmreg2

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
memory to xmmreg	0110 0110:0000 1111: 1101 11gg: mod xmmreg r/m
PAND—Bitwise And	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 1011: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1101 1011: mod xmmreg r/m
PANDN—Bitwise AndNot	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 1111: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1101 1111: mod xmmreg r/m
PAVGB—Average Packed Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:11100 000:11 xmmreg1 xmmreg2
mem to xmmreg	01100110:00001111:11100000 mod xmmreg r/m
PAVGW—Average Packed Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 0011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1110 0011 mod xmmreg r/m
PCMPEQ—Packed Compare For Equality	
xmmreg1 with xmmreg2	0110 0110:0000 1111:0111 01gg: 11 xmmreg1 xmmreg2
xmmreg with memory	0110 0110:0000 1111:0111 01gg: mod xmmreg r/m
PCMPGT—Packed Compare Greater (signed)	
xmmreg1 with xmmreg2	0110 0110:0000 1111:0110 01gg: 11 xmmreg1 xmmreg2
xmmreg with memory	0110 0110:0000 1111:0110 01gg: mod xmmreg r/m
PEXTRW—Extract Word	
xmmreg to reg32, imm8	0110 0110:0000 1111:1100 0101:11 r32 xmmreg: imm8
PINSRW—Insert Word	
reg32 to xmmreg, imm8	0110 0110:0000 1111:1100 0100:11 xmmreg r32: imm8

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
m16 to xmmreg, imm8	0110 0110:0000 1111:1100 0100: mod xmmreg r/m: imm8
PMADDWD—Packed Multiply Add	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1111 0101:11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1111 0101: mod xmmreg r/m
PMAXSW—Maximum of Packed Signed Word Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 1110:11 xmmreg1 xmmreg2
mem to xmmreg	01100110:00001111:11101110: mod xmmreg r/m
PMAXUB—Maximum of Packed Unsigned Byte Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1101 1110: mod xmmreg r/m
PMINSW—Minimum of Packed Signed Word Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1110 1010: mod xmmreg r/m
PMINUB—Minimum of Packed Unsigned Byte Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1101 1010 mod xmmreg r/m
PMOVMSKB—Move Byte Mask To Integer	
xmmreg to reg32	0110 0110:0000 1111:1101 0111:11 r32 xmmreg
PMULHUW—Packed multiplication, store high word (unsigned)	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 0100: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1110 0100: mod xmmreg r/m

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
PMULHW—Packed Multiplication, store high word	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 0101: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1110 0101: mod xmmreg r/m
PMULLW—Packed Multiplication, store low word	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1101 0101: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1101 0101: mod xmmreg r/m
PMULUDQ—Multiply Packed Unsigned Doubleword Integers	
mmreg2 to mmreg1	0000 1111:1111 0100:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1111 0100: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:00001111:1111 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:00001111:1111 0100: mod xmmreg r/m
POR—Bitwise Or	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 1011: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1110 1011: mod xmmreg r/m
PSADBW—Compute Sum of Absolute Differences	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1111 0110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1111 0110: mod xmmreg r/m
PSHUFLW—Shuffle Packed Low Words	
xmmreg2 to xmmreg1, imm8	1111 0010:0000 1111:0111 0000:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	1111 0010:0000 1111:0111 0000:11 mod xmmreg r/m: imm8

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
PSHUFHW—Shuffle Packed High Words	
xmmreg2 to xmmreg1, imm8	1111 0011:0000 1111:0111 0000:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	1111 0011:0000 1111:0111 0000: mod xmmreg r/m: imm8
PSHUFD—Shuffle Packed Doublewords	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0111 0000:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0111 0000: mod xmmreg r/m: imm8
PSLLDQ—Shift Double Quadword Left Logical	
xmmreg, imm8	0110 0110:0000 1111:0111 0011:11 111 xmmreg: imm8
PSLL—Packed Shift Left Logical	
xmmreg1 by xmmreg2	0110 0110:0000 1111:1111 00gg: 11 xmmreg1 xmmreg2
xmmreg by memory	0110 0110:0000 1111:1111 00gg: mod xmmreg r/m
xmmreg by immediate	0110 0110:0000 1111:0111 00gg: 11 110 xmmreg: imm8
PSRA—Packed Shift Right Arithmetic	
xmmreg1 by xmmreg2	0110 0110:0000 1111:1110 00gg: 11 xmmreg1 xmmreg2
xmmreg by memory	0110 0110:0000 1111:1110 00gg: mod xmmreg r/m
xmmreg by immediate	0110 0110:0000 1111:0111 00gg: 11 100 xmmreg: imm8
PSRLDQ—Shift Double Quadword Right Logical	
xmmreg, imm8	0110 0110:00001111:01110011:11 011 xmmreg: imm8
PSRL—Packed Shift Right Logical	
xmmreg1 by xmmreg2	0110 0110:0000 1111:1101 00gg: 11 xmmreg1 xmmreg2
xmmreg by memory	0110 0110:0000 1111:1101 00gg: mod xmmreg r/m

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
xmmreg by immediate	0110 0110:0000 1111:0111 00gg: 11 010 xmmreg: imm8
PSUBQ—Subtract Packed Quadword Integers	
mmreg2 to mmreg1	0000 1111:11111 011:11 mmreg1 mmreg2
mem to mmreg	0000 1111:1111 1011: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:1111 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:1111 1011: mod xmmreg r/m
PSUB—Subtract With Wrap-around	
xmmreg2 from xmmreg1	0110 0110:0000 1111:1111 10gg: 11 xmmreg1 xmmreg2
memory from xmmreg	0110 0110:0000 1111:1111 10gg: mod xmmreg r/m
PSUBS—Subtract Signed With Saturation	
xmmreg2 from xmmreg1	0110 0110:0000 1111:1110 10gg: 11 xmmreg1 xmmreg2
memory from xmmreg	0110 0110:0000 1111:1110 10gg: mod xmmreg r/m
PSUBUS—Subtract Unsigned With Saturation	
xmmreg2 from xmmreg1	0000 1111:1101 10gg: 11 xmmreg1 xmmreg2
memory from xmmreg	0000 1111:1101 10gg: mod xmmreg r/m
PUNPCKH—Unpack High Data To Next Larger Type	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 10gg:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0110 10gg: mod xmmreg r/m
PUNPCKHQDQ—Unpack High Data	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0110 1101: mod xmmreg r/m
PUNPCKL—Unpack Low Data To Next Larger Type	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 00gg:11 xmmreg1 xmmreg2

Table B-27. Formats and Encodings of SSE2 Integer Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	0110 0110:0000 1111:0110 00gg: mod xmmreg r/m
PUNPCKLQDQ—Unpack Low Data	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0110 1100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0110 1100: mod xmmreg r/m
PXOR—Bitwise Xor	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1110 1111: 11 xmmreg1 xmmreg2
memory to xmmreg	0110 0110:0000 1111:1110 1111: mod xmmreg r/m

Table B-28. Format and Encoding of SSE2 Cacheability Instructions

Instruction and Format	Encoding
MASKMOVDQU—Store Selected Bytes of Double Quadword	
xmmreg2 to xmmreg1	0110 0110:0000 1111:1111 0111:11 xmmreg1 xmmreg2
CLFLUSH—Flush Cache Line	
mem	0000 1111:1010 1110: mod 111 r/m
MOVNTPD—Store Packed Double- Precision Floating-Point Values Using Non-Temporal Hint	
xmmreg to mem	0110 0110:0000 1111:0010 1011: mod xmmreg r/m
MOVNTDQ—Store Double Quadword Using Non-Temporal Hint	
xmmreg to mem	0110 0110:0000 1111:1110 0111: mod xmmreg r/m
MOVNTI—Store Doubleword Using Non-Temporal Hint	
reg to mem	0000 1111:1100 0011: mod reg r/m
PAUSE—Spin Loop Hint	1111 0011:1001 0000
LFENCE—Load Fence	0000 1111:1010 1110: 11 101 000
MFENCE—Memory Fence	0000 1111:1010 1110: 11 110 000

B.10 SSE3 FORMATS AND ENCODINGS TABLE

The tables in this section provide SSE3 formats and encodings. Some SSE3 instructions require a mandatory prefix (66H, F2H, F3H) as part of the two-byte opcode. These prefixes are included in the tables.

When in IA-32e mode, use of the REX.R prefix permits instructions that use general purpose and XMM registers to access additional registers. Some instructions require the REX.W prefix to promote the instruction to 64-bit operation. Instructions that require the REX.W prefix are listed (with their opcodes) in Section B.13.

Table B-29. Formats and Encodings of SSE3 Floating-Point Instructions

Instruction and Format	Encoding
ADDSUBPD—Add /Sub packed DP FP numbers from XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	01100110:00001111:11010000:11 xmmreg1 xmmreg2
mem to xmmreg	01100110:00001111:11010000: mod xmmreg r/m
ADDSUBPS—Add /Sub packed SP FP numbers from XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	11110010:00001111:11010000:11 xmmreg1 xmmreg2
mem to xmmreg	11110010:00001111:11010000: mod xmmreg r/m
HADDPD—Add horizontally packed DP FP numbers XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	01100110:00001111:01111100:11 xmmreg1 xmmreg2
mem to xmmreg	01100110:00001111:01111100: mod xmmreg r/m
HADDPS—Add horizontally packed SP FP numbers XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	11110010:00001111:01111100:11 xmmreg1 xmmreg2
mem to xmmreg	11110010:00001111:01111100: mod xmmreg r/m
HSUBPD—Sub horizontally packed DP FP numbers XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	01100110:00001111:01111101:11 xmmreg1 xmmreg2

Table B-29. Formats and Encodings of SSE3 Floating-Point Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	01100110:00001111:01111101: mod xmmreg r/m
HSUBPS—Sub horizontally packed SP FP numbers XMM2/Mem to XMM1	
xmmreg2 to xmmreg1	11110010:00001111:01111101:11 xmmreg1 xmmreg2
mem to xmmreg	11110010:00001111:01111101: mod xmmreg r/m

Table B-30. Formats and Encodings for SSE3 Event Management Instructions

Instruction and Format	Encoding
MONITOR—Set up a linear address range to be monitored by hardware	
eax, ecx, edx	0000 1111 : 0000 0001:11 001 000
MWAIT—Wait until write-back store performed within the range specified by the instruction MONITOR	
eax, ecx	0000 1111 : 0000 0001:11 001 001

Table B-31. Formats and Encodings for SSE3 Integer and Move Instructions

Instruction and Format	Encoding
FISTTP—Store ST in int16 (chop) and pop	
m16int	11011 111 : mod ^A 001 г/m
FISTTP—Store ST in int32 (chop) and pop	
m32int	11011 011 : mod ^A 001 r/m
FISTTP—Store ST in int64 (chop) and pop	
m64int	11011 101 : mod ^A 001 г/m
LDDQU—Load unaligned integer 128-bit	
xmm, m128	11110010:00001111:11110000: mod ^A xmmreg r/m
MOVDDUP—Move 64 bits representing one DP data from XMM2/Mem to XMM1 and duplicate	
xmmreg2 to xmmreg1	11110010:00001111:00010010:11 xmmreg1 xmmreg2

Table B-31. Formats and Encodings for SSE3 Integer and Move Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	11110010:00001111:00010010: mod xmmreg r/m
MOVSHDUP—Move 128 bits representing 4 SP data from XMM2/Mem to XMM1 and duplicate high	
xmmreg2 to xmmreg1	11110011:00001111:00010110:11 xmmreg1 xmmreg2
mem to xmmreg	11110011:00001111:00010110: mod xmmreg r/m
MOVSLDUP—Move 128 bits representing 4 SP data from XMM2/Mem to XMM1 and duplicate low	
xmmreg2 to xmmreg1	11110011:00001111:00010010:11 xmmreg1 xmmreg2
mem to xmmreg	11110011:00001111:00010010: mod xmmreg r/m

B.11 SSSE3 FORMATS AND ENCODING TABLE

The tables in this section provide SSSE3 formats and encodings. Some SSSE3 instructions require a mandatory prefix (66H) as part of the three-byte opcode. These prefixes are included in the table below.

Table B-32. Formats and Encodings for SSSE3 Instructions

Instruction and Format	Encoding
PABSB—Packed Absolute Value Bytes	
mmreg2 to mmreg1	0000 1111:0011 1000: 0001 1100:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0001 1100: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0001 1100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0001 1100: mod xmmreg r/m
PABSD—Packed Absolute Value Double Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0001 1110:11 mmreg1 mmreg2

Table B-32. Formats and Encodings for SSSE3 Instructions (Contd.)

Instruction and Format	Encoding
mem to mmreg	0000 1111:0011 1000: 0001 1110: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0001 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0001 1110: mod xmmreg r/m
PABSW—Packed Absolute Value Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0001 1101:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0001 1101: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0001 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0001 1101: mod xmmreg r/m
PALIGNR—Packed Align Right	
mmreg2 to mmreg1, imm8	0000 1111:0011 1010: 0000 1111:11 mmreg1 mmreg2: imm8
mem to mmreg, imm8	0000 1111:0011 1010: 0000 1111: mod mmreg r/m: imm8
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0000 1111:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1111: mod xmmreg r/m: imm8
PHADDD—Packed Horizontal Add Double Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0010:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0010: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0010: mod xmmreg r/m
PHADDSW—Packed Horizontal Add and Saturate	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0011:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0011: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0011:11 xmmreg1 xmmreg2

Table B-32. Formats and Encodings for SSSE3 Instructions (Contd.)

Instruction and Format	Encoding
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0011: mod xmmreg r/m
PHADDW—Packed Horizontal Add Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0001:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0001: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0001: mod xmmreg r/m
PHSUBD—Packed Horizontal Subtract Double Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0110:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0110: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0110: mod xmmreg r/m
PHSUBSW—Packed Horizontal Subtract and Saturate	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0111:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0111: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0111:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0111: mod xmmreg r/m
PHSUBW—Packed Horizontal Subtract Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0101:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0101: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0101: mod xmmreg r/m

Table B-32. Formats and Encodings for SSSE3 Instructions (Contd.)

Instruction and Format	Encoding
PMADDUBSW—Multiply and Add Packed Signed and Unsigned Bytes	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0100:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0100: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0100: mod xmmreg r/m
PMULHRSW—Packed Multiply HIgn with Round and Scale	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 1011:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 1011: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 1011: mod xmmreg r/m
PSHUFB—Packed Shuffle Bytes	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 0000:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 0000: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 0000:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 0000: mod xmmreg r/m
PSIGNB—Packed Sign Bytes	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 1000:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 1000: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 1000:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 1000: mod xmmreg r/m
PSIGND—Packed Sign Double Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 1010:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 1010: mod mmreg r/m

Table B-32. Formats and Encodings for SSSE3 Instructions (Contd.)

Instruction and Format	Encoding
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 1010: mod xmmreg r/m
PSIGNW—Packed Sign Words	
mmreg2 to mmreg1	0000 1111:0011 1000: 0000 1001:11 mmreg1 mmreg2
mem to mmreg	0000 1111:0011 1000: 0000 1001: mod mmreg r/m
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0000 1001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0000 1001: mod xmmreg r/m

B.12 AESNI AND PCLMULQDQ INSTRUCTION FORMATS AND ENCODINGS

Table B-33 shows the formats and encodings for AESNI and PCLMULQDQ instructions.

Table B-33. Formats and Encodings of AESNI and PCLMULQDQ Instructions

Instruction and Format	Encoding
AESDEC—Perform One Round of an AES Decryption Flow	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000:1101 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000:1101 1110: mod xmmreg r/m
AESDECLAST—Perform Last Round of an AES Decryption Flow	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000:1101 1111:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000:1101 1111: mod xmmreg r/m
AESENC—Perform One Round of an AES Encryption Flow	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000:1101 1100:11 xmmreg1 xmmreg2

Table B-33. Formats and Encodings of AESNI and PCLMULQDQ Instructions

Instruction and Format	Encoding
mem to xmmreg	0110 0110:0000 1111:0011 1000:1101 1100: mod xmmreg r/m
AESENCLAST—Perform Last Round of an AES Encryption Flow	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000:1101 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000:1101 1101: mod xmmreg r/m
AESIMC—Perform the AES InvMixColumn Transformation	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000:1101 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000:1101 1011: mod xmmreg r/m
AESKEYGENASSIST—AES Round Key Generation Assist	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010:1101 1111:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010:1101 1111: mod xmmreg r/m: imm8
PCLMULQDQ—Carry-Less Multiplication Quadword	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010:0100 0100:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010:0100 0100: mod xmmreg r/m: imm8

B.13 SPECIAL ENCODINGS FOR 64-BIT MODE

The following Pentium, P6, MMX, SSE, SSE2, SSE3 instructions are promoted to 64-bit operation in IA-32e mode by using REX.W. However, these entries are special cases that do not follow the general rules (specified in Section B.4).

Table B-34. Special Case Instructions Promoted Using REX.W

Instruction and Format	Encoding
CMOVcc—Conditional Move	
register2 to register1	0100 0R0B 0000 1111: 0100 tttn : 11 reg1 reg2
qwordregister2 to qwordregister1	0100 1R0B 0000 1111: 0100 tttn : 11 qwordreg1 qwordreg2
memory to register	0100 ORXB 0000 1111 : 0100 tttn : mod reg r/m
memory64 to qwordregister	0100 1RXB 0000 1111 : 0100 tttn : mod qwordreg r/m
CVTSD2SI—Convert Scalar Double-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	0100 0R0B 1111 0010:0000 1111:0010 1101:11 r32 xmmreg
xmmreg to r64	0100 1R0B 1111 0010:0000 1111:0010 1101:11 r64 xmmreg
mem64 to r32	0100 0R0XB 1111 0010:0000 1111:0010 1101: mod r32 r/m
mem64 to r64	0100 1RXB 1111 0010:0000 1111:0010 1101: mod r64 r/m
CVTSI2SS—Convert Doubleword Integer to Scalar Single-Precision Floating-Point Value	
r32 to xmmreg1	0100 0R0B 1111 0011:0000 1111:0010 1010:11 xmmreg r32
r64 to xmmreg1	0100 1R0B 1111 0011:0000 1111:0010 1010:11 xmmreg r64
mem to xmmreg	0100 0RXB 1111 0011:0000 1111:0010 1010: mod xmmreg r/m
mem64 to xmmreg	0100 1RXB 1111 0011:0000 1111:0010 1010: mod xmmreg r/m
CVTSI2SD—Convert Doubleword Integer to Scalar Double-Precision Floating-Point Value	
r32 to xmmreg1	0100 0R0B 1111 0010:0000 1111:0010 1010:11 xmmreg r32
r64 to xmmreg1	0100 1R0B 1111 0010:0000 1111:0010 1010:11 xmmreg r64

Table B-34. Special Case Instructions Promoted Using REX.W (Contd.)

Instruction and Format	Encoding
mem to xmmreg	0100 0RXB 1111 0010:0000 1111:00101 010: mod xmmreg r/m
mem64 to xmmreg	0100 1RXB 1111 0010:0000 1111:0010 1010: mod xmmreg r/m
CVTSS2SI—Convert Scalar Single-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	0100 0R0B 1111 0011:0000 1111:0010 1101:11 r32 xmmreg
xmmreg to r64	0100 1R0B 1111 0011:0000 1111:0010 1101:11 r64 xmmreg
mem to r32	0100 0RXB 11110011:00001111:00101101: mod r32 r/m
mem32 to r64	0100 1RXB 1111 0011:0000 1111:0010 1101: mod r64 r/m
CVTTSD2SI—Convert with Truncation Scalar Double-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	0100 0R0B 11110010:00001111:00101100:11 r32 xmmreg
xmmreg to r64	0100 1R0B 1111 0010:0000 1111:0010 1100:11 r64 xmmreg
mem64 to r32	0100 0RXB 1111 0010:0000 1111:0010 1100: mod r32 r/m
mem64 to r64	0100 1RXB 1111 0010:0000 1111:0010 1100: mod r64 r/m
CVTTSS2SI—Convert with Truncation Scalar Single-Precision Floating-Point Value to Doubleword Integer	
xmmreg to r32	0100 0R0B 1111 0011:0000 1111:0010 1100:11 r32 xmmreg1
xmmreg to r64	0100 1R0B 1111 0011:0000 1111:0010 1100:11 r64 xmmreg1
mem to r32	0100 0RXB 1111 0011:0000 1111:0010 1100: mod r32 r/m

Table B-34. Special Case Instructions Promoted Using REX.W (Contd.)

Instruction and Format	Encoding
mem32 to r64	0100 1RXB 1111 0011:0000 1111:0010 1100: mod r64 r/m
MOVD/MOVQ—Move doubleword	
reg to mmxreg	0100 OROB 0000 1111:0110 1110: 11 mmxreg reg
qwordreg to mmxreg	0100 1R0B 0000 1111:0110 1110: 11 mmxreg qwordreg
reg from mmxreg	0100 OROB 0000 1111:0111 1110: 11 mmxreg reg
qwordreg from mmxreg	0100 1R0B 0000 1111:0111 1110: 11 mmxreg qwordreg
mem to mmxreg	0100 ORXB 0000 1111:0110 1110: mod mmxreg r/m
mem64 to mmxreg	0100 1RXB 0000 1111:0110 1110: mod mmxreg r/m
mem from mmxreg	0100 ORXB 0000 1111:0111 1110: mod mmxreg r/m
mem64 from mmxreg	0100 1RXB 0000 1111:0111 1110: mod mmxreg r/m
mmxreg with memory	0100 ORXB 0000 1111:0110 01gg: mod mmxreg r/m
MOVMSKPS—Extract Packed Single-Precision Floating-Point Sign Mask	
xmmreg to r32	0100 0R0B 0000 1111:0101 0000:11 r32 xmmreg
xmmreg to r64	0100 1R0B 00001111:01010000:11 r64 xmmreg
PEXTRW—Extract Word	
mmreg to reg32, imm8	0100 0R0B 0000 1111:1100 0101:11 r32 mmreg: imm8
mmreg to reg64, imm8	0100 1R0B 0000 1111:1100 0101:11 r64 mmreg: imm8
xmmreg to reg32, imm8	0100 0R0B 0110 0110 0000 1111:1100 0101:11 r32 xmmreg: imm8
xmmreg to reg64, imm8	0100 1R0B 0110 0110 0000 1111:1100 0101:11 r64 xmmreg: imm8

Table B-34. Special Case Instructions Promoted Using REX.W (Contd.)

Instruction and Format	Encoding
PINSRW—Insert Word	
reg32 to mmreg, imm8	0100 0R0B 0000 1111:1100 0100:11 mmreg r32: imm8
reg64 to mmreg, imm8	0100 1R0B 0000 1111:1100 0100:11 mmreg r64: imm8
m16 to mmreg, imm8	0100 OROB 0000 1111:1100 0100 mod mmreg r/m: imm8
m16 to mmreg, imm8	0100 1RXB 0000 1111:11000100 mod mmreg r/m: imm8
reg32 to xmmreg, imm8	0100 0RXB 0110 0110 0000 1111:1100 0100:11 xmmreg r32: imm8
reg64 to xmmreg, imm8	0100 0RXB 0110 0110 0000 1111:1100 0100:11 xmmreg r64: imm8
m16 to xmmreg, imm8	0100 0RXB 0110 0110 0000 1111:1100 0100 mod xmmreg r/m: imm8
m16 to xmmreg, imm8	0100 1RXB 0110 0110 0000 1111:1100 0100 mod xmmreg r/m: imm8
PMOVMSKB—Move Byte Mask To Integer	
mmreg to reg32	0100 ORXB 0000 1111:1101 0111:11 r32 mmreg
mmreg to reg64	0100 1R0B 0000 1111:1101 0111:11 г64 mmreg
xmmreg to reg32	0100 0RXB 0110 0110 0000 1111:1101 0111:11 r32 mmreg
xmmreg to reg64	0110 0110 0000 1111:1101 0111:11 г64 хmmreg

B.14 SSE4.1 FORMATS AND ENCODING TABLE

The tables in this section provide SSE4.1 formats and encodings. Some SSE4.1 instructions require a mandatory prefix (66H, F2H, F3H) as part of the three-byte opcode. These prefixes are included in the tables.

In 64-bit mode, some instructions requires REX.W, the byte sequence of REX.W prefix in the opcode sequence is shown.

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding
BLENDPD — Blend Packed Double- Precision Floats	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1010: 0000 1101:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0000 1101: mod xmmreg r/m
BLENDPS — Blend Packed Single- Precision Floats	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1010: 0000 1100:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0000 1100: mod xmmreg r/m
BLENDVPD — Variable Blend Packed Double-Precision Floats	
xmmreg2 to xmmreg1 <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0101:11 xmmreg1 xmmreg2
mem to xmmreg <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0101: mod xmmreg r/m
BLENDVPS — Variable Blend Packed Single-Precision Floats	
xmmreg2 to xmmreg1 <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0100:11 xmmreg1 xmmreg2
mem to xmmreg <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0100: mod xmmreg r/m
DPPD — Packed Double-Precision Dot Products	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0100 0001:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0100 0001: mod xmmreg r/m: imm8
DPPS — Packed Single-Precision Dot Products	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0100 0000:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0100 0000: mod xmmreg r/m: imm8

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding
EXTRACTPS — Extract From Packed Single-Precision Floats	
reg from xmmreg , imm8	0110 0110:0000 1111:0011 1010: 0001 0111:11 xmmreg reg: imm8
mem from xmmreg , imm8	0110 0110:0000 1111:0011 1010: 0001 0111: mod xmmreg r/m: imm8
INSERTPS — Insert Into Packed Single- Precision Floats	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0010 0001:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0010 0001: mod xmmreg r/m: imm8
MOVNTDQA — Load Double Quadword Non-temporal Aligned	
m128 to xmmreg	0110 0110:0000 1111:0011 1000: 0010 1010:11 r/m xmmreg2
MPSADBW — Multiple Packed Sums of Absolute Difference	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0100 0010:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0100 0010: mod xmmreg r/m: imm8
PACKUSDW — Pack with Unsigned Saturation	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 1011: mod xmmreg r/m
PBLENDVB — Variable Blend Packed Bytes	
xmmreg2 to xmmreg1 <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0000:11 xmmreg1 xmmreg2
mem to xmmreg <xmm0></xmm0>	0110 0110:0000 1111:0011 1000: 0001 0000: mod xmmreg r/m
PBLENDW — Blend Packed Words	

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0001 1110:11 xmmreg1 xmmreg2: imm8
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1110: mod xmmreg r/m: imm8
PCMPEQQ — Compare Packed Qword Data of Equal	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 1001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 1001: mod xmmreg r/m
PEXTRB — Extract Byte	
reg from xmmreg , imm8	0110 0110:0000 1111:0011 1010: 0001 0100:11 xmmreg reg: imm8
xmmreg to mem, imm8	0110 0110:0000 1111:0011 1010: 0001 0100: mod xmmreg r/m: imm8
PEXTRD — Extract DWord	
reg from xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0001 0110:11 xmmreg reg: imm8
xmmreg to mem, imm8	0110 0110:0000 1111:0011 1010: 0001 0110: mod xmmreg r/m: imm8
PEXTRQ — Extract QWord	
r64 from xmmreg, imm8	0110 0110:REX.W:0000 1111:0011 1010: 0001 0110:11 xmmreg reg: imm8
m64 from xmmreg, imm8	0110 0110:REX.W:0000 1111:0011 1010: 0001 0110: mod xmmreg r/m: imm8
PEXTRW — Extract Word	
reg from xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0001 0101:11 reg xmmreg: imm8
mem from xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0001 0101: mod xmmreg r/m: imm8
PHMINPOSUW — Packed Horizontal Word Minimum	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0100 0001:11 xmmreg1 xmmreg2

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0100 0001: mod xmmreg r/m		
PINSRB — Extract Byte			
reg to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0010 0000:11 xmmreg reg: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0010 0000: mod xmmreg r/m: imm8		
PINSRD — Extract DWord			
reg to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0010 0010:11 xmmreg reg: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0010 0010: mod xmmreg r/m: imm8		
PINSRQ — Extract QWord			
r64 to xmmreg, imm8	0110 0110:REX.W:0000 1111:0011 1010: 0010 0010:11 xmmreg reg: imm8		
m64 to xmmreg, imm8	0110 0110:REX.W:0000 1111:0011 1010: 0010 0010: mod xmmreg r/m: imm8		
PMAXSB — Maximum of Packed Signed Byte Integers			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1100:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1100: mod xmmreg r/m		
PMAXSD — Maximum of Packed Signed Dword Integers			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1101:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1101: mod xmmreg r/m		
PMAXUD — Maximum of Packed Unsigned Dword Integers			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1111:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1111: mod xmmreg r/m		

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding
PMAXUW — Maximum of Packed Unsigned Word Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1110:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1110: mod xmmreg r/m
PMINSB — Minimum of Packed Signed Byte Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1000:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1000: mod xmmreg r/m
PMINSD — Minimum of Packed Signed Dword Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1001: mod xmmreg r/m
PMINUD — Minimum of Packed Unsigned Dword Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1011:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1011: mod xmmreg r/m
PMINUW — Minimum of Packed Unsigned Word Integers	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 1010:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 1010: mod xmmreg r/m
PMOVSXBD — Packed Move Sign Extend - Byte to Dword	
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0001:11 xmmreg1 xmmreg2
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0001: mod xmmreg r/m

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding		
PMOVSXBQ — Packed Move Sign Extend - Byte to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0010:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0010: mod xmmreg r/m		
PMOVSXBW — Packed Move Sign Extend - Byte to Word			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0000:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0000: mod xmmreg r/m		
PMOVSXWD — Packed Move Sign Extend - Word to Dword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0011:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0011: mod xmmreg r/m		
PMOVSXWQ — Packed Move Sign Extend - Word to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0100:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0100: mod xmmreg r/m		
PMOVSXDQ — Packed Move Sign Extend - Dword to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 0101:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 0101: mod xmmreg r/m		
PMOVZXBD — Packed Move Zero Extend - Byte to Dword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0001:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0001: mod xmmreg r/m		

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding		
PMOVZXBQ — Packed Move Zero Extend - Byte to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0010:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0010: mod xmmreg r/m		
PMOVZXBW — Packed Move Zero Extend - Byte to Word			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0000:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0000: mod xmmreg r/m		
PMOVZXWD — Packed Move Zero Extend - Word to Dword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0011:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0011: mod xmmreg r/m		
PMOVZXWQ — Packed Move Zero Extend - Word to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0100:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0100: mod xmmreg r/m		
PMOVZXDQ — Packed Move Zero Extend - Dword to Qword			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0011 0101:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0101: mod xmmreg r/m		
PMULDQ — Multiply Packed Signed Dword Integers			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0010 1000:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0010 1000: mod xmmreg r/m		

Table B-35. Encodings of SSE4.1 instructions

Instruction and Format	Encoding		
PMULLD — Multiply Packed Signed Dword Integers, Store low Result			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0100 0000:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0100 0000: mod xmmreg r/m		
PTEST — Logical Compare			
xmmreg2 to xmmreg1	0110 0110:0000 1111:0011 1000: 0001 0111:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0001 0111: mod xmmreg r/m		
ROUNDPD — Round Packed Double- Precision Values			
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0000 1001:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1001: mod xmmreg r/m: imm8		
ROUNDPS — Round Packed Single- Precision Values			
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0000 1000:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1000: mod xmmreg r/m: imm8		
ROUNDSD — Round Scalar Double- Precision Value			
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0000 1011:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1011: mod xmmreg r/m: imm8		
ROUNDSS — Round Scalar Single- Precision Value			
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0000 1010:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg, imm8	0110 0110:0000 1111:0011 1010: 0000 1010: mod xmmreg r/m: imm8		

B.15 SSE4.2 FORMATS AND ENCODING TABLE

The tables in this section provide SSE4.2 formats and encodings. Some SSE4.2 instructions require a mandatory prefix (66H, F2H, F3H) as part of the three-byte opcode. These prefixes are included in the tables. In 64-bit mode, some instructions requires REX.W, the byte sequence of REX.W prefix in the opcode sequence is shown.

Table B-36. Encodings of SSE4.2 instructions

Instruction and Format	Encoding
CRC32 — Accumulate CRC32	
reg2 to reg1	1111 0010:0000 1111:0011 1000: 1111 000w :11 reg1 reg2
mem to reg	1111 0010:0000 1111:0011 1000: 1111 000w: mod reg r/m
bytereg2 to reg1	1111 0010:0100 WR0B:0000 1111:0011 1000: 1111 0000 :11 reg1 bytereg2
m8 to reg	1111 0010:0100 WR0B:0000 1111:0011 1000: 1111 0000 : mod reg r/m
qwreg2 to qwreg1	1111 0010:0100 1R0B:0000 1111:0011 1000: 1111 0000 :11 qwreg1 qwreg2
mem64 to qwreg	1111 0010:0100 1R0B:0000 1111:0011 1000: 1111 0000 : mod qwreg r/m
PCMPESTRI— Packed Compare Explicit-Length Strings To Index	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0110 0001:11 xmmreg1 xmmreg2: imm8
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0110 0001: mod xmmreg r/m
PCMPESTRM— Packed Compare Explicit-Length Strings To Mask	
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0110 0000:11 xmmreg1 xmmreg2: imm8
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0110 0000: mod xmmreg r/m
PCMPISTRI— Packed Compare Implicit-Length String To Index	

Table B-36. Encodings of SSE4.2 instructions

Instruction and Format	Encoding		
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0110 0011:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0110 0011: mod xmmreg r/m		
PCMPISTRM— Packed Compare Implicit-Length Strings To Mask			
xmmreg2 to xmmreg1, imm8	0110 0110:0000 1111:0011 1010: 0110 0010:11 xmmreg1 xmmreg2: imm8		
mem to xmmreg	0110 0110:0000 1111:0011 1010: 0110 0010: mod xmmreg r/m		
PCMPGTQ— Packed Compare Greater Than			
xmmreg to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0111:11 xmmreg1 xmmreg2		
mem to xmmreg	0110 0110:0000 1111:0011 1000: 0011 0111: mod xmmreg r/m		
POPCNT— Return Number of Bits Set to 1			
reg2 to reg1	1111 0011:0000 1111:1011 1000:11 reg1 reg2		
mem to reg1	1111 0011:0000 1111:1011 1000:mod reg1 r/m		
qwreg2 to qwreg1	1111 0011:0100 1R0B:0000 1111:1011 1000:11 reg1 reg2		
mem64 to qwreg1	1111 0011:0100 1R0B:0000 1111:1011 1000:mod reg1 r/m		

B.16 FLOATING-POINT INSTRUCTION FORMATS AND ENCODINGS

Table B-35 shows the five different formats used for floating-point instructions. In all cases, instructions are at least two bytes long and begin with the bit pattern 11011.

Table B-37. General Floating-Point Instruction Formats

First Byte	Second Byte	Optional Fields

Table B-37. General Floating-Point Instruction Formats

							_				
1	11011	OI	PA	1	m	od	1	ОРВ	r/m	s-i-b	disp
2	11011	M	F	OPA	m	od	OP	В	r/m	s-i-b	disp
3	11011	d	Р	OPA	1	1	OPB	R	ST(i)		
4	11011	0	0	1	1	1	1		OP		
5	11011	0	1	1	1	1	1		OP		
	15–11	10	9	8	7	6	5	4 3	2 1 0	•	
MF = Memory Format $R XOR d = 0$ — Destination OP S $00 - 32$ -bit real $R XOR d = 1$ — Source OP Destination OP S $01 - 32$ -bit integer							-				
10 - 64-bit real $ST(i) = Register stack element i11 - 16-bit integer 000 = Stack Top$											
P = F	P = Pop 001 = Second stack element										

P = Pop

0 — Do not pop stack 1 — Pop stack after operation

d = Destination

0 — Destination is ST(0) 1 — Destination is ST(i)

111 = Eighth stack element

The Mod and R/M fields of the ModR/M byte have the same interpretation as the corresponding fields of the integer instructions. The SIB byte and disp (displacement) are optionally present in instructions that have Mod and R/M fields. Their presence depends on the values of Mod and R/M, as for integer instructions.

Table B-36 shows the formats and encodings of the floating-point instructions.

Table B-38. Floating-Point Instruction Formats and Encodings

Instruction and Format	Encoding
F2XM1 - Compute 2 ^{ST(0)} - 1	11011 001 : 1111 0000
FABS - Absolute Value	11011 001 : 1110 0001
FADD - Add	
$ST(0) \leftarrow ST(0) + 32$ -bit memory	11011 000 : mod 000 r/m
$ST(0) \leftarrow ST(0) + 64$ -bit memory	11011 100 : mod 000 r/m
$ST(d) \leftarrow ST(0) + ST(i)$	11011 d00 : 11 000 ST(i)
FADDP - Add and Pop	
$ST(0) \leftarrow ST(0) + ST(i)$	11011 110 : 11 000 ST(i)
FBLD - Load Binary Coded Decimal	11011 111 : mod 100 r/m
FBSTP - Store Binary Coded Decimal and Pop	11011 111 : mod 110 r/m

Table B-38. Floating-Point Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
FCHS - Change Sign	11011 001 : 1110 0000
FCLEX - Clear Exceptions	11011 011 : 1110 0010
FCOM - Compare Real	
32-bit memory	11011 000 : mod 010 r/m
64-bit memory	11011 100 : mod 010 r/m
ST(i)	11011 000 : 11 010 ST(i)
FCOMP - Compare Real and Pop	
32-bit memory	11011 000 : mod 011 r/m
64-bit memory	11011 100 : mod 011 r/m
ST(i)	11011 000 : 11 011 ST(i)
FCOMPP - Compare Real and Pop Twice	11011 110:11 011 001
FCOMIP - Compare Real, Set EFLAGS, and Pop	11011 111 : 11 110 ST(i)
FCOS - Cosine of ST(0)	11011 001 : 1111 1111
FDECSTP - Decrement Stack-Top Pointer	11011 001 : 1111 0110
FDIV - Divide	
$ST(0) \leftarrow ST(0) \div 32$ -bit memory	11011 000 : mod 110 r/m
$ST(0) \leftarrow ST(0) \div 64$ -bit memory	11011 100 : mod 110 r/m
$ST(d) \leftarrow ST(0) \div ST(i)$	11011 d00 : 1111 R ST(i)
FDIVP - Divide and Pop	
$ST(0) \leftarrow ST(0) \div ST(i)$	11011 110:1111 1 ST(i)
FDIVR - Reverse Divide	
ST(0) ← 32-bit memory ÷ ST(0)	11011 000 : mod 111 r/m
ST(0) ← 64-bit memory ÷ ST(0)	11011 100 : mod 111 r/m
$ST(d) \leftarrow ST(i) \div ST(0)$	11011 d00 : 1111 R ST(i)
FDIVRP - Reverse Divide and Pop	
ST(0) " ST(i) ÷ ST(0)	11011 110 : 1111 0 ST(i)
FFREE - Free ST(i) Register	11011 101 : 1100 0 ST(i)
FIADD - Add Integer	
$ST(0) \leftarrow ST(0) + 16$ -bit memory	11011 110 : mod 000 r/m
$ST(0) \leftarrow ST(0) + 32$ -bit memory	11011 010 : mod 000 r/m

Table B-38. Floating-Point Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
FICOM - Compare Integer	
16-bit memory	11011 110 : mod 010 r/m
32-bit memory	11011 010 : mod 010 r/m
FICOMP - Compare Integer and Pop	
16-bit memory	11011 110 : mod 011 r/m
32-bit memory	11011 010 : mod 011 r/m
FIDIV	
$ST(0) \leftarrow ST(0) \div 16$ -bit memory	11011 110 : mod 110 r/m
$ST(0) \leftarrow ST(0) \div 32$ -bit memory	11011 010 : mod 110 r/m
FIDIVR	
ST(0) ← 16-bit memory ÷ ST(0)	11011 110 : mod 111 r/m
$ST(0) \leftarrow 32$ -bit memory $\div ST(0)$	11011 010 : mod 111 r/m
FILD - Load Integer	
16-bit memory	11011 111 : mod 000 r/m
32-bit memory	11011 011 : mod 000 r/m
64-bit memory	11011 111 : mod 101 r/m
FIMUL	
$ST(0) \leftarrow ST(0) \times 16$ -bit memory	11011 110: mod 001 r/m
$ST(0) \leftarrow ST(0) \times 32$ -bit memory	11011 010 : mod 001 r/m
FINCSTP - Increment Stack Pointer	11011 001 : 1111 0111
FINIT - Initialize Floating-Point Unit	
FIST - Store Integer	
16-bit memory	11011 111 : mod 010 r/m
32-bit memory	11011 011 : mod 010 r/m
FISTP - Store Integer and Pop	
16-bit memory	11011 111 : mod 011 r/m
32-bit memory	11011 011 : mod 011 r/m
64-bit memory	11011 111 : mod 111 r/m
FISUB	
$ST(0) \leftarrow ST(0) - 16$ -bit memory	11011 110 : mod 100 r/m

Table B-38. Floating-Point Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding	
ST(0) ← ST(0) - 32-bit memory	11011 010 : mod 100 r/m	
FISUBR		
ST(0) ← 16-bit memory – ST(0)	11011 110 : mod 101 r/m	
ST(0) ← 32-bit memory – ST(0)	11011 010 : mod 101 r/m	
FLD - Load Real		
32-bit memory	11011 001 : mod 000 r/m	
64-bit memory	11011 101 : mod 000 r/m	
80-bit memory	11011 011 : mod 101 r/m	
ST(i)	11011 001 : 11 000 ST(i)	
FLD1 - Load +1.0 into ST(0)	11011 001 : 1110 1000	
FLDCW – Load Control Word	11011 001 : mod 101 r/m	
FLDENV - Load FPU Environment	11011 001 : mod 100 r/m	
FLDL2E - Load $log_2(\epsilon)$ into ST(0)	11011 001 : 1110 1010	
FLDL2T - Load log ₂ (10) into ST(0)	11011 001 : 1110 1001	
FLDLG2 - Load log ₁₀ (2) into ST(0)	11011 001 : 1110 1100	
FLDLN2 - Load $\log_{\epsilon}(2)$ into ST(0)	11011 001 : 1110 1101	
FLDPI – Load π into ST(0)	11011 001 : 1110 1011	
FLDZ - Load +0.0 into ST(0)	11011 001 : 1110 1110	
FMUL - Multiply		
$ST(0) \leftarrow ST(0) \times 32$ -bit memory	11011 000 : mod 001 r/m	
$ST(0) \leftarrow ST(0) \times 64$ -bit memory	11011 100 : mod 001 r/m	
$ST(d) \leftarrow ST(0) \times ST(i)$	11011 d00:1100 1 ST(i)	
FMULP - Multiply		
$ST(i) \leftarrow ST(0) \times ST(i)$	11011 110 : 1100 1 ST(i)	
FNOP - No Operation	11011 001 : 1101 0000	
FPATAN - Partial Arctangent	11011 001 : 1111 0011	
FPREM - Partial Remainder	11011 001 : 1111 1000	
FPREM1 - Partial Remainder (IEEE)	11011 001 : 1111 0101	
FPTAN - Partial Tangent	11011 001 : 1111 0010	
FRNDINT - Round to Integer	11011 001 : 1111 1100	
FRSTOR - Restore FPU State	11011 101 : mod 100 r/m	

Table B-38. Floating-Point Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
FSAVE - Store FPU State	11011 101 : mod 110 r/m
FSCALE - Scale	11011 001 : 1111 1101
FSIN - Sine	11011 001 : 1111 1110
FSINCOS - Sine and Cosine	11011 001 : 1111 1011
FSQRT - Square Root	11011 001 : 1111 1010
FST - Store Real	
32-bit memory	11011 001 : mod 010 r/m
64-bit memory	11011 101 : mod 010 r/m
ST(i)	11011 101 : 11 010 ST(i)
FSTCW - Store Control Word 11011 001 : mod 111 r/m	
FSTENV - Store FPU Environment	11011 001 : mod 110 r/m
FSTP - Store Real and Pop	
32-bit memory	11011 001 : mod 011 r/m
64-bit memory	11011 101 : mod 011 r/m
80-bit memory	11011 011 : mod 111 r/m
ST(i)	11011 101 : 11 011 ST(i)
FSTSW - Store Status Word into AX	11011 111 : 1110 0000
FSTSW – Store Status Word into Memory	11011 101 : mod 111 r/m
FSUB - Subtract	
$ST(0) \leftarrow ST(0) - 32$ -bit memory	11011 000 : mod 100 r/m
ST(0) ← ST(0) - 64-bit memory 11011 100 : mod 100 r/m	
$ST(d) \leftarrow ST(0) - ST(i)$	11011 d00 : 1110 R ST(i)
FSUBP - Subtract and Pop	
$ST(0) \leftarrow ST(0) - ST(i)$	11011 110 : 1110 1 ST(i)
FSUBR - Reverse Subtract	
$ST(0) \leftarrow 32$ -bit memory - $ST(0)$	11011 000 : mod 101 r/m
ST(0) ← 64-bit memory - ST(0)	11011 100 : mod 101 r/m
$ST(d) \leftarrow ST(i) - ST(0)$	11011 d00 : 1110 R ST(i)
FSUBRP – Reverse Subtract and Pop	
$ST(i) \leftarrow ST(i) - ST(0)$	11011 110 : 1110 0 ST(i)
FTST - Test	11011 001 : 1110 0100

Table B-38. Floating-Point Instruction Formats and Encodings (Contd.)

Instruction and Format	Encoding
FUCOM - Unordered Compare Real	11011 101 : 1110 0 ST(i)
FUCOMP - Unordered Compare Real and Pop	11011 101 : 1110 1 ST(i)
FUCOMPP – Unordered Compare Real and Pop Twice	11011 010 : 1110 1001
FUCOMI – Unorderd Compare Real and Set EFLAGS	11011 011 : 11 101 ST(i)
FUCOMIP - Unorderd Compare Real, Set EFLAGS, and Pop	11011 111 : 11 101 ST(i)
FXAM - Examine	11011 001 : 1110 0101
FXCH - Exchange ST(0) and ST(i)	11011 001 : 1100 1 ST(i)
FXTRACT - Extract Exponent and Significand	11011 001 : 1111 0100
$FYL2X - ST(1) \times log_2(ST(0))$	11011 001 : 1111 0001
FYL2XP1 - ST(1) × log ₂ (ST(0) + 1.0)	11011 001 : 1111 1001
FWAIT - Wait until FPU Ready	1001 1011

B.17 VMX INSTRUCTIONS

Table B-37 describes virtual-machine extensions (VMX).

Table B-39. Encodings for VMX Instructions

Instruction and Format	Encoding
INVEPT—Invalidate Cached EPT Mappings	
Descriptor m128 according to reg	01100110 00001111 00111000 10000000: mod reg r/m
INVVPID—Invalidate Cached VPID Mappings	
Descriptor m128 according to reg	01100110 00001111 00111000 10000001: mod reg r/m
VMCALL—Call to VM Monitor	
Call VMM: causes VM exit.	00001111 00000001 11000001
VMCLEAR—Clear Virtual-Machine Control Structure	
mem32:VMCS_data_ptr	01100110 00001111 11000111: mod 110 r/m
mem64:VMCS_data_ptr	01100110 00001111 11000111: mod 110 r/m
VMLAUNCH—Launch Virtual Machine	
Launch VM managed by Current_VMCS	00001111 00000001 11000010
VMRESUME—Resume Virtual Machine	
Resume VM managed by Current_VMCS	00001111 00000001 11000011
VMPTRLD—Load Pointer to Virtual- Machine Control Structure	
mem32 to Current_VMCS_ptr	00001111 11000111: mod 110 r/m
mem64 to Current_VMCS_ptr	00001111 11000111: mod 110 r/m
VMPTRST—Store Pointer to Virtual- Machine Control Structure	
Current_VMCS_ptr to mem32	00001111 11000111: mod 111 r/m
Current_VMCS_ptr to mem64	00001111 11000111: mod 111 г/m
VMREAD—Read Field from Virtual- Machine Control Structure	
г32 (VMCS_fieldn) to г32	00001111 01111000: 11 reg2 reg1
r32 (VMCS_fieldn) to mem32	00001111 01111000: mod r32 r/m
г64 (VMCS_fieldn) to г64	00001111 01111000: 11 reg2 reg1
r64 (VMCS_fieldn) to mem64	00001111 01111000: mod r64 r/m

Table B-39. Encodings for VMX Instructions

Instruction and Format	Encoding
VMWRITE—Write Field to Virtual-Machine Control Structure	
г32 to г32 (VMCS_fieldn)	00001111 01111001: 11 reg1 reg2
mem32 to r32 (VMCS_fieldn)	00001111 01111001: mod r32 r/m
r64 to r64 (VMCS_fieldn)	00001111 01111001: 11 reg1 reg2
mem64 to r64 (VMCS_fieldn)	00001111 01111001: mod r64 r/m
VMXOFF—Leave VMX Operation	
Leave VMX.	00001111 00000001 11000100
VMXON—Enter VMX Operation	
Enter VMX.	11110011 000011111 11000111: mod 110 r/m

B.18 SMX INSTRUCTIONS

Table B-38 describes Safer Mode extensions (VMX). **GETSEC leaf functions are selected by a valid value in EAX on input.**

Table B-40. Encodings for SMX Instructions

Instruction and Format	Encoding
GETSEC—GETSEC leaf functions are selected by the value in EAX on input	
GETSEC[CAPABILITIES].	00001111 00110111 (EAX= 0)
GETSEC[ENTERACCS].	00001111 00110111 (EAX= 2)
GETSEC[EXITAC].	00001111 00110111 (EAX= 3)
GETSEC[SENTER].	00001111 00110111 (EAX= 4)
GETSEC[SEXIT].	00001111 00110111 (EAX= 5)
GETSEC[PARAMETERS].	00001111 00110111 (EAX= 6)
GETSEC[SMCTRL].	00001111 00110111 (EAX= 7)
GETSEC[WAKEUP].	00001111 00110111 (EAX= 8)

INSTRUCTION FORMATS AND ENCODINGS

APPENDIX C INTEL® C/C++ COMPILER INTRINSICS AND FUNCTIONAL EQUIVALENTS

The two tables in this appendix itemize the Intel C/C++ compiler intrinsics and functional equivalents for the Intel MMX technology, SSE, SSE2, SSE3, and SSSE3 instructions.

There may be additional intrinsics that do not have an instruction equivalent. It is strongly recommended that the reader reference the compiler documentation for the complete list of supported intrinsics. Please refer to http://www.intel.com/support/performancetools/.

Table C-1 presents simple intrinsics and Table C-2 presents composite intrinsics. Some intrinsics are "composites" because they require more than one instruction to implement them.

Intel C/C++ Compiler intrinsic names reflect the following naming conventions:

where:

<intrin_op></intrin_op>	Indicates the intrinsics basic operation; for example, add for

addition and sub for subtraction

cinalo-procision floating point

<suffix> Denotes the type of data operated on by the instruction. The

first one or two letters of each suffix denotes whether the data is packed (p), extended packed (ep), or scalar (s).

The remaining letters denote the type:

S	single-precision moating point
d	double-precision floating point
i128	signed 128-bit integer
i64	signed 64-bit integer
u64	unsigned 64-bit integer
i32	signed 32-bit integer
u32	unsigned 32-bit integer
i16	signed 16-bit integer
u16	unsigned 16-bit integer
i8	signed 8-bit integer
u8	unsigned 8-bit integer

The variable r is generally used for the intrinsic's return value. A number appended to a variable name indicates the element of a packed object. For example, r0 is the lowest word of r.


The packed values are represented in right-to-left order, with the lowest value being used for scalar operations. Consider the following example operation:

```
double a[2] = \{1.0, 2.0\};
__m128d t = _mm_load_pd(a);
```

The result is the same as either of the following:

```
_m128d t = _mm_set_pd(2.0, 1.0);
_m128d t = _mm_setr_pd(1.0, 2.0);
```

In other words, the XMM register that holds the value t will look as follows:



The "scalar" element is 1.0. Due to the nature of the instruction, some intrinsics require their arguments to be immediates (constant integer literals).

To use an intrinsic in your code, insert a line with the following syntax:

data_type intrinsic_name (parameters)

Where:

__m64, __m128, __m128d, or __m128i. Only the

_mm_empty intrinsic returns void.

intrinsic_name Is the name of the intrinsic, which behaves like a function

that you can use in your C/C++ code instead of in-lining the

actual instruction.

parameters Represents the parameters required by each intrinsic.

C.1 SIMPLE INTRINSICS

NOTE

For detailed descriptions of the intrinsics in Table C-1, see the corresponding mnemonic in Chapter 3 in the "Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2A", or Chapter 4, "Instruction Set Reference, N-Z" in the "Intel® 64 and IA-32 Architectures Software Developer's Manual, Volume 2B".

Table C-1. Simple Intrinsics

ADDPD _m128d _mm_add_pd(_m128d a, _m128d b) ADDPS _m128 _mm_add_ps(_m128 a, _m128 b) ADDSD _m128d _mm_add_sd(_m128d a, _m128d b) ADDSS _m128 _mm_add_ss(_m128 a, _m128 b) ADDSUBPD _m128d _mm_addsub_pd(_m128d a, _m128d b) ADDSUBPS _m128 _mm_addsub_ps(_m128 a, _m128 b) AESDEC _m128i _mm_aesdec (_m128i, _m128i) AESDECLAST _m128i _mm_aesdec(_m128i, _m128i) AESENC _m128i _mm_aesenc (_m128i, _m128i) AESENCLAST _m128i _mm_aesenc (_m128i, _m128i) AESENCLAST _m128i _mm_aesimc (_m128i, _m128i) AESENCLAST _m128i _mm_aesimc (_m128i, _m128i) AESKEYGENASSIST _m128i _mm_aesimc (_m128i, _m128d b) ANDNPD _m128d _mm_andnot_pd(_m128d a, _m128d b) ANDNPS _m128 _mm_andnot_ps(_m128 a, _m128 b) ANDPD _m128 _mm_and_ps(_m128 a, _m128 b) BLENDPD _m128 _mm_and_ps(_m128 v1, _m128 v2, const int mask) BLENDPS _m128 _mm_blend_ps(_m128 v1, _m128 v2, const int mask) BLENDVPD _m128 _mm_blendv_pd(_m128d v1, _m128 v2, _m128 v3) CLFLUSH _void _mm_clfflush(void const *p) CMPPD	Mnemonic	Intrinsic
ADDPS m128 _mm_add_ps(m128 a,m128 b) ADDSD m128d _mm_add_sd(m128d a,m128d b) ADDSS m128 _mm_add_ss(m128 a,m128 b) ADDSUBPD m128d _mm_addsub_pd(m128d a,m128d b) AESDEC m128i _mm_aesdec (_m128i,m128i) AESDECLAST m128i _mm_aesdeclast (m128i,m128i) AESENC m128i _mm_aesenc (_m128i,m128i) AESENCLAST m128i _mm_aesimc (_m128i, _m128i) AESIMC m128i _mm_aesimc (_m128i, const int) AESKEYGENASSIST _m128i _mm_aesimc (_m128d, const int) ANDNPD _m128d _mm_andnot_pd(_m128d a,m128d b) ANDNPS _m128 _mm_and_pd(_m128d a,m128d b) ANDPD _m128d _mm_and_ps(_m128 a,m128 b) BLENDPD _m128d _mm_blend_pd(_m128d v1, _m128d v2, const int mask) BLENDPD _m128 _mm_blend_ps(_m128 v1, _m128 v2, const int mask) BLENDVPD _m128d _mm_blendv_pd(_m128d v1, _m128d v2, _m128d v3) BLENDVPS _m128 _mm_blendv_ps(_m128 v1, _m128 v2, _m128 v3) CLFLUSH void _mm_ctflush(void const *p) CMPPD _m128d _mm_ccmpeq_pd(_m128d a, _m128d b)	ADDPD	m128d mm add pd(m128d a, m128d b)
ADDSD _m128d _mm_add_sd(_m128d a, _m128d b) ADDSS _m128 _mm_add_ss(_m128 a, _m128 b) ADDSUBPD _m128d _mm_addsub_pd(_m128d a, _m128d b) ADDSUBPS _m128 _mm_addsub_ps(_m128 a, _m128 b) AESDEC _m128i _mm_aesdec (_m128i, _m128i) AESDECLAST _m128i _mm_aesdeclast (_m128i, _m128i) AESENC _m128i _mm_aesenc (_m128i, _m128i) AESENCLAST _m128i _mm_aesenc (_m128i, _m128i) AESIMC _m128i _mm_aesimc (_m128i, _m128i) AESKEYGENASSIST _m128i _mm_aesimc (_m128d, _const int) ANDNPD _m128d _mm_andnot_pd(_m128d a, _m128d b) ANDNPS _m128 _mm_and_pd(_m128d a, _m128 b) ANDPD _m128d _mm_and_pd(_m128d a, _m128d b) ANDPS _m128 _mm_and_ps(_m128 a, _m128 b) BLENDPD _m128d _mm_blend_pd(_m128d v1, _m128d v2, const int mask) BLENDPS _m128 _mm_blend_ps(_m128 v1, _m128d v2, _m128d v3) BLENDVPS _m128 _mm_blendv_ps(_m128 v1, _m128 v2, _m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD _m128d _mm_ccmpeq_pd(_m128d a, _m128d b)	ADDPS	
ADDSS _m128 _mm_add_ss(_m128 a, _m128 b) ADDSUBPD _m128d _mm_addsub_pd(_m128d a, _m128d b) ADDSUBPS _m128 _mm_addsub_ps(_m128 a, _m128 b) AESDEC _m128i _mm_aesdec(_m128i, _m128i) AESDECLAST _m128i _mm_aesdeclast (_m128i, _m128i) AESENC _m128i _mm_aesenc(_m128i, _m128i) AESENCLAST _m128i _mm_aesimc (_m128i, _m128i) AESIMC _m128i _mm_aesimc (_m128i) AESKEYGENASSIST _m128i _mm_aesimc (_m128i, const int) ANDNPD _m128d _mm_andnot_ps(_m128d a, _m128d b) ANDPS _m128 _mm_and_pd(_m128d a, _m128 b) ANDPD _m128 _mm_and_ps(_m128 a, _m128 b) BLENDPD _m128 _mm_and_ps(_m128 a, _m128 b) BLENDPD _m128d _mm_blend_pd(_m128d v1, _m128 v2, const int mask) BLENDPS _m128 _mm_blend_ps(_m128 v1, _m128 v2, const int mask) BLENDVPD _m128d _mm_blendv_ps(_m128 v1, _m128 v2, _m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD _m128d _mm_cmpeq_pd(_m128d a, _m128d b)	ADDSD	
ADDSUBPD m128d _mm_addsub_pd(m128d a,m128d b) ADDSUBPS m128 _mm_addsub_ps(m128 a,m128 b) AESDEC m128i _mm_aesdec (_m128i,m128i) AESDECLAST m128i _mm_aesdeclast (_m128i,m128i) AESENC m128i _mm_aesenc (_m128i,m128i) AESENCLAST m128i _mm_aesimc (_m128i,m128i) AESIMC m128i _mm_aesimc (_m128i) AESKEYGENASSIST m128i _mm_aesimc (_m128 a,m128d b) ANDNPD m128d _mm_andnot_ps(m128 a,m128 d) ANDNPS m128 _mm_and_ps(m128 a,m128 b) ANDPD m128 _mm_and_ps(m128 a,m128 b) BLENDPD m128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPS m128 _mm_blend_ps(_m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(_m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_ciffush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	ADDSS	,
AESDEC m128i _mm_aesdec (_m128i, _m128i) AESDECLAST _m128i _mm_aesdeclast (_m128i, _m128i) AESENC _m128i _mm_aesenc (_m128i, _m128i) AESENCLAST _m128i _mm_aesenclast (_m128i, _m128i) AESIMC _m128i _mm_aesimc (_m128i) AESKEYGENASSIST _m128i _mm_aesimc (_m128i, const int) ANDNPD _m128d _mm_andnot_pd(_m128d a, _m128d b) ANDNPS _m128 _mm_and_pt(_m128d a, _m128 b) ANDPD _m128d _mm_and_ps(_m128 a, _m128 b) BLENDPD _m128d _mm_blend_pd(_m128d v1, _m128d v2, const int mask) BLENDPS _m128 _mm_blend_ps(_m128 v1, _m128 v2, const int mask) BLENDVPD _m128d _mm_blendv_pd(_m128d v1, _m128d v2, _m128d v3) BLENDVPS _m128 _mm_blendv_ps(_m128 v1, _m128 v2, _m128 v3) CLFLUSH void _mm_clfflush(void const *p) CMPPD _m128d _mm_cmpeq_pd(_m128d a, _m128d b)	ADDSUBPD	
AESDECLAST m128i _mm_aesdeclast (m128i,m128i) AESENC m128i _mm_aesenc (m128i,m128i) AESENCLAST m128i _mm_aesenclast (m128i,m128i) AESIMC m128i _mm_aesimc (m128i) AESKEYGENASSIST m128i _mm_aesimc (m128i, const int) ANDNPD m128d _mm_andnot_pd(m128d a,m128d b) ANDNPS m128 _mm_and_pd(m128d a,m128d b) ANDPD m128d _mm_and_ps(m128d a,m128d b) BLENDPD m128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPS m128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	ADDSUBPS	m128 _mm_addsub_ps(m128 a,m128 b)
AESENCm128i _mm_aesenc (_m128i, _m128i) AESENCLASTm128i _mm_aesenclast (_m128i, _m128i) AESIMCm128i _mm_aesimc (_m128i) AESKEYGENASSISTm128i _mm_aesimc (_m128i, const int) ANDNPDm128d _mm_andnot_pd(_m128d a, _m128d b) ANDNPSm128 _mm_andnot_ps(_m128 a, _m128 b) ANDPDm128d _mm_and_pd(_m128d a, _m128d b) ANDPSm128 _mm_and_ps(_m128 a, _m128 b) BLENDPDm128d _mm_blend_pd(_m128d v1, _m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(_m128 v1, _m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(_m128d v1, _m128d v2, _m128d v3) BLENDVPSm128 _mm_blendv_ps(_m128 v1, _m128 v2, _m128d v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(_m128d a, _m128d b)	\ESDEC	m128i _mm_aesdec (m128i,m128i)
AESENCLAST m128i _mm_aesenclast (m128i,m128i) AESIMC m128i _mm_aesimc (m128i) AESKEYGENASSIST m128i _mm_aesimc (m128i, const int) ANDNPD m128d _mm_andnot_pd(m128d a,m128d b) ANDNPS m128 _mm_and_ps(m128 a,m128 b) ANDPD m128d _mm_and_ps(m128d a,m128d b) ANDPS m128 _mm_and_ps(m128 a,m128 b) BLENDPD m128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPS m128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	\esdeclast	m128i _mm_aesdeclast (m128i,m128i)
AESIMC m128i _mm_aesimc (m128i) AESKEYGENASSIST m128i _mm_aesimc (m128i, const int) ANDNPD m128d _mm_andnot_pd(m128d a,m128d b) ANDNPS m128 _mm_and_ps(m128 a,m128 b) ANDPD m128d _mm_and_ps(m128d a,m128d b) ANDPS m128 _mm_and_ps(m128 a,m128 b) BLENDPD m128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPS m128 _mm_blendv_ps(m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	AESENC .	m128i _mm_aesenc (m128i,m128i)
AESKEYGENASSIST m128i _mm_aesimc (m128i, const int) ANDNPD m128d _mm_andnot_pd(m128d a,m128d b) ANDNPS m128 _mm_andnot_ps(m128 a,m128 b) ANDPD m128d _mm_and_pd(m128d a,m128d b) ANDPS m128 _mm_and_ps(m128 a,m128 b) BLENDPD m128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPS m128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	AESENCLAST	m128i _mm_aesenclast (m128i,m128i)
ANDNPDm128d _mm_andnot_pd(m128d a,m128d b) ANDNPSm128 _mm_andnot_ps(m128 a,m128 b) ANDPDm128d _mm_and_pd(m128d a,m128d b) ANDPSm128 _mm_and_ps(m128 a,m128 b) BLENDPDm128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPSm128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	/ ESIMC	m128i _mm_aesimc (m128i)
ANDNPSm128 _mm_andnot_ps(m128 a,m128 b) ANDPDm128d _mm_and_pd(m128d a,m128d b) ANDPSm128 _mm_and_ps(m128 a,m128 b) BLENDPDm128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPSm128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	\eskeygenassist	m128i _mm_aesimc (m128i, const int)
ANDPDm128d _mm_and_pd(m128d a,m128d b) ANDPSm128 _mm_and_ps(m128 a,m128 b) BLENDPDm128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPSm128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	ANDNPD	m128d _mm_andnot_pd(m128d a,m128d b)
ANDPSm128 _mm_and_ps(m128 a,m128 b) BLENDPDm128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPSm128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	Andnps	m128 _mm_andnot_ps(m128 a,m128 b)
BLENDPDm128d _mm_blend_pd(m128d v1,m128d v2, const int mask) BLENDPSm128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPDm128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPSm128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSHvoid _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	NDPD	m128d _mm_and_pd(m128d a,m128d b)
BLENDPS m128 _mm_blend_ps(m128 v1,m128 v2, const int mask) BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	ANDPS	m128 _mm_and_ps(m128 a,m128 b)
BLENDVPD m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3) BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	BLENDPD	m128d _mm_blend_pd(m128d v1,m128d v2, const int mask)
BLENDVPS m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3) CLFLUSH void _mm_clflush(void const *p) CMPPD m128d _mm_cmpeq_pd(m128d a,m128d b)	BLENDPS	m128 _mm_blend_ps(m128 v1,m128 v2, const int mask)
CLFLUSH void _mm_clflush(void const *p) CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	BLENDVPD	m128d _mm_blendv_pd(m128d v1,m128d v2,m128d v3)
CMPPDm128d _mm_cmpeq_pd(m128d a,m128d b)	BLENDVPS	m128 _mm_blendv_ps(m128 v1,m128 v2,m128 v3)
	LFLUSH	void _mm_clflush(void const *p)
4001 11 12 1001 10011	MPPD	m128d _mm_cmpeq_pd(m128d a,m128d b)
m128d _mm_cmplt_pd(m128d a,m128d b)		m128d _mm_cmplt_pd(m128d a,m128d b)
m128d _mm_cmple_pd(m128d a,m128d b)		m128d _mm_cmple_pd(m128d a,m128d b)
m128d _mm_cmpgt_pd(m128d a,m128d b)		m128d _mm_cmpgt_pd(m128d a,m128d b)
m128d _mm_cmpge_pd(m128d a,m128d b)		m128d _mm_cmpge_pd(m128d a,m128d b)
m128d _mm_cmpneq_pd(m128d a,m128d b)		m128d _mm_cmpneq_pd(m128d a,m128d b)
m128d _mm_cmpnlt_pd(m128d a,m128d b)		m128d _mm_cmpnlt_pd(m128d a,m128d b)
m128d _mm_cmpngt_pd(m128d a,m128d b)		m128d _mm_cmpngt_pd(m128d a,m128d b)
m128d _mm_cmpnge_pd(m128d a,m128d b)		m128d _mm_cmpnge_pd(m128d a,m128d b)
m128d _mm_cmpord_pd(m128d a,m128d b)		m128d _mm_cmpord_pd(m128d a,m128d b)
m128d _mm_cmpunord_pd(m128d a,m128d b)		m128d _mm_cmpunord_pd(m128d a,m128d b)
m128d _mm_cmpnle_pd(m128d a,m128d b)		m128d _mm_cmpnle_pd(m128d a,m128d b)
CMPPSm128 _mm_cmpeq_ps(m128 a,m128 b)	MPPS	m128 _mm_cmpeq_ps(m128 a,m128 b)
m128 _mm_cmplt_ps(m128 a,m128 b)		m128 _mm_cmplt_ps(m128 a,m128 b)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic
	m128 _mm_cmple_ps(m128 a,m128 b)
	m128 _mm_cmpgt_ps(m128 a,m128 b)
	m128 _mm_cmpge_ps(m128 a,m128 b)
	m128 _mm_cmpneq_ps(m128 a,m128 b)
	m128 _mm_cmpnlt_ps(m128 a,m128 b)
	m128 _mm_cmpngt_ps(m128 a,m128 b)
	m128 _mm_cmpnge_ps(m128 a,m128 b)
	m128 _mm_cmpord_ps(m128 a,m128 b)
	m128 _mm_cmpunord_ps(m128 a,m128 b)
	m128 _mm_cmpnle_ps(m128 a,m128 b)
CMPSD	m128d _mm_cmpeq_sd(m128d a,m128d b)
	m128d _mm_cmplt_sd(m128d a,m128d b)
	m128d _mm_cmple_sd(m128d a,m128d b)
	m128d _mm_cmpgt_sd(m128d a,m128d b)
	m128d _mm_cmpge_sd(m128d a,m128d b)
	m128 _mm_cmpneq_sd(m128d a,m128d b)
	m128 _mm_cmpnlt_sd(m128d a,m128d b)
	m128d _mm_cmpnle_sd(m128d a,m128d b)
	m128d _mm_cmpngt_sd(m128d a,m128d b)
	m128d _mm_cmpnge_sd(m128d a,m128d b)
	m128d _mm_cmpord_sd(m128d a,m128d b)
	m128d _mm_cmpunord_sd(m128d a,m128d b)
CMPSS	m128 _mm_cmpeq_ss(m128 a,m128 b)
	m128 _mm_cmplt_ss(m128 a,m128 b)
	m128 _mm_cmple_ss(m128 a,m128 b)
	m128 _mm_cmpgt_ss(m128 a,m128 b)
	m128 _mm_cmpge_ss(m128 a,m128 b)
	m128 _mm_cmpneq_ss(m128 a,m128 b)
	m128 _mm_cmpnlt_ss(m128 a,m128 b)
	m128 _mm_cmpnle_ss(m128 a,m128 b)
	m128 _mm_cmpngt_ss(m128 a,m128 b)
	m128 _mm_cmpnge_ss(m128 a,m128 b)
	m128 _mm_cmpord_ss(m128 a,m128 b)
	m128 _mm_cmpunord_ss(m128 a,m128 b)
COMISD	int _mm_comieq_sd(m128d a,m128d b)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic
	int mm comilt sd(m128d a, m128d b)
	int _mm_comile_sd(m128d a,m128d b)
	int _mm_comigt_sd(m128d a,m128d b)
	int _mm_comige_sd(m128d a,m128d b)
	int _mm_comineq_sd(m128d a,m128d b)
COMISS	int _mm_comieq_ss(_m128 a,m128 b)
	int _mm_comilt_ss(m128 a,m128 b)
	int _mm_comile_ss(m128 a,m128 b)
	int _mm_comigt_ss(m128 a,m128 b)
	int _mm_comige_ss(m128 a,m128 b)
	int _mm_comineq_ss(m128 a,m128 b)
CRC32	unsigned int _mm_crc32_u8(unsigned int crc, unsigned char data)
	unsigned int _mm_crc32_u16(unsigned int crc, unsigned short data)
	unsigned int _mm_crc32_u32(unsigned int crc, unsigned int data)
	unsignedint64 _mm_crc32_u64(unsingedint64 crc, unsignedint64 data)
CVTDQ2PD	m128d _mm_cvtepi32_pd(m128i a)
CVTDQ2PS	m128 _mm_cvtepi32_ps(m128i a)
CVTPD2DQ	
CVTPD2PI	m64 _mm_cvtpd_pi32(m128d a)
CVTPD2PS	m128 _mm_cvtpd_ps(m128d a)
CVTPI2PD	m128d _mm_cvtpi32_pd(m64 a)
CVTPI2PS	m128 _mm_cvt_pi2ps(m128 a,m64 b) m128 _mm_cvtpi32_ps(m128 a,m64 b)
CVTPS2DQ	m128i _mm_cvtps_epi32(m128 a)
CVTPS2PD	m128d _mm_cvtps_pd(m128 a)
CVTPS2PI	m64 _mm_cvt_ps2pi(m128 a) m64 _mm_cvtps_pi32(m128 a)
CVTSD2SI	int _mm_cvtsd_si32(m128d a)
CVTSD2SS	m128 _mm_cvtsd_ss(m128 a,m128d b)
CVTSI2SD	m128d _mm_cvtsi32_sd(m128d a, int b)
CVTSI2SS	m128 _mm_cvt_si2ss(m128 a, int b) m128 _mm_cvtsi32_ss(m128 a, int b) m128 _mm_cvtsi64_ss(m128 a,int64 b)
CVTSS2SD	m128d _mm_cvtss_sd(m128d a,m128 b)
CVTSS2SI	int _mm_cvt_ss2si(m128 a) int _mm_cvtss_si32(m128 a)
CVTTPD2DQ	m128i _mm_cvttpd_epi32(m128d a)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic
CVTTPD2PI	m64 _mm_cvttpd_pi32(m128d a)
CVTTPS2DQ	m128i _mm_cvttps_epi32(m128 a)
CVTTPS2PI	m64 _mm_cvtt_ps2pi(m128 a) m64 _mm_cvttps_pi32(m128 a)
CVTTSD2SI	int _mm_cvttsd_si32(m128d a)
CVTTSS2SI	int _mm_cvtt_ss2si(m128 a) int _mm_cvttss_si32(m128 a)
	m64 _mm_cvtsi32_si64(int i)
	int _mm_cvtsi64_si32(m64 m)
DIVPD	m128d _mm_div_pd(m128d a,m128d b)
DIVPS	m128 _mm_div_ps(m128 a,m128 b)
DIVSD	m128d _mm_div_sd(m128d a,m128d b)
DIVSS	m128 _mm_div_ss(m128 a,m128 b)
DPPD	m128d _mm_dp_pd(m128d a,m128d b, const int mask)
DPPS	m128 _mm_dp_ps(m128 a,m128 b, const int mask)
EMMS	void _mm_empty()
EXTRACTPS	int _mm_extract_ps(m128 src, const int ndx)
HADDPD	m128d _mm_hadd_pd(m128d a,m128d b)
HADDPS	m128 _mm_hadd_ps(m128 a,m128 b)
HSUBPD	m128d _mm_hsub_pd(m128d a,m128d b)
HSUBPS	m128 _mm_hsub_ps(m128 a,m128 b)
INSERTPS	m128 _mm_insert_ps(m128 dst,m128 src, const int ndx)
LDDQU	m128i _mm_lddqu_si128(m128i const *p)
LDMXCSR	mm_setcsr(unsigned int i)
LFENCE	void _mm_lfence(void)
MASKMOVDQU	void _mm_maskmoveu_si128(m128i d,m128i n, char *p)
MASKMOVQ	void _mm_maskmove_si64(m64 d,m64 n, char *p)
MAXPD	m128d _mm_max_pd(m128d a,m128d b)
MAXPS	m128 _mm_max_ps(m128 a,m128 b)
MAXSD	m128d _mm_max_sd(m128d a,m128d b)
MAXSS	m128 _mm_max_ss(m128 a,m128 b)
MFENCE	void _mm_mfence(void)
MINPD	m128d _mm_min_pd(m128d a,m128d b)
MINPS	m128 _mm_min_ps(m128 a,m128 b)
MINSD	m128d _mm_min_sd(m128d a,m128d b)
MINSS	m128 _mm_min_ss(m128 a,m128 b)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic
MONITOR	void _mm_monitor(void const *p, unsigned extensions, unsigned hints)
MOVAPD	m128d _mm_load_pd(double * p)
	void_mm_store_pd(double *p,m128d a)
MOVAPS	m128 _mm_load_ps(float * p)
	void_mm_store_ps(float *p,m128 a)
MOVD	m128i _mm_cvtsi32_si128(int a)
	int _mm_cvtsi128_si32(m128i a)
	m64 _mm_cvtsi32_si64(int a)
	int _mm_cvtsi64_si32(m64 a)
MOVDDUP	m128d _mm_movedup_pd(m128d a)
	m128d _mm_loaddup_pd(double const * dp)
MOVDQA	m128i _mm_load_si128(m128i * p)
	void_mm_store_si128(m128i *p,m128i a)
MOVDQU	m128i _mm_loadu_si128(m128i * p)
	void_mm_storeu_si128(m128i *p,m128i a)
MOVDQ2Q	m64 _mm_movepi64_pi64(m128i a)
MOVHLPS	m128 _mm_movehl_ps(m128 a,m128 b)
MOVHPD	m128d _mm_loadh_pd(m128d a, double * p)
	void _mm_storeh_pd(double * p,m128d a)
MOVHPS	m128 _mm_loadh_pi(m128 a,m64 * p)
	void _mm_storeh_pi(m64 * p,m128 a)
MOVLPD	m128d _mm_loadl_pd(m128d a, double * p)
	void _mm_storel_pd(double * p,m128d a)
MOVLPS	m128 _mm_loadl_pi(m128 a,m64 *p)
	void_mm_storel_pi(m64 * p,m128 a)
MOVLHPS	m128 _mm_movelh_ps(m128 a,m128 b)
MOVMSKPD	int _mm_movemask_pd(m128d a)
MOVMSKPS	int _mm_movemask_ps(m128 a)
MOVNTDQA	m128i _mm_stream_load_si128(m128i *p)
MOVNTDQ	void_mm_stream_si128(m128i * p,m128i a)
MOVNTPD	void_mm_stream_pd(double * p,m128d a)
MOVNTPS	void_mm_stream_ps(float * p,m128 a)
MOVNTI	void_mm_stream_si32(int * p, int a)
MOVNTQ	void_mm_stream_pi(m64 * p,m64 a)
MOVQ	m128i _mm_loadl_epi64(m128i * p)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic
	void_mm_storel_epi64(_m128i * p,m128i a)
	m128i _mm_move_epi64(m128i a)
MOVQ2DQ	m128i _mm_movpi64_epi64(m64 a)
MOVSD	m128d _mm_load_sd(double * p)
	void_mm_store_sd(double * p,m128d a)
	m128d _mm_move_sd(m128d a,m128d b)
MOVSHDUP	m128 _mm_movehdup_ps(m128 a)
MOVSLDUP	m128 _mm_moveldup_ps(m128 a)
MOVSS	m128 _mm_load_ss(float * p)
	void_mm_store_ss(float * p,m128 a)
	m128 _mm_move_ss(m128 a,m128 b)
MOVUPD	m128d _mm_loadu_pd(double * p)
	void_mm_storeu_pd(double *p,m128d a)
MOVUPS	m128 _mm_loadu_ps(float * p)
	void_mm_storeu_ps(float *p,m128 a)
MPSADBW	m128i _mm_mpsadbw_epu8(m128i s1,m128i s2, const int mask)
MULPD	m128d _mm_mul_pd(m128d a,m128d b)
MULPS	m128 _mm_mul_ss(m128 a,m128 b)
MULSD	m128d _mm_mul_sd(m128d a,m128d b)
MULSS	m128 _mm_mul_ss(m128 a,m128 b)
MWAIT	void _mm_mwait(unsigned extensions, unsigned hints)
ORPD	m128d _mm_or_pd(m128d a,m128d b)
ORPS	m128 _mm_or_ps(m128 a,m128 b)
PABSB	m64 _mm_abs_pi8 (m64 a)
	m128i _mm_abs_epi8 (m128i a)
PABSD	m64 _mm_abs_pi32 (m64 a)
	m128i _mm_abs_epi32 (m128i a)
PABSW	m64 _mm_abs_pi16 (m64 a)
	m128i _mm_abs_epi16 (m128i a)
PACKSSWB	m128i _mm_packs_epi16(m128i m1,m128i m2)
PACKSSWB	m64 _mm_packs_pi16(m64 m1,m64 m2)
PACKSSDW	m128i _mm_packs_epi32 (m128i m1,m128i m2)
PACKSSDW	m64 _mm_packs_pi32 (m64 m1,m64 m2)
PACKUSDW	m128i _mm_packus_epi32(m128i m1,m128i m2)
PACKUSWB	m128i _mm_packus_epi16(m128i m1,m128i m2)

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PACKUSWB	m64 _mm_packs_pu16(m64 m1,m64 m2)	
PADDB	m128i _mm_add_epi8(m128i m1,m128i m2)	
PADDB	m64 _mm_add_pi8(m64 m1,m64 m2)	
PADDW	m128i _mm_add_epi16(m128i m1,m128i m2)	
PADDW	m64 _mm_add_pi16(m64 m1,m64 m2)	
PADDD	m128i _mm_add_epi32(m128i m1,m128i m2)	
PADDD	m64 _mm_add_pi32(m64 m1,m64 m2)	
PADDQ	m128i _mm_add_epi64(m128i m1,m128i m2)	
PADDQ	m64 _mm_add_si64(m64 m1,m64 m2)	
PADDSB	m128i _mm_adds_epi8(m128i m1,m128i m2)	
PADDSB	m64 _mm_adds_pi8(m64 m1,m64 m2)	
PADDSW	m128i _mm_adds_epi16(m128i m1,m128i m2)	
PADDSW	m64 _mm_adds_pi16(m64 m1,m64 m2)	
PADDUSB	m128i _mm_adds_epu8(m128i m1,m128i m2)	
PADDUSB	m64 _mm_adds_pu8(m64 m1,m64 m2)	
PADDUSW	m128i _mm_adds_epu16(m128i m1,m128i m2)	
PADDUSW	m64 _mm_adds_pu16(m64 m1,m64 m2)	
PALIGNRm64 _mm_alignr_pi8 (m64 a,m64 b, int n)		
	m128i _mm_alignr_epi8 (m128i a,m128i b, int n)	
PAND	m128i _mm_and_si128(m128i m1,m128i m2)	
PAND	m64 _mm_and_si64(m64 m1,m64 m2)	
PANDN	m128i _mm_andnot_si128(m128i m1,m128i m2)	
PANDN	m64 _mm_andnot_si64(m64 m1,m64 m2)	
PAUSE	void _mm_pause(void)	
PAVGB	m128i _mm_avg_epu8(m128i a,m128i b)	
PAVGB	m64 _mm_avg_pu8(m64 a,m64 b)	
PAVGW	m128i _mm_avg_epu16(m128i a,m128i b)	
PAVGW	m64 _mm_avg_pu16(m64 a,m64 b)	
PBLENDVB	m128i _mm_blendv_epi (m128i v1,m128i v2,m128i mask)	
PBLENDW	m128i _mm_blend_epi16(m128i v1,m128i v2, const int mask)	
PCLMULQDQ	m128i _mm_clmulepi64_si128 (m128i,m128i, const int)	
PCMPEQB	m128i _mm_cmpeq_epi8(m128i m1,m128i m2)	
PCMPEQB	m64 _mm_cmpeq_pi8(m64 m1,m64 m2)	
PCMPEQQ	m128i _mm_cmpeq_epi64(m128i a,m128i b)	
PCMPEQW	m128i _mm_cmpeq_epi16 (m128i m1,m128i m2)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PCMPEQW	m64 _mm_cmpeq_pi16 (m64 m1,m64 m2)	
PCMPEQD	m128i _mm_cmpeq_epi32(m128i m1,m128i m2)	
PCMPEQD	m64 _mm_cmpeq_pi32(m64 m1,m64 m2)	
PCMPESTRI	int _mm_cmpestri (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestra (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrc (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestro (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrs (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrz (m128i a, int la,m128i b, int lb, const int mode)	
PCMPESTRM	m128i _mm_cmpestrm (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestra (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrc (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestro (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrs (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrz (m128i a, int la,m128i b, int lb, const int mode)	
PCMPGTB	m128i _mm_cmpgt_epi8 (m128i m1,m128i m2)	
PCMPGTB	m64 _mm_cmpgt_pi8 (m64 m1,m64 m2)	
PCMPGTW	m128i _mm_cmpgt_epi16(m128i m1,m128i m2)	
PCMPGTW	m64 _mm_cmpgt_pi16 (m64 m1,m64 m2)	
PCMPGTD	m128i _mm_cmpgt_epi32(m128i m1,m128i m2)	
PCMPGTD	m64 _mm_cmpgt_pi32(m64 m1,m64 m2)	
PCMPISTRI	m128i _mm_cmpestrm (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestra (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrc (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestro (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpestrs (m128i a, int la,m128i b, int lb, const int mode)	
	int _mm_cmpistrz (m128i a,m128i b, const int mode)	
PCMPISTRM	m128i _mm_cmpistrm (m128i a,m128i b, const int mode)	
	int _mm_cmpistra (m128i a,m128i b, const int mode)	
	int _mm_cmpistrc (m128i a,m128i b, const int mode)	
	int _mm_cmpistro (m128i a,m128i b, const int mode)	
	int _mm_cmpistrs (m128i a,m128i b, const int mode)	
	int _mm_cmpistrz (m128i a,m128i b, const int mode)	
PCMPGTQ	m128i _mm_cmpgt_epi64(m128i a,m128i b)	
PEXTRB	int _mm_extract_epi8 (m128i src, const int ndx)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PEXTRD	int _mm_extract_epi32 (m128i src, const int ndx)	
PEXTRQ	int64 _mm_extract_epi64 (m128i src, const int ndx)	
PEXTRW	int _mm_extract_epi16(m128i a, int n)	
PEXTRW	int _mm_extract_pi16(m64 a, int n)	
	int _mm_extract_epi16 (m128i src, int ndx)	
PHADDD	m64 _mm_hadd_pi32 (m64 a,m64 b)	
	m128i _mm_hadd_epi32 (m128i a,m128i b)	
PHADDSW	m64 _mm_hadds_pi16 (m64 a,m64 b)	
	m128i _mm_hadds_epi16 (m128i a,m128i b)	
PHADDW	m64 _mm_hadd_pi16 (m64 a,m64 b)	
	m128i _mm_hadd_epi16 (m128i a,m128i b)	
PHMINPOSUW	m128i _mm_minpos_epu16(m128i packed_words)	
PHSUBD	m64 _mm_hsub_pi32 (m64 a,m64 b)	
	m128i _mm_hsub_epi32 (m128i a,m128i b)	
PHSUBSW	m64 _mm_hsubs_pi16 (m64 a,m64 b)	
	m128i _mm_hsubs_epi16 (m128i a,m128i b)	
PHSUBW	m64 _mm_hsub_pi16 (m64 a,m64 b)	
	m128i _mm_hsub_epi16 (m128i a,m128i b)	
PINSRB	m128i _mm_insert_epi8(m128i s1, int s2, const int ndx)	
PINSRD	m128i _mm_insert_epi32(m128i s2, int s, const int ndx)	
PINSRQ	m128i _mm_insert_epi64(m128i s2,int64 s, const int ndx)	
PINSRW	m128i _mm_insert_epi16(m128i a, int d, int n)	
PINSRW	m64 _mm_insert_pi16(m64 a, int d, int n)	
PMADDUBSW	m64 _mm_maddubs_pi16 (m64 a,m64 b)	
	m128i _mm_maddubs_epi16 (m128i a,m128i b)	
PMADDWD	m128i _mm_madd_epi16(m128i m1m128i m2)	
PMADDWD	m64 _mm_madd_pi16(m64 m1,m64 m2)	
PMAXSB	m128i _mm_max_epi8(m128i a,m128i b)	
PMAXSD	m128i _mm_max_epi32(m128i a,m128i b)	
PMAXSW	m128i _mm_max_epi16(m128i a,m128i b)	
PMAXSW	m64 _mm_max_pi16(m64 a,m64 b)	
PMAXUB	m128i _mm_max_epu8(m128i a,m128i b)	
PMAXUB	m64 _mm_max_pu8(m64 a,m64 b)	
PMAXUD	m128i _mm_max_epu32(m128i a,m128i b)	
PMAXUW	m128i _mm_max_epu16(m128i a,m128i b)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PMINSB	_m128i _mm_min_epi8(m128i a,m128i b)	
PMINSD	m128i _mm_min_epi32(m128i a,m128i b)	
PMINSW	m128i _mm_min_epi16(m128i a,m128i b)	
PMINSW	m64 _mm_min_pi16(m64 a,m64 b)	
PMINUB	m128i _mm_min_epu8(m128i a,m128i b)	
PMINUB	m64 _mm_min_pu8(m64 a,m64 b)	
PMINUD	m128i _mm_min_epu32 (m128i a,m128i b)	
PMINUW	m128i _mm_min_epu16 (m128i a,m128i b)	
PMOVMSKB	int _mm_movemask_epi8(m128i a)	
PMOVMSKB	int _mm_movemask_pi8(m64 a)	
PMOVSXBW	m128i _mm_ cvtepi8_epi16(m128i a)	
PMOVSXBD	m128i _mm_ cvtepi8_epi32(m128i a)	
PMOVSXBQ	m128i _mm_ cvtepi8_epi64(m128i a)	
PMOVSXWD	m128i _mm_ cvtepi16_epi32(m128i a)	
PMOVSXWQ	m128i _mm_ cvtepi16_epi64(m128i a)	
PMOVSXDQ	m128i _mm_ cvtepi32_epi64(m128i a)	
PMOVZXBW	m128i _mm_ cvtepu8_epi16(m128i a)	
PMOVZXBD	m128i _mm_ cvtepu8_epi32(m128i a)	
PMOVZXBQ	m128i _mm_ cvtepu8_epi64(m128i a)	
PMOVZXWD	m128i _mm_ cvtepu16_epi32(m128i a)	
PMOVZXWQ	m128i _mm_ cvtepu16_epi64(m128i a)	
PMOVZXDQ	m128i _mm_ cvtepu32_epi64(m128i a)	
PMULDQ	m128i _mm_mul_epi32(m128i a,m128i b)	
PMULHRSW	m64 _mm_mulhrs_pi16 (m64 a,m64 b)	
	m128i _mm_mulhrs_epi16 (m128i a,m128i b)	
PMULHUW	m128i _mm_mulhi_epu16(m128i a,m128i b)	
PMULHUW	m64 _mm_mulhi_pu16(m64 a,m64 b)	
PMULHW	m128i _mm_mulhi_epi16(m128i m1,m128i m2)	
PMULHW	m64 _mm_mulhi_pi16(m64 m1,m64 m2)	
PMULLUD	m128i _mm_mullo_epi32(m128i a,m128i b)	
PMULLW	m128i _mm_mullo_epi16(m128i m1,m128i m2)	
PMULLW	m64 _mm_mullo_pi16(m64 m1,m64 m2)	
PMULUDQ	m64 _mm_mul_su32(m64 m1,m64 m2)	
	m128i _mm_mul_epu32(m128i m1,m128i m2)	

Table C-1. Simple Intrinsics (Contd.)

POPCNT	int _mm_popcnt_u32(unsigned int a)	
	int64_t _mm_popcnt_u64(unsignedint64 a)	
POR	m64 _mm_or_si64(m64 m1,m64 m2)	
POR	m128i _mm_or_si128(m128i m1,m128i m2)	
PREFETCHh	void _mm_prefetch(char *a, int sel)	
PSADBW	m128i _mm_sad_epu8(m128i a,m128i b)	
PSADBW	m64 _mm_sad_pu8(m64 a,m64 b)	
PSHUFB	m64 _mm_shuffle_pi8 (m64 a,m64 b)	
	m128i _mm_shuffle_epi8 (m128i a,m128i b)	
PSHUFD	m128i _mm_shuffle_epi32(m128i a, int n)	
PSHUFHW	m128i _mm_shufflehi_epi16(m128i a, int n)	
PSHUFLW	m128i _mm_shufflelo_epi16(m128i a, int n)	
PSHUFW	m64 _mm_shuffle_pi16(m64 a, int n)	
PSIGNB	m64 _mm_sign_pi8 (m64 a,m64 b)	
	m128i _mm_sign_epi8 (m128i a,m128i b)	
PSIGND	m64 _mm_sign_pi32 (m64 a,m64 b)	
	m128i _mm_sign_epi32 (m128i a,m128i b)	
PSIGNW	m64 _mm_sign_pi16 (m64 a,m64 b)	
	m128i _mm_sign_epi16 (m128i a,m128i b)	
PSLLW	m128i _mm_sll_epi16(m128i m,m128i count)	
PSLLW	m128i _mm_slli_epi16(m128i m, int count)	
PSLLW	m64 _mm_sll_pi16(m64 m,m64 count)	
	m64 _mm_slli_pi16(m64 m, int count)	
PSLLD	m128i _mm_slli_epi32(m128i m, int count)	
	m128i _mm_sll_epi32(m128i m,m128i count)	
PSLLD	m64 _mm_slli_pi32(m64 m, int count)	
	m64 _mm_sll_pi32(m64 m,m64 count)	
PSLLQ	m64 _mm_sll_si64(m64 m,m64 count)	
	m64 _mm_slli_si64(m64 m, int count)	
PSLLQ	m128i _mm_sll_epi64(m128i m,m128i count)	
	m128i _mm_slli_epi64(m128i m, int count)	
PSLLDQ	m128i _mm_slli_si128(m128i m, int imm)	
PSRAW	m128i _mm_sra_epi16(m128i m,m128i count)	
	m128i _mm_srai_epi16(m128i m, int count)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PSRAW	m64 _mm_sra_pi16(m64 m,m64 count)	
	m64 _mm_srai_pi16(m64 m, int count)	
PSRAD	m128i _mm_sra_epi32 (m128i m,m128i count)	
	m128i _mm_srai_epi32 (m128i m, int count)	
PSRAD	m64 _mm_sra_pi32 (m64 m,m64 count)	
	m64 _mm_srai_pi32 (m64 m, int count)	
PSRLW	_m128i _mm_srl_epi16 (m128i m,m128i count)	
	m128i _mm_srli_epi16 (m128i m, int count)	
	m64 _mm_srl_pi16 (m64 m,m64 count)	
	m64 _mm_srli_pi16(m64 m, int count)	
PSRLD	m128i _mm_srl_epi32 (m128i m,m128i count)	
	m128i _mm_srli_epi32 (m128i m, int count)	
PSRLD	m64 _mm_srl_pi32 (m64 m,m64 count)	
	m64 _mm_srli_pi32 (m64 m, int count)	
PSRLQ	m128i _mm_srl_epi64 (m128i m,m128i count)	
	m128i _mm_srli_epi64 (m128i m, int count)	
PSRLQ	m64 _mm_srl_si64 (m64 m,m64 count)	
	m64 _mm_srli_si64 (m64 m, int count)	
PSRLDQ	m128i _mm_srli_si128(m128i m, int imm)	
PSUBB	m128i _mm_sub_epi8(m128i m1,m128i m2)	
PSUBB	m64 _mm_sub_pi8(m64 m1,m64 m2)	
PSUBW	m128i _mm_sub_epi16(m128i m1,m128i m2)	
PSUBW	m64 _mm_sub_pi16(m64 m1,m64 m2)	
PSUBD	m128i _mm_sub_epi32(m128i m1,m128i m2)	
PSUBD	m64 _mm_sub_pi32(m64 m1,m64 m2)	
PSUBQ	m128i _mm_sub_epi64(m128i m1,m128i m2)	
PSUBQ	m64 _mm_sub_si64(m64 m1,m64 m2)	
PSUBSB	m128i _mm_subs_epi8(m128i m1,m128i m2)	
PSUBSB	m64 _mm_subs_pi8(m64 m1,m64 m2)	
PSUBSW	m128i _mm_subs_epi16(m128i m1,m128i m2)	
PSUBSW	m64 _mm_subs_pi16(m64 m1,m64 m2)	
PSUBUSB	m128i _mm_subs_epu8(m128i m1,m128i m2)	
PSUBUSB	m64 _mm_subs_pu8(m64 m1,m64 m2)	
PSUBUSW	m128i _mm_subs_epu16(m128i m1,m128i m2)	
PSUBUSW	m64 _mm_subs_pu16(m64 m1,m64 m2)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
PTEST	int _mm_testz_si128(m128i s1,m128i s2)	
	int _mm_testc_si128(m128i s1,m128i s2)	
	int _mm_testnzc_si128(m128i s1,m128i s2)	
PUNPCKHBW	m64 _mm_unpackhi_pi8(m64 m1,m64 m2)	
PUNPCKHBW	m128i _mm_unpackhi_epi8(m128i m1,m128i m2)	
PUNPCKHWD	m64 _mm_unpackhi_pi16(m64 m1,m64 m2)	
PUNPCKHWD	m128i _mm_unpackhi_epi16(m128i m1,m128i m2)	
PUNPCKHDQ	m64 _mm_unpackhi_pi32(m64 m1,m64 m2)	
PUNPCKHDQ	m128i _mm_unpackhi_epi32(m128i m1,m128i m2)	
PUNPCKHQDQ	m128i _mm_unpackhi_epi64(m128i m1,m128i m2)	
PUNPCKLBW	m64 _mm_unpacklo_pi8 (m64 m1,m64 m2)	
PUNPCKLBW	m128i _mm_unpacklo_epi8 (m128i m1,m128i m2)	
PUNPCKLWD	m64 _mm_unpacklo_pi16(m64 m1,m64 m2)	
PUNPCKLWD	m128i _mm_unpacklo_epi16(m128i m1,m128i m2)	
PUNPCKLDQ	m64 _mm_unpacklo_pi32(m64 m1,m64 m2)	
PUNPCKLDQ	m128i _mm_unpacklo_epi32(m128i m1,m128i m2)	
PUNPCKLQDQ	m128i _mm_unpacklo_epi64(m128i m1,m128i m2)	
PXOR	m64 _mm_xor_si64(m64 m1,m64 m2)	
PXOR	m128i _mm_xor_si128(m128i m1,m128i m2)	
RCPPS	m128 _mm_rcp_ps(m128 a)	
RCPSS	m128 _mm_rcp_ss(m128 a)	
ROUNDPD	m128 mm_round_pd(m128d s1, int iRoundMode)	
	m128 mm_floor_pd(m128d s1)	
	m128 mm_ceil_pd(m128d s1)	
ROUNDPS	m128 mm_round_ps(m128 s1, int iRoundMode)	
	m128 mm_floor_ps(m128 s1)	
	m128 mm_ceil_ps(m128 s1)	
ROUNDSD	m128d mm_round_sd(m128d dst,m128d s1, int iRoundMode)	
	m128d mm_floor_sd(m128d dst,m128d s1)	
	m128d mm_ceil_sd(m128d dst,m128d s1)	
ROUNDSS	m128 mm_round_ss(m128 dst,m128 s1, int iRoundMode)	
	m128 mm_floor_ss(m128 dst,m128 s1)	
	m128 mm_ceil_ss(m128 dst,m128 s1)	
RSQRTPS	m128 _mm_rsqrt_ps(m128 a)	
RSQRTSS	m128 _mm_rsqrt_ss(m128 a)	

Table C-1. Simple Intrinsics (Contd.)

Mnemonic	Intrinsic	
SFENCE	void_mm_sfence(void)	
SHUFPD	m128d _mm_shuffle_pd(m128d a,m128d b, unsigned int imm8)	
SHUFPS	m128 _mm_shuffle_ps(m128 a,m128 b, unsigned int imm8)	
SQRTPD	m128d _mm_sqrt_pd(m128d a)	
SQRTPS	m128 _mm_sqrt_ps(m128 a)	
SQRTSD	m128d _mm_sqrt_sd(m128d a)	
SQRTSS	m128 _mm_sqrt_ss(m128 a)	
STMXCSR	_mm_getcsr(void)	
SUBPD	m128d _mm_sub_pd(m128d a,m128d b)	
SUBPS	m128 _mm_sub_ps(m128 a,m128 b)	
SUBSD	m128d _mm_sub_sd(m128d a,m128d b)	
SUBSS	m128 _mm_sub_ss(m128 a,m128 b)	
UCOMISD	int _mm_ucomieq_sd(m128d a,m128d b)	
	int _mm_ucomilt_sd(m128d a,m128d b)	
	int _mm_ucomile_sd(m128d a,m128d b)	
	int _mm_ucomigt_sd(m128d a,m128d b)	
	int _mm_ucomige_sd(m128d a,m128d b)	
	int _mm_ucomineq_sd(m128d a,m128d b)	
UCOMISS	int _mm_ucomieq_ss(m128 a,m128 b)	
	int _mm_ucomilt_ss(m128 a,m128 b)	
	int _mm_ucomile_ss(m128 a,m128 b)	
	int _mm_ucomigt_ss(m128 a,m128 b)	
	int _mm_ucomige_ss(m128 a,m128 b)	
	int _mm_ucomineq_ss(m128 a,m128 b)	
UNPCKHPD	m128d _mm_unpackhi_pd(m128d a,m128d b)	
UNPCKHPS	m128 _mm_unpackhi_ps(m128 a,m128 b)	
UNPCKLPD	m128d _mm_unpacklo_pd(m128d a,m128d b)	
UNPCKLPS	m128 _mm_unpacklo_ps(m128 a,m128 b)	
XORPD	m128d _mm_xor_pd(m128d a,m128d b)	
XORPS	m128 _mm_xor_ps(m128 a,m128 b)	
L	ı	

C.2 COMPOSITE INTRINSICS

Table C-2. Composite Intrinsics

Mnemonic	Intrinsic
(composite)	m128i _mm_set_epi64(m64 q1,m64 q0)
(composite)	m128i _mm_set_epi32(int i3, int i2, int i1, int i0)
(composite)	m128i_mm_set_epi16(short w7,short w6, short w5, short w4, short w3, short w2, short w1,short w0)
(composite)	m128i _mm_set_epi8(char w15,char w14, char w13, char w12, char w11, char w10, char w9, char w8, char w7,char w6, char w5, char w4, char w3, char w2,char w1, char w0)
(composite)	m128i _mm_set1_epi64(m64 q)
(composite)	m128i _mm_set1_epi32(int a)
(composite)	m128i _mm_set1_epi16(short a)
(composite)	m128i _mm_set1_epi8(char a)
(composite)	m128i _mm_setr_epi64(m64 q1,m64 q0)
(composite)	m128i _mm_setr_epi32(int i3, int i2, int i1, int i0)
(composite)	m128i_mm_setr_epi16(short w7,short w6, short w5, short w4, short w3, short w2, short w, short w0)
(composite)	m128i _mm_setr_epi8(char w15,char w14, char w13, char w12, char w11, char w10, char w9, char w8,char w7, char w6,char w5, char w4, char w3, char w2,char w1,char w0)
(composite)	m128i _mm_setzero_si128()
(composite)	m128 _mm_set_ps1(float w) m128 _mm_set1_ps(float w)
(composite)	m128cmm_set1_pd(double w)
(composite)	m128d _mm_set_sd(double w)
(composite)	m128d _mm_set_pd(double z, double y)
(composite)	m128 _mm_set_ps(float z, float y, float x, float w)
(composite)	m128d _mm_setr_pd(double z, double y)
(composite)	m128 _mm_setr_ps(float z, float y, float x, float w)
(composite)	m128d _mm_setzero_pd(void)
(composite)	m128 _mm_setzero_ps(void)
MOVSD + shuffle	m128d _mm_load_pd(double * p) m128d _mm_load1_pd(double *p)
MOVSS + shuffle	m128 _mm_load_ps1(float * p) m128 _mm_load1_ps(float *p)
MOVAPD + shuffle	m128d _mm_loadr_pd(double * p)
MOVAPS + shuffle	m128 _mm_loadr_ps(float * p)
MOVSD + shuffle	void _mm_store1_pd(double *p,m128d a)

INTEL® C/C++ COMPILER INTRINSICS AND FUNCTIONAL EQUIVALENTS

Table C-2. Composite Intrinsics (Contd.)

Mnemonic	Intrinsic
MOVSS + shuffle	void _mm_store_ps1(float * p,m128 a) void _mm_store1_ps(float *p,m128 a)
MOVAPD + shuffle	_mm_storer_pd(double * p,m128d a)
MOVAPS + shuffle	_mm_storer_ps(float * p,m128 a)

Numerics	bootstrap processor, 6-21, 6-28, 6-37, 6-39, 6-40
0000, B-59	BOUND instruction, 3-89, 4-468
64-bit mode	BOUND range exceeded exception (#BR), 3-89,
control and debug registers, 2-15	4-468
default operand size, 2-15	Branch hints, 2-2 Brand information, 3-224
direct memory-offset MOVs, 2-13	processor brand index, 3-228
general purpose encodings, B-24	processor brand string, 3-225
immediates, 2-14	BSF instruction, 3-92
introduction, 2-9	BSR instruction, 3-95
machine instructions, B-1	BSWAP instruction, 3-98
reg (reg) field, B-4 REX prefixes, 2-9, B-2	BT instruction, 3-100
RIP-relative addressing, 2-14	BTC instruction, 3-103, 3-592
SIMD encodings, B-54	BTR instruction, 3-106, 3-592
special instruction encodings, B-94	BTS instruction, 3-109, 3-592
summary table notation, 3-10	Byte order, 1-4
A	С
AAA instruction, 3-23, 3-25	Cache and TLB information, 3-218
AAD instruction, 3-25	Cache Inclusiveness, 3-201
AAM instruction, 3-27	Caches, invalidating (flushing), 3-527, 4-500
AAS instruction, 3-29	CALL instruction, 3-112
Access rights, segment descriptor, 3-563	GETSEC, 6-3
ADC instruction, 3-31, 3-592	CBW instruction, 3-131
ADD instruction, 3-23, 3-35, 3-290, 3-592	CDQ instruction, 3-288
ADDPD instruction, 3-38	CDQE instruction, 3-131 CF (carry) flag, EFLAGS register, 3-35, 3-100, 3-103,
ADDPS instruction, 3-40	3-106, 3-109, 3-133, 3-142, 3-294,
Addressing methods	3-493, 3-499, 3-744, 4-292, 4-359,
RIP-relative, 2-14 Addressing, segments, 1-6	4-377, 4-381, 4-408, 4-422
ADDSD instruction, 3-42	CLC instruction, 3-133
ADDSS instruction, 3-44	CLD instruction, 3-134
ADDSUBPD instruction, 3-46	CLFLUSH instruction, 3-135
ADDSUBPS instruction, 3-49	CPUID flag, 3-217
AESDEC/AESDECLAST- Perform One Round of an AES	CLI instruction, 3-137
Decryption Flow, 3-58	CLTS instruction, 3-140
AESIMC- Perform the AES InvMixColumn	CMC instruction, 3-142 CMOVcc flag, 3-217
Transformation, 3-54	CMOVcc instructions, 3-143
AESKEYGENASSIST - AES Round Key Generation	CPUID flag, 3-217
Assist, 3-62 AND instruction, 3-64, 3-592	CMP instruction, 3-150
ANDNPD instruction, 3-71	CMPPD instruction, 3-153
ANDNPS instruction, 3-73	CMPPS instruction, 3-163
ANDPD instruction, 3-67	CMPS instruction, 3-170, 4-315
ANDPS instruction, 3-69	CMPSB instruction, 3-170
Arctangent, x87 FPU operation, 3-393	CMPSD instruction, 3-170, 3-176
ARPL instruction, 3-75	CMPSQ instruction, 3-170 CMPSS instruction, 3-182
authenticated code execution mode, 6-4	CMPSW instruction, 3-170
	CMPXCHG instruction, 3-188, 3-592
В	CMPXCHG16B instruction, 3-191
Base (operand addressing), 2-4	CPUID bit, 3-213
BCD integers	CMPXCHG8B instruction, 3-191
packed, 3-290, 3-292, 3-331, 3-333	CPUID flag, 3-216
unpacked, 3-23, 3-25, 3-27, 3-29	COMISD instruction, 3-194
Binary numbers, 1-6	COMISS instruction, 3-196
Bit order, 1-4	Compatibility mode

introduction, 2-9	processor type field, 3-210
see 64-bit mode	RDMSR flag, 3-216
summary table notation, 3-11	returned in EBX, 3-211
Compatibility, software, 1-5	returned in ECX & EDX, 3-211
compilers	self snoop, 3-218
documentation, 1-9	SpeedStep technology, 3-213
Condition code flags, EFLAGS register, 3-143	SS2 extensions flag, 3-218
Condition code flags, x87 FPU status word	SSE extensions flag, 3-218
flags affected by instructions, 3-18	SSE3 extensions flag, 3-212
setting, 3-443, 3-445, 3-448	SSSE3 extensions flag, 3-213
Conditional jump, 3-542	SYSENTER flag, 3-216
Conforming code segment, 3-564	SYSEXIT flag, 3-216
Constants (floating point), loading, 3-381	thermal management, 3-223, 3-224
Control registers, moving values to and from, 3-648	thermal monitor, 3-213, 3-217, 3-218
Cosine, x87 FPU operation, 3-349, 3-418	time stamp counter, 3-216
CPL, 3-137, 4-472	using CPUID, 3-198
CPUID instruction, 3-198, 3-217	vendor ID string, 3-208
36-bit page size extension, 3-217	version information, 3-199, 3-223
AP-485, 1-9	virtual 8086 Mode flag, 3-216
APIC on-chip, 3-216	virtual address bits, 3-207
basic CPUID information, 3-199	WRMSR flag, 3-216
cache and TLB characteristics, 3-200	CQO instruction, 3-288
CLFLUSH flag, 3-217	CRO control register, 4-396
CLFLUSH instruction cache line size, 3-211	CS register, 3-114, 3-512, 3-531, 3-551, 3-643,
	4-190
CMPXCHG16B flag, 3-213	
CMPXCHG8B flag, 3-216	CVTDQ2PD instruction, 3-234
CPL qualified debug store, 3-213	CVTDQ2PS instruction, 3-241
debug extensions, CR4.DE, 3-216	CVTPD2DQ instruction, 3-243
debug store supported, 3-217	CVTPD2PI instruction, 3-246
deterministic cache parameters leaf, 3-200,	CVTPD2PS instruction, 3-248
3-203, 3-204, 3-205	CVTPI2PD instruction, 3-251
extended function information, 3-205, 3-206	CVTPI2PS instruction, 3-253
feature information, 3-215	CVTPS2DQ instruction, 3-255, 3-256
FPU on-chip, 3-216	CVTPS2PD instruction, 3-257
FSAVE flag, 3-217	CVTPS2PI instruction, 3-260
FXRSTOR flag, 3-217	CVTSD2SI instruction, 3-262
HT technology flag, 3-218	CVTSD2SS instruction, 3-264
IA-32e mode available, 3-206	CVTSI2SD instruction, 3-266
input limits for EAX, 3-207	CVTSI2SS instruction, 3-268
L1 Context ID, 3-213	CVTSS2SD instruction, 3-270
	CVTSS2SI instruction, 3-270
local APIC physical ID, 3-211	
machine check architecture, 3-217	CVTTPD2DQ instruction, 3-274
machine check exception, 3-216	CVTTPD2PI instruction, 3-274, 3-277
memory type range registers, 3-216	CVTTPS2DQ instruction, 3-279
MONITOR feature information, 3-223	CVTTPS2PI instruction, 3-282
MONITOR/MWAIT flag, 3-212	CVTTSD2SI instruction, 3-284
MONITOR/MWAIT leaf, 3-201, 3-202, 3-203,	CVTTSS2SI instruction, 3-286
3-204	CWD instruction, 3-288
MWAIT feature information, 3-223	CWDE instruction, 3-131
page attribute table, 3-217	C/C++ compiler intrinsics
page size extension, 3-216	compiler functional equivalents, C-1
performance monitoring features, 3-224	composite, C-17
physical address bits, 3-207	description of, 3-15
physical address extension, 3-216	lists of, C-1
power management, 3-223, 3-224	simple, C-2
processor brand index, 3-211, 3-224	Simple, O Z
processor brand string, 3-206, 3-224	
processor serial number, 3-200, 3-217	

D	F
D (default operation size) flag, segment descriptor, 4-195	F2XM1 instruction, 3-323, 3-466 FABS instruction, 3-325
DAA instruction, 3-290	FADD instruction, 3-327
DAS instruction, 3-292	FADDP instruction, 3-327
Debug registers, moving value to and from, 3-652	Far pointer, loading, 3-571
DEC instruction, 3-294, 3-592	Far return, RET instruction, 4-318
Denormalized finite number, 3-448	FBLD instruction, 3-331
Detecting and Enabling SMX	FBSTP instruction, 3-333
level 2, 6-2	FCHS instruction, 3-336
DF (direction) flag, EFLAGS register, 3-134, 3-172,	FCLEX instruction, 3-338
3-503, 3-595, 3-712, 4-27, 4-363, 4-409	FCMOVcc instructions, 3-340
Displacement (operand addressing), 2-4	FCOM instruction, 3-342
DIV instruction, 3-297	FCOMI instruction, 3-346
Divide error exception (#DE), 3-297	FCOMP instruction, 3-346
DIVPD instruction, 3-301	FCOMP instruction, 3-342
DIVPS instruction, 3-303	FCOMPP instruction, 3-342
DIVSD instruction, 3-305 DIVSS instruction, 3-307	FCOS instruction, 3-349 FDECSTP instruction, 3-351
DS register, 3-171, 3-572, 3-595, 3-712, 4-26, 4-27	FDIV instruction, 3-353
D3 register, 0-17 1, 0-072, 0-090, 0-7 12, 4-20, 4-27	FDIVP instruction, 3-353
	FDIVR instruction, 3-357
E	FDIVRP instruction, 3-357
EDI register, 4-362, 4-409, 4-414	Feature information, processor, 3-198
Effective address, 3-577	FFREE instruction, 3-361
EFLAGS register	FIADD instruction, 3-327
condition codes, 3-147, 3-340, 3-346	FICOM instruction, 3-362
flags affected by instructions, 3-18	FICOMP instruction, 3-362
popping, 4-200	FIDIV instruction, 3-353
popping on return from interrupt, 3-531	FIDIVR instruction, 3-357
pushing, 4-283	FILD instruction, 3-365
pushing on interrupts, 3-512	FIMUL instruction, 3-388
saving, 4-348	FINCSTP instruction, 3-367
status flags, 3-150, 3-547, 4-369, 4-449 EIP register, 3-113, 3-512, 3-531, 3-551	FINIT instruction, 3-369
EMMS instruction, 3-315	FINIT/FNINIT instructions, 3-410
Encodings	FIST instruction, 3-371
See machine instructions, opcodes	FISTP instruction, 3-371
ENTER instruction, 3-317	FISTTP instruction, 3-375 FISUB instruction, 3-435
GETSEC, 6-4, 6-12	FISUBR instruction, 3-439
Error numbers	FLD instruction, 3-378
VM-instruction error field, 5-34	FLD1 instruction, 3-381
ES register, 3-572, 4-27, 4-362, 4-363, 4-414, 4-415	FLDCW instruction, 3-383
ESI register, 3-171, 3-595, 3-712, 4-26, 4-409	FLDENV instruction, 3-385
ESP register, 3-114, 4-190	FLDL2E instruction, 3-381
Exceptions	FLDL2T instruction, 3-381
BOUND range exceeded (#BR), 3-89, 4-468	FLDLG2 instruction, 3-381
notation, 1-7	FLDLN2 instruction, 3-381
overflow exception (#0F), 3-511	FLDPI instruction, 3-381
returning from, 3-531	FLDZ instruction, 3-381
GETSEC, 6-4, 6-6 Expanded extraction from floating point number	Floating point instructions
Exponent, extracting from floating-point number, 3-466	machine encodings, B-95
Extract exponent and significand, x87 FPU operation	Floating-point exceptions
, 3-466	SSE and SSE2 SIMD, 3-21
, 0 100	x87 FPU, 3-21
	Flushing caches, 3-527, 4-500
	TLB entry 3-529

FMUL instruction, 3-388 FMULP instruction, 3-388 FNCLEX instruction, 3-338 FNINIT instruction, 3-369	pushing all, 4-280 GETSEC, 6-1, 6-3, 6-7 GS register, 3-572
FNOP instruction, 3-392	THE STATE OF THE S
FNSAVE instruction, 3-410	Н
FNSTCW instruction, 3-426	HADDPD instruction, 3-472, 3-474
FNSTENV instruction, 3-385, 3-429	HADDPS instruction, 3-475
FNSTSW instruction, 3-432	Hexadecimal numbers, 1-6
FPATAN instruction, 3-393	HLT instruction, 3-479
FPREM instruction, 3-396	HSUBPD instruction, 3-481
FPREM1 instruction, 3-399	HSUBPS instruction, 3-484
	Hyper-Threading Technology
FPTAN instruction, 3-402	CPUID flag, 3-218
FRNDINT instruction, 3-405	Cl Old flag, 3-210
FRSTOR instruction, 3-407	
FS register, 3-572	I
FSAVE instruction, 3-410	IA-32e mode
FSAVE/FNSAVE instructions, 3-407	CPUID flag, 3-206
FSCALE instruction, 3-414	introduction, 2-9, 2-16
FSIN instruction, 3-416	see 64-bit mode
FSINCOS instruction, 3-418	
FSQRT instruction, 3-421	see compatibility mode
FST instruction, 3-423	IA32_SYSENTER_CS MSR, 4-440, 4-445
FSTCW instruction, 3-426	IA32_SYSENTER_EIP MSR, 4-440
FSTENV instruction, 3-429	IA32_SYSENTER_ESP MSR, 4-440
FSTP instruction, 3-423	IDIV instruction, 3-488
FSTSW instruction, 3-432	IDT (interrupt descriptor table), 3-512, 3-584
FSUB instruction, 3-435	IDTR (interrupt descriptor table register), 3-584,
FSUBP instruction, 3-435	4-391
FSUBR instruction, 3-439	IF (interrupt enable) flag, EFLAGS register, 3-137,
FSUBRP instruction, 3-439	4-410
FTST instruction, 3-443	Immediate operands, 2-4
FUCOM instruction, 3-445	IMUL instruction, 3-492
FUCOMI instruction, 3-346	IN instruction, 3-497
FUCOMIP instruction, 3-346	INC instruction, 3-499, 3-592
FUCOMP instruction, 3-445	Index (operand addressing), 2-4
FUCOMPP instruction, 3-445	Initialization x87 FPU, 3-369
FXAM instruction, 3-448	initiating logical processor, 6-4, 6-6, 6-12, 6-13, 6-27
FXCH instruction, 3-450	6-28
FXRSTOR instruction, 3-452	INS instruction, 3-502, 4-315
CPUID flag, 3-217	INSB instruction, 3-502
FXSAVE instruction, 3-456, 4-494, 4-496, 4-510,	INSD instruction, 3-502
4-522, 4-529, 4-533, 4-538	instruction encodings, B-89, B-98
CPUID flag, 3-217	Instruction format
FXTRACT instruction, 3-414, 3-466	base field, 2-4
FYL2X instruction, 3-468	description of reference information, 3-1
FYL2XP1 instruction, 3-470	displacement, 2-4
	immediate, 2-4
	index field, 2-4
G	Mod field, 2-4
GDT (global descriptor table), 3-584, 3-587	ModR/M byte, 2-4
GDTR (global descriptor table register), 3-584, 4-373	opcode, 2-3
General-purpose instructions	operands, 1-6
64-bit encodings, B-24	prefixes, 2-1
non-64-bit encodings, B-9	reg/opcode field, 2-4
General-purpose registers	r/m field, 2-4
moving value to and from, 3-643	scale field, 2-4
popping all, 4-195	SIB byte, 2-4

See also: machine instructions, opcodes	LEA instruction, 3-577
Instruction reference, nomenclature, 3-1	LEAVE instruction, 3-580
Instruction set, reference, 3-1	LES instruction, 3-571
INSW instruction, 3-502	LFENCE instruction, 3-582
INT 3 instruction, 3-511	LFS instruction, 3-571
Integer, storing, x87 FPU data type, 3-371	
	LGDT instruction, 3-584
Intel 64 architecture	LGS instruction, 3-571
definition of, 1-3	LIDT instruction, 3-584
instruction format, 2-1	LLDT instruction, 3-587
relation to IA-32, 1-3	LMSW instruction, 3-590
Intel developer link, 1-9	Load effective address operation, 3-577
Intel NetBurst microarchitecture, 1-2	LOCK prefix, 3-32, 3-36, 3-65, 3-104, 3-107, 3-110,
Intel VTuna Performance Applyage	3-189, 3-294, 3-499, 3-592, 4-9, 4-14,
Intel VTune Performance Analyzer	4-17, 4-360, 4-422, 4-504, 4-508, 4-516
related information, 1-9	Locking operation, 3-592
Intel Xeon processor, 1-1	LODS instruction, 3-594, 4-315
Intel® Trusted Execution Technology, 6-4	LODSB instruction, 3-594
Inter-privilege level	LODSD instruction, 3-594
call, CALL instruction, 3-113	LODSQ instruction, 3-594
return, RET instruction, 4-318	LODSW instruction, 3-594
Interrupts	Log epsilon, x87 FPU operation, 3-468
interrupt vector 4, 3-511	Log (base 2), x87 FPU operation, 3-470
returning from, 3-531	LOOP instructions, 3-598
software, 3-511	LOOPcc instructions, 3-598
INTn instruction, 3-511	LSL instruction, 3-601
INTO instruction, 3-511	LSS instruction, 3-571
Intrinsics	LTR instruction, 3-605
compiler functional equivalents, C-1	
composite, C-17	M
description of, 3-15	Machine check architecture
list of, C-1	
simple, C-2	CPUID flag, 3-217
INVD instruction, 3-527	description, 3-217
INVLPG instruction, 3-529	Machine instructions
IOPL (I/O privilege level) field, EFLAGS register, 3-137,	64-bit mode, B-1
4-283, 4-410	condition test (tttn) field, B-7
IRET instruction, 3-531	direction bit (d) field, B-8
IRETD instruction, 3-531	floating-point instruction encodings, B-95
	general description, B-1
J	general-purpose encodings, B-9–B-53
	legacy prefixes, B-2
Jcc instructions, 3-542	MMX encodings, B-55–B-58
JMP instruction, 3-550	opcode fields, B-2
Jump operation, 3-550	operand size (w) bit, B-5
	P6 family encodings, B-59
L	Pentium processor family encodings, B-53
L1 Context ID, 3-213	reg (reg) field, B-3, B-4
LAHF instruction, 3-561	REX prefixes, B-2
LAR instruction, 3-563	segment register (sreg) field, B-6
Last branch	sign-extend (s) bit, B-5
interrupt & exception recording	SIMD 64-bit encodings, B-54
	special 64-bit encodings, B-94
description of, 4-332	special fields, B-2
LDDQU instruction, 3-567	special-purpose register (eee) field, B-6
LDMXCSR instruction, 3-569 LDS instruction, 3-571	SSE encodings, B-60–B-69
LDT (local descriptor table), 3-587	SSE2 encodings, B-69–B-86
	SSE3 encodings, B-87–B-89
LDTR (local descriptor table register), 3-587, 4-394	SSSE3 encodings, B-89–B-93

VMX encodings, B-115–B-116, B-117	MOVSHDUP instruction, 3-719
See also: opcodes	MOVSLDUP instruction, 3-722
Machine status word, CRO register, 3-590, 4-396	MOVSQ instruction, 3-711
MASKMOVDQU instruction, 3-608	MOVSS instruction, 3-725
MASKMOVQ instruction, 3-610	MOVSW instruction, 3-711
MAXPD instruction, 3-616	MOVSX instruction, 3-728
MAXPS instruction, 3-619	MOVSXD instruction, 3-728
MAXSD instruction, 3-622	MOVUPD instruction, 3-731
MAXSS instruction, 3-624	MOVUPS instruction, 3-734
measured environment, 6-1	MOVZX instruction, 3-737
Measured Launched Environment, 6-1, 6-33	MSRs (model specific registers)
MFENCE instruction, 3-626	reading, 4-301
MINPD instruction, 3-628	MUL instruction, 3-27, 3-744
MINPS instruction, 3-631	MULPD instruction, 3-747
MINSD instruction, 3-634	MULPS instruction, 3-749
MINSS instruction, 3-636	MULSD instruction, 3-751
MLE, 6-1	MULSS instruction, 3-753
MMX instructions	Multi-byte no operation, 4-9, 4-12, B-16
CPUID flag for technology, 3-217	MVMM, 6-1, 6-6, 6-7, 6-49
encodings, B-55	MWAIT instruction, 3-755
Mod field, instruction format, 2-4	CPUID flag, 3-212
Model & family information, 3-223	feature data, 3-223
ModR/M byte, 2-4	
16-bit addressing forms, 2-6	N
32-bit addressing forms of, 2-7	
description of, 2-4	NaN. testing for, 3-443
MONITOR instruction, 3-638	Near
CPUID flag, 3-212	return, RET instruction, 4-318
feature data, 3-223	NEG instruction, 3-592, 4-9
MOV instruction, 3-641	NetBurst microarchitecture (see Intel NetBurst
MOV instruction (control registers), 3-648	microarchitecture)
MOV instruction (debug registers), 3-652, 3-660	No operation, 4-9, 4-12, B-16
MOVAPD instruction, 3-654	Nomenclature, used in instruction reference pages
MOVAPS instruction, 3-657	3-1
MOVD instruction, 3-660	NOP instruction, 4-12
MOVDDUP instruction, 3-666	NOT instruction, 3-592, 4-14
MOVDQ2Q instruction, 3-675	Notation
MOVDQA instruction, 3-669	bit and byte order, 1-4
MOVDQU instruction, 3-672	exceptions, 1-7
MOVHLPS instruction, 3-677	hexadecimal and binary numbers, 1-6
MOVHPD instruction, 3-679	instruction operands, 1-6
MOVHPS instruction, 3-681	reserved bits, 1-5
MOVLHP instruction, 3-683	segmented addressing, 1-6
MOVLHPS instruction, 3-683	Notational conventions, 1-4
MOVLPD instruction, 3-685	NT (nested task) flag, EFLAGS register, 3-531
MOVLPS instruction, 3-687	
MOVMSKPD instruction, 3-689	0
MOVMSKPS instruction, 3-691	OF (carry) flag, EFLAGS register, 3-493
MOVNTDQ instruction, 3-697	OF (overflow) flag, EFLAGS register, 3-35, 3-511,
MOVNTI instruction, 3-699	3-744, 4-359, 4-377, 4-381, 4-422
MOVNTPD instruction, 3-701	Opcode format, 2-3
MOVNTPS instruction, 3-703	Opcodes
MOVNTQ instruction, 3-705	addressing method codes for, A-2
MOVQ instruction, 3-660, 3-707	extensions, A-21
MOVQ2DQ instruction, 3-709	extensions tables, A-22
MOVS instruction, 3-711, 4-315	group numbers, A-21
MOVSB instruction, 3-711	integers
MOVSD instruction, 3-711, 3-716	···g*

b. d d A 44	D
one-byte opcodes, A-11	Pending break enable, 3-218
two-byte opcodes, A-13	Pentium 4 processor, 1-1
key to abbreviations, A-2	Pentium II processor, 1-2
look-up examples, A-5, A-21, A-24	Pentium III processor, 1-2
ModR/M byte, A-21	Pentium Pro processor, 1-2
one-byte opcodes, A-5, A-11	Pentium processor, 1-1
opcode maps, A-1	Pentium processor family processors
operand type codes for, A-3	machine encodings, B-53
register codes for, A-4	Performance-monitoring counters
superscripts in tables, A-8	CPUID inquiry for, 3-224
two-byte opcodes, A-6, A-7, A-13	PEXTRW instruction, 4-102
VMX instructions, B-115, B-117	PHADDD instruction, 4-106
x87 ESC instruction opcodes, A-24	PHADDSW instruction, 4-109
Operands, 1-6	PHADDW instruction, 4-106
OR instruction, 3-592, 4-16	PHSUBD instruction, 4-113
ORPD instruction, 4-19	PHSUBSW instruction, 4-116
ORPS instruction, 4-21	PHSUBW instruction, 4-113
OUT instruction, 4-23	Pi, 3-381
OUTS instruction, 4-26, 4-315	PINSRW instruction, 4-121, 4-223
OUTSB instruction, 4-26	PMADDUBSW instruction, 4-124
OUTSD instruction, 4-26	PMADDUDSW instruction, 4-124
OUTSW instruction, 4-26	PMADDWD instruction, 4-126
Overflow exception (#0F), 3-511	PMAXSW instruction, 4-134
	PMAXUB instruction, 4-137
P	PMINSW instruction, 4-149
-	PMINUB instruction, 4-152
P6 family processors	PMOVMSKB instruction, 4-155
description of, 1-1	PMULHRSW instruction, 4-171
machine encodings, B-59	PMULHUW instruction, 4-174
PABSB instruction, 4-32	PMULHW instruction, 4-177
PABSD instruction, 4-32	PMULLW instruction, 4-182
PABSW instruction, 4-32	PMULUDQ instruction, 4-185
PACKSSDW instruction, 4-36	POP instruction, 4-188
PACKSSWB instruction, 4-36	POPA instruction, 4-195
PACKUSWB instruction, 4-43	POPAD instruction, 4-195
PADDB instruction, 4-46	POPF instruction, 4-200
PADDD instruction, 4-46	POPFD instruction, 4-200
PADDQ instruction, 4-50	POPFQ instruction, 4-200
PADDSB instruction, 4-52	POR instruction, 4-204
PADDSW instruction, 4-52	•
PADDUSB instruction, 4-55	PREFETCHh instruction, 4-206
PADDUSW instruction, 4-55	Prefixes
PADDW instruction, 4-46	Address-size override prefix, 2-2
PALIGNR instruction, 4-58	Branch hints, 2-2
	branch hints, 2-2
PAND instruction, 4-60	instruction, description of, 2-1
PANDN instruction, 4-62	legacy prefix encodings, B-2
GETSEC, 6-5	LOCK, 2-2, 3-592
PAUSE instruction, 4-64	Operand-size override prefix, 2-2
PAVGB instruction, 4-66	REP or REPE/REPZ, 2-2
PAVGW instruction, 4-66	REPNE/REPNZ, 2-2
PCE flag, CR4 register, 4-305	REP/REPE/REPZ/REPNE/REPNZ, 4-313
PCMPEQB instruction, 4-79	REX prefix encodings, B-2
PCMPEQD instruction, 4-79	Segment override prefixes, 2-2
PCMPEQW instruction, 4-79	PSADBW instruction, 4-209
PCMPGTB instruction, 4-89	Pseudo-functions
PCMPGTD instruction, 4-89	VMfail. 5-2
PCMPGTW instruction, 4-89	VMfaillnvalid, 5-2
PE (protection enable) flag, CRO register, 3-590	VMfailValid, 5-2

VMsucceed, 5-2	REP/REPE/REPZ/REPNE/REPNZ prefixes, 3-172,
PSHUFB instruction, 4-212	3-503, 4-27, 4-313
PSHUFD instruction, 4-215	Reserved
PSHUFHW instruction, 4-217	use of reserved bits, 1-5
PSHUFLW instruction, 4-219	Responding logical processor, 6-6
PSHUFW instruction, 4-219	
	responding logical processor, 6-4, 6-5, 6-6
PSIGNB instruction, 4-223	RET instruction, 4-318
PSIGND instruction, 4-223	REX prefixes
PSIGNW instruction, 4-223	addressing modes, 2-11
PSLLD instruction, 4-230	and INC/DEC, 2-10
PSLLDQ instruction, 4-228	encodings, 2-10, B-2
PSLLQ instruction, 4-230	field names, 2-11
PSLLW instruction, 4-230	ModR/M byte, 2-10
PSRAD instruction, 4-237	overview, 2-9
PSRAW instruction, 4-237	REX.B, 2-10
PSRLD instruction, 4-244	REX.R, 2-10
PSRLDQ instruction, 4-242	REX.W, 2-10
PSRLQ instruction, 4-244	special encodings, 2-13
PSRLW instruction, 4-244	RIP-relative addressing, 2-14
PSUBB instruction, 4-250	ROL instruction, 4-288
PSUBD instruction, 4-250	ROR instruction, 4-288
PSUBQ instruction, 4-254	Rounding
PSUBSB instruction, 4-256	modes, floating-point operations, 4-332
PSUBSW instruction, 4-256	Rounding control (RC) field
PSUBUSB instruction, 4-259	MXCSR register, 4-332
PSUBUSW instruction, 4-259	x87 FPU control word, 4-332
PSUBW instruction, 4-250	Rounding, round to integer, x87 FPU operation, 3-405
PUNPCKHBW instruction, 4-264	RPL field, 3-75
PUNPCKHDQ instruction, 4-264	RSM instruction, 4-341
PUNPCKHQDQ instruction, 4-264	RSQRTPS instruction, 4-343
PUNPCKHWD instruction, 4-264	RSQRTSS instruction, 4-346
PUNPCKLBW instruction, 4-270	R/m field, instruction format, 2-4
PUNPCKLDQ instruction, 4-270	
PUNPCKLQDQ instruction, 4-270	S
PUNPCKLWD instruction, 4-270	
PUSH instruction, 4-275	Safer Mode Extensions, 6-1
PUSHA instruction, 4-280	SAHF instruction, 4-348
PUSHAD instruction, 4-280	SAL instruction, 4-350
PUSHF instruction, 4-283	SAR instruction, 4-350
PUSHFD instruction, 4-283	SBB instruction, 3-592, 4-358
PXOR instruction, 4-286	Scale (operand addressing), 2-4
	Scale, x87 FPU operation, 3-414
	Scan string instructions, 4-362
R	SCAS instruction, 4-315, 4-362
RC (rounding control) field, x87 FPU control word,	SCASB instruction, 4-362
3-372, 3-381, 3-423	SCASD instruction, 4-362
RCL instruction, 4-288	SCASW instruction, 4-362
RCPPS instruction, 4-296	Segment
RCPSS instruction, 4-299	descriptor, segment limit, 3-601
	limit, 3-601
RCR instruction, 4-288	registers, moving values to and from, 3-643
RDMSR instruction, 4-301, 4-305, 4-309	
CPUID flag, 3-216	selector, RPL field, 3-75
RDPMC instruction, 4-303	Segmented addressing, 1-6
RDTSC instruction, 4-309, 4-311	Self Snoop, 3-218
Reg/opcode field, instruction format, 2-4	GETSEC, 6-2, 6-4, 6-6
Related literature, 1-8	SENTER sleep state, 6-12
Remainder, x87 FPU operation, 3-399	SETcc instructions, 4-367
	GETSEC, 6-5

SF (sign) flag, EFLAGS register, 3-35 SFENCE instruction, 4-372 SGDT instruction, 4-373	STI instruction, 4-410 STMXCSR instruction, 4-413 STOS instruction, 4-315, 4-414
SHAF instruction, 4-348	STOSB instruction, 4-414
Shift instructions, 4-350	STOSD instruction, 4-414
SHL instruction, 4-350	STOSQ instruction, 4-414
SHLD instruction, 4-376	STOSW instruction, 4-414
SHR instruction, 4-350	STR instruction, 4-419
SHRD instruction, 4-380	String instructions, 3-170, 3-502, 3-594, 3-711,
SHUFPD instruction, 4-384	4-26, 4-362, 4-414
SHUFPS instruction, 4-387	SUB instruction, 3-29, 3-292, 3-592, 4-421
SIB byte, 2-4	SUBPD instruction, 4-424
32-bit addressing forms of, 2-8	SUBSS instruction, 4-431
description of, 2-4	SWAPGS instruction, 4-433
SIDT instruction, 4-373, 4-391	SYSCALL instruction, 4-435
Significand, extracting from floating-point number,	SYSENTER instruction, 4-437
3-466	CPUID flag, 3-216
SIMD floating-point exceptions, unmasking, effects of	SYSEXIT instruction, 4-442
, 3-569	CPUID flag, 3-216
Sine, x87 FPU operation, 3-416, 3-418	SYSRET instruction, 4-446
SINIT, 6-5	
SLDT instruction, 4-394	T
GETSEC, 6-5	Tangent, x87 FPU operation, 3-402
SMSW instruction, 4-396	Task register
SpeedStep technology, 3-213	loading, 3-605
SQRTPD instruction, 4-399	storing, 4-419
SQRTPS instruction, 4-401	Task switch
SQRTSD instruction, 4-404	CALL instruction, 3-113
SQRTSS instruction, 4-406	return from nested task, IRET instruction, 3-531
Square root, Fx87 PU operation, 3-421	TEST instruction, 4-448, 4-490
SS register, 3-572, 3-643, 4-190	Thermal Monitor
SSE extensions	CPUID flag, 3-218
cacheability instruction encodings, B-68	Thermal Monitor 2, 3-213
CPUID flag, 3-218	CPUID flag, 3-213
floating-point encodings, B-60 instruction encodings, B-60	Time Stamp Counter, 3-216
integer instruction encodings, B-67	Time-stamp counter, reading, 4-309, 4-311
memory ordering encodings, B-68	TLB entry, invalidating (flushing), 3-529
SSE2 extensions	Trusted Platform Module, 6-6
cacheability instruction encodings, B-86	TS (task switched) flag, CR0 register, 3-140
CPUID flag, 3-218	TSD flag, CR4 register, 4-309, 4-311
floating-point encodings, B-70	TSS, relationship to task register, 4-419
integer instruction encodings, B-79	, , , , , , , , , , , , , , , , , , ,
SSE3	U
CPUID flag, 3-212	
SSE3 extensions	UCOMISD instruction, 4-451
CPUID flag, 3-212	UCOMISS instruction, 4-453
event mgmt instruction encodings, B-88	UD2 instruction, 4-455
floating-point instruction encodings, B-87	Undefined, format opcodes, 3-443
integer instruction encodings, B-88, B-89	Unordered values, 3-342, 3-443, 3-445
SSSE3 extensions, B-89, B-98	UNPCKHPD instruction, 4-456
CPUID flag, 3-213	UNPCKHPS instruction, 4-459 UNPCKLPD instruction, 4-462
Stack, pushing values on, 4-275	UNPCKLPS instruction, 4-465
Status flags, EFLAGS register, 3-147, 3-150, 3-340, 3-346, 3-547, 4-369, 4-449	ON CREE S HISH OCHOR, 4-405
STC instruction, 4-408	V
STD instruction, 4-409	VERR instruction, 4-472
Stepping information, 3-223	Version information, processor, 3-198

VERW instruction, 4-472 VEX, 3-4 VEX.B, 3-4 VEX.L, 3-4 VEX.mmmmm, 3-4 VEX.pp, 3-5 VEX.R, 3-6 VEX.vvvv, 3-4 VEX.W, 3-4 VEX.W, 3-4 Virtual Machine Monitor, 6-1 VM (virtual 8086 mode) flag, EFLAGS register, 3-531 VMCALL instruction, 5-1 VMCLEAR instruction, 5-1 VMCS error numbers, 5-34 VM-instruction error field, 5-34 VM-instruction error field, 5-34 VMLAUNCH instruction, 5-1 VMM, 6-1 VMPTRLD instruction, 5-1 VMPTRST instruction, 5-1 VMRESUME instruction, 5-1 VMRESUME instruction, 5-1 VMRESUME instruction, 5-1 VMXOFF instruction, 5-1 VMXOFF instruction, 5-1 VMXOFF instruction, 5-1 VMXON instruction, 5-2	restoring, 3-407 saving, 3-410, 3-429, 3-432 TOP field, 3-367 x87 FPU flags affected by instructions, 3-18 x87 FPU tag word, 3-385, 3-407, 3-410, 3-429 XADD instruction, 3-592, 4-504 XCHG instruction, 3-592, 4-507 XFEATURE_ENABLED_MASK, 4-510, 4-523, 4-529, 4-533, 4-534, 4-538, 4-539 XGETBV, 4-510, 4-522, B-59 XLAB instruction, 4-512 XLAT instruction, 4-512 XOR instruction, 4-518 XORPD instruction, 4-518 XORPS instruction, 4-520 XRSTOR, 4-530, 4-534, B-59 XSAVE, 4-510, 4-511, 4-522, 4-523, 4-524, 4-525, 4-526, 4-527, 4-529, 4-530, 4-531, 4-532, 4-533, 4-534, 4-536, 4-537, 4-539, B-59 XSETBV, 4-533, 4-538, B-59 Z ZF (zero) flag, EFLAGS register, 3-188, 3-563, 3-598, 3-601, 4-315, 4-472
W WAIT/FWAIT instructions, 4-498 GETSEC, 6-6 WBINVD instruction, 4-500 WBINVD/INVD bit, 3-201 Write-back and invalidate caches, 4-500 WRMSR instruction, 4-502 CPUID flag, 3-216	
x87 FPU checking for pending x87 FPU exceptions, 4-498 constants, 3-381 initialization, 3-369 instruction opcodes, A-24 x87 FPU control word loading, 3-383, 3-385 RC field, 3-372, 3-381, 3-423 restoring, 3-407 saving, 3-410, 3-429 storing, 3-426 x87 FPU data pointer, 3-385, 3-407, 3-410, 3-429 x87 FPU instruction pointer, 3-385, 3-407, 3-410, 3-429 x87 FPU last opcode, 3-385, 3-407, 3-410, 3-429 x87 FPU status word condition code flags, 3-342, 3-362, 3-443, 3-445, 3-448 loading, 3-385	